

# service reference guide

HP Compaq Business PC dx7200 Series  
1st Edition

This document provides information on the removal and replacement of all parts as well as information on troubleshooting, Desktop Management, setup utilities, PATA and SATA drives, safety, routine care, connector pin assignments, POST error messages, and diagnostic indicator lights.

Document Part Number 390812-001



i n v e n t





**Service Reference Guide**  
HP Compaq Business PC dx7200 Series  
1st Edition

Document Part Number: 390812-001

**July 2005**

© Copyright 2005 Hewlett-Packard Development Company, L.P.  
The information contained herein is subject to change without notice.

Microsoft, MS-DOS, Windows, Windows NT, and Windows XP are trademarks of Microsoft Corporation in the U.S. and other countries.

Intel is a trademark of Intel Corporation in the U.S. and other countries.

UNIX is a registered trademark of The Open Group.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

This document contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.



**WARNING:** Text set off in this manner indicates that failure to follow directions could result in bodily harm or loss of life.

---



**CAUTION:** Text set off in this manner indicates that failure to follow directions could result in damage to equipment or loss of information.

---

### **Service Reference Guide**

HP Compaq Business PC dx7200 Series

First Edition (July 2005)

Document Part Number: 390812-001

---

# Contents

## 1 Installing the Operating System

1.1 Installing or Upgrading Device Drivers .....	1-1
1.2 Transferring Files and Settings .....	1-2
1.3 Backing Up and Restoring Files .....	1-2
1.3.1 Creating a Backup File—Windows XP Professional .....	1-2
1.3.2 Restoring from the Backup File—Windows XP Professional .....	1-2
1.4 Converting to NTFS .....	1-2
1.5 HP Software .....	1-2

## 2 Setup Utilities and Diagnostics Features

2.1 Power-On Self-Test (POST) .....	2-1
2.2 Computer Setup Utilities .....	2-2
2.2.1 Using Computer Setup (F10) Utilities .....	2-3
2.2.2 Computer Setup Menu .....	2-4
2.2.3 Recovering the Configuration Settings .....	2-14
2.3 HP Insight Diagnostics .....	2-14
2.3.1 Accessing HP Insight Diagnostics .....	2-14
2.3.2 Survey Tab .....	2-15
2.3.3 Test Tab .....	2-16
2.3.4 Status Tab .....	2-17
2.3.5 Log Tab .....	2-17
2.3.6 Saving and Printing Information in HP Insight Diagnostics .....	2-17
2.3.7 Downloading the Latest Version of HP Insight Diagnostics .....	2-18

## 3 Desktop Management

3.1 Initial Configuration and Deployment .....	3-1
3.1.1 Altiris Deployment Solution Agent .....	3-2
3.1.2 HP Local Recovery .....	3-2
3.2 Remote System Installation .....	3-2
3.3 Software Updating and Management .....	3-3
3.3.1 HP System Software Manager .....	3-3
3.3.2 HP Client Manager .....	3-3
3.3.3 HP Client Management Solutions using Altiris .....	3-4
3.3.4 HP Local Recovery .....	3-5
3.3.5 Dantz Retrospect Express .....	3-5
3.3.6 Proactive Change Notification .....	3-6
3.3.7 Subscriber's Choice .....	3-6
3.3.8 Retired Solutions .....	3-6
3.4 ROM Flash .....	3-7
3.4.1 Remote ROM Flash .....	3-7

3.4.2 HPQFlash	3-7
3.4.3 Boot Block Emergency Recovery Mode	3-7
3.4.4 Replicating the Setup	3-8
3.4.5 Dual-State Power Button	3-13
3.4.6 World Wide Web Site	3-13
3.4.7 Building Blocks and Partners	3-13
3.5 Asset Tracking and Security	3-14
3.5.1 Password Security	3-17
3.5.2 Establishing a Setup Password Using Computer Setup	3-17
3.5.3 Establishing a Power-On Password Using Computer Setup	3-18
3.5.4 DriveLock	3-20
3.5.5 Smart Cover Sensor	3-22
3.5.6 Cable Lock Provision	3-24
3.5.7 TPM Embedded Security Chip and HP ProtectTools Security Manager	3-24
3.6 Fault Notification and Recovery	3-24
3.6.1 Drive Protection System	3-24
3.6.2 Surge-Tolerant Power Supply	3-24
3.6.3 Thermal Sensor	3-24

## 4 Serial and Parallel ATA Drive Guidelines and Features

4.1 SATA 1.5 and 3.0 Hard Drives	4-1
4.2 SATA Hard Drive Cables	4-2
4.2.1 SATA Data Cable	4-2
4.2.2 SATA Power Cable	4-2
4.3 PATA Device Information	4-3
4.4 PATA Cables	4-3
4.4.1 PATA Data Cable	4-3
4.4.2 PATA Power Cable	4-4
4.5 PATA Drive Installation Guidelines	4-4
4.5.1 PATA Device Classes	4-4
4.6 SATA SMART Drives	4-5
4.7 Drive Capacities	4-5
4.8 SATA BIOS	4-5
4.8.1 Legacy Mode	4-6
4.8.2 Native Mode	4-6
4.9 Mixed Devices Boot and Drive Letter Ordering	4-7

## 5 Identifying the Chassis, Routine Care, and Disassembly Preparation

5.1 Chassis Designations	5-1
5.1.1 Microtower (MT)	5-1
5.1.2 Slim Tower (ST)	5-2
5.2 Electrostatic Discharge Information	5-3
5.2.1 Generating Static	5-3
5.2.2 Preventing Electrostatic Damage to Equipment	5-3
5.2.3 Personal Grounding Methods and Equipment	5-4
5.2.4 Grounding the Work Area	5-4
5.2.5 Recommended Materials and Equipment	5-4
5.3 Operating Guidelines	5-5

5.4 Routine Care . . . . .	5-5
5.4.1 General Cleaning Safety Precautions . . . . .	5-5
5.4.2 Cleaning the Computer Case . . . . .	5-6
5.4.3 Cleaning the Keyboard . . . . .	5-6
5.4.4 Cleaning the Monitor . . . . .	5-7
5.4.5 Cleaning the Mouse . . . . .	5-7
5.5 Service Considerations . . . . .	5-7
5.5.1 Power Supply Fan . . . . .	5-7
5.5.2 Tools and Software Requirements . . . . .	5-7
5.5.3 Screws . . . . .	5-8
5.5.4 Cables and Connectors . . . . .	5-8
5.5.5 Hard Drives . . . . .	5-8
5.5.6 Lithium Coin Cell Battery . . . . .	5-9

## 6 Removal and Replacement Procedures— Microtower (MT) Chassis

6.1 Preparation for Disassembly . . . . .	6-1
6.2 External Security Devices . . . . .	6-2
6.2.1 Installing a Cable Lock . . . . .	6-2
6.2.2 Installing a Padlock . . . . .	6-3
6.3 Access Panel . . . . .	6-4
6.4 Front Bezel . . . . .	6-5
6.5 Front Drive Bezels . . . . .	6-7
6.5.1 5.25" Drive Bezel Blank . . . . .	6-7
6.5.2 Diskette Drive Bezel . . . . .	6-8
6.5.3 3.5" Drive Bezel Blank . . . . .	6-8
6.6 Cable Management . . . . .	6-9
6.7 Memory . . . . .	6-10
6.8 Expansion Cards . . . . .	6-12
6.9 Drives . . . . .	6-16
6.9.1 Drive Positions . . . . .	6-16
6.9.2 Removing a Drive . . . . .	6-17
6.9.3 Installing a Drive . . . . .	6-19
6.10 Chassis Fan . . . . .	6-22
6.11 Front I/O Panel Housing Assembly . . . . .	6-23
6.12 Front I/O Devices . . . . .	6-24
6.13 Power Switch Assembly . . . . .	6-25
6.14 Heatsink . . . . .	6-26
6.15 Processor . . . . .	6-27
6.16 Speaker . . . . .	6-29
6.17 Power Supply . . . . .	6-30
6.18 System Board . . . . .	6-32
6.19 Battery . . . . .	6-33
6.19.1 Type 1 Battery Holder . . . . .	6-34
6.19.2 Type 2 Battery Holder . . . . .	6-35
6.19.3 Type 3 Battery Holder . . . . .	6-36

## **7 Removal and Replacement Procedures— Slim Tower (ST) Chassis**

7.1 Preparation for Disassembly . . . . .	7-1
7.2 Unlocking the Smart Cover Lock . . . . .	7-3
7.3 Hood Sensor . . . . .	7-5
7.4 External Security Devices . . . . .	7-6
7.4.1 Security Clip . . . . .	7-6
7.4.2 Cable Lock . . . . .	7-6
7.4.3 Padlock . . . . .	7-7
7.5 Computer Cover . . . . .	7-8
7.6 Front Drive Bezels . . . . .	7-9
7.7 Cable Management . . . . .	7-11
7.8 Memory . . . . .	7-12
7.9 Vertically Oriented Expansion Card . . . . .	7-14
7.9.1 Expansion Card Retainer . . . . .	7-14
7.9.2 PCI Expansion Card . . . . .	7-15
7.9.3 PCI Express Expansion Card . . . . .	7-17
7.10 Drives . . . . .	7-18
7.10.1 Drive Positions . . . . .	7-18
7.10.2 Optical Drive . . . . .	7-19
7.10.3 External 3.5-inch Drive . . . . .	7-21
7.10.4 Primary Hard Drive . . . . .	7-23
7.11 Fan Shroud . . . . .	7-27
7.12 Chassis Fan . . . . .	7-28
7.13 Front I/O Devices . . . . .	7-29
7.14 Power Switch Assembly . . . . .	7-30
7.15 Heatsink . . . . .	7-31
7.16 Processor . . . . .	7-32
7.17 Speaker . . . . .	7-34
7.18 Power Supply . . . . .	7-35
7.19 System Board . . . . .	7-37
7.20 Battery . . . . .	7-40
7.20.1 Type 1 Battery Holder . . . . .	7-41
7.20.2 Type 2 Battery Holder . . . . .	7-42
7.20.3 Type 3 Battery Holder . . . . .	7-43

### **A Connector Pin Assignments**

### **B Power Cord Set Requirements**

### **C POST Error Messages**

### **D Troubleshooting Without Diagnostics**

### **E System Board and Riser Board Reference Designators**

### **F Memory**


### **Index**




---

# Installing the Operating System

---

 **CAUTION:** Do not add optional hardware or third-party devices to your computer until the operating system is successfully installed. Doing so may cause errors and may prevent the operating system from installing properly.


---

 **CAUTION:** Once the automatic installation has begun, DO NOT TURN OFF THE COMPUTER UNTIL THE PROCESS IS COMPLETE. Turning off the computer during the installation process might damage the software that runs the computer or prevent its proper installation.

---

The first time the computer is turned on, the operating system is automatically installed. This takes approximately 10 minutes, depending on the system hardware configuration. At the beginning of the installation process, you are prompted to select the appropriate language for the operating system. Read and follow the instructions that appear on the screen to complete the installation. During this process, do not turn off your computer unless you are directed to do so.

---

 If the computer shipped with more than one operating system language on the hard drive, the installation process could take up to 60 minutes.

---

## 1.1 Installing or Upgrading Device Drivers

To install hardware devices such as a printer, a display adapter, or network adapter after the operating system installation is completed, the operating system needs access to the appropriate software drivers for the devices.


If prompted for the I386 directory, replace the path specification with **C:\i386**, or use the **Browse** button in the dialog box to locate the i386 folder. This action points the operating system to the appropriate drivers.

Obtain the latest support software, including support software for the operating system from [www.hp.com](http://www.hp.com). Click **Driver Downloads**, select **Download drivers and software**, enter the model number of the computer, and press **Enter**.

You can also obtain the latest support software on CDs. The following Web site provides information on how to purchase a support software CD subscription:

<http://h18000.www1.hp.com/support/files/desktops/us/purchase.html>

---

 If the computer has an optical CD-RW drive, install the appropriate application to be able to write to the drive. To install the application, double-click the Setup Software icon on the desktop or the application launcher and select the **Easy CD Creator** and **Direct CD** option when prompted.

---

## 1.2 Transferring Files and Settings

Use the Microsoft Windows XP Files and Settings Transfer Wizard to move files and settings from an old computer to a new one. Click **Start > All Programs > Accessories > System Tools > Files and Settings Transfer Wizard**.

## 1.3 Backing Up and Restoring Files

### 1.3.1 Creating a Backup File—Windows XP Professional

1. Click **Start > All Programs > Accessories > System Tools > Backup**.
2. Use the Backup or Restore Wizard to create a backup file or tape.



---

A backup file can be saved to a hard disk, a floppy disk, CD, USB flash media device, tape drive, or to any other removable or nonremovable media.

---

### 1.3.2 Restoring from the Backup File—Windows XP Professional

1. Click **Start > All Programs > Accessories > System Tools > Backup**.
2. Use the Backup or Restore Wizard to restore files from a backup file.



---

A backup file can be on a hard disk, a floppy disk, CD, USB flash media device, tape drive, or any other removable or nonremovable media.

---

## 1.4 Converting to NTFS

### Windows XP Professional

To convert a FAT or FAT32 volume to NTFS,

1. Click **Start > All Programs > Accessories > Command Prompt**.
2. Type **convert drive\_letter: /fs:ntfs** (where *drive\_letter* is the volume to be converted) and press **Enter**.

## 1.5 HP Software

The Microsoft Windows XP Professional operating system is preinstalled on the computer and will be configured automatically the first time the computer is turned on. The following HP software may also be installed at that time on selected models:

- Computer Setup Utilities
- HP Support Software including device drivers
- *Online Safety & Comfort Guide*
- Power Management with energy saver features
- Security Management tools
- Software Support Management tools

Certain drivers and utilities are available only in selected languages. You can obtain the latest version of these files, in English and selected other languages, in one of three ways:

- Support Software CD
- HP Web site at [www.hp.com](http://www.hp.com)
- *Restore Plus!* CD, which is supplied with many HP models



Additional HP software may be required in certain situations.

---



---

## Setup Utilities and Diagnostics Features

Setup Utilities (F10) and diagnostic features provide information needed about the computer system when contacting Customer Support. These tools can also be used to:

- Change factory default settings and to set or change the system configuration, which may be necessary when you add or remove hardware.
- Determine if all of the devices installed on the computer are recognized by the system and functioning properly.
- Determine information about the operating environment of the computer.
- Solve system configuration errors detected but not automatically fixed during the Power-On Self-Test (POST).
- Establish and manage passwords and other security features.
- Establish and manage energy-saving timeouts.



All features identified in this chapter may not be available on all HP products.

---

### 2.1 Power-On Self-Test (POST)

POST is a series of diagnostic tests that runs automatically when the system is turned on. POST checks the following items to ensure that the computer system is functioning properly:

- Keyboard
- Memory modules
- All mass storage devices
- Processors
- Controllers



If the Power-On Password is set, a key icon appears on the screen while POST is running. You will need to enter the password before continuing. Refer to [Section 3.1, “Initial Configuration and Deployment”](#) for information on setting, deleting, or bypassing the password.

---

If POST finds an error in the system, an audible and/or visual message occurs. For POST error messages and their solutions refer to [Appendix C, “POST Error Messages.”](#)

## 2.2 Computer Setup Utilities

Use Computer Setup Utilities (F10) to:

- Change factory default settings.
- Set the system date and time.
- Set, view, change, or verify the system configuration, including settings for processor, graphics, memory, audio, storage, communications, and input devices.
- Modify the boot order of bootable devices such as hard drives, diskette drives, optical drives, or USB flash media devices.
- Enable Quick Boot, which is faster than Full Boot but does not run all of the diagnostic tests run during a Full Boot. You can set the system to:
  - always Quick Boot (default);
  - periodically Full Boot (from every 1 to 30 days); or
  - always Full Boot.
- Select Post Messages Enabled or Disabled to change the display status of Power-On Self-Test (POST) messages. Post Messages Disabled suppresses most POST messages, such as memory count, product name, and other non-error text messages. If a POST error occurs, the error is displayed regardless of the mode selected. To manually switch to Post Messages Enabled during POST, press any key (except **F1** through **F12**).
- Establish an Ownership Tag, the text of which is displayed each time the system is turned on or restarted.
- Enter the Asset Tag or property identification number assigned by the company to this computer.
- Enable the power-on password prompt during system restarts (warm boots) as well as during power-on.
- Establish a setup password that controls access to Computer Setup (F10) Utility and the settings described in this section.
- Secure integrated I/O functionality, including the serial, USB, or parallel ports, audio, or embedded NIC, so that they cannot be used until they are unsecured.
- Enable or disable removable media boot ability.
- Enable or disable legacy diskette write ability (when supported by hardware).
- Solve system configuration errors detected but not automatically fixed during the Power-On Self-Test (POST).
- Replicate the system setup by saving system configuration information on diskette and restoring it on one or more computers.
- Execute self-tests on a specified ATA hard drive (when supported by drive).
- Enable or disable DriveLock security (when supported by drive).

## 2.2.1 Using Computer Setup (F10) Utilities

Computer Setup can be accessed only by turning on the computer or restarting the system. To access the Computer Setup Utilities menu, complete the following steps:

1. Turn on or restart the computer. If you are in Windows, click **Start >Shut Down >Restart**.
2. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.



If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.


If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

3. Select your language from the list and press the **Enter** key.
4. A choice of five headings appears in the Computer Setup Utilities menu: File, Storage, Security, Power, and Advanced.
5. Use the arrow (left and right) keys to select the appropriate heading. Use the arrow (up and down) keys to select the option you want, then press **Enter**. To return to the Computer Setup Utilities menu, press **Esc**.
6. To apply and save changes, select **File > Save Changes and Exit**.
  - If you have made changes that you do not want applied, select **Ignore Changes and Exit**.
  - To reset to factory settings or previously saved default settings, select **Set Defaults and Exit**. This option will restore the original factory system defaults.








**CAUTION:** Do NOT turn the computer power OFF while the ROM is saving your F10 Computer Setup changes because the CMOS could become corrupted. It is safe to turn off all power to the computer after you exit the F10 Setup screen.



## 2.2.2 Computer Setup Menu





Heading	Option	Description
File	System Information	Lists: <ul style="list-style-type: none"> <li>• Product name</li> <li>• SKU number (some models)</li> <li>• Processor type/speed/stepping</li> <li>• Cache size (L1/L2) (dual core processors have this listed twice)</li> <li>• Total installed memory size, speed, and operating mode (Single Channel, Dual Channel, or Asymmetric) (if applicable)</li> <li>• Installed memory in each DIMM slot, grouped by channels (if applicable)</li> <li>• Integrated MAC address for embedded, enabled NIC (if applicable)</li> <li>• System BIOS (includes family name and version)</li> <li>• Chassis serial number</li> <li>• Asset tracking number</li> </ul>
	About	Displays copyright information.
	Set Time and Date	Allows you to set system time and date.
	Flash System ROM	Allows you to select a drive containing a new BIOS.
	Replicated Setup	<p><b>Save to Removable Media</b> Saves system configuration, including CMOS, to a formatted 1.44-MB diskette, a USB flash media device, or a diskette-like device (a storage device set to emulate a diskette drive).</p> <p><b>Restore from Removable Media</b> Restores system configuration from a diskette, a USB flash media device, or a diskette-like device.</p>
	Default Setup	<p><b>Save Current Settings as Default</b> Saves the current system configuration settings as the default.</p> <p><b>Restore Factory Settings as Default</b> Restores the factory system configuration settings as the default.</p>
	Apply Defaults and Exit	Applies the currently selected default settings and clears any established passwords.
	Ignore Changes and Exit	Exits Computer Setup without applying or saving any changes.
	Save Changes and Exit	Saves changes to system configuration or default settings and exits Computer Setup.
 Support for specific Computer Setup options may vary depending on the hardware configuration.		







Heading	Option	Description															
Storage	Device Configuration	<p>Lists all installed BIOS-controlled storage devices. When a device is selected, detailed information and options are displayed. The following options may be presented.</p> <hr/> <p><b>Diskette Type</b> Identifies the highest capacity media type accepted by the diskette drive. Legacy Diskette Drives Options are 3.5" 1.44 MB, and 5.25" 1.2 MB.</p> <hr/> <p><b>Drive Emulation</b> Allows you to select a drive emulation type for a certain storage device. (For example, a Zip drive can be made bootable by selecting diskette emulation.)</p> <hr/> <table border="1"> <thead> <tr> <th>Drive Type</th> <th>Emulation Options</th> </tr> </thead> <tbody> <tr> <td rowspan="2">ATAPI Zip drive</td> <td>None (treated as Other)</td> </tr> <tr> <td>Diskette (treated as diskette drive)</td> </tr> <tr> <td rowspan="2">ATA Hard disk</td> <td>None (treated as Other)</td> </tr> <tr> <td>Hard disk (treated as hard drive)</td> </tr> <tr> <td>Legacy diskette</td> <td>No emulation options available</td> </tr> <tr> <td>CD-ROM drive</td> <td>No emulation options available</td> </tr> <tr> <td rowspan="2">ATAPI LS-120</td> <td>None (treated as Other).</td> </tr> <tr> <td>Diskette (treated as diskette drive).</td> </tr> </tbody> </table> <hr/> <p> Support for specific Computer Setup options may vary depending on the hardware configuration.</p>	Drive Type	Emulation Options	ATAPI Zip drive	None (treated as Other)	Diskette (treated as diskette drive)	ATA Hard disk	None (treated as Other)	Hard disk (treated as hard drive)	Legacy diskette	No emulation options available	CD-ROM drive	No emulation options available	ATAPI LS-120	None (treated as Other).	Diskette (treated as diskette drive).
Drive Type	Emulation Options																
ATAPI Zip drive	None (treated as Other)																
	Diskette (treated as diskette drive)																
ATA Hard disk	None (treated as Other)																
	Hard disk (treated as hard drive)																
Legacy diskette	No emulation options available																
CD-ROM drive	No emulation options available																
ATAPI LS-120	None (treated as Other).																
	Diskette (treated as diskette drive).																




Heading	Option	Description
Storage (continued)	Device Configuration (continued)	<p><b>Default Values IDE/SATA</b></p> <p>If selected, this option allows you to specify the default values for the Multisector Transfers, Transfer Mode, and Translation Mode for ATA devices.</p> <p><b>Multisector Transfers</b> (ATA disks only) Specifies how many sectors are transferred per multi-sector PIO operation. Options (subject to device capabilities) are Disabled, 8, and 16.</p> <p><b>Transfer Mode</b> (IDE devices only) Specifies the active data transfer mode. Options (subject to device capabilities) are PIO 0, Max PIO, Enhanced DMA, Ultra DMA 0, and Max UDMA.</p> <p><b>Translation Mode</b> (ATA disks only) Lets you select the translation mode to be used for the device. This enables the BIOS to access disks partitioned and formatted on other systems and may be necessary for users of older versions of UNIX (e.g., SCO UNIX version 3.2). Options are Automatic, Bit-Shift, LBA Assisted, User, and None</p> <p> <b>CAUTION:</b> Ordinarily, the translation mode selected automatically by the BIOS should not be changed. If the selected translation mode is not compatible with the translation mode that was active when the disk was partitioned and formatted, the data on the disk will be inaccessible.</p> <p><b>Translation Parameters</b> (ATA disks only)</p> <p> This feature appears only when User translation mode is selected.</p> <p>Allows you to specify the parameters (logical cylinders, heads, and sectors per track) used by the BIOS to translate disk I/O requests (from the operating system or an application) into terms the hard drive can accept. Logical cylinders may not exceed 1024. The number of heads may not exceed 256. The number of sectors per track may not exceed 63. These fields are only visible and changeable when the drive translation mode is set to User.</p>
	Storage Options	<p><b>Removable Media Boot</b> Enables/disables ability to boot the system from removable media.</p> <hr/> <p><b>Legacy Diskette Write</b> Enables/disables ability to write data to legacy diskettes.</p> <p> After saving changes to Removable Media Write, the computer will restart. Turn the computer off, then on, manually.</p>
<p> Support for specific Computer Setup options may vary depending on the hardware configuration.</p>		


Heading	Option	Description
Storage (continued)	Storage Options (continued)	<p><b>BIOS DMA Data Transfers</b></p> <p>Allows you to control how BIOS device I/O requests are serviced. When “Enable” is selected, the BIOS will service ATA device read and write requests with DMA data transfers. When “Disable” is selected, the BIOS will service ATA device read and write requests with PIO data transfers.</p> <hr/> <p><b>SATA Emulation</b></p> <p>Allows you to choose how the SATA controller and devices are accessed by the operating system.</p> <p>“<u>Separate IDE Controller</u>” is the default option. Up to 4 SATA and 2 PATA devices may be accessed in this mode. The SATA and PATA controllers appear as two separate IDE controllers. Use this option with Microsoft Windows 2000 and Windows XP.</p> <ul style="list-style-type: none"> <li>• SATA 0 is seen as SATA Primary Device 0</li> <li>• SATA 1 (if present) is seen as SATA Secondary Device 0</li> <li>• SATA 2 (if present) is seen as SATA Primary Device 1.</li> <li>• SATA 3 (if present) is seen as SATA Secondary Device 1.</li> </ul> <p>“<u>Combined IDE Controller</u>” is the other option. Up to 2 PATA and 2 SATA devices may be accessed in this mode. The SATA and PATA controllers appear as one combined IDE controller. Use this option with Microsoft Windows 98 and earlier operating systems.</p> <ul style="list-style-type: none"> <li>• PATA Primary Device 0 replaces SATA 1</li> <li>• PATA Primary Device 1 replaces SATA 3</li> </ul> <hr/> <p><b>IDE Controller</b></p> <p>Allows you to enable or disable the primary IDE controller. This feature is supported on some models only.</p> <hr/> <p><b>Primary SATA Controller</b></p> <p>Allows you to enable or disable the Primary SATA controller.</p> <hr/> <p><b>Secondary SATA Controller</b></p> <p>Allows you to enable or disable the Secondary SATA controller. This feature is supported on some models only.</p> <hr/> <p>DPS Self-Test</p> <p>Allows you to execute self-tests on ATA hard drives capable of performing the Drive Protection System (DPS) self-tests.</p> <p> This selection will only appear when at least one drive capable of performing the DPS self-tests is attached to the system.</p> <hr/> <p> Support for specific Computer Setup options may vary depending on the hardware configuration.</p>

Heading	Option	Description
Storage (continued)	Boot Order	<p>Allows you to:</p> <ul style="list-style-type: none"> <li>Specify the order in which attached devices (such as a USB flash media device, diskette drive, hard drive, optical drive, or network interface card) are checked for a bootable operating system image. Each device on the list may be individually excluded from or included for consideration as a bootable operating system source.</li> <li>Specify the order of attached hard drives. The first hard drive in the order will have priority in the boot sequence and will be recognized as drive C (if any devices are attached).</li> </ul> <p> MS-DOS drive lettering assignments may not apply after a non-MS-DOS operating system has started.</p> <p><b>Shortcut to Temporarily Override Boot Order</b></p> <p>To boot <b>one time</b> from a device other than the default device specified in Boot Order, restart the computer and press <b>F9</b> when the monitor light turns green. After POST is completed, a list of bootable devices is displayed. Use the arrow keys to select the preferred bootable device and press <b>Enter</b>. The computer then boots from the selected non-default device for this one time.</p>
Security	Smart Card Options	Allows you to enable/disable the Smart Card to be used in place of the Power-On Password. This option only appears if a Smart Card reader is attached to the system.
	Setup Password	<p>Allows you to set and enables setup (administrator) password.</p> <p> If the setup password is set, it is required to change Computer Setup options, flash the ROM, and make changes to certain plug and play settings under Windows.</p>
	Power-On Password	Allows you to set and enable power-on password.
	Password Options (This selection will appear only if a power-on password is set.)	<p>Allows you to:</p> <ul style="list-style-type: none"> <li>Lock legacy resources (appears if a setup password is set)</li> <li>Enable/disable network server mode (appears if a power-on password is set)</li> <li>Specify whether the password is required for warm boot (<b>CTRL+ALT+DEL</b>). (appears if a power-on password is set)</li> </ul>
	Smart Cover	<p>Allows you to:</p> <ul style="list-style-type: none"> <li>Lock/unlock the Cover Lock.</li> <li>Set the Cover Removal Sensor to Disable/Notify User/Setup Password.</li> </ul> <p> <i>Notify User</i> alerts the user that the sensor has detected that the cover has been removed. <i>Setup Password</i> requires that the setup password be entered to boot the computer if the sensor detects that the cover has been removed.</p> <p>This feature is supported on some models only.</p>
<p> Support for specific Computer Setup options may vary depending on the hardware configuration.</p>		

Heading	Option	Description
Security (continued)	Embedded Security	<p>Allows you to:</p> <ul style="list-style-type: none"> <li>• Enable/disable the Embedded Security device.</li> <li>• Reset the device to Factory Settings.</li> <li>• Enable/disable power-on authentication support.</li> <li>• Reset authentication credentials.</li> </ul> <p>This feature is supported on some models only.</p>
	Device Security	Enables/disables serial ports, parallel port, front USB ports, system audio, internal speaker (does not affect external speakers) network controllers (some models), MultiBay devices (some models), SMBus controller (some models), SCSI controllers (some models), and embedded security device.
	Network Service Boot	Enables/disables the computer's ability to boot from an operating system installed on a network server. (Feature available on NIC models only; the network controller must reside on the PCI bus or be embedded on the system board.)
	System IDs	<p>Allows you to set:</p> <ul style="list-style-type: none"> <li>• Asset tag (18-byte identifier) and ownership Tag (80-byte identifier displayed during POST).</li> <li>• Chassis serial number or Universal Unique Identifier (UUID) number. The UUID can only be updated if the current chassis serial number is invalid. (These ID numbers are normally set in the factory and are used to uniquely identify the system.)</li> <li>• Keyboard locale setting (for example, English or German) for System ID entry.</li> </ul>
	DriveLock Security	<p>Allows you to assign or modify a master or user password for drives that support ATA Security. When this feature is enabled, the user is prompted to provide one of the DriveLock passwords during POST. If neither is successfully entered, the hard drive will remain inaccessible until one of the passwords is successfully provided during a subsequent cold-boot sequence.</p> <p> This selection will only appear when at least one drive that supports ATA Security is attached to the system.</p>
	OS Security	<ul style="list-style-type: none"> <li>• Data Execution Prevention (some models) (enable/disable). Helps prevent OS security breaches.</li> <li> This selection is in effect only if the processor and operating system being used comprehend and utilize this feature.</li> <li>• Intel Virtualization Technology (some models) (enable/disable). Changing this setting requires turning the computer off and then back on.</li> <li> This selection is in effect only if the processor and operating system being used comprehend and utilize this feature.</li> </ul>

 Support for specific Computer Setup options may vary depending on the hardware configuration.

Heading	Option	Description
Security (continued)	Data Execution Prevention	<p>Enable/Disable. Data Execution Prevention Mode help prevent OS security breaches.</p> <p> This selection is in effect only if the processor and operating system being used comprehend and utilize the function.</p>
Power	OS Power Management	<ul style="list-style-type: none"> <li>• Runtime Power Management - Enable/Disable. Allows certain operating systems to reduce processor voltage and frequency when the current software load does not require the full capabilities of the processor. This option is only available when supported by the processor.</li> <li>• Idle Power Savings - Extended/Normal. Allows certain operating systems to decrease the processors power consumption when the processor is idle. This option is only available when supported by the processor.</li> <li>• ACPI S3 Support - Enables or disables ACPI S3 support.</li> <li>• ACPI S3 Hard Disk Reset - Enabling this causes the BIOS to ensure hard disks are ready to accept commands after resuming from S3 before returning control to the operating system.</li> <li>• ACPI S3 PS2 Mouse Wakeup - Enables or disables waking from S3 due to PS2 mouse activity.</li> <li>• USB Wake on Device Insertion - Allows system to wake from Standby on USB device insertion.</li> </ul>
	Hardware Power Management	SATA power management enables or disables SATA bus and/or device power management.
	Thermal	<p>Fan idle mode - This bar graph controls the minimum permitted fan speed.</p> <p> This setting only changes the minimum fan speed. The fans are still automatically controlled.</p>
<p> Support for specific Computer Setup options may vary depending on the hardware configuration.</p>		

Heading	Option	Description
Advanced* *For advanced users only	Power-On Options	<p>Allows you to set:</p> <ul style="list-style-type: none"> <li>• POST mode (QuickBoot, FullBoot, or FullBoot every 1-30 days).</li> <li>• POST messages (enable/disable).</li> <li>• <b>F9</b> prompt (enable/disable). Enabling this feature will display the text <b>F9=Boot Menu</b> during POST. Disabling this feature prevents the text from being displayed but pressing <b>F9</b> will still access the Shortcut Boot (Order) Menu screen. See <b>Storage &gt; Boot Order</b> for more information.</li> <li>• <b>F10</b> prompt (enable/disable). Enabling this feature will display the text <b>F10=Setup</b> during POST. Disabling this feature prevents the text from being displayed but pressing <b>F10</b> will still access the Setup screen.</li> <li>• <b>F12</b> prompt (enable/disable). Enabling this feature will display the text <b>F12=Network Service Boot</b> during POST. Disabling this feature prevents the text from being displayed but pressing <b>F12</b> will still force the system to attempt booting from the network.</li> <li>• Option ROM* prompt (enable/disable). Enabling this feature will cause the system to display a message before loading options ROMs. (This feature is supported on some models only.)</li> <li>• Remote wakeup boot source (remote server/local hard drive).</li> <li>• After Power Loss (off/on/previous state): Set this option to <b>ON</b>: <ul style="list-style-type: none"> <li>• Off - causes the computer to remain powered off when power is restored.</li> <li>• On - causes the computer to power on automatically as soon as power is restored.</li> <li>• On - allows you to power on the computer using a power strip switch, if the computer is connected to an electric power strip.</li> <li>• Previous state - causes the computer to power on automatically as soon as power is restored, if it was on when power was lost.</li> </ul> </li> </ul> <p> If you turn off power to your computer using the switch on a power strip, you will not be able to use the suspend/sleep feature or the Remote Management features.</p> <ul style="list-style-type: none"> <li>• POST Delay (in seconds) (enable/disable). Enabling this feature will add a user-specified delay to the POST process. This delay is sometimes needed for hard disks on some PCI cards that spin up very slowly; so slowly that they are not ready to boot by the time POST is finished. The POST delay also gives you more time to press <b>F10</b> to enter Computer (F10) Setup.</li> <li>• I/O APIC Mode (enable/disable). Enabling this feature will allow Microsoft Windows Operating Systems to run optimally. This feature must be disabled for certain non-Microsoft Operating Systems to work properly.</li> </ul>




Support for specific Computer Setup options may vary depending on the hardware configuration.

Heading	Option	Description
Advanced* (continued) *For advanced users only	Power-On Options (continued)	Allows you to set: (continued) <ul style="list-style-type: none"> <li>• Hyper-threading (enable/disable)</li> <li>• Set Up Browse Mode (enable/disable). Enabling this feature permits Computer Setup to be viewed, but not changed, without entering the setup password.</li> <li>• Limit CPUID Maximum Value to 3 - Restricts the number of CPUID functions reported by the microprocessor. Enable this feature if booting to WinNT.</li> <li>• ACPI/USB Buffers @ Top of Memory (enable/disable). Enabling this feature places USB memory buffers at the top of memory. The advantage is that some amount of memory below 1 MB is freed up for use by option ROMs. The disadvantage is that a popular memory manager, HIMEM.SYS, does not work properly when USB buffers are at top of memory AND the system has 64 MB or less of RAM.</li> </ul>
	Execute Memory Test	Restarts the computer and executes the POST memory test.
	BIOS Power-On	Allows you to set the computer to turn on automatically at a time you specify.
	Onboard Devices	Allows you to set resources for or disable onboard system devices (diskette controller, serial port, or parallel port).
	PCI Devices	<ul style="list-style-type: none"> <li>• Lists currently installed PCI devices and their IRQ settings.</li> <li>• Allows you to reconfigure IRQ settings for these devices or to disable them entirely. These settings have no effect under an APIC-based operating system.</li> </ul>
	PCI VGA Configuration	Displayed only if there are multiple PCI video adapters in the system. Allows you to specify which VGA controller will be the "boot" or primary VGA controller.
	Bus Options	On some models, allows you to enable or disable: <ul style="list-style-type: none"> <li>• PCI SERR# Generation.</li> <li>• PCI VGA palette snooping, which sets the VGA palette snooping bit in PCI configuration space; only needed when more than one graphics controller is installed.</li> </ul>



Support for specific Computer Setup options may vary depending on the hardware configuration.



Heading	Option	Description
Advanced* (continued) *For advanced users only	Device options	<p>Allows you to set:</p> <ul style="list-style-type: none"> <li>Printer mode (bi-directional, EPP &amp; ECP, output only).</li> <li><b>Num Lock</b> state at power-on (off/on).</li> <li>S5 Wake on LAN (enable/disable). <ul style="list-style-type: none"> <li>To disable Wake on LAN during the off state (S5), use the arrow (left and right) keys to select the <b>Advanced &gt; Device Options</b> menu and set the S5 Wake on Lan feature to "Disable." This obtains the lowest power consumption available on the computer during S5. It does not affect the ability of the computer to Wake on LAN from suspend or hibernation, but will prevent it from waking from S5 via the network. It does not affect operation of the network connection while the computer is on.</li> <li>If a network connection is not required, completely disable the network controller (NIC) by using the arrow (left and right) keys to select the <b>Security &gt; Device Security</b> menu. Set the Network Controller option to "Device Hidden." This prevents the network controller from being used by the operating system and reduces the power used by the computer in S5.</li> </ul> </li> <li>Processor cache (enable/disable).</li> <li>Unique Sleep State Blink Patterns. Allows you to choose an LED blink pattern that uniquely identifies each sleep state. <ul style="list-style-type: none"> <li>1 blink followed by 2-sec. pause = S1</li> <li>2 blinks followed by 2-sec. pause = S2</li> <li>3 blinks followed by 2-sec. pause = S3</li> </ul> </li> <li>Integrated Video (enable/disable) Allows you to use integrated video and PCI Up Solution video at the same time (available on some models only).</li> </ul> <p> Inserting a PCI or PCI Express video card automatically disables Integrated Video. When PCI Express video is on, Integrated Video must remain disabled.</p> <ul style="list-style-type: none"> <li>Monitor Tracking (enable/disable). Allows ROM to save monitor asset information.</li> <li>NIC PXE Option ROM Download (enable/disable). The BIOS contains an embedded NIC option ROM to allow the unit to boot through the network to a PXE server. This is typically used to download a corporate image to a hard drive. The NIC option ROM takes up memory space below 1MB commonly referred to as DOS Compatibility Hole (DCH) space. This space is limited. This F10 option will allow users to disable the downloading of this embedded NIC option ROM thus giving more DCH space for additional PCI cards which may need option ROM space. The default will be to have the NIC option ROM enabled.</li> </ul>
	PCI VGA Configuration	Displayed only if there are multiple PCI video adapters in the system. Allows you to specify which VGA controller will be the "boot" or primary VGA controller.



Support for specific Computer Setup options may vary depending on the hardware configuration.

## 2.2.3 Recovering the Configuration Settings

This method of recovery requires that you first perform the Save to Removable Media command with the Computer Setup (F10) Utility before Restore is needed.



It is recommended that you save any modified computer configuration settings to a diskette, a USB flash media device, or a diskette-like device (a storage device set to emulate a diskette drive) and save the diskette or device for possible future use.

To restore the configuration, insert the diskette, USB flash media device, or other storage media emulating a diskette with the saved configuration and perform the Restore from Removable Media command with the Computer Setup (F10) Utility.

## 2.3 HP Insight Diagnostics



HP Insight Diagnostics is included on the *Documentation and Diagnostics* CD with some computer models only.

The HP Insight Diagnostics utility allows you to view information about the hardware configuration of the computer and perform hardware diagnostic tests on the subsystems of the computer. The utility simplifies the process of effectively identifying, diagnosing, and isolating hardware issues.

The Survey tab is displayed when you invoke HP Insight Diagnostics. This tab shows the current configuration of the computer. From the Survey tab, there is access to several categories of information about the computer. Other tabs provide additional information, including diagnostic test options and test results. The information in each screen of the utility can be saved as an html file and stored on a diskette or USB HP Drive Key.

Use HP Insight Diagnostics to determine if all the devices installed on the computer are recognized by the system and functioning properly. Running tests is optional but recommended after installing or connecting a new device.

You should run tests, save the test results, and print them so that you have printed reports available before placing a call to the Customer Support Center.




Third party devices may not be detected by HP Insight Diagnostics.

### 2.3.1 Accessing HP Insight Diagnostics

You must boot to the *Documentation and Diagnostics* CD, as described in the steps below, to access HP Insight Diagnostics.


1. While the computer is on, insert the *Documentation and Diagnostics* CD into an optical drive on the computer.
2. Shut down the operating system and turn off the computer.
3. Turn on the computer. The system will boot to the CD.

---

 If the system does not boot to the CD in the optical drive, you may need to change the boot order in the Computer Setup (F10) utility so that the system attempts to boot to the optical drive before booting to the hard drive. Refer to the *Computer Setup (F10) Utility Guide* on the *Documentation and Diagnostics* CD for more information.

---

4. When prompted, press the **Y** key if you want to operate in Safe mode or any other key if you want to operate in Regular mode.
- 

 Regular mode is the default mode if no keys are pressed within the specified time frame. If the screen remains blank after pressing any key other than **Y**, try rebooting and select safe mode when prompted.

---

5. Select the appropriate language and click **Continue**.
- 

 It is recommended that you accept the assigned default keyboard for your language unless you want to test your specific keyboard.

---

6. In the End User License Agreement page, click **Agree** if you agree with the terms. The HP Insight Diagnostics utility launches with the Survey tab displayed.

## 2.3.2 Survey Tab

The **Survey** tab displays important system configuration information. In the **View** section on the left side of the screen, you can select the **Summary** view to see limited configuration data or select the **Advanced** view to see all the data in the selected category. Regardless of whether you choose **Advanced** or **Summary**, the following categories of information are available on the **Survey** tab:

**All**—Gives a listing of all categories of information about the computer.

**Overview**—Gives you a listing of general information about the computer.

**Architecture**—Provides system BIOS and PCI device information.

**Asset Control**—Shows asset tag, system serial number, and processor information.

**Communication**—Shows information about the computer parallel (LPT) and serial (COM) port settings, plus USB and network controller information.

**Graphics**—Shows information about the graphics controller of the computer.

**Input Devices**—Shows information about the keyboard, mouse, and other input devices connected to the computer.

**Memory**—Shows information about all memory in the computer. This includes memory slots on the system board and any memory modules installed.

**Miscellaneous**—Shows information obtained from the computer configuration memory (CMOS), system management BIOS data, system board data, and diagnostics component information.

**Storage**—Shows information about storage media connected to the computer. This list includes all fixed disks, diskette drives, and optical drives.

**System**—Shows information about the system board, processor, chassis, and BIOS, plus internal speaker and PCI bus information.

## 2.3.3 Test Tab

The Test tab allows you to choose various parts of the system to test. You can also choose the type of test and testing mode.

There are two test modes to choose from:

- **Interactive Mode**—Provides maximum control over the testing process. The diagnostic software will prompt you for input during tests that require your interaction. You may also determine whether the test passed or failed.
- **Unattended Mode**—Does not display prompts and requires no interaction. If errors are found, they are displayed when testing is complete.

There are three types of tests to choose from:

- **Quick Test**—Provides a predetermined script where a sample of each hardware component is exercised and requires no user intervention in either Unattended or Interactive mode.
- **Complete Test**—Provides a predetermined script where each hardware component is fully tested. There are more tests available in the Interactive mode, but these require user intervention.
- **Custom Test**—Provides the most flexibility in controlling the testing of a system. The Custom Test mode allows you to specifically select which devices, tests, and test parameters are run.

To begin testing:

1. Select the Test tab.
2. On the left side of the tab, select the **Type of Test** to perform (**Quick**, **Complete**, or **Custom**).
3. On the left side of the tab, select the **Test Mode** (**Interactive** or **Unattended**).
4. Select the device to be tested from the drop-down list.
5. Choose how you want the test to be executed, either **Number of Loops** or **Total Test Time**. When choosing to run the test over a specified number of loops, enter the number of loops to perform. If you desire to have the diagnostic test for a specified time period, enter the amount of time in minutes.
6. Click **Begin Testing** to start the test. The Status tab, which allows you to monitor the progress of the test, is automatically displayed during the testing process. When the test is complete, the Status tab shows whether the device passed or failed.
7. If errors are found, go to the Log tab and click the **Error Log** to display more detailed information and recommended actions.

## 2.3.4 Status Tab

The Status tab displays the status of the selected tests. The type of test executed (**Quick**, **Complete**, or **Custom**) is also displayed. The main progress bar displays the percent complete of the current set of tests. While testing is in progress, a **Cancel Testing** button is displayed for use if you want to cancel the test.

After testing has completed, the **Cancel Testing** button is replaced with a **Retest** button. The **Retest** button will retest the last set of tests executed. This enables you to re-run the set of tests without having to re-enter the data in the Test tab.

The Status tab also shows:

- The devices being tested
- The tests that are running
- The overall elapsed time
- The individual elapsed test times
- The condition status of each test

## 2.3.5 Log Tab

The Log tab contains two logs, a **Test Log** and an **Error Log**, each of which can be selected from the left side of the tab.

The **Test Log** displays all tests that have been executed, the number of times of execution, the number of times the test failed, and the time it took to complete the test. The **Clear Test Log** button will clear the contents of the **Test Log**.

The **Error Log** displays the tests for devices that have failed during the diagnostic testing and includes the following columns of information.

- The **Description** section describes the error that the diagnostic test found.
- The **Recommended Repair** will give a recommended action that should be performed to resolve the failed hardware.
- The **Failed Count** is the number of times the test has failed.
- The **Error Code** provides a numerical code for the failure. The error codes are defined in the Help tab.
- The **Clear Error Log** button will clear the contents of the Error Log.

## 2.3.6 Saving and Printing Information in HP Insight Diagnostics

You can save the information displayed in the HP Insight Diagnostics Status and Log tabs to a diskette or a USB 2.0 HP Drive Key (64MB or higher). You can not save to the hard drive. The system will automatically create an html file that has the same appearance as the information displayed on the screen.

1. Insert a diskette or USB 2.0 HP Drive Key (capacity must be 64MB or higher). USB 1.0 Drive Keys are not supported.
2. Click **Save** in the upper right corner of the tab.
3. Select **Save to the floppy** or **Save to USB key**.
4. Enter a file name in the **File Name** box and click the **Save** button. An html file will be saved to the inserted diskette or USB HP Drive Key.

5. Print the information from the storage device used to save it.



---

To exit HP Insight Diagnostics, click Exit in the upper right corner of the screen then remove the *Documentation and Diagnostics* CD from the optical drive.

---

### 2.3.7 Downloading the Latest Version of HP Insight Diagnostics

1. Go to [www.hp.com](http://www.hp.com).
2. Click the **Driver Downloads** or **Support & Troubleshooting** link.
3. Click the **Download driver and software** radio button.
4. Enter your product number (for example, dc7600) in the text box and press the **Enter** key.
5. Select your product.
6. Select your OS.
7. Click the **Diagnostics** link.
8. Select **HP Insight Diagnostics** and click **Download**.



---

The download includes instructions on how to create the bootable CD.

---

---

## Desktop Management

HP Client Management Solutions provides standards-based solutions for managing and controlling desktops, workstations, and notebook PCs in a networked environment.

The key capabilities and features of desktop management are:

- Initial configuration and deployment
- Remote system installation
- Software updating and management
- ROM flash
- Asset tracking and security
- Fault notification and recovery



Support for specific features described in this guide may vary by model or software version.

---

### 3.1 Initial Configuration and Deployment

HP computers come with a preinstalled system software image. After a brief software “unbundling” process, the computer is ready to be used.

A customized software image may be deployed by:

- Installing additional software applications after unbundling the preinstalled software image.
- Using software deployment tools, such as Altiris Deployment Solution, to replace the preinstalled software with a customized software image.
- Using a disk cloning process to copy the contents from one hard drive to another.

The best deployment method depends on your information technology environment and processes. The PC Deployment section of the HP Lifecycle Solutions Web site (<http://whp-sp-orig.extweb.hp.com/country/us/en/solutions.html>) provides information to help you select the best deployment method.

The *Restore Plus!* CD, ROM-based setup, and ACPI hardware provide further assistance with recovery of system software, configuration management and troubleshooting, and power management.

### 3.1.1 Altiris Deployment Solution Agent

This program is pre-loaded on the computer. When installed, it enables communication with the administrator Deployment Solution console.

To install Altiris Deployment Solution Agent:

1. Click **Start**.
2. Click **All Programs**.
3. Click **Software Setup**.
4. Click **Next**.
5. Scroll down and click on the link to install Altiris AClient.

### 3.1.2 HP Local Recovery

Local Recovery backs-up data and system files to a protected area on the hard drive. If data or files are lost, deleted, or corrupted, Local Recovery can be used to retrieve data or restore the last good system image.

To install this pre-loaded program:

1. Click **Start**.
2. Click **Local Recovery**.
3. Click **Next**.
4. Scroll down and click on the link to install HP Local Recovery.

## 3.2 Remote System Installation

Remote System Installation allows you to start and set up your system using the software and configuration information located on a network server by initiating the Preboot Execution Environment (PXE). The Remote System Installation feature is usually used as a system setup and configuration tool, and can be used for the following tasks:

- Formatting a hard drive.
- Deploying a software image on one or more new PCs.
- Remotely updating the system BIOS in flash ROM. See [Section 3.4.1, “Remote ROM Flash.”](#)
- Configuring the system BIOS settings.

To initiate Remote System Installation, press **F12** when the F12 = Network Service Boot message appears in the lower-right corner of the HP logo screen. Follow the instructions on the screen to continue the process. The default boot order is a BIOS configuration setting that can be changed to always attempt to PXE boot.

HP and Altiris have partnered to provide tools designed to make the task of corporate PC deployment and management easier and less time-consuming, ultimately lowering the total cost of ownership and making HP PCs the most manageable client PCs in the enterprise environment.



## 3.3 Software Updating and Management

HP provides several tools for managing and updating software on desktops, workstations, and notebooks:

- HP System Software Manager
- HP Client Manager
- HP Client Management Solutions using Altiris
- HP Local Recovery
- Dantz Backup and Recovery
- HP Proactive Change Notification
- HP Subscriber's Choice

### 3.3.1 HP System Software Manager

HP System Software Manager (SSM) is a free utility that automates remote deployment of device drivers and BIOS updates for networked HP business PCs. When SSM runs, it silently (without user interaction) determines the revision levels of drivers and BIOS installed on each networked client system and compares this inventory against system software SoftPaks that have been tested and stored in a central file store. SSM then automatically updates any down-revision system software on the networked PCs to the later levels available in the file store. Since SSM only allows distribution of SoftPak updates to the correct client system models, administrators can confidently and efficiently use SSM to keep system software updated.

System Software Manager integrates with enterprise software distribution tools such as Microsoft Systems Management Server (SMS). Using SSM, you can distribute customer-created or third-party updates that have been packaged in the SSM-format.

SSM may be downloaded at no charge by visiting [www.hp.com/go/ssm](http://www.hp.com/go/ssm).

### 3.3.2 HP Client Manager

HP Client Manager, developed with Altiris, is available free for supported HP business desktop, notebook, and workstation models. SSM is integrated into HP Client Manager and enables central tracking, monitoring, and management of the hardware aspects of HP client systems.

Use HP Client Manager to:

- Get valuable hardware information such as CPU, memory, video, and security settings
- Monitor system health to fix problems before they occur
- Install drivers and BIOS updates without visiting each PC
- Remotely configure BIOS and security settings
- Automate processes to quickly resolve hardware problems

HP Client Manager uses the same Altiris infrastructure as the other Altiris client lifecycle management solutions. This design provides a significant benefit for the IT staff, since only one infrastructure needs to be setup and maintained. Since information is stored in one database, you get complete and consistent inventory reports as well as system health and security information. You use a single, consistent console interface for scheduling and tracking progress of both hardware and software management tasks for client systems.

For more information on HP Client Manager, visit [www.hp.com/go/easydeploy](http://www.hp.com/go/easydeploy).

### 3.3.3 HP Client Management Solutions using Altiris

Additional Altiris client management solutions can be purchased through HP that complement the hardware management capabilities of HP Client Manager. These Altiris solutions address client IT lifecycle challenges including:

- Inventory assessment
- Software license compliance
- Personality migration
- Software image deployment
- Software distribution
- Asset management
- Client backup and recovery
- Problem resolution

For more information on HP Client Management Solutions using Altiris, visit [www.hp.com/go/easydeploy](http://www.hp.com/go/easydeploy).

HP and Altiris have a unique alliance that extends beyond sales and marketing to include joint development and technology sharing that spans HP Client, Server, OpenView, and Services groups to provide best-of-breed solutions for HP partners and customers.

Starting in 1999, Compaq personal systems group and Altiris entered into an alliance to combine the strength of Compaq as a pioneer in PC hardware and manageability with the strength of Altiris' PC deployment and migration capabilities. The relationship expanded into a strategic alliance with the introduction of comprehensive cost-reducing IT lifecycle management solutions including the jointly developed HP Client Manager, which provides best-of-breed hardware management for HP PCs.

Building upon the success of the personal systems group, in 2001 the industry standard servers group introduced the ProLiant Essentials Rapid Deployment Pack, an OEM version of Altiris Deployment Solution combined with HP's SmartStart Toolkit. HP utilizes this solution for provisioning ProLiant servers (including blade servers) as well as Blade PCs, a core component of HP's Consolidated Client Infrastructure.

Following the HP and Compaq merger, the alliance has continued to expand with the following offerings:

- Altiris Deployment Solution is available for a free 30-day trial for HP business PCs, after which a license may be purchased.
- HP Local Recovery, a client backup/recovery utility, is available for free with HP business PCs.
- Altiris Connector for HP OpenView provides client inventory and event integration with HP OpenView Network Node Manager, Operations, and Service Desk.
- Altiris Connector for HP Systems Insight Manager enables consolidated deployment and management of HP clients and servers from the HP Systems Insight Manager console.

HP leads the market by offering a single management solution and console for deploying and configuring PCs, handhelds, thin clients, and Windows and Linux servers plus rich integration with HP enterprise management tools. HP offers extensive training and services expertise available from the HP Services organization and Altiris. This combination of HP Client Management Solutions and services capability provides the best choice for customers trying to reduce the cost and complexity of managing client systems.

### 3.3.4 HP Local Recovery

Local Recovery provides data and system file protection for HP business desktops, notebooks, and workstations. With Local Recovery, you can quickly recover and get back to work when information is accidentally deleted or your operating system is corrupted. Designed for disconnected or seldom-connected users, Local Recovery protects your HP computer's data and system state through scheduled snapshots stored in a protected area on the local hard disk. You can initiate a backup or restore by simply clicking your mouse or pressing the F11 key in a pre-boot environment. System backup and disaster recovery is now easy for all users regardless of connectivity.

Local Recovery is available for free with HP business PCs. Two additional client recovery products are also available. Upgrading to these products provides you with additional recovery features:

- **Local Recovery Pro**—Provides all the capabilities of Local Recovery plus support for backup and recovery to a secondary hard drive and for open and locked files. During a backup snapshot, open/locked file support preserves information in open applications such as E-mail messages, presentations, and word processing documents.
- **Recovery Solution**—Provides complete enterprise-level backup and recovery of PCs from a central administrative console. The solution supports data backup to a protected area on the local hard disk drive as well as to a network storage area. This network-based recovery feature provides a high level of protection against data lost due to hard drive failure or stolen and misplaced PCs.

For more information on HP Local Recovery, visit [www.hp.com/go/easydeploy](http://www.hp.com/go/easydeploy).

### 3.3.5 Dantz Retrospect Express

Dantz Retrospect Express protects a single Windows desktop or notebook computer. Retrospect Express allows recovery from data loss due to viruses, newly installed software, user error, damaged hardware, hardware upgrades, hackers, and lost or stolen computers. It offers a choice between simple duplicates or comprehensive backups and an intuitive setup wizard to get you up and running in minutes. Retrospect Express comes with Disaster Recovery built into the product for the best protection available. Visit [http://www.dantz.com/en/partners/oem\\_solutions.dtml](http://www.dantz.com/en/partners/oem_solutions.dtml) to view a list of hardware manufacturers who bundle Retrospect with their products and to learn where to buy these products.

Install Retrospect Express and perform your first backup in less than two minutes. With Retrospect, you can implement a backup plan by answering a few simple questions. Restores are quick and painless. When you need to perform a restore, Retrospect Express automatically locates files even if you do not know which piece of backup media contains the files.

Duplicate Files and Folders to an External Hard Drive with the Push of a Button. The duplicate operation copies information from the computer's hard drive to the external hard drive. (For external hard drives with a built-in backup button, duplicates can be initiated simply by pressing the button.) With duplicates, the files and folders on the external hard drive can be easily viewed, manipulated, and restored by using Windows Explorer. The duplication process saves space by overwriting any previous backup data on the external drive and saves time by copying only files that are new or that have changed since the last backup.

Back Up Multiple Versions of Files and Folders. Comprehensive backups retain prior versions of files and folders and allow you to roll back a computer to any prior point in time before a data-corrupting event occurred. Each time a backup operation is performed, Retrospect Express creates a restore point, which can contain all the information a user needs to retrieve files or restore an entire computer (disaster recovery)—including all operating system files and settings,

device drivers, and applications and their settings. Restore points are captured quickly and they provide 100% accurate restores to any point in time that a backup was performed—exceeding the capability of other backup software.

For more information on Dantz Retrospect Express, visit <http://www.dantz.com>.

### 3.3.6 Proactive Change Notification

The Proactive Change Notification program uses the Subscriber's Choice Web site in order to proactively and automatically:

- Send you Proactive Change Notification (PCN) E-mails informing you of hardware and software changes to most commercial computers and servers, up to 60 days in advance
- Send you E-mail containing Customer Bulletins, Customer Advisories, Customer Notes, Security Bulletins, and Driver alerts for most commercial computers and servers

You create your own profile to ensure that you only receive the information relevant to a specific IT environment. To learn more about the Proactive Change Notification program and create a custom profile, visit <http://www.hp.com/go/pcn>.

### 3.3.7 Subscriber's Choice

Subscriber's Choice is a client-based service from HP. Based on your profile, HP will supply you with personalized product tips, feature articles, and/or driver and support alerts/notifications. Subscriber's Choice Driver and Support Alerts/Notifications will deliver E-mails notifying you that the information you subscribed to in your profile is available for review and retrieval. To learn more about Subscriber's Choice and create a custom profile, visit <http://www.hp.com/go/pcn>.

### 3.3.8 Retired Solutions

The Desktop Management Task Force (DMTF) introduced the Desktop Management Interface (DMI) standard almost ten years ago. Due to new standards adoption such as the Common Information Model (CIM), the DMTF has initiated end-of-life for DMI. Given other advancements in HP Client Management Solutions, HP Systems Insight Manager, and Microsoft's implementation of CIM, known as Windows Management Instrumentation (WMI), the HP Insight Management Agent is no longer being provided on new HP commercial desktop, workstation, and notebook models introduced after January 1, 2004.

The Insight Management (IM) Agent provided the following features:

- DMI support allowed a client system to be managed by Insight Manager 7 or other DMI-compliant management applications.
- A Web agent allowed the system to be managed both locally and remotely by a web browser.
- Health alerting could notify the user locally or be sent to a central console.

Insight Manager has been replaced by HP Systems Insight Manager Software (HP SIM). HP SIM uses WMI to retrieve client system information. The Altiris Connector for HP Systems Insight Manager is available and enables the HP Client Management Solutions through the HP SIM console.

HP Client Management Solutions support reporting of health alerts to a system management console or optionally to be displayed locally on the client computer. Microsoft WMI is standard with Windows 2000 and Windows XP. WMI provides hardware inventory and alert information directly through the Windows OS to a system management application.

## 3.4 ROM Flash

The computer's BIOS is stored in a programmable flash ROM (read only memory). By establishing a setup password in the Computer Setup (F10) Utility, you can protect the ROM from being unintentionally updated or overwritten. This is important to ensure the operating integrity of the computer. Should you need or want to upgrade the BIOS, you may download the latest BIOS images from the HP driver and support page: <http://www.hp.com/support/files>.

**CAUTION:** For maximum ROM protection, be sure to establish a setup password. The setup password prevents unauthorized ROM upgrades. System Software Manager allows the system administrator to set the setup password on one or more PCs simultaneously. For more information, visit <http://www.hp.com/go/ssm>.

### 3.4.1 Remote ROM Flash

Remote ROM Flash allows the system administrator to safely upgrade the ROM on remote HP computers directly from the centralized network management console. Enabling the system administrator to perform this task remotely on multiple computers results in a consistent deployment of, and greater control over, HP PC BIOS images over the network. It also results in greater productivity and lower total cost of ownership.



The computer must be powered on, or turned on through Remote Wakeup, to take advantage of Remote ROM Flash.

For more information on Remote ROM Flash, refer to the HP Client Manager or System Software Manager at <http://h18000.www1.hp.com/im/prodinfo.html>.

### 3.4.2 HPQFlash

The HPQFlash utility is used to locally update or restore the system BIOS on individual PCs through a Windows operating system.

For more information on HPQFlash, visit <http://www.hp.com/support/files> and enter the product name/number of the computer when prompted.

### 3.4.3 Boot Block Emergency Recovery Mode

Boot Block Emergency Recovery Mode permits system recovery in the unlikely event of a ROM flash failure. For example, if a power failure were to occur during a BIOS upgrade, the ROM flash would be incomplete. This would render the system BIOS unusable. The Boot Block is a flash-protected section of the ROM that contains code that checks for a valid system BIOS image when the system is turned on.

- If the system BIOS image is valid, the system starts normally.
- If the system BIOS image is not valid, a failsafe Boot Block BIOS provides enough support to:
  - search removable media for BIOS image files. If an appropriate BIOS image file is found, it is automatically flashed into the ROM.
  - start the system from bootable removable media that automatically invokes system BIOS upgrade utilities.

When an invalid system BIOS image is detected, the system power LED will blink red 8 times, one blink every second. Simultaneously, the speaker will beep 8 times. If the portion of the system ROM containing the video option ROM image is not corrupt, “Boot Block Emergency Recovery Mode” will be displayed on the screen.

To recover the system after it enters Boot Block Emergency Recovery Mode, complete the following steps:

1. Turn off the power.
2. Insert a diskette, CD, or USB flash device containing the desired BIOS image file in the root directory. Note: The media must be formatted using the FAT12, FAT16, or FAT32 file system.
3. Turn on the computer.

If no appropriate BIOS image file is found, the failsafe Boot Block BIOS will attempt to start the system from a bootable device. If no bootable device is found, you will be prompted to insert media containing a BIOS image file or BIOS upgrade utility.

If the system successfully reprograms the ROM, the system will automatically power off.

4. Remove the removable media used to upgrade the BIOS.
5. Turn the power on to restart the computer.

### 3.4.4 Replicating the Setup

In a managed networked environment HP Client Manager or System Software Manager (SSM) may be used to replicate a setup configuration to many systems. For more information on HP Client Manager and SSM, visit <http://www.hp.com/go/easydeploy>.



Both procedures require a diskette drive or a supported USB flash media device, such as an HP Drive Key.

---

#### Copying to Single Computer



**CAUTION:** A setup configuration is model-specific. Unpredictable results may occur if source and target computers are not the same model. For example, do not copy the setup configuration from a dc7nnn Ultra-Slim Desktop to a dx6nnn Slim Tower.

---

1. Select a setup configuration to copy. Turn off the computer. If you are in Windows, click **Start > Shut Down > Shut Down**.
2. If you are using a USB flash media device, insert it now.
3. Turn on the computer.
4. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.



If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

---

5. If you are using a a diskette, insert it now.

6. Select **File > Replicated Setup > Save to Removable Media**. Follow the instructions on the screen to create the configuration diskette or USB flash media device.
7. Turn off the computer to be configured and insert the configuration diskette or USB flash media device.
8. Turn on the computer to be configured.
9. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.
10. Select **File > Replicated Setup > Restore from Removable Media**, and follow the instructions on the screen.
11. Restart the computer when the configuration is complete.

## Copying to Multiple Computers



**CAUTION:** A setup configuration is model-specific. Unpredictable results may occur if source and target computers are not the same model. For example, do not copy the setup configuration from a dc7nnn Ultra-Slim Desktop to a dx6nnn Slim Tower.

This method takes a little longer to prepare the configuration diskette or USB flash media device, but copying the configuration to target computers is significantly faster.



A bootable diskette is required for this procedure or to create a bootable USB flash media device. If Windows XP is not available to use to create a bootable diskette, use the method for copying to a single computer instead (see “[Copying to Single Computer](#)”).

1. Create a bootable diskette or USB flash media device. See “[Supported USB Flash Media Device](#)” or “[Unsupported USB Flash Media Device](#).”



**CAUTION:** Not all computers can be booted from a USB flash media device. If the default boot order in the Computer Setup (F10) Utility lists the USB device before the hard drive, the computer can be booted from a USB flash media device. Otherwise, a bootable diskette must be used.

2. Select a setup configuration to copy. Turn off the computer. If you are in Windows, click **Start > Shut Down > Shut Down**.
3. If you are using a USB flash media device, insert it now.
4. Turn on the computer.
5. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.



If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

6. If you are using a diskette, insert it now.
7. Select **File > Replicated Setup > Save to Removable Media**. Follow the instructions on the screen to create the configuration diskette or USB flash media device.

8. Download a BIOS utility for replicating setup (repset.exe) and copy it onto the configuration diskette or USB flash media device. To obtain this utility, go to <http://www.hp.com/support/files> and enter the model number of the computer.
9. On the configuration diskette or USB flash media device, create an autoexec.bat file containing the following command:  
**repset.exe**
10. Turn off the computer to be configured. Insert the configuration diskette or USB flash media device and turn the computer on. The configuration utility will run automatically.
11. Restart the computer when the configuration is complete.

## Creating a Bootable Device


### Supported USB Flash Media Device

Supported devices have a preinstalled image to simplify the process of making them bootable. All HP or Compaq and most other USB flash media devices have this preinstalled image. If the USB flash media device being used does not have this image, use the procedure later in this section (see “[Unsupported USB Flash Media Device](#)”).

To create a bootable USB flash media device, you must have:

- A supported USB flash media device.
- A bootable DOS diskette with the FDISK and SYS programs. (If SYS is not available, FORMAT may be used, but all existing files on the USB flash media device will be lost.)
- A PC that is bootable from a USB flash media device.

---


 **CAUTION:** Not all computers can be booted from a USB flash media device. If the default boot order in the Computer Setup (F10) Utility lists the USB device before the hard drive, the computer can be booted from a USB flash media device. Otherwise, a bootable diskette must be used.

---

1. Turn off the computer.
2. Insert the USB flash media device into one of the computer’s USB ports and remove all other USB storage devices except USB diskette drives.
3. Insert a bootable DOS diskette with FDISK.COM and either SYS.COM or FORMAT.COM into a diskette drive and turn on the computer to boot to the DOS diskette.
4. Run FDISK from the A:\ prompt by typing **FDISK** and pressing Enter. If prompted, click **Yes (Y)** to enable large disk support.
5. Enter Choice [**5**] to display the drives in the system. The USB flash media device will be the drive that closely matches the size of one of the drives listed. It will usually be the last drive in the list. Note the letter of the drive.

USB flash media device drive: \_\_\_\_\_

---

 **CAUTION:** If a drive does not match the USB flash media device, do not proceed. Data loss can occur. Check all USB ports for additional storage devices. If any are found, remove them, reboot the computer, and proceed from step 4. If none are found, either the system does not support the USB flash media device or the USB flash media device is defective. DO NOT proceed in attempting to make the USB flash media device bootable.


---

6. Exit FDISK by pressing the **Esc** key to return to the A:\ prompt.



7. If your bootable DOS diskette contains SYS.COM, go to step 8. Otherwise, go to step 9.
8. At the A:\ prompt, enter **SYS x:** where x represents the drive letter noted above.

---


 **CAUTION:** Be sure that you have entered the correct drive letter for the USB flash media device.

---

After the system files have been transferred, SYS will return to the A:\ prompt. Go to step 13.

9. Copy any files you want to keep from your USB flash media device to a temporary directory on another drive (for example, the system's internal hard drive).
10. At the A:\ prompt, enter **FORMAT /S X:** where X represents the drive letter noted before.

---


 **CAUTION:** Be sure that you have entered the correct drive letter for the USB flash media device.

---

FORMAT will display one or more warnings and ask you each time whether you want to proceed. Enter **Y** each time. FORMAT will format the USB flash media device, add the system files, and ask for a Volume Label.

11. Press **Enter** for no label or enter one if desired.
12. Copy any files you saved in step 9 back to your USB flash media device.
13. Remove the diskette and reboot the computer. The computer will boot to the USB flash media device as drive C.

---

 The default boot order varies from computer to computer, and it can be changed in the Computer Setup (F10) Utility.

If you have used a DOS version from Windows 9x, you may see a brief Windows logo screen. If you do not want this screen, add a zero-length file named LOGO.SYS to the root directory of the USB flash media device.

---


Return to [“Copying to Multiple Computers.”](#)

### Unsupported USB Flash Media Device

To create a bootable USB flash media device, you must have:

- A supported USB flash media device.
- A bootable DOS diskette with the FDISK and SYS programs. (If SYS is not available, FORMAT may be used, but all existing files on the USB flash media device will be lost.)
- A PC that is bootable from a USB flash media device.


---

 **CAUTION:** Not all computers can be booted from a USB flash media device. If the default boot order in the Computer Setup (F10) Utility lists the USB device before the hard drive, the computer can be booted from a USB flash media device. Otherwise, a bootable diskette must be used.

---

1. If there are any PCI cards in the system that have SCSI, ATA RAID, or SATA drives attached, turn off the computer and unplug the power cord.

---

 **CAUTION:** The power cord **MUST** be unplugged.

---

2. Open the computer and remove the PCI cards.

3. Insert the USB flash media device into one of the computer's USB ports and remove all other USB storage devices except USB diskette drives. Close the computer cover.
4. Plug in the power cord and turn on the computer.
5. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.



If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

---

6. Go to **Advanced > PCI Devices** to disable both the PATA and SATA controllers. When disabling the SATA controller, note the IRQ to which the controller is assigned. You will need to reassign the IRQ later. Exit setup, confirming the changes.  
SATA IRQ: \_\_\_\_\_
7. Insert a bootable DOS diskette with FDISK.COM and either SYS.COM or FORMAT.COM into a diskette drive and turn on the computer to boot to the DOS diskette.
8. Run FDISK and delete any existing partitions on the USB flash media device. Create a new partition and mark it active. Exit FDISK by pressing the **Esc** key.
9. If the system did not automatically restart when exiting FDISK, press **Ctrl+Alt+Del** to reboot to the DOS diskette.
10. At the A:\ prompt, type **FORMAT C: /S** and press **Enter**. Format will format the USB flash media device, add the system files, and ask for a Volume Label.
11. Press **Enter** for no label or enter one if desired.
12. Turn off the computer and unplug the power cord. Open the computer and re-install any PCI cards that were previously removed. Close the computer cover.
13. Plug in the power cord, remove the diskette, and turn on the computer.
14. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.
15. Go to **Advanced > PCI Devices** and re-enable the PATA and SATA controllers that were disabled in step 6. Put the SATA controller on its original IRQ.
16. Save the changes and exit. The computer will boot to the USB flash media device as drive C.



The default boot order varies from computer to computer, and it can be changed in the Computer Setup (F10) Utility. Refer to the *Computer Setup (F10) Utility Guide* on the *Documentation and Diagnostics* CD for instructions.

If you have used a DOS version from Windows 9x, you may see a brief Windows logo screen. If you do not want this screen, add a zero-length file named LOGO.SYS to the root directory of the USB flash media device.

---

Return to [“Copying to Multiple Computers.”](#)

### 3.4.5 Dual-State Power Button

With Advanced Configuration and Power Interface (ACPI) enabled, the power button can function either as an on/off switch or as a standby button. The stand-by feature does not completely turn off power, but instead causes the computer to enter a low-power standby state. This allows you to power down quickly without closing applications and to return quickly to the same operational state without any data loss.

To change the power button's configuration, complete the following steps:

1. Left click on the **Start Button**, then select **Control Panel > Power Options**.
2. In the **Power Options Properties**, select the **Advanced** tab.
3. In the **Power Button** section, select **Stand by**.

After configuring the power button to function as a standby button, press the power button to put the system in a very low power state (standby). Press the button again to quickly bring the system out of standby to full power status. To completely turn off all power to the system, press and hold the power button for four seconds.



**CAUTION:** Do not use the power button to turn off the computer unless the system is not responding; turning off the power without operating system interaction could cause damage to or loss of data on the hard drive.

### 3.4.6 World Wide Web Site

When making the transition to new or revised operating systems, it is important to implement the support software designed for that operating system. If you plan to run a version of Microsoft Windows that is different from the version included with the computer, you must install corresponding device drivers and utilities to ensure that all features are supported and functioning properly.

HP has made the task of locating, accessing, evaluating, and installing the latest support software easier. You can download the software from <http://www.hp.com/support>. The Web site contains the latest device drivers, utilities, and flashable ROM images needed to run the latest Microsoft Windows operating system on the HP computer.

### 3.4.7 Building Blocks and Partners

HP management solutions integrate with other systems management applications, and are based on industry standards, such as:

- Web-Based Enterprise Management (WBEM)
- Windows Management Interface (WMI)
- Wake on LAN Technology
- ACPI
- SMBIOS
- Pre-boot Execution (PXE) support

## 3.5 Asset Tracking and Security

Asset tracking features incorporated into the computer provide key asset tracking data that can be managed using HP Systems Insight Manager, HP Client Manager or other system management applications. Seamless, automatic integration between asset tracking features and these products enables you to choose the management tool that is best suited to the environment and to leverage the investment in existing tools.

HP also offers several solutions for controlling access to valuable components and information. HP Embedded Security for ProtectTools, if installed, prevents unauthorized access to data and checks system integrity and authenticates third-party users attempting system access. (For more information, refer to the *HP ProtectTools Security Manager Guide* at [www.hp.com](http://www.hp.com).) Security features such as HP Embedded Security for ProtectTools, the Smart Cover Sensor and the Smart Cover Lock, available on some models, help to prevent unauthorized access to the internal components of the personal computer. By disabling parallel, serial, or USB ports, or by disabling removable media boot capability, you can protect valuable data assets. Memory Change and Smart Cover Sensor alerts can be automatically forwarded to system management applications to deliver proactive notification of tampering with a computer's internal components.





HP Embedded Security for ProtectTools, the Smart Cover Sensor, and the Smart Cover Lock are available as options on some systems.

Use the following utilities to manage security settings on the HP computer:

- Locally, using the Computer Setup Utilities. See the *Computer Setup (F10) Utility Guide* on the *Documentation and Diagnostics* CD included with the computer for additional information and instructions on using the Computer Setup Utilities.
- Remotely, using HP Client Manager or System Software Manager. This software enables the secure, consistent deployment and control of security settings from a simple command-line utility.

The following table and sections refer to managing security features of the computer locally through the Computer Setup (F10) Utilities.



### Computer Setup Utilities (F10) Security Features

Feature	Description
Smart Card Options	Allows you to enable/disable the Smart Card to be used in place of the Power-On Password.
Setup Password	Allows you to set and enable setup (administrator) password.  If the setup password is set, it is required to change Computer Setup options, flash the ROM, and make changes to certain plug and play settings under Windows.
Power-On Password	Allows you to set and enable power-on password.
	For more information about Computer Setup, see the <i>Computer Setup (F10) Utility Guide</i> . Support for security features may vary depending on your specific computer configuration.

---

**Computer Setup Utilities (F10) Security Features** *(Continued)*


---






Feature	Description
Password Options (This selection will appear only if a power-on password is set.)	Allows you to: <ul style="list-style-type: none"> <li>• Lock legacy resources (appears if a setup password is set).</li> <li>• Enable/disable network server mode.</li> <li>• Specify whether the password is required for warm boot (<b>CTRL+ALT+DEL</b>) (appears if a power-on password is set).</li> </ul>
Smart Cover	Allows you to: <ul style="list-style-type: none"> <li>• Enable/disable the Cover Lock.</li> <li>• Enable/disable the Cover Removal Sensor.</li> </ul> <p> <i>Notify User</i> alerts the user that the sensor has detected that the cover has been removed. <i>Setup Password</i> requires that the setup password be entered to boot the computer if the sensor detects that the cover has been removed.</p> <p>This feature is supported on some models only and will only appear if a Smart Card reader is attached to the system.</p>
Embedded Security	Allows you to: <ul style="list-style-type: none"> <li>• Enable/disable the Embedded Security device.</li> <li>• Reset the device to Factory Settings.</li> <li>• Enable/disable power-on authentication support. (some models)</li> <li>• Reset authentication credential. (some models)</li> </ul>
Device Security	Enables/disables serial ports, parallel port, front USB ports, system audio, internal speakers (some models) network controllers (some models), MultiBay devices (some models), SMBus controller (some models), SCSI controllers (some models), and Embedded security device (some models).
Network Service Boot	Enables/disables the computer's ability to boot from an operating system installed on a network server. (Feature available on NIC models only; the network controller must reside on the PCI bus or be embedded on the system board.)
System IDs	Allows you to set: <ul style="list-style-type: none"> <li>• Asset tag (18-byte identifier) and ownership Tag (80-byte identifier displayed during POST).</li> </ul> <p>Chassis serial number or Universal Unique Identifier (UUID) number. The UUID can only be updated if the current chassis serial number is invalid. (These ID numbers are normally set in the factory and are used to uniquely identify the system.)</p> <ul style="list-style-type: none"> <li>• Keyboard locale setting (for example, English or German) for System ID entry.</li> </ul>
<p> For more information about Computer Setup, see the <i>Computer Setup (F10) Utility Guide</i>. Support for security features may vary depending on your specific computer configuration.</p>	

---

---

**Computer Setup Utilities (F10) Security Features** *(Continued)*


---

Feature	Description
DriveLock (some models)	<p>Allows you to assign or modify a master or user password for certain ATA hard drives. When this feature is enabled, the user is prompted to provide one of the DriveLock passwords during POST. If neither is successfully entered, the hard drive will remain inaccessible until one of the passwords is successfully provided during a subsequent cold-boot sequence.</p> <p> This selection will only appear when at least one drive that supports ATA Security is attached to the system.</p>
OS Security (some models)	<ul style="list-style-type: none"> <li data-bbox="727 579 1370 638">• Data Execution Prevention (some models) (enable/disable). Helps prevent OS security breaches.</li> <li data-bbox="703 659 1370 709"> This selection is in effect only if the processor and operating system being used comprehend and utilize this feature.</li> <li data-bbox="727 722 1386 810">• Intel Virtualization Technology (some models) (enable/disable). Changing this setting requires turning the computer off and then back on.</li> <li data-bbox="703 831 1370 877"> This selection is in effect only if the processor and operating system being used comprehend and utilize this feature.</li> </ul>
Data Execution Prevention (some models)	<p>Enable/Disable. Data Execution Prevention Mode help prevent OS security breaches.</p> <p> This selection is in effect only if the processor and operating system being used comprehend and utilize the function.</p>
<p> For more information about Computer Setup, see the <i>Computer Setup (F10) Utility Guide</i>. Support for security features may vary depending on your specific computer configuration.</p>	

---

---

## Mechanical Security Features

Feature	Purpose	How It Is Established
Memory Change Alerts	Detects when memory modules have been added, moved, or removed; notifies user and system administrator.	For information on enabling Memory Change Alerts, refer to the online <i>Desktop Management Guide</i> on the <i>Documentation and Diagnostics</i> CD.
Cable Lock Provision	Inhibits access to the interior of the computer to prevent unwanted configuration changes or component removal. Can also be used to secure the computer to a fixed object to prevent theft.	Install a cable lock to secure the computer to a fixed object.
Security Loop Provision	Inhibits access to the interior of the computer to prevent unwanted configuration changes or component removal.	Install a lock in the security loop to prevent unwanted configuration changes or component removal.

---

### 3.5.1 Password Security

The power-on password prevents unauthorized use of the computer by requiring entry of a password to access applications or data each time the computer is turned on or restarted. The setup password specifically prevents unauthorized access to Computer Setup, and can also be used as an override to the power-on password. That is, when prompted for the power-on password, entering the setup password instead will allow access to the computer.

A network-wide setup password can be established to enable the system administrator to log in to all network systems to perform maintenance without having to know the power-on password, even if one has been established.

### 3.5.2 Establishing a Setup Password Using Computer Setup

If the system is equipped with an embedded security device, refer to the *HP ProtectTools Security Manager Guide* at [www.hp.com](http://www.hp.com). Establishing a setup password through Computer Setup prevents modification of the computer (use of the Computer Setup (F10) utility) until the password is entered.

1. Turn on or restart the computer. If you are in Windows, click **Start > Shut Down > Restart**.
2. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.



If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

---

3. Select **Security**, then select **Setup Password** and follow the instructions on the screen.
4. Before exiting, Select **File > Save Changes and Exit**.

### 3.5.3 Establishing a Power-On Password Using Computer Setup

Establishing a power-on password through Computer Setup prevents access to the computer when power is turned on, unless the password is entered. When a power-on password is set, Computer Setup presents Password Options under the Security menu. Password options include Password Prompt on Warm Boot. When Password Prompt on Warm Boot is enabled, the password must also be entered each time the computer is rebooted.

1. Turn on or restart the computer. If you are in Windows, click **Start > Shut Down > Restart**.
2. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.



If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

3. Select **Security**, then **Power-On Password** and follow the instructions on the screen.
4. Before exiting, select **File > Save Changes and Exit**.

#### Entering a Power-On Password

To enter a power-on password, complete the following steps:

1. Turn on or restart the computer. If you are in Windows, click **Start > Shut Down > Restart**.
2. When the key icon appears on the monitor, type the current password, then press **Enter**.



Type carefully; for security reasons, the characters you type do not appear on the screen.

If you enter the password incorrectly, a broken key icon appears. Try again. After three unsuccessful tries, you must turn off the computer, then turn it on again before you can continue.

#### Entering a Setup Password

If the system is equipped with an embedded security device, refer to the *HP ProtectTools Security Manager Guide* at [www.hp.com](http://www.hp.com).

If a setup password has been established on the computer, you will be prompted to enter it each time you run Computer Setup.

1. Turn on or restart the computer. If you are in Windows, click **Start > Shut Down > Restart**.
2. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.




If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

3. When the key icon appears on the monitor, type the setup password, then press **Enter**.



---

 Type carefully; for security reasons, the characters you type do not appear on the screen.


---

If you enter the password incorrectly, a broken key icon appears. Try again. After three unsuccessful tries, you must turn off the computer, then turn it on again before you can continue.

## Changing a Power-On or Setup Password

If the system is equipped with an embedded security device, refer to the *HP ProtectTools Security Manager Guide* at [www.hp.com](http://www.hp.com).


1. Turn on or restart the computer. If you are in Windows, click **Start > Shut Down > Restart**.
  2. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.
- 

 If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.


---

3. When the key icon appears, type the current password, a slash (/) or alternate delimiter character, the new password, another slash (/) or alternate delimiter character, and the new password again as shown:  
**current password/new password/new password**
- 

 Type carefully; for security reasons, the characters you type do not appear on the screen.

---

4. Press **Enter**.
  5. The new password takes effect the next time you turn on the computer.
- 


 Refer to “[National Keyboard Delimiter Characters](#)” for information about the alternate delimiter characters. The power-on password and setup password may also be changed using the Security options in Computer Setup.

---

## Deleting a Power-On or Setup Password

If the system is equipped with an embedded security device, refer to the *HP ProtectTools Security Manager Guide* at [www.hp.com](http://www.hp.com).

1. Turn on or restart the computer. If you are in Windows, click **Start > Shut Down > Restart**.
  2. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.
- 

 If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

---

3. When the key icon appears, type the current password followed by a slash (/) or alternate delimiter character as shown:  
**current password/**
4. Press **Enter**.



Refer to the National Keyboard Delimiter Character table below for information about the alternate delimiter characters. The power-on password and setup password may also be changed using the Security options in Computer Setup.

## National Keyboard Delimiter Characters

Each keyboard is designed to meet country-specific requirements. The syntax and keys that you use for changing or deleting your password depend on the keyboard that came with your computer.

National Keyboard Delimiter Characters					
Arabic	/	Greek	-	Russian	/
Belgian	=	Hebrew	.	Slovakian	-
BHCSY*	-	Hungarian	-	Spanish	-
Brazilian	/	Italian	-	Swedish/Finnish	/
Chinese	/	Japanese	/	Swiss	-
Czech	-	Korean	/	Taiwanese	/
Danish	-	Latin American	-	Thai	/
French	!	Norwegian	-	Turkish	.
French Canadian	é	Polish	-	U.K. English	/
German	-	Portuguese	-	U.S. English	/

\* For Bosnia-Herzegovina, Croatia, Slovenia, and Yugoslavia

## Clearing Passwords

If you forget the password, you cannot access the computer. Refer to the *Troubleshooting Guide* on the *Documentation and Diagnostics* CD for instructions on clearing passwords.

If the system is equipped with an embedded security device, refer to the *HP ProtectTools Security Manager Guide* at [www.hp.com](http://www.hp.com).

## 3.5.4 DriveLock

DriveLock is an industry-standard security feature that prevents unauthorized access to the data on ATA hard drives. DriveLock has been implemented as an extension to Computer Setup. It is only available when hard drives that support the ATA Security command set are detected.

DriveLock is intended for HP customers for whom data security is the paramount concern. For such customers, the cost of the hard drive and the loss of the data stored on it is inconsequential when compared with the damage that could result from unauthorized access to its contents. In order to balance this level of security with the practical need to accommodate a forgotten password, the HP implementation of DriveLock employs a two-password security scheme. One password is intended to be set and used by a system administrator while the other is typically set and used by the end-user. There is no “back-door” that can be used to unlock the drive if both passwords are lost. Therefore, DriveLock is most safely used when the data contained on the hard drive is replicated on a corporate information system or is regularly backed up.

In the event that both DriveLock passwords are lost, the hard drive is rendered unusable. For users who do not fit the previously defined customer profile, this may be an unacceptable risk. For users who do fit the customer profile, it may be a tolerable risk given the nature of the data stored on the hard drive.

## **Using DriveLock**

The DriveLock option appears under the Security menu in Computer Setup. The user is presented with options to set the master password or to enable DriveLock. A user password must be provided in order to enable DriveLock. Since the initial configuration of DriveLock is typically performed by a system administrator, a master password should be set first. HP encourages system administrators to set a master password whether they plan to enable DriveLock or keep it disabled. This will give the administrator the ability to modify DriveLock settings if the drive is locked in the future. Once the master password is set, the system administrator may enable DriveLock or choose to keep it disabled.

If a locked hard drive is present, POST will require a password to unlock the device. If a power-on password is set and it matches the device's user password, POST will not prompt the user to re-enter the password. Otherwise, the user will be prompted to enter a DriveLock password. Either the master or the user password may be used. Users will have two attempts to enter a correct password. If neither attempt succeeds, POST will continue but the drive will remain inaccessible.

## **DriveLock Applications**

The most practical use of the DriveLock security feature is in a corporate environment. The system administrator would be responsible for configuring the hard drive which would involve, among other things, setting the DriveLock master password. In the event that the user forgets the user password or the equipment is passed on to another employee, the master password can always be used to reset the user password and regain access to the hard drive.


HP recommends that corporate system administrators who choose to enable DriveLock also establish a corporate policy for setting and maintaining master passwords. This should be done to prevent a situation where an employee intentionally or unintentionally sets both DriveLock passwords before leaving the company. In such a scenario, the hard drive would be rendered unusable and require replacement. Likewise, by not setting a master password, system administrators may find themselves locked out of a hard drive and unable to perform routine checks for unauthorized software, other asset control functions, and support.

For users with less stringent security requirements, HP does not recommend enabling DriveLock. Users in this category include personal users or users who do not maintain sensitive data on their hard drives as a common practice. For these users, the potential loss of a hard drive resulting from forgetting both passwords is much greater than the value of the data DriveLock has been designed to protect. Access to Computer Setup and DriveLock can be restricted through the Setup password. By specifying a Setup password and not giving it to end users, system administrators are able to restrict users from enabling DriveLock.

### 3.5.5 Smart Cover Sensor

Cover Removal Sensor, available on some models, is a combination of hardware and software technology that can alert you when the computer cover or side panel has been removed. There are three levels of protection, as described in the following table.


Smart Cover Sensor Protection Levels		
Level	Setting	Description
Level 0	Disabled	Smart Cover Sensor is disabled (default).
Level 1	Notify User	When the computer is restarted, the screen displays a message indicating that the computer cover or side panel has been removed.
Level 2	Setup Password	When the computer is restarted, the screen displays a message indicating that the computer cover or side panel has been removed. You must enter the setup password to continue.

 These settings can be changed using Computer Setup. For more information about Computer Setup, see the *Computer Setup (F10) Utility Guide*.

#### Setting the Smart Cover Sensor Protection Level

To set the Smart Cover Sensor protection level, complete the following steps:

1. Turn on or restart the computer. If you are in Windows, click **Start > Shut Down > Restart**.
2. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.


 If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.


If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

3. Select **Security > Smart Cover > Cover Removal Sensor**, and select the desired security level.
4. Before exiting, select **File > Save Changes and Exit**.

#### Smart Cover Lock

The Smart Cover Lock is a software-controllable cover lock featured on some HP computers. This lock prevents unauthorized access to the internal components. Computers ship with the Smart Cover Lock in the unlocked position.

 **CAUTION:** For maximum cover lock security, be sure to establish a setup password. The setup password prevents unauthorized access to the Computer Setup utility.

 The Smart Cover Lock is available as an option on some systems.

---

## Locking the Smart Cover Lock

To activate and lock the Smart Cover Lock, complete the following steps:

1. Turn on or restart the computer. If you are in Windows, click **Start > Shut Down > Restart**.
2. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.



If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

3. Select **Security > Smart Cover > Cover Lock > Lock** option.
4. Before exiting, select **File > Save Changes and Exit**.

---

## Unlocking the Smart Cover Lock

1. Turn on or restart the computer. If you are in Windows, click **Start > Shut Down > Restart**.
2. As soon as the computer is turned on, press and hold the **F10** key until you enter Computer Setup. Press **Enter** to bypass the title screen, if necessary.



If you do not press the **F10** key at the appropriate time, you must restart the computer and press and hold the **F10** key again to access the utility.

If you are using a PS/2 keyboard, you may see a Keyboard Error message—disregard it.

3. Select **Security > Smart Cover > Cover Lock > Unlock**.
4. Before exiting, select **File > Save Changes and Exit**.

---

## Using the Smart Cover FailSafe Key

If you enable the Smart Cover Lock and cannot enter your password to disable the lock, you will need a Smart Cover FailSafe Key to open the computer cover. You will need the key in any of the following circumstances:

- Power outage
- Startup failure
- PC component failure (such as processor or power supply)
- Forgotten password



**CAUTION:** The Smart Cover FailSafe Key is a specialized tool available from HP. Be prepared; order this key before you need one (Tamper-resistant wrench PN 166527-001 or tamper-resistant bits PN 166527-002).

For more information about using the Smart Cover FailSafe Key, consult the *Hardware Reference Guide*.

### 3.5.6 Cable Lock Provision

The rear panel of the computer accommodates a cable lock so that the computer can be physically secured to a work area. For illustrated instructions, please see the Removal and Replacement chapter for the specific chassis.

### 3.5.7 TPM Embedded Security Chip and HP ProtectTools Security Manager

The TPM Embedded Security Chip uses a root key protected in silicon to enhance native Microsoft operating system file and folder encryption and lay the foundation for authentication of TPM-enabled PCs to the corporate network.

HP ProtectTools Security Manager can be configured to prevent unauthorized access using Smart Cards, TPM Embedded security chips, USB tokens and other security technologies. HP ProtectTools Security Manager is completely customizable, providing the flexibility to choose the level of security that best meets customers' needs.

For more information on HP Business PC security solutions, visit <http://h18004.www1.hp.com/products/security>.

## 3.6 Fault Notification and Recovery

Fault Notification and Recovery features combine innovative hardware and software technology to prevent the loss of critical data and minimize unplanned downtime.

If the computer is connected to a network managed by HP Client Manager, the computer sends a fault notice to the network management application. With HP Client Manager, you can also remotely schedule diagnostics to automatically run on all managed PCs and create a summary report of failed tests.

### 3.6.1 Drive Protection System

The Drive Protection System (DPS) is a diagnostic tool built into the hard drives installed in some HP computers. DPS is designed to help diagnose problems that might result in unwarranted hard drive replacement.

When HP computers are built, each installed hard drive is tested using DPS, and a permanent record of key information is written onto the drive. Each time DPS is run, test results are written to the hard drive. Your service provider can use this information to help diagnose conditions that caused you to run the DPS software. Refer to the *Troubleshooting Guide* for instructions on using DPS.

### 3.6.2 Surge-Tolerant Power Supply

An integrated surge-tolerant power supply provides greater reliability when the computer is hit with an unpredictable power surge. This power supply is rated to withstand a power surge of up to 2000 volts without incurring any system downtime or data loss.

### 3.6.3 Thermal Sensor

The thermal sensor is a hardware and software feature that tracks the internal temperature of the computer. This feature displays a warning message when the normal range is exceeded, which gives you time to take action before internal components are damaged or data is lost.

# Serial and Parallel ATA Drive Guidelines and Features



Serial ATA = SATA  
Parallel ATA = PATA

HP only supports the use of a MultiBay PATA (IDE) hard drive on this model of computer. 3.5-inch PATA hard drives are not supported.

## 4.1 SATA 1.5 and 3.0 Hard Drives

Serial ATA Hard Drive Characteristics	
Number of pins/conductors in data cable	7/7
Number of pins in power cable	15
Maximum data cable length	39.37 in (100 cm)
Data interface voltage differential	400-700 mV
Drive voltages	3.3 V, 5V, 12 V
Jumpers for configuring drive	N/A
Data transfer rate, 40 GB	1.5 Gb/s 3.0 Gb/s (some models)
Data transfer rate, 80 GB and greater	3.0 Gb/s

SATA connectors on the system board are color coded to make identification easier.

SATA Identification	Color	Port	Attachment Sequence
Primary channel, device 0	Dark blue	SATA 0	1
Primary channel, device 1	Light Blue	SATA 2	4
Secondary channel, device 0	White	SATA 1	2
Secondary channel, device 1	Orange	SATA 3	3



If there is an error on the application of the attach rules, a POST error message may be displayed.

## 4.2 SATA Hard Drive Cables

### 4.2.1 SATA Data Cable

Always use an HP approved SATA 3.0 Gb/s cable as it is fully backwards compatible with the SATA 1.5 Gb/s drives.

Current HP desktop products ship with SATA 1.5 Gb/s or 3.0 Gb/s hard drives.

SATA data cables are susceptible to damage if overflexed. Never crease a SATA data cable and never bend it tighter than a 30 mm (1.18 in) radius.

The SATA data cable is a thin, 7-pin cable designed to transmit data for only a single drive. As shown in the table, each cable has 3 grounds, and 4 transmit/receive pins.

Pin Number	Usage	Device Plug	Host Plug
P1	Ground	Ground	Ground
P2*	A+	Transmit data	Receive data
P3*	A-	Transmit data	Receive data
P4	Ground	Ground	Ground
P5**	B-	Receive data	Transmit data
P6**	B+	Receive data	Transmit data
P7	Ground	Ground	Ground

\*P2 and P3 differential signal pair

\*\*P5 and P6 differential signal pair

### 4.2.2 SATA Power Cable

Pin	Usage	Notes	Pin	Usage	Notes
P1	V3.3	3.3 V power	P9	V5	5 V power
P2	V3.3	3.3 V power	P10	Ground	
P3	V3.3	3.3 V power	P11	Ground	
P4	Ground		P12	Ground	
P5	Ground		P13	V 12	12 V power
P6	Ground		P14	V12	12 V power
P7	V5	5 V power	P15	V12	12 V power
P8	V5	5 V power			



## 4.3 PATA Device Information

This information applies to optical drives in a computer having one or two SATA drive controllers and a single PATA drive controller.

Only a MultiBay PATA hard drive is supported on these computers. No other PATA hard drives are supported on these models.

<b>Parallel ATA MultiBay Hard Drive Characteristics</b>	
Number of pins/conductors in data cable	40/80
Number of pins in power cable	4
Maximum data cable length	18 in (45.7 cm)
Data interface voltage	5V
Drive voltages	5V
Jumpers for configuring drive	Required
Data transfer rate	24 MB/s

## 4.4 PATA Cables

### 4.4.1 PATA Data Cable

<b>Pin</b>	<b>Signal</b>	<b>Pin</b>	<b>Signal</b>	<b>Pin</b>	<b>Signal</b>
1	Reset	15	DD1	29	DMAK
2	Ground	16	DD14	30	Ground
3	DD7	17	DD0	31	INTRQ
4	DD8	18	DD15	32	IOCS16
5	DD6	19	Ground	33	DA1
6	DD9	20	(Key)	34	PDIAG (cable detect)
7	DD5	21	DMARQ	35	DA0
8	DD10	22	Ground	36	DA2
9	DD4	23	DLOW	37	CS1FX
10	DD11	24	Ground	38	CS3FX
11	DD3	25	DIOR	39	DASP
12	DD12	26	Ground	40	Ground
13	DD2	27	IORDY		
14	DD13	28	CSEL		

## 4.4.2 PATA Power Cable

Pin	Usage
1	+12 V
2	Ground
3	Ground
4	+5 V

## 4.5 PATA Drive Installation Guidelines

The computer system boards for these products have one Parallel ATA (PATA) channel with a single connector. The channel can have up to two devices attached to it. All drives are connected to the channel using an industry-standard 80-conductor cable.



The industry-standard 1.44 MB diskette drive has its own separate channel and is not included as a part of the maximum two drives.

Each drive attached to a channel must have a drive designation. If a drive is attached to the Device 0 cable position and its cable-select jumper is present, the drive is designated as Device 0. Similarly, if a drive is attached to the Device 1 cable position and its cable-select jumper is present, the drive is designated as Device 1.

For optimal performance of a computer system, all drives need to be attached to the PATA channel(s) in a specified sequence. This sequence is determined by the device class of the drives and by specific attach sequence rules.

### 4.5.1 PATA Device Classes

In order to determine the best drive attach sequence, ATA/ATAPI drives are segregated into four different classes based upon the bandwidth demands they place on an ATA channel. The most demanding devices are in Class 1 and the least demanding are in Class 4.

Class 1 Hard Drives	Class 2 High Speed Optical Drives	Class 3 Optical Storage Drives	Class 4 Magnetic Storage Drives
Supported only on USDT chassis with MultiBay	DVD DVD-CD R/W	R/W CD-ROM CD-ROM	Zip

### General Attach Guidelines

- The lower the device class number, the faster the device and the more bandwidth required.
- Drives installed in the Device 0 position receive the greatest possible bandwidth.

## 4.6 SATA SMART Drives

The Self Monitoring Analysis and Recording Technology (SMART) SATA drives for the HP Personal Computers have built-in drive failure prediction that warns the user or network administrator of an impending failure or crash of the hard drive. The SMART drive tracks fault prediction and failure indication parameters such as reallocated sector count, spin retry count, and calibration retry count. If the drive determines that a failure is imminent, it generates a fault alert.

## 4.7 Drive Capacities

The combination of the file system and the operating system used in the computer determines the maximum usable size of a drive partition. A drive partition is the largest segment of a drive that may be properly accessed by the operating system. A single hard drive may therefore be subdivided into a number of unique drive partitions in order to make use of all of its space.

Because of the differences in the way that drive sizes are calculated, the size reported by the operating system may differ from that marked on the hard drive or listed in the computer specification. Drive size calculations by drive manufacturers are bytes to the base 10 while calculations by Microsoft are bytes to the base 2.

Drive/Partition Capacity Limits				
File System	Controller Type	Operating System	Maximum Size	
			Partition	Drive
FAT 32	ATA	Windows 2000/ XP	32 GB	128 PB
NTFS	ATA	Windows NT/2000/XP	2 TB	128 PB

## 4.8 SATA BIOS

Windows 2000 and XP	Windows 9x, NT, and Linux
Enhanced Mode (default BIOS Setting) —Separate IDE controller	Compatibility Mode (non-default BIOS Setting) —Combined IDE controller
<ul style="list-style-type: none"> <li>• PATA Controller in Legacy Mode               <ul style="list-style-type: none"> <li>- Device 0 is accessible as Device 0 of PATA controller's Primary Channel</li> <li>- Device 1 is accessible as Device 1 of PATA controller's Primary Channel</li> </ul> </li> <li>• SATA Controller in Native Mode               <ul style="list-style-type: none"> <li>- SATA 0 is accessible as Device 0 of SATA controller's Primary Channel</li> <li>- SATA 1 is accessible as Device 0 of SATA controller's Secondary Channel</li> <li>- SATA 2 is accessible as Device 1 of SATA controller's Primary Channel</li> <li>- SATA 3 is accessible as Device 1 of SATA controller's Secondary Channel</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>• PATA Controller in Legacy Mode               <ul style="list-style-type: none"> <li>- Device 0 is accessible as Device 0 of the combined controller's Secondary Channel</li> <li>- Device 1 is accessible as Device 1 of the combined controller's Secondary Channel</li> </ul> </li> <li>• SATA Controller in Legacy Mode               <ul style="list-style-type: none"> <li>- SATA 0 is accessible as Device 0 of the combined controller's Primary Channel</li> <li>- SATA 1 is inaccessible</li> <li>- SATA 2 is accessible as device 1 of the combined controller's Primary Channel</li> <li>- SATA 3 is inaccessible</li> </ul> </li> </ul>

## 4.8.1 Legacy Mode

The Legacy mode is used to access devices attached to an embedded ATA controller. Each channel of the controller requires two fixed I/O address ranges and an IRQ.

- Primary Channel
  - Command block: 1F0h - 1F7h
  - Control block: 3F6h
  - IRQ: 14
- Secondary Channel
  - Command block: 170h - 177h
  - Control block: 376h
  - IRQ: 15

## 4.8.2 Native Mode

The native mode is used to access devices attached to SATA controllers and is the default mode for all integrated SATA controllers. It is not supported by many legacy operating systems. Addresses are assigned by PCI Plug-n-Play BIOS and the IRQ is shared with multiple controllers. Base Address Registers for the Command and Control Block are found in the PCI Configuration Space.

- Offset 10h—Primary Command base address
- Offset 14h—Primary Control base address
- Offset 18h—Secondary Command base address
- Offset 1Ch—Secondary Control base address

## 4.9 Mixed Devices Boot and Drive Letter Ordering

<b>SATA Emulation</b>	<b>Hard Drive Order</b>	<b>HDD Boot and Drive Letter Ordering</b>
Separate IDE Controller (default). Used with Windows 2000 and XP.	A. Integrated SATA B. Integrated IDE	A1. SATA 0 A2. SATA 2 A3. SATA 1 A4. SATA 3 B1. IDE Device 0 B2. IDE Device 1
Separate IDE Controller. Used with Windows 2000 and XP.	A. Integrated IDE B. Integrated SATA	A1. IDE Device 0 A2. IDE Device 1 B1. SATA 0 B2. SATA 2 B3. SATA 1 B4. SATA 3
Combined with IDE Controller. Used with Windows 9x, NT, and Linux.	A. Integrated SATA B. Integrated IDE	A1. SATA 0 A2. SATA 2 B1. IDE Device 0 B2. IDE Device 1
Combined with IDE Controller. Used with Windows 9x, NT, and Linux.	A. Integrated IDE B. Integrated SATA	A1. IDE Device 0 A2. IDE Device 1 B1. SATA 0 B2. SATA 2



---

# Identifying the Chassis, Routine Care, and Disassembly Preparation

This chapter provides general service information for the computer. Adherence to the procedures and precautions described in this chapter is essential for proper service.



**CAUTION:** When the computer is plugged into an AC power source, voltage is always applied to the system board. You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.

---

## 5.1 Chassis Designations

### 5.1.1 Microtower (MT)



## 5.1.2 Slim Tower (ST)





## 5.2 Electrostatic Discharge Information

A sudden discharge of static electricity from your finger or other conductor can destroy static-sensitive devices or microcircuitry. Often the spark is neither felt nor heard, but damage occurs. An electronic device exposed to electrostatic discharge (ESD) may not appear to be affected at all and can work perfectly throughout a normal cycle. The device may function normally for a while, but it has been degraded in the internal layers, reducing its life expectancy.

Networks built into many integrated circuits provide some protection, but in many cases, the discharge contains enough power to alter device parameters or melt silicon junctions.

### 5.2.1 Generating Static

The following table shows that:

- Different activities generate different amounts of static electricity.
- Static electricity increases as humidity decreases.

Event	Relative Humidity		
	55%	40%	10%
Walking across carpet	7,500 V	15,000 V	35,000 V
Walking across vinyl floor	3,000 V	5,000 V	12,000 V
Motions of bench worker	400 V	800 V	6,000 V
Removing DIPs* from plastic tube	400 V	700 V	2,000 V
Removing DIPs* from vinyl tray	2,000 V	4,000 V	11,500 V
Removing DIPs* from Styrofoam	3,500 V	5,000 V	14,500 V
Removing bubble pack from PCB	7,000 V	20,000 V	26,500 V
Packing PCBs in foam-lined box	5,000 V	11,000 V	21,000 V

\*These are then multi-packaged inside plastic tubes, trays, or Styrofoam.



700 volts can degrade a product.

### 5.2.2 Preventing Electrostatic Damage to Equipment

Many electronic components are sensitive to ESD. Circuitry design and structure determine the degree of sensitivity. The following packaging and grounding precautions are necessary to prevent damage to electric components and accessories.

- To avoid hand contact, transport products in static-safe containers such as tubes, bags, or boxes.
- Protect all electrostatic parts and assemblies with conductive or approved containers or packaging.
- Keep electrostatic sensitive parts in their containers until they arrive at static-free stations.
- Place items on a grounded surface before removing them from their container.
- Always be properly grounded when touching a sensitive component or assembly.
- Avoid contact with pins, leads, or circuitry.
- Place reusable electrostatic-sensitive parts from assemblies in protective packaging or conductive foam.

### 5.2.3 Personal Grounding Methods and Equipment

Use the following equipment to prevent static electricity damage to equipment:

- **Wrist straps** are flexible straps with a maximum of one-megohm  $\pm$  10% resistance in the ground cords. To provide proper ground, a strap must be worn snug against bare skin. The ground cord must be connected and fit snugly into the banana plug connector on the grounding mat or workstation.
- **Heel straps/Toe straps/Boot straps** can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use them on both feet with a maximum of one-megohm  $\pm$  10% resistance between the operator and ground.

Static Shielding Protection Levels	
Method	Voltage
Antistatic plastic	1,500
Carbon-loaded plastic	7,500
Metallized laminate	15,000

### 5.2.4 Grounding the Work Area

To prevent static damage at the work area, use the following precautions:

- Cover the work surface with approved static-dissipative material. Provide a wrist strap connected to the work surface and properly grounded tools and equipment.
- Use static-dissipative mats, foot straps, or air ionizers to give added protection.
- Handle electrostatic sensitive components, parts, and assemblies by the case or PCB laminate. Handle them only at static-free work areas.
- Turn off power and input signals before inserting and removing connectors or test equipment.
- Use fixtures made of static-safe materials when fixtures must directly contact dissipative surfaces.
- Keep work area free of nonconductive materials such as ordinary plastic assembly aids and Styrofoam.
- Use field service tools, such as cutters, screwdrivers, and vacuums, that are conductive.

### 5.2.5 Recommended Materials and Equipment

Materials and equipment that are recommended for use in preventing static electricity include:

- Antistatic tape
- Antistatic smocks, aprons, or sleeve protectors
- Conductive bins and other assembly or soldering aids
- Conductive foam
- Conductive tabletop workstations with ground cord of one-megohm  $\pm$  10% resistance
- Static-dissipative table or floor mats with hard tie to ground
- Field service kits

- Static awareness labels
- Wrist straps and footwear straps providing one-megohm +/- 10% resistance
- Material handling packages
- Conductive plastic bags
- Conductive plastic tubes
- Conductive tote boxes
- Opaque shielding bags
- Transparent metallized shielding bags
- Transparent shielding tubes

## 5.3 Operating Guidelines

To prevent overheating and to help prolong the life of the computer:

- Keep the computer away from excessive moisture, direct sunlight, and extremes of heat and cold.
- Operate the computer on a sturdy, level surface. Leave a 10.2-cm (4-inch) clearance on all vented sides of the computer and above the monitor to permit the required airflow.
- Never restrict the airflow into the computer by blocking any vents or air intakes. Do not place the keyboard, with the keyboard feet down, directly against the front of the desktop unit as this also restricts airflow.
- Occasionally clean the air vents on all vented sides of the computer. Lint, dust, and other foreign matter can block the vents and limit the airflow. Be sure to unplug the computer before cleaning the air vents.
- Never operate the computer with the cover or side panel removed.
- Do not stack computers on top of each other or place computers so near each other that they are subject to each other's re-circulated or preheated air.
- If the computer is to be operated within a separate enclosure, intake and exhaust ventilation must be provided on the enclosure, and the same operating guidelines listed above will still apply.
- Keep liquids away from the computer and keyboard.
- Never cover the ventilation slots on the monitor with any type of material.
- Install or enable power management functions of the operating system or other software, including sleep states.

## 5.4 Routine Care

### 5.4.1 General Cleaning Safety Precautions

1. Never use solvents or flammable solutions to clean the computer.
2. Never immerse any parts in water or cleaning solutions; apply any liquids to a clean cloth and then use the cloth on the component.
3. Always unplug the computer when cleaning with liquids or damp cloths.

4. Always unplug the computer before cleaning the keyboard, mouse, or air vents.
5. Disconnect the keyboard before cleaning it.
6. Wear safety glasses equipped with side shields when cleaning the keyboard.

## 5.4.2 Cleaning the Computer Case

Follow all safety precautions in [Section 5.4.1](#) before cleaning the computer.

To clean the computer case, follow the procedures described below:

- To remove light stains or dirt, use plain water with a clean, lint-free cloth or swab.
- For stronger stains, use a mild dishwashing liquid diluted with water. Rinse well by wiping it with a cloth or swab dampened with clear water.
- For stubborn stains, use isopropyl (rubbing) alcohol. No rinsing is needed as the alcohol will evaporate quickly and not leave a residue.
- After cleaning, always wipe the unit with a clean, lint-free cloth.
- Occasionally clean the air vents on the computer. Lint and other foreign matter can block the vents and limit the airflow.

## 5.4.3 Cleaning the Keyboard

Follow all safety precautions in [Section 5.4.1](#) before cleaning the keyboard.

To clean the tops of the keys or the keyboard body, follow the procedures described in [Section 5.4.2](#).

When cleaning debris from under the keys, review all rules in [Section 5.4.1](#) before following these procedures:



**CAUTION:** Use safety glasses equipped with side shields before attempting to clean debris from under the keys.

---

- Visible debris underneath or between the keys may be removed by vacuuming or shaking.
  - Canned, pressurized air may be used to clean debris from under the keys. Caution should be used as too much air pressure can dislodge lubricants applied under the wide keys.
  - If you remove a key, use a specially designed key puller to prevent damage to the keys. This tool is available through many electronic supply outlets.
- 



**CAUTION:** Never remove a wide leveled key (like the space bar) from the keyboard. If these keys are improperly removed or installed, the keyboard may not function properly.

---

- Cleaning under a key may be done with a swab moistened with isopropyl alcohol and squeezed out. Be careful not to wipe away lubricants necessary for proper key functions. Use tweezers to remove any fibers or dirt in confined areas. Allow the parts to air dry before reassembly.

## 5.4.4 Cleaning the Monitor

- Wipe the monitor screen with a clean cloth moistened with water or with a towelette designed for cleaning monitors. Do not use sprays or aerosols directly on the screen; the liquid may seep into the housing and damage a component. Never use solvents or flammable liquids on the monitor.
- To clean the monitor body follow the procedures in [Section 5.4.2](#).

## 5.4.5 Cleaning the Mouse

Before cleaning the mouse, ensure that the power to the computer is turned off.

- Clean the mouse ball by first removing the retaining plate and the ball from the housing. Pull out any debris from the ball socket and wipe the ball with a clean, dry cloth before reassembly.
- To clean the mouse body, follow the procedures in [Section 5.4.2](#).

## 5.5 Service Considerations

Listed below are some of the considerations that you should keep in mind during the disassembly and assembly of the computer.

### 5.5.1 Power Supply Fan

The power supply fan is a variable-speed fan based on the temperature in the power supply.



**CAUTION:** The cooling fan is always on when the computer is in the "On" mode. The cooling fan is off when the computer is in "Standby," "Suspend," or "Off" modes.

You must disconnect the power cord from the power source before opening the computer to prevent system board or component damage.

---

### 5.5.2 Tools and Software Requirements

To service the computer, you need the following:

- Torx T-15 screwdriver (HP screwdriver with bits, PN 161946-001)
- Torx T-15 screwdriver with small diameter shank (for certain front bezel removal)
- Flat-bladed screwdriver (may sometimes be used in place of the Torx screwdriver)
- Phillips #2 screwdriver
- Diagnostics software
- HP tamper-resistant T-15 wrench (Smart Cover FailSafe Key, PN 166527-001) or HP tamper-resistant bits (Smart Cover FailSafe Key, PN 166527-002)

### 5.5.3 Screws

The screws used in the computer are not interchangeable. They may have standard or metric threads and may be of different lengths. If an incorrect screw is used during the reassembly process, it can damage the unit. HP strongly recommends that all screws removed during disassembly be kept with the part that was removed, then returned to their proper locations.



Metric screws have a black finish.  
U.S. screws have a silver finish and are used on hard drives only.



As each subassembly is removed from the computer, it should be placed away from the work area to prevent damage.

### 5.5.4 Cables and Connectors

Most cables used throughout the unit are flat, flexible cables. These cables must be handled with care to avoid damage. Apply only the tension required to seat or unseat the cables during insertion or removal from the connector. Handle cables by the connector whenever possible. In all cases, avoid bending or twisting the cables, and ensure that the cables are routed in such a way that they cannot be caught or snagged by parts being removed or replaced.



**CAUTION:** When servicing this computer, ensure that cables are placed in their proper location during the reassembly process. Improper cable placement can damage the computer.

### 5.5.5 Hard Drives

Handle hard drives as delicate, precision components, avoiding all physical shock and vibration. This applies to failed drives as well as replacement spares.

- If a drive must be mailed, place the drive in a bubble-pack mailer or other suitable protective packaging and label the package “Fragile: Handle With Care.”
- Do not remove hard drives from the shipping package for storage. Keep hard drives in their protective packaging until they are actually mounted in the CPU.
- Avoid dropping drives from any height onto any surface.
- If you are inserting or removing a hard drive, turn off the computer. Do not remove a hard drive while the computer is on or in standby mode.
- Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector. For more information about preventing electrostatic damage, refer to [Section 5.2, “Electrostatic Discharge Information.”](#)
- Do not use excessive force when inserting a drive.
- Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

## 5.5.6 Lithium Coin Cell Battery

The battery that comes with the computer provides power to the real-time clock and has a minimum lifetime of about three years.

See the appropriate removal and replacement chapter for the chassis you are working on in this guide for instructions on the replacement procedures.



**WARNING:** This computer contains a lithium battery. There is a risk of fire and chemical burn if the battery is handled improperly. Do not disassemble, crush, puncture, short external contacts, dispose in water or fire, or expose it to temperatures higher than 140°F (60°C). Do not attempt to recharge the battery.

---



Batteries, battery packs, and accumulators should not be disposed of together with the general household waste. In order to forward them to recycling or proper disposal, please use the public collection system or return them to HP, their authorized partners, or their agents.

---





---

## Removal and Replacement Procedures— Microtower (MT) Chassis

Adherence to the procedures and precautions described in this chapter is essential for proper service. After completing all necessary removal and replacement procedures, run the Diagnostics utility to verify that all components operate properly.



---

Not all features listed in this guide are available on all computers.

---

### 6.1 Preparation for Disassembly

See [Chapter 5, “Identifying the Chassis, Routine Care, and Disassembly Preparation”](#) for initial safety procedures.

1. Remove/disengage any security devices that prohibit opening the computer (See [Section 6.2, “External Security Devices”](#)).
2. Close any open software applications.
3. Exit the operating system.
4. Remove any diskette or compact disc from the computer.
5. Turn off the computer and any peripheral devices that are connected to it.



---

**CAUTION:** Turn off the computer before disconnecting any cables.

---



---

**CAUTION:** Regardless of the power-on state, voltage is always present on the system board as long as the system is plugged into an active AC outlet. In some systems the cooling fan is on even when the computer is in the “Standby,” or “Suspend” modes. The power cord should always be disconnected before servicing a unit.

---

6. Disconnect the power cord from the electrical outlet and then from the computer.
7. Disconnect all peripheral device cables from the computer.



---

During disassembly, label each cable as you remove it, noting its position and routing. Keep all screws with the units removed.

---



---

**CAUTION:** The screws used in the computer are of different thread sizes and lengths; using the wrong screw in an application may damage the unit.


---

## 6.2 External Security Devices

### 6.2.1 Installing a Cable Lock


The cable lock may be used to secure the computer access panel to the chassis and, at the same time, secure the computer to a fixed object.

Insert the cable lock in the location shown below.




## 6.2.2 Installing a Padlock

A padlock may be used by itself to secure the access panel to the computer chassis. A padlock may also be used with a security cable to secure the computer to a fixed object.




## 6.3 Access Panel

1. Prepare the computer for disassembly (Section 6.1).


 **CAUTION:** Before removing the computer access panel, ensure that the computer is turned off and that the power cord is disconnected from the electrical outlet.

---

2. Loosen the captive thumbscrew **1** that secures the access panel to the computer chassis.
  3. Slide the access panel **2** back about 1 inch (2.5 cm), then lift it off the unit.
- 

 You may want to lay the computer on its side to install internal parts. Be sure the side with the access panel and pull grip is facing up.


---




To install the access panel, reverse the removal procedure.

## 6.4 Front Bezel

1. Prepare the computer for disassembly (Section 6.1).
2. Remove the access panel (Section 6.3).
3. To remove the front bezel, press in on the two bottom tabs on the left side of the bezel ❶ so that they release from the chassis. Then press in on the upper tab on the left side of the bezel so that it releases from the chassis. The bezel will rotate out slightly from left to right.


 **CAUTION:** Do not over-rotate or try to pull the bezel off at this point, otherwise you may break the remaining hooks on the inside of the bezel.



4. Press down on the upper right corner of the bezel to release the hook that secures the top of the bezel to the chassis. Continue to rotate the bezel, then push the bezel to the left to release the right side latches and rotate the bezel off the chassis from left to right ❷.

To reinstall the front bezel:

1. Position the chassis in the upright position.
2. Insert the hooks on the right side of the bezel into the rectangular holes on the chassis ❶ then rotate the bezel into place ❷ so that the three tabs on the left side of the bezel and the single tab on the upper right corner of the bezel snap into the slots on the chassis.




## 6.5 Front Drive Bezels

Follow these steps before removing or installing a front drive bezel.

1. Prepare the computer for disassembly ([Section 6.1](#)).
2. Remove the access panel ([Section 6.3](#)).
3. Remove the front bezel ([Section 6.4](#)).

### 6.5.1 5.25" Drive Bezel Blank


Press the two retaining tabs on the inside of the large bezel towards the outside of the bezel to release the bezel blank ❶. At the same time, pull the bezel blank in to remove it from the front bezel ❷.



To install a bezel blank, reverse the removal procedure.

## 6.5.2 Diskette Drive Bezel


Press the two upper ❶ or the two lower ❷ tabs for the diskette drive bezel towards the center of the drive bezel and push the bezel out to remove it from the front bezel.



To install a bezel or a bezel blank, reverse the removal procedure.

## 6.5.3 3.5" Drive Bezel Blank

Press the two upper ❶ or the two lower ❷ tabs for the 3.5" drive bezel towards the center of the 3.5" drive bezel and push the bezel blank out to remove it from the front bezel.



To install a bezel blank, reverse the removal procedure.




## 6.6 Cable Management


Always follow good cable management practices when working inside the computer.

- Keep cables away from major heat sources like the heatsink.
- Do not jam cables on top of expansion cards or memory modules. Printed circuit cards like these are not designed to take excessive pressure on them.
- Keep cables clear of sliding or moveable parts to prevent them from being cut or crimped when the parts are moved.
- When folding a flat ribbon cable, never fold to a sharp crease. Sharp creases may damage the wires.
- Some flat ribbon cables come prefolded. Never change the folds on these cables.
- Do not bend any cable sharply. A sharp bend can break the internal wires.
- Never bend a SATA data cable tighter than a 30 mm (1.18 in) radius.
- Never crease a SATA data cable.
- Do not rely on components like the drive cage, power supply, or computer cover to push cables down into the chassis. Always position the cables to lay properly by themselves.

When removing the power supply power cables from the P1 or P3 connectors on the system board, always follow these steps:

1. Squeeze on the top of the retaining latch attached to the cable end of the connector ❶.
2. Grasp the cable end of the connector and pull it straight up ❷.

 **CAUTION:** Always pull the connector - NEVER pull on the cable. Pulling on the cable could damage the cable and result in a failed power supply.



## 6.7 Memory

**CAUTION:** The memory module sockets have gold metal contacts. When upgrading the memory, it is important to use memory modules with gold metal contacts to prevent corrosion and/or oxidation resulting from having incompatible metals in contact with each other.


**CAUTION:** Static electricity can damage the electronic components of the computer or optional cards. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. Refer to [Section 5.2, “Electrostatic Discharge Information”](#) for more information.


**CAUTION:** When handling a memory module, be careful not to touch any of the contacts. Doing so may damage the module.

1. Prepare the computer for disassembly ([Section 6.1](#)).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on ([Section 6.3](#)).

**WARNING:** To reduce risk of personal injury from hot surfaces, allow the internal system components to cool before touching.

3. Open both latches of the memory module socket ❶, and insert the memory module into the socket ❷. Refer to [Appendix F, “Memory”](#) for the correct sequence for installing memory modules to get optimal performance.



 A memory module can be installed in only one way. Match the notch on the module with the tab on the memory socket. It may be easier to install a memory module in some cases if the main power cable from the power supply to the system board is temporarily disconnected.

4. Push the module down into the socket, ensuring that the module is fully inserted and properly seated. Make sure the latches are in the closed position ❸.




The computer automatically recognizes the additional memory when the computer is turned on.

To reassemble the computer, reverse the removal procedure.

## 6.8 Expansion Cards

1. Prepare the computer for disassembly ([Section 6.1](#)).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on ([Section 6.3](#)).
3. On the rear of the computer, a sliding slot cover lock secures the expansion card brackets and expansion slot covers in place. Remove the thumbscrew that holds the slot cover lock in place **1** and slide the slot cover lock away from the brackets **2** so that they are no longer secured by the lock.




4. Before installing an expansion card, remove the expansion slot cover or the existing expansion card.




Before removing an installed expansion card, disconnect any cables that may be attached to the expansion card.

---


- a. If you are installing an expansion card in a vacant socket, remove the appropriate expansion slot cover on the back of the chassis. Pull the slot cover straight up from the socket then away from the inside of the chassis.



- b. If removing a standard PCI expansion card, hold the card at each end, and carefully rock it back and forth until the connectors pull free from the socket. Pull the expansion card straight up from the socket ❶ then away from the inside of the chassis ❷ to release it from the chassis frame. Be sure not to scrape the card against the other components.



- c. If removing a PCI Express x16 card, pull the retention arm on the back of the expansion socket away from the card and carefully rock the card back and forth until the connectors pull free from the socket. Pull the expansion card straight up from the socket then away from the inside of the chassis to release it from the chassis frame. Be sure not to scrape the card against the other components.




5. If not replacing the old expansion card with a new expansion card, install an expansion slot cover to close the open slot. Insert the metal slot cover in the opened slot and slide the slot cover lock down to secure the slot cover in place.



**CAUTION:** After removing an expansion card, you must replace it with a new card or expansion slot cover for proper cooling of internal components during operation.

---


6. If replacing or adding a new expansion card, hold the card just above the expansion slot on the system board then move the card toward the rear of the chassis ❶ so that the bracket on the card is aligned with the open slot on the rear of the chassis. Press the card straight down into the expansion slot on the system board ❷.



When installing an expansion card, press firmly on the card so that the whole connector seats properly in the expansion card slot.

---

7. If you are replacing an expansion card, store the old card in the anti-static packaging that contained the new card.
8. While holding the expansion card bracket against the chassis, slide the slot cover lock down toward the expansion card brackets and slot covers ❶ to secure them in place and replace the thumbscrew ❷ that secures the slot cover lock.



9. Connect external cables to the installed card, if needed. Connect internal cables to the system board, if needed.


## 6.9 Drives

The computer supports up to six drives that may be installed in various configurations.

This Section describes the procedure for replacing or upgrading the storage drives. A Torx T-15 screwdriver is needed to remove and install the guide screws on a drive.

**CAUTION:** Make sure personal files on the hard drive are backed up to an external storage device before removing the hard drive. Failure to do so will result in data loss. After replacing the primary hard drive, you will need to run the *Restore Plus! CD* to load the HP factory-installed files.

### 6.9.1 Drive Positions



**Drive Positions**

Item	Description
❶	Two 5.25-inch, half-height bays for optional drives
❷	Two standard 3.5-inch, one-third height bays (1.44-MB diskette drive shown)*
❸	Two internal 3.5-inch, one-third height bays for hard drives

\*A 3.5-inch diskette drive or zip drive may be installed in this bay but the correct bezel must be installed to ensure proper air flow.


## 6.9.2 Removing a Drive

1. Remove any removable media, such as a compact disc or diskette, from the drive.
2. Prepare the computer for disassembly ([Section 6.1](#)).
3. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on ([Section 6.3](#)).
4. Remove the front bezel ([Section 6.4](#)).
5. Disconnect the power and data cables from the back of the drive, as shown in the following illustrations.

### Disconnecting Optical Drive Cables




### Disconnecting Diskette Drive Cables






## Disconnecting Hard Drive Cables



Some products use straight cable connectors while others use right angle connectors.

## Releasing the Drives

6. A latch drive bracket with release tabs secures the drives in the drive bay. Lift the release tab on the latch drive bracket ❶ for the drive you want to remove, then slide the drive from its drive bay ❷.



7. Remove the four guide screws (two on each side) from the old drive. You will need these screws to install a new drive.

## 6.9.3 Installing a Drive



**CAUTION:** To prevent loss of work and damage to the computer or drive:

- If you are inserting or removing a hard drive, shut down the operating system properly, then turn off the computer. Do not remove a hard drive while the computer is on or in standby mode.
  - Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector. Refer to [Section 5.2, “Electrostatic Discharge Information”](#) for more information about preventing electrostatic damage.
  - Handle a drive carefully; do not drop it.
  - Do not use excessive force when inserting a drive.
  - Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.
- 

1. Install four guide screws (two on each side) into the new drive. The screws help guide the drive into its proper position in the bay.


- If this is a new installation, guide screws are provided on the front of the chassis under the front bezel.
  - If this is a replacement drive, use the screws removed from the old drive.
- 



There are a total of eight extra guide screws on the front of the chassis. Four have U.S. threads and four have metric threads. Metric screws have a black finish. U.S. threaded screws have a silver finish. Make sure to install the appropriate guide screws into the drive.

---

2. Align the guide screws with the guide slots, then slide the drive into the drive bay, making sure it is fully seated.




3. Reconnect the power and data cables to the drive as shown in the following illustrations.




Refer to [Chapter 4, “Serial and Parallel ATA Drive Guidelines and Features”](#) for information on attaching the cabling to get optimum performance.

---


### Connecting Optical Drive Cables



### Connecting Diskette Drive Cables



## Connecting Hard Drive Cables



Some products use straight cable connectors while others use right angle connectors.

---

4. Install the front bezel ([Section 6.4](#)).
  5. Install the access panel ([Section 6.3](#)).
  6. Turn on the computer.
- 




If you replaced the primary hard drive, the *Restore Plus!* CD may be used to restore the operating system, software drivers, and/or any software applications that were preinstalled on the computer. Follow the instructions in the guide included with the *Restore Plus!* CD. When the restore process has completed, reinstall any personal files that were backed up before replacing the hard drive.

---

## 6.10 Chassis Fan


1. Prepare the computer for disassembly (Section 6.1).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on (Section 6.3).
3. Disconnect the power cable that connects the chassis fan to the system board ❶.
4. Remove the four screws from the exterior rear of the chassis that secure the fan ❷.
5. Remove the fan from the chassis ❸.



To install the chassis fan, reverse the removal procedure.

## 6.11 Front I/O Panel Housing Assembly


1. Prepare the computer for disassembly (Section 6.1).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on (Section 6.3).
3. Disconnect three attaching cables from the system board: the power switch/LED cable, the front USB cable, and the front audio cable.
4. Remove the two screws that secure the housing to the chassis ❶ then pull the housing away from the chassis ❷.



To install the housing assembly, reverse the removal procedures.

## 6.12 Front I/O Devices


1. Prepare the computer for disassembly (Section 6.1).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on (Section 6.3).
3. Remove the front I/O panel assembly (Section 6.11).
4. Remove the two screws that hold the USB and audio port assembly in place ❶.
5. Remove the I/O device assembly from the I/O panel by pushing it out of the housing ❷.



To install the I/O devices, reverse the removal procedures and then reinstall the housing assembly.

## 6.13 Power Switch Assembly

1. Prepare the computer for disassembly (Section 6.1).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on (Section 6.3).
3. Remove the front I/O panel assembly (Section 6.11).
4. Squeeze the switch holder retaining clips together ❶ and push the switch assembly out of the front I/O panel housing ❷.




5. Place the switch holder with the switch installed into the inside of the front I/O panel housing and position the legs of the retaining clip into the clip slots. Press firmly so that the clips will penetrate the slot openings and latch into place. If one clip will not easily engage, it may be necessary to use the end of a ball point pen (or another thin, stiff object) to compress the clip leg while inserting it into the clip slot.
6. Reconnect the housing assembly to the front of the chassis and reconnect the cables to the system board.




## 6.14 Heatsink


1. Prepare the computer for disassembly (Section 6.1).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on (Section 6.3).
3. Disconnect the heatsink fan cable from the system board.
4. Disconnect the four-pin power cable from the system board to make it easier to access the heatsink.
5. Loosen the four captive screws ❶ that secure the heatsink to the system board tray.

 **CAUTION:** Heatsink retaining screws should be removed in diagonally opposite pairs (as in an X) to even the downward forces on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

6. Lift the heatsink from atop the processor ❷ and set it on its side to keep from contaminating the work area with thermal grease.



When reinstalling the heatsink, make sure that its bottom has been cleaned with an alcohol wipe and fresh thermal grease has been applied to the top of the processor.

 **CAUTION:** Heatsink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heatsink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

## 6.15 Processor

1. Prepare the computer for disassembly (Section 6.1).
2. Remove the computer cover (Section 6.3).
3. Disconnect the heatsink control cable from the system board and remove the heatsink (Section 6.14).
4. Rotate the locking lever to its full open position ❶.
5. Raise and rotate the microprocessor retainer to its fully open position ❷.
6. Carefully lift the processor from the socket ❸.


---

**CAUTION:** Do NOT handle the pins in the processor socket. These pins are very fragile and handling them could cause irreparable damage. Once pins are damaged it may be necessary to replace the system board.

---

**CAUTION:** The heatsink must be installed within 24 hours of installing the processor to prevent damage to the processor's solder connections.

---



To install a new processor:

1. Place the processor in its socket and close the retainer.
2. Secure the locking lever.

If reusing the existing heatsink, go to step 3.

If using a new heatsink, go to step 6.

3. If reusing the existing heatsink, clean the bottom of the heatsink with the alcohol pad provided in the spares kit.

---

**CAUTION:** Before reinstalling the heatsink you must clean the top of the processor and the bottom of the heatsink with an alcohol pad supplied in the spares kit. After the alcohol has evaporated, apply thermal grease to the top of the processor from the syringe supplied in the spares kit.

---

4. Apply the thermal grease provided in the spares kit to the top of the processor and install the heatsink atop the processor.
5. Go to step 7.
6. If using a new heatsink, remove the protective covering from the bottom of the heatsink and place it in position atop the processor.
7. Secure the heatsink to the system board and system board tray with the four captive screws and attach the heatsink control cable to the system board.



**CAUTION:** Heatsink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heatsink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

---




After installing a new processor onto the system board, always update the system ROM to ensure that the latest version of the BIOS is being used on the computer. The latest system BIOS can be found on the Web at: <http://h18000.www1.hp.com/support/files>.

---

## 6.16 Speaker

1. Prepare the computer for disassembly ([Section 6.1](#)).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on ([Section 6.3](#)).
3. Move/remove any components necessary to gain access to the speaker.
4. Disconnect the speaker wire from the system board connector.
5. Remove the two plastic push pins that secure the speaker to the chassis.
6. Remove the speaker by lifting it up and out of the retaining clips.




To install the speaker, reverse the removal procedures.


## 6.17 Power Supply

**WARNING:** Voltage is always present on the system board when the computer is plugged into an active AC outlet. To avoid possible personal injury and damage to the equipment the power cord should be disconnected from the computer and/or the AC outlet before opening the computer.

1. Prepare the computer for disassembly ([Section 6.1](#)).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on ([Section 6.3](#)).
3. Disconnect all power cables from the mass storage devices and from the system board.
4. Remove the screws that connect the power supply to the chassis **1**.




5. Pull the power supply towards the front of the chassis while depressing the two sets of retaining clips **1** to allow the power supply to move far enough to lift it from the chassis **2**.



To install the power supply, reverse the removal procedure.

## 6.18 System Board

1. Prepare the computer for disassembly (Section 6.1).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on (Section 6.3).
3. Remove all PCI and PCI Express expansion boards (Section 6.8).
4. Disconnect all cables connected to the system board, noting their location for reinstallation.
5. Remove the 3-1/4" drives from the drive cage to make it easier to handle the system board.
6. Remove the eight screws that secure the system board to the chassis ❶, then slide the system board towards the front of the chassis to remove it ❷.



To install the system board, reverse the removal procedures.

## 6.19 Battery

The battery that comes with your computer provides power to the real-time clock and has a lifetime of about three years. When replacing the battery, use a battery equivalent to the battery originally installed on the computer. The computer comes with a 3-volt lithium coin cell battery.



The lifetime of the lithium battery can be extended by plugging the computer into a live AC wall socket. The lithium battery is only used when the computer is NOT connected to AC power.



**WARNING:** This computer contains an internal lithium manganese dioxide battery. There is a risk of fire and burns if the battery is not handled properly. To reduce the risk of personal injury:

- Do not attempt to recharge the battery.
- Do not expose to temperatures higher than 140°F (60°C)
- Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.
- Replace the battery only with the HP spare designated for this product.



**CAUTION:** Before replacing the battery, it is important to back up the computer CMOS settings. When the battery is removed or replaced, the CMOS settings will be cleared. Refer to the *Computer Setup (F10) Utility Guide* for information on backing up the CMOS settings.



Batteries, battery packs, and accumulators should not be disposed of together with the general household waste. In order to forward them to recycling or proper disposal, please use the public collection system or return them to HP, their authorized partners, or their agents.



**CAUTION:** Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object.

1. Prepare the computer for disassembly ([Section 6.1](#)).
2. Remove the access panel and rotate the computer so the system board is parallel to the table to make it easier to work on ([Section 6.3](#)).




It may be necessary to remove an expansion card to gain access to the battery.

3. Locate the battery and battery holder on the system board.
4. Depending on the type of battery holder on your system board, complete the following instructions to replace the battery:



## 6.19.1 Type 1 Battery Holder


1. Lift the battery out of its holder.



2. Slide the replacement battery into position, positive side up.
3. The battery holder automatically secures the battery in the proper position.
4. Replace the computer access panel ([Section 6.3](#)).
5. Plug in the computer and turn on power to the computer.
6. Reset the date and time, your passwords, and any special system setups, using Computer Setup. Refer to the *Computer Setup (F10) Utility Guide*.

## 6.19.2 Type 2 Battery Holder


1. To release the battery from its holder, squeeze the metal clamp that extends above one edge of the battery. When the battery pops up, lift it out ❶.
2. To insert the new battery, slide one edge of the replacement battery under the holder's lip with the positive side up ❷. Push the other edge down until the clamp snaps over the other edge of the battery.



3. Replace the computer cover or access panel ([Section 6.3](#)).
4. Plug in the computer and turn on power to the computer.
5. Reset the date and time, your passwords, and any special system setups, using Computer Setup. Refer to the *Computer Setup (F10) Utility Guide*.

### 6.19.3 Type 3 Battery Holder

1. Pull back on the clip ❶ that holds the battery in place, then remove the battery ❷.
2. Insert the new battery and position the clip back in place.



3. Replace the computer access panel ([Section 6.3](#)).
4. Plug in the computer and turn on power.
5. Reset the date and time, your passwords, and any special system setups, using Computer Setup. Refer to the *Computer Setup (F10) Utility Guide*.



---

## Removal and Replacement Procedures— Slim Tower (ST) Chassis

Adherence to the procedures and precautions described in this chapter is essential for proper service. After completing all necessary removal and replacement procedures, run the Diagnostics utility to verify that all components operate properly.



---

Not all features listed in this guide are available on all computers.

---

### 7.1 Preparation for Disassembly

See [Chapter 5, “Identifying the Chassis, Routine Care, and Disassembly Preparation,”](#) for initial safety procedures.

1. Remove/disengage any security devices that prohibit opening the computer ([Section 7.2, “Unlocking the Smart Cover Lock,”](#) and [Section 7.4, “External Security Devices”](#)).
2. Close any open software applications.
3. Exit the operating system.
4. Remove any diskette or compact disc from the computer.
5. Turn off the computer and any peripheral devices that are connected to it.



---

**CAUTION:** Turn off the computer before disconnecting any cables.

---



---

**CAUTION:** Regardless of the power-on state, voltage is always present on the system board as long as the system is plugged into an active AC outlet. In some systems the cooling fan is on even when the computer is in the “Standby,” or “Suspend” modes. The power cord should always be disconnected before servicing a unit.

---

6. Disconnect the power cord from the electrical outlet and then from the computer.
7. Disconnect all peripheral device cables from the computer.



---

During disassembly, label each cable as you remove it, noting its position and routing. Keep all screws with the units removed.

---



---

**CAUTION:** The screws used in the computer are of different thread sizes and lengths; using the wrong screw in an application may damage the unit.

---

8. Lift the computer off the stand.



9. Lay the computer on its side (with the computer cover facing up) before removing the computer cover and installing hardware.

## 7.2 Unlocking the Smart Cover Lock

If you have locked the Smart Cover Lock use Computer Setup to unlock the lock. Refer to the *Desktop Management Guide* on the *Documentation and Diagnostics* CD for more information about the Smart Cover Lock.


If you cannot access Computer Setup to unlock the cover you will need to remove the locking solenoid by using the Smart Cover FailSafe Key (Spare part number 166527-001 or 166527-002). Once the solenoid has been deactivated or removed the access panel can be removed.

The Smart Cover FailSafe Key will be needed in any of the following circumstances:

- Power outage
- Startup failure
- Processor or power supply failure
- Lost password

To open the computer cover with the Smart Cover Lock engaged:


1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Using the Smart Cover FailSafe Key, remove the tamper-proof screw ❶ that secures the Smart Cover Lock to the inside of the chassis.
3. Push the metal arm that wraps around the air vent grid up and back ❷ to free the Smart Cover Lock from the chassis.



4. Remove the computer cover ([Section 7.5](#)).

To reattach the Smart Cover Lock:


1. Install the Smart Cover Lock assembly on the inside of the rear panel with the metal arm **1** wrapped around the air vent grid on the back of the chassis.
2. Use the supplied tamper-resistant screw **2** to secure the Smart Cover Lock to the chassis.





## 7.3 Hood Sensor

1. Prepare the computer for disassembly (Section 7.1).
2. Remove the computer cover (Section 7.5).
3. Remove the special security clip (Section 7.4.1) from the top rear corner of the power supply cage.
4. Raise the power supply to its full upright position.
5. Disconnect the hood sensor cable from the system board.
6. Slide the hood sensor switch mounted on the power supply towards the outside of the computer ❶ and lower it through the slot ❷.




To install the hood sensor, reverse the removal procedure.

## 7.4 External Security Devices

### 7.4.1 Security Clip

A special clip is required to secure the computer from intrusion. This clip must be installed before installing the computer cover.



### 7.4.2 Cable Lock

The cable lock may be used to secure the computer cover to the chassis and, at the same time, secure the computer to a fixed object.

Insert the cable lock in the location shown below.




### 7.4.3 Padlock

A padlock may be used by itself to secure the computer cover to the computer chassis. A padlock may also be used with a security cable to secure the computer to a fixed object.



## 7.5 Computer Cover

1. Prepare the computer for disassembly (Section 7.1).

 **CAUTION:** Before removing the computer cover, ensure that the computer is turned off and that the power cord is disconnected from the electrical outlet.

---

1. Press the buttons on the left and right sides of the computer ①.
2. Slide the computer cover towards the front of the computer until it stops ②, then lift it up and off the chassis.




To install the computer cover, reverse the removal procedure.

## 7.6 Front Drive Bezels

1. Prepare the computer for disassembly (Section 7.1).
2. Remove the computer cover (Section 7.5).
3. Remove the drive bezel by pushing the top tab on the right side of the larger front bezel as shown ❶ and rotating the drive bezel away from the larger front bezel ❷.




The drive bezel will vary depending on the computer configuration.



4. Install a bezel or a bezel blank by pushing the bezel into place.



There are three drive bezel inserts that are available.



Item	Description
❶	Diskette drive bezel
❷	Hard drive bezel
❸	3.5" drive bezel


## 7.7 Cable Management


The Slim Tower chassis is a very compact computer and proper routing of the internal cables is critical to the operation of the computer. Follow good cable management practices when working inside the computer.

- Keep cables away from major heat sources like the heatsink.
- Do not jam cables on top of expansion cards or memory modules. Printed circuit cards like these are not designed to take excessive pressure on them.
- Keep cables clear of movable or rotating parts like the power supply and drive cage to prevent them from being cut or crimped when the component is lowered into its normal position.
- When folding a flat ribbon cable, never fold to a sharp crease. Sharp creases may damage the wires.
- Some flat ribbon cables come prefolded. Never change the folds on these cables.
- Do not bend any cable sharply. A sharp bend can break the internal wires.
- Never bend a SATA data cable tighter than a 30 mm (1.18 in) radius.
- Never crease a SATA data cable.
- Do not rely on components like the drive cage, power supply, or computer cover to push cables down into the chassis. Always position the cables to lay properly by themselves.

When removing the power supply power cables from the P1 or P3 connectors on the system board, always follow these steps:

1. Squeeze on the top of the retaining latch attached to the cable end of the connector ❶.
2. Grasp the cable end of the connector and pull it straight up ❷.

 **CAUTION:** Always pull the connector - NEVER pull on the cable. Pulling on the cable could damage the cable and result in a failed power supply.



## 7.8 Memory

**CAUTION:** The memory module sockets have gold metal contacts. When upgrading the memory, it is important to use memory modules with gold metal contacts to prevent corrosion and/or oxidation resulting from having incompatible metals in contact with each other.


**CAUTION:** Static electricity can damage the electronic components of the computer or optional cards. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object. Refer to [Section 5.2, “Electrostatic Discharge Information”](#) for more information.


**CAUTION:** When handling a memory module, be careful not to touch any of the contacts. Doing so may damage the module.

1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).

**WARNING:** To reduce risk of personal injury from hot surfaces, allow the internal system components to cool before touching.

3. Open both latches of the memory module socket ❶, and insert the memory module into the socket ❷. Refer to [Appendix F, “Memory”](#) for the correct sequence for installing memory modules to get optimal performance.




 A memory module can be installed in only one way. Match the notch on the module with the tab on the memory socket.

4. Push the module down into the socket, ensuring that the module is fully inserted and properly seated. Make sure the latches are in the closed position ❸.
5. Repeat steps 3 and 4 for any additional modules that you want to install.




---

 The computer automatically recognizes the additional memory when the computer is turned on.

---

To reassemble the computer, reverse the removal procedure.

---


 If you normally lock the Smart Cover Lock, use Computer Setup to relock the lock and enable the Smart Cover Sensor.

---

## 7.9 Vertically Oriented Expansion Card

### 7.9.1 Expansion Card Retainer


1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).
3. Release the slot cover retention latch that secures the PCI slot covers by lifting the green tab on the latch and rotating the latch to the full open position **1**.
4. Remove the single screw that keeps the card retainer in place **2** and slide the retainer to the left to remove it from the chassis **3**.



To install the card retainer, reverse the removal procedure.

## 7.9.2 PCI Expansion Card

1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).
3. Identify the slot into which you want to insert the expansion card.
4. Release the slot cover retention latch that secures the PCI slot covers by lifting the green tab on the latch and rotating the latch to the full open position ❶.
5. Remove the slot cover by sliding it up and out of the computer ❷.




6. Install the expansion card by sliding the card under the slot cover retention latch then pressing the card down into the slot on the system board.



Be sure not to scrape other components in the chassis when installing an expansion card.

---



7. Rotate the slot cover retention latch back in place to secure the expansion card.



When you install an expansion card, make sure the metal bracket on the card slides into the slot on the back of the computer then press down firmly on the card so that the whole connector seats properly in the expansion card slot.

---




**CAUTION:** All expansion card slots on the rear of the computer must contain either an expansion card or slot cover for proper cooling of internal components during operation.

---

### 7.9.3 PCI Express Expansion Card


To remove a PCI Express expansion card:

1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).
3. Release the slot cover retention latch on the back of the computer that secures the PCI slot covers by lifting the green tab on the latch and rotating the latch to the open position.
4. Pull the retention arm on the back of the PCI Express expansion socket away from the card (on x16 card socket only) and carefully rock the card back and forth until the connectors pull free from the socket. Pull the expansion card straight up from the socket then away from the inside of the chassis. Be sure not to scrape the card against the other components.



5. If you are not installing a new expansion card, install an expansion slot cover to close the open slot.
6. Rotate the slot cover retention latch back in place to secure the expansion cards and expansion slot covers.

---

 **CAUTION:** All expansion card slots on the rear of the computer must contain either an expansion card or slot cover for proper cooling of internal components during operation.


---

## 7.10 Drives

A Torx T-15 screwdriver is needed to remove and install the guide screws on a drive.

**CAUTION:** Make sure personal files on the hard drive are backed up to an external storage device before removing the hard drive. Failure to do so will result in data loss. After replacing the primary hard drive, you will need to run the *Restore Plus!* CD to load the HP factory-installed files.

### 7.10.1 Drive Positions



**Drive Positions**

Item	Description
①	3.5-inch, internal, standard hard drive bay
②	3.5-inch drive bay (1.44-MB diskette drive shown)*
③	5.25-inch drive bay for optional drives

\*A 3.5-inch diskette drive, hard drive, or Zip drive may be installed in this bay but the correct bezel must be installed to ensure proper air flow.

To verify the type and size of the storage device installed in the computer, run Computer Setup.


## 7.10.2 Optical Drive




An optical drive is a CD-ROM, CD-R/RW, DVD-ROM, DVD+R/RW, or CD-RW/DVD Combo drive.

---


1. Remove any removable media, such as a CD or DVD, from the drive.
2. Prepare the computer for disassembly ([Section 7.1](#)).
3. Remove the computer cover ([Section 7.5](#)).
4. Rotate the drive cage to its upright position by pulling on the green-tabbed lip.



5. Disconnect the power and data cables from the rear of the optical drive.



6. Rotate the drive cage down to its normal position before trying to remove the drive.
7. Press the green drive retainer latch and slide the drive forward and lift it from the drive cage.



To replace the drive, reverse the removal procedure.



When replacing the drive, transfer the four screws from the old drive to the new one. The screws take the place of drive rails.

---




**CAUTION:** Use only 5-mm long screws as guide screws. Longer screws can damage the internal components of the drive.

---

### 7.10.3 External 3.5-inch Drive


1. Remove any removable media, such as a diskette, from the drive.
2. Prepare the computer for disassembly ([Section 7.1](#)).
3. Remove the computer cover ([Section 7.5](#)).
4. Remove the optical drive ([Section 7.10.2](#)).
5. Rotate the drive cage to its upright position by pulling on the green-tabbed lip.
6. Disconnect the signal and power cables from the drive. The other end of the cables should remain connected to the system board. (Diskette drive is shown.)




7. Rotate the drive cage down to its normal position before trying to remove the drive.



8. Press the green drive retention latch **1** located on the side of the diskette drive to disengage the drive from the drive cage and slide the diskette drive forward approximately 6mm (1/4 inch) **2**.



9. Lift the rear of the drive up so that the rear guide screws clear the top of the drive cage **1**. As the drive rises it automatically slides forward until it is free from the drive cage **2**.




To replace the drive, reverse the removal procedure making sure you rotate the rear of the drive down, pivoting on the front screws.




When replacing the drive, transfer the four metric screws from the old drive to the new one. The screws take the place of drive rails.

## 7.10.4 Primary Hard Drive

A Torx T-15 screwdriver is needed to remove and install the guide screws on a hard drive.

 **CAUTION:** Make sure personal files on the hard drive are backed up to an external storage device before removing the hard drive. Failure to do so will result in data loss. After replacing the primary hard drive, you will need to run the *Restore Plus!* CD to load the HP factory-installed files.


---

 **CAUTION:** To prevent loss of work and damage to the computer or drive:


- If you are inserting or removing a hard drive, shut down the operating system properly, then turn off the computer. Do not remove a hard drive while the computer is on or in standby mode.
- Before handling a drive, ensure that you are discharged of static electricity. While handling a drive, avoid touching the connector. Refer to [Section 5.2, "Electrostatic Discharge Information"](#) for more information about preventing electrostatic damage.
- Handle a drive carefully; do not drop it.
- Do not use excessive force when inserting a drive.
- Avoid exposing a hard drive to liquids, temperature extremes, or products that have magnetic fields such as monitors or speakers.

---


1. Prepare the computer for disassembly ([Section 7.1](#)).
  2. Remove the computer cover ([Section 7.5](#)).
  3. Rotate the drive cage to its upright position by pulling on the green-tabbed lip.
- 

 It is not necessary to remove the drives from the drive cage.


---




4. Remove the security clip that secures the backwall to the power supply.




5. Rotate the power supply to its full upright position.



6. Disconnect the power ❶ and data ❷ cables from the back of the hard drive.



7. Pull the tab that locks the drive in place away from the drive ❶, slide the hard drive toward the front of the computer, then lift it up and out of the bay ❷.



To install a hard drive, reverse the above procedure.



---

The replacement hard drive kit includes several data cables. Make sure to use the cable that is exactly the same as the factory-installed cable.


---




---

If the system has only one SATA hard drive, the data cable must be connected to the **blue** connector labeled P60 SATA 0 first to avoid any hard drive performance problems.

---

 When replacing the hard drive, transfer the four screws from the old drive to the new one. The screws take the place of drive rails. You will need a Torx T-15 screwdriver to remove and re-install the guide screws. HP has provided four extra 6-32 standard guide screws on the front of the chassis, under the computer cover. The 6-32 standard guide screws are silver and are used only for the hard drive.


---

 If you replaced the primary hard drive, insert the *Restore Plus!* CD to restore the operating system, software drivers, and any software applications that were preinstalled on the computer. Follow the instructions in the guide included with the *Restore Plus!* CD. When the restore process has completed, reinstall any personal files that you backed up before replacing the hard drive.

---

## 7.11 Fan Shroud


1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).
3. Lift up on the fan shroud to remove it from the computer.



When replacing the shroud, make sure that it does not get caught on the wires from either the fan or the speaker.

## 7.12 Chassis Fan


1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).
3. Remove the fan shroud ([Section 7.11](#)).
4. Disconnect the chassis fan cable from the system board.
5. Remove the four screws that secure the fan to the chassis, then remove the fan from the chassis.



To install the chassis fan, reverse the removal procedure. Be sure to orient the air flow into the unit. Refer to the air flow arrows on the side of the fan housing for proper air flow orientation.

## 7.13 Front I/O Devices

1. Prepare the computer for disassembly (Section 7.1).
2. Remove the computer cover (Section 7.5).
3. Remove the two screws that secure the front I/O device to the chassis ❶.
4. Rotate the drive cage to its full upright position.
5. Disconnect the front I/O cable from the system board.
6. Push the front I/O device into the chassis ❷ and snake the cable through the tunnel ❸ to remove the device from the chassis.




To reinstall the front I/O device, reverse the removal procedure.



## 7.14 Power Switch Assembly

1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).
3. Disconnect the power switch/LED cable from the system board.
4. Squeeze the switch holder retaining clips together at the front of the chassis **1** and push the switch assembly out of the chassis **2**. Push the two LEDs out of the chassis **3**.
5. If necessary, the LED holders may also be removed by squeezing the clips and pushing them out of the front of the chassis.




To install the power switch and LEDs, reverse the removal procedure.

## 7.15 Heatsink


1. Prepare the computer for disassembly (Section 7.1).
2. Remove the computer cover (Section 7.5).
3. Remove the fan shroud (Section 7.11).
4. Disconnect the fan control cable from the system board.
5. Loosen the four captive screws that secure the heatsink to the system board tray.

---

 **CAUTION:** Heatsink retaining screws should be removed in diagonally opposite pairs (as in an X) to even the downward forces on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.


---

6. Lift the heatsink from atop the processor and set it on its side to keep from contaminating the work area with thermal grease.




When reinstalling the heatsink, make sure that its bottom has been cleaned with an alcohol wipe and fresh thermal grease has been applied to the top of the processor.

---

 **CAUTION:** Heatsink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heatsink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

---

---

 **CAUTION:** Failure to install the fan shroud may cause the computer to overheat.


---

## 7.16 Processor

1. Prepare the computer for disassembly (Section 7.1).
2. Remove the computer cover (Section 7.5).
3. Remove the fan shroud (Section 7.11).
4. Disconnect the heatsink control cable from the system board and remove the heatsink (Section 7.15).
5. Rotate the locking lever to its full open position ❶.
6. Raise and rotate the microprocessor retainer to its fully open position ❷.
7. Carefully lift the processor from the socket ❸.

**CAUTION:** Do NOT handle the pins in the processor socket. These pins are very fragile and handling them could cause irreparable damage. Once pins are damaged it may be necessary to replace the system board.

**CAUTION:** The heatsink must be installed within 24 hours of installing the processor to prevent damage to the processor's solder connections.



To install a new processor:

1. Place the processor in its socket and close the retainer.
2. Secure the locking lever.

If reusing the existing heatsink, go to step 3.

If using a new heatsink, go to step 6.

3. If reusing the existing heatsink, clean the bottom of the heatsink with the alcohol pad provided in the spares kit.

**CAUTION:** Before reinstalling the heatsink you must clean the top of the processor and the bottom of the heatsink with an alcohol pad supplied in the spares kit. After the alcohol has evaporated, apply thermal grease to the top of the processor from the syringe supplied in the spares kit.

4. Apply the thermal grease provided in the spares kit to the top of the processor and install the heatsink atop the processor.
5. Go to step 7.
6. If using a new heatsink, remove the protective covering from the bottom of the heatsink and place it in position atop the processor.
7. Secure the heatsink to the system board and system board tray with the four captive screws and attach the heatsink control cable to the system board.



**CAUTION:** Heatsink retaining screws should be tightened in diagonally opposite pairs (as in an X) to evenly seat the heatsink on the processor. This is especially important as the pins on the socket are very fragile and any damage to them may require replacing the system board.

---




After installing a new processor onto the system board, always update the system ROM to ensure that the latest version of the BIOS is being used on the computer. The latest system BIOS can be found on the Web at: <http://h18000.www1.hp.com/support/files>.

---

## 7.17 Speaker

1. Prepare the computer for disassembly (Section 7.1).
2. Remove the computer cover (Section 7.5).
3. Remove the fan shroud (Section 7.11).
4. Remove the heatsink control cable and the heatsink from the system board (Section 7.15).
5. Remove any memory modules that might interfere with the screwdriver used for removing the speaker.
6. Disconnect the speaker wire from the system board.
7. Remove the two screws that secure the speaker to the chassis ❶.
8. Rotate the top of the speaker back to clear the lip on the top of the chassis, then lift the speaker up and out of the chassis ❷.



To install the speaker, reverse the removal procedures.

**CAUTION:** Before reinstalling the heatsink you must clean the top of the processor and the bottom of the heatsink with an alcohol pad supplied in the speaker spares kit. After the alcohol has evaporated, apply thermal grease to the top of the processor from the syringe supplied in the speaker spares kit.


## 7.18 Power Supply



**WARNING:** Voltage is always present on the system board when the computer is plugged into an active AC outlet. To avoid possible personal injury and damage to the equipment the power cord should be disconnected from the computer and/or the AC outlet before opening the computer.


---

1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).
3. Remove the security clip.



4. Rotate the drive cage up and disconnect the power cables from all of the drives.
5. Disconnect the power cables from the system board.
6. Release the power supply cable from the cable retaining clips on the bottom of the chassis under the drive cage.
7. Disconnect the hood sensor from the system board and remove the sensor from the power supply if required ([Section 7.3](#)).

8. Rotate the power supply to its full upright position ❶, then lift the power supply straight up and out of the chassis ❷.



To install the power supply, reverse the removal procedure.


---

**CAUTION:** When installing the power supply cables, make sure they are properly positioned so they are not cut by the drive cage and are not pinched by the rotating power supply.

---


## 7.19 System Board

1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).
3. Remove all PCI and PCI Express expansion boards ([Section 7.9](#)).
4. Remove the fan shroud from the chassis ([Section 7.10](#)).
5. Rotate the drive cage to its full upright position.
6. Remove the security clip ([Section 7.4.1](#)) and rotate the power supply to its full upright position.
7. Disconnect the data and power cables from the system board.







8. Disconnect the serial port from the system board.



9. Disconnect the balance of the cables from the system board.
10. Remove the long mounting screw that secures the system board tray to the chassis.




11. Slide the system board tray assembly towards the front of the chassis, about 1/4 inch and lift the system board up and out of the chassis.




12. Remove the heatsink from the system board and the system board tray ([Section 7.15](#)).  
To install the system board, reverse the removal procedure.


---

 The heatsink should be installed on the system board before the system board is reinstalled in the chassis.


---

 **CAUTION:** Before reinstalling the heatsink you must clean the top of the processor and the bottom of the heatsink with an alcohol pad supplied in the spares kit. After the alcohol has evaporated, apply thermal grease to the top of the processor from the syringe supplied in the spares kit.

---

 When reinstalling the system board it is important to secure the system board and tray to the chassis with the long retaining screw before performing any subsequent steps.

---

 **CAUTION:** When reconnecting the cables it is important that they be positioned so they do not interfere with the rotation of the drive cage or power supply.

---

## 7.20 Battery

The battery that comes with this computer provides power to the real-time clock and has a lifetime of about three years. When replacing the battery, use a battery equivalent to the battery originally installed on the computer. The computer comes with a 3-volt lithium coin cell battery.



The lifetime of the lithium battery can be extended by plugging the computer into a live AC wall socket. The lithium battery is only used when the computer is NOT connected to AC power.



**WARNING:** This computer contains an internal lithium manganese dioxide battery. There is a risk of fire and burns if the battery is not handled properly. To reduce the risk of personal injury:

- Do not attempt to recharge the battery.
- Do not expose to temperatures higher than 140°F (60°C).
- Do not disassemble, crush, puncture, short external contacts, or dispose of in fire or water.
- Replace the battery only with the HP spare designated for this product.



**CAUTION:** Before replacing the battery, it is important to back up the computer CMOS settings. When the battery is removed or replaced, the CMOS settings will be cleared. Refer to the *Computer Setup (F10) Utility Guide* for information on backing up the CMOS settings.



Batteries, battery packs, and accumulators should not be disposed of together with the general household waste. In order to forward them to recycling or proper disposal, please use the public collection system or return them to HP, their authorized partners, or their agents.



**CAUTION:** Static electricity can damage the electronic components of the computer or optional equipment. Before beginning these procedures, ensure that you are discharged of static electricity by briefly touching a grounded metal object.

1. Prepare the computer for disassembly ([Section 7.1](#)).
2. Remove the computer cover ([Section 7.5](#)).




It may be necessary to remove an expansion card to gain access to the battery.

3. Locate the battery and battery holder on the system board.
4. Carefully pull the cable bundle out of the way to access the battery.
5. Depending on the type of battery holder on your system board, complete the following instructions to replace the battery:

## 7.20.1 Type 1 Battery Holder


1. Lift the battery out of its holder.



2. Slide the replacement battery into position, positive side up.
3. The battery holder automatically secures the battery in the proper position.
4. Replace the computer access panel.
5. Plug in the computer and turn on power to the computer.
6. Reset the date and time, your passwords, and any special system setups, using Computer Setup. Refer to the *Computer Setup (F10) Utility Guide*.

## 7.20.2 Type 2 Battery Holder


1. To release the battery from its holder, squeeze the metal clamp that extends above one edge of the battery. When the battery pops up, lift it out ❶.
2. To insert the new battery, slide one edge of the replacement battery under the holder's lip with the positive side up ❷. Push the other edge down until the clamp snaps over the other edge of the battery.



3. Replace the computer access panel.
4. Plug in the computer and turn on power to the computer.
5. Reset the date and time, your passwords, and any special system setups, using Computer Setup. Refer to the *Computer Setup (F10) Utility Guide*.

### 7.20.3 Type 3 Battery Holder

1. Pull back on the clip ❶ that holds the battery in place, then remove the battery ❷.
2. Insert the new battery and position the clip back in place.




3. Replace the computer access panel.
4. Plug in the computer and turn on power to the computer.
5. Reset the date and time, your passwords, and any special system setups, using Computer Setup. Refer to the *Computer Setup (F10) Utility Guide*.


## Connector Pin Assignments

This appendix contains the pin assignments for many computer and workstation connectors. Some of these connectors may not be used on the product being serviced.


### Keyboard

Connector and Icon	Pin	Signal
	1	Data
	2	Unused
	3	Ground
	4	+5 VDC
	5	Clock
	6	Unused



### Mouse

Connector and Icon	Pin	Signal
	1	Data
	2	Unused
	3	Ground
	4	+5 VDC
	5	Clock
	6	Unused

### Ethernet BNC


Connector and Icon	Pin	Signal
	1 (Center)	Data
	2 (Shield)	Ground

### Ethernet RJ-45

Connector and Icon		Pin	Signal
 		1	(+) Transmit Data
		2	(-) Transmit Data
		3	(+) Receive Data
		4	Unused
		5	Unused
		6	(-) Receive Data
		7	Unused
		8	Unused

### Ethernet AUI

#### Connector and Icon




Pin	Signal	Pin	Signal
1	Ground	9	Positive AUI Differential Receive
2	Negative AUI Differential Collision	10	+12V
3	Positive AUI Differential Collision	11	Ground
4	Negative AUI Differential Transmit	12	Ground
5	Positive AUI Differential Transmit	13	Unused
6	Ground	14	Unused
7	Ground	15	Unused
8	Negative AUI Differential Receive	16	Unused



## Parallel Interface

### Connector and Icon



Pin	Signal	Pin	Signal	Pin	Signal
1	Strobe	7	Data Bit 5	13	Select
2	Data Bit 0	8	Data Bit 6	14	Auto Linefeed
3	Data Bit 1	9	Data Bit 7	15	Error
4	Data Bit 2	10	Acknowledge	16	Initialize Printer
5	Data Bit 3	11	Busy	17	Select IN
6	Data Bit 4	12	Paper End	18-25	Signal Ground

## Serial Interface, Powered and Non-Powered

Connector and Icon	Pin	Signal
	1	Carrier Detect (12V if powered)
	2	Receive Data
	3	Transmit Data
	4	Data Terminal Ready
	5	Signal Ground
	6	Data Set Ready
	7	Request to Send
	8	Clear to Send
	9	Ring Indicator (5V if powered)


## USB

Connector and Icon	Pin	Signal
	1	+5 VDC
	2	- Data
	3	+ Data
	4	Ground


## Microphone

Connector and Icon (1/8" miniphone)	Pin	Signal
	1 (Tip)	Audio
	2 (Ring)	Power
	3 (Shield)	Ground


### Headphone

Connector and Icon (1/8" miniphone)	Pin	Signal
	1 (Tip)	Audio_Left
	2 (Ring)	Audio_Right
	3 (Shield)	Ground

### Line-In Audio

Connector and Icon (1/8" miniphone)	Pin	Signal
	1 (Tip)	Audio_In_Left
	2 (Ring)	Audio_In_Right
	3 (Shield)	Ground

### Line-Out Audio


Connector and Icon (1/8" miniphone)	Pin	Signal
	1 (Tip)	Audio_Out_Left
	2 (Ring)	Audio_Out_Right
	3 (Shield)	Ground

### SCSI Low Voltage Differential/Single Ended (LVD/SE)

#### Connector and Icon



Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1-16	Ground	40	-D0	49-50	Ground	60	-MSG
17-18	TERMPWR	41	-D1	51-52	TERMPW	61	-SEL
19	Reserved	42	-D1	53	Reserved	62	-C/D
20-34	Ground	43	-D3	54	Ground	63	-REQ
35	-D12	44	-D4	55	-ATN	64	-I/O
36	-D13	45	-D5	56	Ground	65	-D
37	-D14	46	-D6	57	-BSY	66	-D
38	-D15	47	-D7	58	-ACK	67	-D
39	-DP1	48	-DPO	59	-RST	68	-D

**Ultra SCSI****Connector and Icon**


Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1-11	Ground	29	DB3	37	Reserved	45	RST #
12	Reserved	30	DB4	38	TERMPWR	46	MSG #
13	Open	31	DB5	39	Reserved	47	SEL #
14	Reserved	32	DB6	40	Ground	48	C/D
15-25	Ground	33	DB7	41	ATN #	49	REQ #
26	DB0	34	DBP	42	Ground	50	Input/Output
27	DB1	35	Ground	43	BSY #		
28	DB2	36	Ground	44	ACK #		

**External Infrared Transceiver****Connector and Icon**


Pin	Signal	Pin	Signal	Pin	Signal
1	Transmit	4	5V	7	Not Used
2	Receive	5	Mode	8	Not Used
3	Ground	6	Not Used		

**Monitor****Connector and Icon**

Pin	Signal	Pin	Signal	Pin	Signal
1	Red Analog	6	Ground	11	Not used
2	Green Analog	7	Ground	12	DDC Serial Data
3	Blue Analog	8	Ground	13	Horizontal Sync
4	Not used	9	+5V (fused)	14	Vertical Sync
5	Ground	10	Ground	15	DDC Serial Clock

**ATA/ATAPI (IDE) Standard Drive Cable****Connector**


Pin	Signal	Pin	Signal	Pin	Signal
1	Reset	15	DD1	29	DMAK
2	Ground	16	DD14	30	Ground
3	DD7	17	DD0	31	INTRQ
4	DD8	18	DD15	32	IOCS16
5	DD6	19	Ground	33	DA1
6	DD9	20	(Key)	34	PDIAG (cable detect)
7	DD5	21	DMARQ	35	DA0
8	DD10	22	Ground	36	DA2
9	DD4	23	DIOW	37	CS1FX
10	DD11	24	Ground	38	CS3FX
11	DD3	25	DIOR	39	DASP
12	DD12	26	Ground	40	Ground
13	DD2	27	IORDY		
14	DD13	28	CSEL		

**MultiBay CD-ROM Adapter****Connector**

Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	RESDRV_	18	D15	35	A0	52	FP05
2	GROUND	19	GROUND	36	A2	53	FP06
3	D07	20	(key)	37	CS1FX	54	FP07
4	D08	21	DRQ	38	CS3FX	55	FP08
5	D06	22	GROUND	39	DASP	56	FP09
6	D09	23	IOW	40	GROUND	57	FP10
7	D05	24	GROUND	41	+5VMLOG	58	FP11
8	D10	25	IOR	42	-5VMOT	59	FP12
9	D04	26	GROUND	43	GROUND	60	FP13
10	D11	27	IOCHDRY	44	AUDIO_L	61	FP14
11	D03	28	CABLE SELECT	45	A_GROUND_R	62	FP15
12	D12	29	DAK	46	A_GROUND_I	63	FP16
13	D02	30	GROUND	47	audio_r	64	FP17
14	D13	31	IRQ	48	FP01	65	FP18
15	D01	32	IO16	49	FP02	66	FP19
16	D14	33	A1	50	FP03	67	FP20
17	D00	34	PDIAG	51	FP04	68	FP21

## 24-Pin Power


### Connector



Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	+3.3 V	7	GND	13	+3.3 V	19	GND
2	+3.3 V	8	POK	14	-12 V	20	open
3	GND	9	+5 V <sub>aux</sub>	15	GND	21	+5 V
4	+5 V	10	+12 V	16	PSON	22	+5 V
5	GND	11	+12 V	17	GND	23	+5 V
6	+5 V	12	+3.3 V	18	GND	24	GND

## 24-Pin MicroFit Power


### Connector



Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	+5 V <sub>aux</sub>	7	PWRGD	13	+12 V	19	GND
2	GND	8	+3.3 V	14	+5 V Sense	20	+3.3 Sense
3	+5 V	9	+3.3 V	15	GND	21	+3.3 V
4	+5 V	10	Tach	16	+5 V	22	+3.3 V
5	PS_ON	11	GND	17	+5 V	23	GND
6	GND	12	Fan-CMD	18	+3.3 V	24	-12 V

## 4-Pin Power (for CPU)


### Connector and Icon



### Pin Signal


1	GND
2	GND
3	+12 V CPU
4	-12 V CPU

### 6-Pin Power (for CPU)

Connector and Icon	Pin	Signal
	1	GND
	2	GND
	3	GND
	4	12 V CPU
	5	12 V CPU
	6	+12 V

### SATA Data and Power

#### Drive Connector



Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
S1	Ground	S2	A+	S3	A-	S4	Ground
S5	B-	S6	B+	S7	Ground		
P1	V 3.3	P2	V 3.3	P3	V 3.3	P4	Ground
P5	Ground	P6	Ground	P7	V 5	P8	V 5
P9	V 5	P10	Ground	P11	Reserved	P12	Ground
P13	V 12	P14	V 12	P15	V 12		

\*S = Data, P = Power

## PCI Express

### x1, x4, x8, and x16 PCI Express Connector



#### Pin A

Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	PRSNT1#	6	JTAG3	11	PERST#	16	PERp0	21	PERp1
2	+12V	7	JTAG4	12	GND	17	PERn0	22	PERn1
3	+12V	8	JTAG5	13	REFCLK+	18	GND	23	GND
4	GND	9	+3.3v	14	REFCLK-	19	RSVD	24	GND
5	JTAG2	10	+3.3v	15	GND	20	GND	25	PERp2
26	PERn(2)	31	GND	36	PERn4	41	GND	46	GND
27	GND	32	RSVD	37	GND	42	GND	47	PERp7
28	GND	33	RSVD	38	GND	43	PERp6	48	PERn7
29	PERp3	34	GND	39	PERp5	44	PERn6	49	GND
30	PERn3	35	PERp4	40	PERn5	45	GND	50	RSVD
51	GND	56	PERp9	61	PERn10	66	GND	71	GND
52	PERp8	57	PERn9	62	GND	67	GND	72	PERp13
53	PERn8	58	GND	63	GND	68	PERp12	73	PERn13
54	GND	59	GND	64	PERp11	69	PERn12	74	GND
55	GND	60	PERp10	65	PERn11	70	GND	75	GND
76	PERp14	81	PERn15						
77	PERn14	82	GND						
78	GND								
79	GND								
80	PERp15								

#### Pin B information is on the next page

##### Notes:

- x1 PCI Express uses pins 1-18
- x4 PCI Express uses pins 1-32
- x8 PCI Express uses pins 1-49
- x16 PCI Express uses pins 1-82

## PCI Express

### x1, x4, x8, and x16 PCI Express Connector



#### Pin B

Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
1	+12V	6	SMDAT	11	WAKE#	16	GND	21	GND
2	+12V	7	GND	12	RSVD	17	PRSNT2#	22	GND
3	RSVD	8	+3.3v	13	GND	18	GND	23	PETp2
4	GND	9	JTAG1	14	PETp0	19	PETp1	24	PETn2
5	SMCLK	10	3.3vAux	15	PETn0	20	PETn1	25	GND
26	GND	31	PRSNT2#	36	GND	41	PETp6	46	PETn7
27	PETp3	32	GND	37	PETp5	42	PRTn6	47	GND
28	PETn3	33	PETp4	38	PETn5	43	GND	48	PRSNT2#
29	GND	34	PETn4	39	GND	44	GND	49	GND
30	RSVD	35	GND	40	GND	45	PETp7	50	PETp8
51	PETn8	56	GND	61	GND	66	PETp12	71	PETn13
52	GND	57	GND	62	PETp11	67	PETn12	72	GND
53	GND	58	PETp10	63	PETn11	68	GND	73	GND
54	PETp9	59	PETn10	64	GND	69	GND	74	PETp14
55	PETn9	60	GND	65	GND	70	PETp13	75	PETn14
76	GND	81	PRSNT2#						
77	GND	82	RSVD						
78	PETp15								
79	PETn15								
80	GND								


#### Notes:

- x1 PCI Express uses pins 1-18
- x4 PCI Express uses pins 1-32
- x8 PCI Express uses pins 1-49
- x16 PCI Express uses pins 1-82



## DVI Connector

### Connector and Icon



Pin	Signal	Pin	Signal
1	T.M.D.S. Data2-	13	T.M.D.S. Data3+
2	T.M.D.S. Data2+	14	+5V Power
3	T.M.D.S. Data2/4 Shield	15	Ground (for +5V)
4	T.M.D.S. Data4-	16	Hot Plug Detect
5	T.M.D.S. Data4+	17	T.M.D.S. Data0-
6	DDC Clock	18	T.M.D.S. Data0+
7	DDC Data	19	T.M.D.S. Data0/5 Shield
8	No Connect	20	T.M.D.S. Data5-
9	T.M.D.S. Data1-	21	T.M.D.S. Data5+
10	T.M.D.S. Data1+	22	T.M.D.S. Data Shield
11	T.M.D.S. Data1/3 Shield	23	T.M.D.S. Clock+
12	T.M.D.S. Data3-	24	T.M.D.S. Clock-



---

## Power Cord Set Requirements

The power supplies on some computers have external power switches. The voltage select switch feature on the computer permits it to operate from any line voltage between 100-120 or 220-240 volts AC. Power supplies on those computers that do not have external power switches are equipped with internal switches that sense the incoming voltage and automatically switch to the proper voltage.

The power cord set received with the computer meets the requirements for use in the country where you purchased the equipment.

Power cord sets for use in other countries must meet the requirements of the country where you use the computer.

### General Requirements

The requirements listed below are applicable to all countries:

1. The power cord must be approved by an acceptable accredited agency responsible for evaluation in the country where the power cord set will be installed.
2. The power cord set must have a minimum current capacity of 10A (7A Japan only) and a nominal voltage rating of 125 or 250 volts AC, as required by each country's power system.
3. The diameter of the wire must be a minimum of 0.75 mm<sup>2</sup> or 18AWG, and the length of the cord must be between 1.8 m (6 feet) and 3.6 m (12 feet).

The power cord should be routed so that it is not likely to be walked on or pinched by items placed upon it or against it. Particular attention should be paid to the plug, electrical outlet, and the point where the cord exits from the product.



**WARNING:** Do not operate this product with a damaged power cord set. If the power cord set is damaged in any manner, replace it immediately.

---

### Japanese Power Cord Requirements

For use in Japan, use only the power cord received with this product.



**CAUTION:** Do not use the power cord received with this product on any other products.

---

## Country-Specific Requirements

Additional requirements specific to a country are shown in parentheses and explained below.

Country	Accrediting Agency	Country	Accrediting Agency
Australia (1)	EANSW	Italy (1)	IMQ
Austria (1)	OVE	Japan (3)	METI
Belgium (1)	CEBC	Norway (1)	NEMKO
Canada (2)	CSA	Sweden (1)	SEMKO
Denmark (1)	DEMKO	Switzerland (1)	SEV
Finland (1)	SETI	United Kingdom (1)	BSI
France (1)	UTE	United States (2)	UL
Germany (1)	VDE		

1. The flexible cord must be <HAR> Type HO5VV-F, 3-conductor, 0.75mm<sup>2</sup> conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country where it will be used.
2. The flexible cord must be Type SVT or equivalent, No. 18 AWG, 3-conductor. The wall plug must be a two-pole grounding type with a NEMA 5-15P (15A, 125V) or NEMA 6-15P (15A, 250V) configuration.
3. Appliance coupler, flexible cord, and wall plug must bear a "T" mark and registration number in accordance with the Japanese Dentori Law. Flexible cord must be Type VCT or VCTF, 3-conductor, 0.75 mm<sup>2</sup> conductor size. Wall plug must be a two-pole grounding type with a Japanese Industrial Standard C8303 (7A, 125V) configuration.

---

## POST Error Messages

### POST Error Messages

An error message results if the Power-On Self-Test (POST) encounters a problem. This test runs when the system is turned on, checking assemblies within the computer and reporting any errors found.

Not all computers use all of the codes listed.

#### POST Error Messages

Screen Message	Probable Cause	Recommended Action
101-Option ROM Checksum Error	System ROM or expansion board option ROM checksum.	<p>Verify the correct ROM.</p> <p>Flash the ROM if needed.</p> <p>If an expansion card was recently added, remove it and see if the problem remains.</p> <p>Clear CMOS.</p> <p>If the message disappears, there may be a problem with the expansion card.</p> <p>Replace the system board.</p>
103-System Board Failure	DMA or timers.	<p>Clear CMOS.</p> <p>Remove expansion boards.</p> <p>Replace the system board.</p>
110-Out of Memory Space for Option ROMs	Recently added PCI expansion card contains an option ROM too large to download during POST.	<p>If a PCI expansion card was recently added, remove it to see if the problem remains.</p> <p>In Computer Setup, disable the NIC PXE Option ROM Download to prevent PXE option ROM for the internal NIC from being downloaded during POST to free more memory for an expansion card's option ROM. Internal PXE option ROM is used for booting from the NIC to a PXE server.</p> <p>Ensure that the ACPI/USB Buffers @ Top of Memory setting in Computer Setup is enabled.</p>

**POST Error Messages** (Continued)

<b>Screen Message</b>	<b>Probable Cause</b>	<b>Recommended Action</b>
162-System Options Not Set	Configuration incorrect. RTC (real-time clock) battery may need to be replaced.	Run Computer Setup (F10 Setup) and check configuration of <b>Onboard Devices</b> . Set the date and time under <b>Control Panel</b> or in F10 Setup depending on the operating system. If the problem persists, replace the RTC battery.
163-Time & Date Not Set	Invalid time or date in configuration memory. RTC (real-time clock) battery may need to be replaced.	Set the date and time under <b>Control Panel</b> or in F10 Setup depending on the operating system. If the problem persists, replace the RTC battery.
	CMOS jumper may not be properly installed.	Check for proper placement of the CMOS jumper, if applicable.
164-Memory Size Error	Memory amount has changed since the last boot (memory added or removed).	Press the <b>F1</b> key to save the memory changes.
	Memory configuration is incorrect.	Run Computer Setup (F10 Setup). Make sure memory module(s) (if any) are installed properly. If third party memory has been added, test using HP-only memory. Verify proper memory module type.
201-Memory Error	RAM failure.	Run Computer Setup (F10 Setup) or Windows utilities. Ensure memory and continuity modules are installed correctly. Verify proper memory module type. Remove and replace the identified faulty memory module(s). If the error persists after replacing memory modules, replace the system board.
202-Memory Type Mismatch	Memory modules do not match each other.	Replace memory modules with matched sets.

**POST Error Messages** (Continued)

<b>Screen Message</b>	<b>Probable Cause</b>	<b>Recommended Action</b>
207-ECC Corrected Single Bit Errors in DIMM slot(s)	Memory module is experiencing correctable errors.	<p>If additional memory was recently added, remove it to see if the problem remains.</p> <p>If memory module was not recently installed and frequency of error message increases, consider replacing the module.</p> <p>Check product documentation for memory support information.</p>
213-Incompatible memory Module in memory Socket(s) X,X, X	A memory module in memory socket identified in the error message is missing critical SPD information, or is incompatible with the chipset.	<p>Verify proper memory module type.</p> <p>Try another memory socket.</p> <p>Replace memory with a module conforming to the SPD standard.</p>
214-DIMM Configuration Warning	Populated DIMM configuration is not optimized.	Rearrange the DIMMS so that each channel has the same amount of memory.
216-Memory Size Exceeds Maximum Supported	Recently added memory module(s) exceeds the supported memory amount for the system.	<p>If additional memory was recently added, remove it to see if the problem remains.</p> <p>Check product documentation for memory support information.</p>
219-ECC Memory Module Detected. ECC Modules not supported on this platform	Recently added memory module(s) support ECC memory error correction.	<p>If additional memory was recently added, remove it to see if the problem remains.</p> <p>Check product documentation for memory support information.</p>
301-Keyboard Error	Keyboard failure.	<p>Reconnect keyboard with computer turned off.</p> <p>Check connector for bent or missing pins.</p> <p>Ensure that none of the keys are depressed.</p> <p>Replace keyboard.</p>
303-Keyboard Controller Error	I/O board keyboard controller.	<p>Reconnect keyboard with computer turned off.</p> <p>Replace the system board.</p>

**POST Error Messages** (Continued)

<b>Screen Message</b>	<b>Probable Cause</b>	<b>Recommended Action</b>
304-Keyboard or System Unit Error	Keyboard failure.	Reconnect the keyboard with computer turned off. Ensure that none of the keys are depressed. Replace keyboard. Replace system board.
404-Parallel Port Address Conflict Detected	Both external and internal ports are assigned to parallel port X.	Remove any parallel port expansion cards. Clear CMOS. Reconfigure card resources and/or run Computer Setup.
410-Audio Interrupt Conflict	IRQ address conflicts with another device.	Enter Computer Setup and reset the IRQ in <b>Advanced &gt; Onboard Devices</b> .
411-Network Interface Card Interrupt Conflict	IRQ address conflicts with another device.	Enter Computer Setup and reset the IRQ in <b>Advanced &gt; Onboard Devices</b> .
501-Display Adapter Failure	Graphics display controller.	Reseat the graphics card (if applicable). Clear CMOS. Verify that the monitor is attached and turned on. Replace the graphics card (if applicable).
510-Splash Screen image corrupted	Splash Screen image has errors.	Reflash the system ROM with the latest BIOS image
511-CPU, CPUA, or CPUB Fan not detected	Fan is not connected or may have malfunctioned.	Reseat fan cable. Reseat the fan. Replace the fan.
512-Chassis, rear chassis, or front chassis fan not detected	Fan is not connected, may have malfunctioned.	Reseat chassis, rear chassis, or front chassis fan cable. Reseat chassis, rear chassis, or front chassis fan. Replace chassis, rear chassis, or front chassis fan.
514-CPU or Chassis Fan not detected.	CPU or chassis fan is not connected or may have malfunctioned.	Reseat CPU or chassis fan. Reseat fan cable. Replace CPU or chassis fan.
601-Diskette Controller Error	Diskette controller circuitry or floppy drive circuitry incorrect.	Run Computer Setup (F10 Setup). Check and/or replace cables. Clear CMOS. Replace diskette drive. Replace the system board.



**POST Error Messages** (Continued)

<b>Screen Message</b>	<b>Probable Cause</b>	<b>Recommended Action</b>
605-Diskette Drive Type Error	Mismatch in drive type.	Run Computer Setup (F10 Setup). Disconnect any other diskette controller devices (tape drives). Clear CMOS.
610-External Storage Device Failure	External tape drive not connected.	Reinstall tape drive or press <b>F1</b> and allow system to reconfigure without the drive.
611-Primary Floppy Port Address Assignment Conflict	Configuration error.	Run Computer Setup and check the configuration in <b>Advanced &gt; Onboard Devices</b> .
660-Display cache is detected unreliable	Integrated graphics controller display cache is not working properly and will be disabled.	Replace system board if minimal graphics degrading is an issue.
912-Computer Cover Has Been Removed Since Last System Start Up	Computer cover was removed since the last system startup.	No action required.
914-Hood Lock Coil is NOT connected	Smart Cover Lock mechanism is missing or not connected.	Reconnect or replace hood locking mechanism. Reseat or replace hood locking mechanism cable.
917-Front Audio not Detected	Front audio harness has been detached or unseated from the system board.	Reconnect or replace front audio harness.
918-Front USB Not Connected	Front USB harness has been detached or unseated from system board.	Reconnect or replace front USB harness.
919-Front Panel, MultiPort, and/or MultiBay Risers not Detected.	Riser card has been removed or has not been reinstalled properly in the system.	Unplug computer and install/reinstall riser cord.
921-Device in PCI Express slot failed to initialize.	There is an incompatibility/problem with this device and the system or PCI Express Link could not be retrained to an x1.	Try rebooting the system. If the error reoccurs, the device may not work with this system.
1151-Serial Port A Address Conflict Detected	Both external and internal serial ports are assigned to COM1.	Remove any serial port expansion cards. Clear CMOS. Reconfigure card resources and/or run Computer Setup or Windows utilities.

**POST Error Messages** (Continued)

<b>Screen Message</b>	<b>Probable Cause</b>	<b>Recommended Action</b>
1152-Serial Port B Address Conflict Detected	Both external and internal serial ports are assigned to COM2.	Remove any serial port expansion cards. Clear CMOS. Reconfigure card resources and/or run Computer Setup or Windows utilities.
1155-Serial Port Address Conflict Detected	Both external and internal serial ports are assigned to same IRQ.	Remove any serial port expansion cards. Clear CMOS. Reconfigure card resources and/or run Computer Setup or Windows utilities.
1201-System Audio Address Conflict Detected	Device IRQ address conflicts with another device.	Enter Computer Setup and reset the IRQ in <b>Advanced &gt; Onboard Devices</b> .
1202-MIDI Port Address Conflict Detected	Device IRQ address conflicts with another device.	Enter Computer Setup and reset the IRQ in <b>Advanced &gt; Onboard Devices</b> .
1203-Game Port Address Conflict Detected	Device IRQ address conflicts with another device.	Enter Computer Setup and reset the IRQ in <b>Advanced &gt; Onboard Devices</b> .
1720-SMART Hard Drive Detect Imminent Failure	Hard drive is about to fail. (Some hard drives have a firmware patch that will fix an erroneous error message.)	Determine if hard drive is giving correct error message. Run the Drive Protection System test if applicable. Apply firmware patch if applicable. (visit <a href="http://www.hp.com/support">www.hp.com/support</a> ) Back up contents and replace hard drive.
1785-MultiBay incorrectly installed	<i>(for integrated MultiBay/USDT systems)</i> MultiBay device not properly seated. or MultiBay riser not properly seated.	Ensure the MultiBay device is fully inserted. Ensure the MultiBay riser is properly seated.
1794-Inaccessible devices attached to SATA 1 and/or SATA 3	A device is attached to SATA 1 and/or SATA 3. Devices attached to these connectors will be inaccessible while "SATA Emulation" is set to "Combined IDE Controller" in Computer Setup.	If using Windows 2000 or Windows XP, change "SATA Emulation" to "Separate IDE Controller" in Computer Setup. If not using Windows 2000 or Windows XP, relocate the affected devices to SATA 0 or SATA 2 (if available). Remove the affected devices from SATA 1 and SATA 3.

**POST Error Messages** (Continued)

<b>Screen Message</b>	<b>Probable Cause</b>	<b>Recommended Action</b>
1796-SATA Cabling Error	One or more SATA devices are improperly attached. For optimal performance, the SATA 0 and SATA 1 connectors must be used before SATA 2 and SATA 3.	Ensure SATA connectors are used in ascending order. For one device, use SATA 0. For two devices, use SATA 0 and SATA 1. For three devices, use SATA 0, SATA 1, and SATA 2.
1800-Temperature Alert	Internal temperature exceeds specification.	Check that computer air vents are not blocked and the processor cooling fan is running. Verify processor speed selection. Replace the processor. Replace the system board.
1801-Microcode Patch Error	Processor not supported by ROM BIOS.	Upgrade BIOS to proper version. Change the processor.
1802-Processor Not Supported	Recently installed processor may not be supported by the system board.	If processor was recently replaced, restore the original processor to see if the problem remains. Check product documentation for processor support information.
Invalid Electronic Serial Number.	Electronic serial number has become corrupted.	Run Computer Setup. If Setup already has data in the field or will not allow the serial number to be entered, download from <a href="http://www.hp.com">http://www.hp.com</a> and run SP5572.EXE (SNZERO.EXE). Run Computer Setup and try to enter serial number under Security, System ID, then save changes.

**POST Error Messages** *(Continued)*

<b>Screen Message</b>	<b>Probable Cause</b>	<b>Recommended Action</b>
Network Server Mode Active and No Keyboard Attached	Keyboard failure while Network Server Mode enabled.	Reconnect keyboard with computer turned off. Check connector for bent or missing pins. Ensure that none of the keys are depressed. Replace keyboard.
Parity Check 2	Parity RAM failure.	Run Computer Setup and diagnostic utilities.
System will not boot without fan.	CPU fan not installed or disconnected in VSFF chassis.	Open hood, press the power button, and see if the processor fan spins. If not spinning, make sure the fan cable is plugged into the system board. Ensure the heatsink is properly seated. If the heatsink is properly installed and the fan connected but does not spin, replace the heatsink-fan assembly.

## POST Diagnostic Front Panel LEDs and Audible Codes

This section covers the front panel LED codes as well as the audible codes that may occur before or during POST that do not necessarily have an error code or text message associated with them.



If you see flashing LEDs on a PS/2 keyboard, look for flashing LEDs on the front panel of the computer and refer to the following table to determine the front panel LED codes.



Recommended actions in the following table are listed in the order in which they should be performed.



Beeps will occur only for 5 iterations and then stop. LEDs will continue to blink until corrective action is taken.

### POST Diagnostic Front Panel LEDs and Audible Codes

Activity	Beeps	Possible Cause	Recommended Action
Green Power LED On.	None	Computer on.	None
Green Power LED flashes every two seconds.	None	Computer in Suspend to RAM mode (some models only) or normal Suspend mode.	None required. Press any key or move the mouse to wake the computer.
Red Power LED flashes two times, once every second, followed by a two second pause.	2	Processor thermal protection activated: A fan may be blocked or not turning. OR The heatsink/fan assembly is not properly attached to the processor.	Ensure that the computer air vents are not blocked and the processor cooling fan is running. Open hood, press power button, and see if the processor fan spins. If the processor fan is not spinning, make sure the fan's cable is plugged onto the system board header. Ensure the fan is fully/properly seated or installed. If fan is plugged in and seated properly, but is not spinning, then replace processor fan. Reseat processor heatsink and verify that the fan assembly is properly attached. Contact an authorized reseller or service provider.
Red Power LED flashes three times, once every second, followed by a two second pause.	3	Processor not installed (not an indicator of bad processor).	Check to see that the processor is present. Reseat the processor.

**POST Diagnostic Front Panel LEDs and Audible Codes** (Continued)

<b>Activity</b>	<b>Beeps</b>	<b>Possible Cause</b>	<b>Recommended Action</b>
Red Power LED flashes four times, once every second, followed by a two second pause.	4	Power failure (power supply is overloaded).	<p>Open the hood and ensure the power supply cable is seated into the connector on the system board.</p> <p>Check if a device is causing the problem by removing ALL attached devices (such as hard, diskette, or optical drives, and expansion cards). Power on the system. If the system enters the POST, then power off and replace one device at a time and repeat this procedure until failure occurs. Replace the device that is causing the failure. Continue adding devices one at a time to ensure all devices are functioning properly.</p> <p>Replace the power supply. Replace the system board.</p>
Red Power LED flashes five times, once every second, followed by a two second pause.	5	Pre-video memory error.	<p>Reseat DIMMs. Power on the system.</p> <p>Replace DIMMs one at a time to isolate the faulty module.</p> <p>Replace third-party memory with HP memory.</p> <p>Replace the system board.</p>
Red Power LED flashes six times, once every second, followed by a two second pause.	6	Pre-video graphics error.	<p>For systems with a graphics card: Reseat the graphics card. Power on the system.</p> <p>Replace the graphics card.</p> <p>Replace the system board.</p> <p>For systems with integrated graphics, replace the system board.</p>
Red Power LED flashes seven times, once every second, followed by a two second pause.	7	System board failure (ROM detected failure prior to video).	Replace the system board.
Red Power LED flashes eight times, once every second, followed by a two second pause.	8	Invalid ROM based on bad checksum.	<p>Reflash the ROM with the latest BIOS image. See the "ROM Flash" section of the <i>Desktop Management Guide</i> on the <i>Documentation and Diagnostics</i> CD.</p> <p>Replace the system board.</p>

**POST Diagnostic Front Panel LEDs and Audible Codes** (Continued)

<b>Activity</b>	<b>Beeps</b>	<b>Possible Cause</b>	<b>Recommended Action</b>
Red Power LED flashes nine times, once every second, followed by a two second pause.	9	System powers on but is unable to boot.	<p>Check that the voltage selector, located on the rear of the power supply (some models), is set to the appropriate voltage. Proper voltage setting depends on your region.</p> <p>Replace the power supply.</p> <p>Replace the system board.</p> <p>Replace the processor.</p>
Red Power LED flashes ten times, once every second, followed by a two second pause.	10	Bad option card.	<p>Check each option card by removing the card (one at a time if multiple cards), then power on the system to see if fault goes away.</p> <p>Once a bad card is identified, remove and replace the bad option card.</p> <p>Replace the system board.</p>
System does not power on and LEDs are not flashing.	None	System unable to power on.	<p>Press and hold the power button for less than 4 seconds. If the hard drive LED turns green, then:</p> <p>Check that the voltage selector, located on the rear of the power supply, is set to the appropriate voltage. Proper voltage setting depends on your region.</p> <p>Remove the expansion cards one at a time until the LED light on the system board turns on.</p> <p>Replace the system board.</p> <p>OR</p> <p>Press and hold the power button for less than 4 seconds. If the hard drive LED does not turn on green then:</p> <p>Check that the unit is plugged into a working AC outlet.</p> <p>Open hood and check that the power button harness is properly connected to the system board.</p> <p>Check that both power supply cables are properly connected to the system board.</p> <p>Check to see if the LED light on the system board is turned on. If it is turned on, then replace the power button harness.</p> <p>If the LED light on the system board is not turned on, then replace the power supply.</p> <p>Replace the system board.</p>





---

# Troubleshooting Without Diagnostics


## Preliminary Checklist

This section describes some simple, preliminary tests and guidelines for troubleshooting the computer without using the diagnostics.

- Are the computer and monitor connected to a working electrical outlet?
- Is the voltage select switch is set to the appropriate voltage for your region (115V or 230V)?
- Is the computer turned on?
- Is the green power light illuminated?
- Is the monitor turned on?
- Is the green monitor light illuminated?
- Turn up the monitor brightness and contrast controls if the monitor is dim.
- If the system has multiple video sources (embedded, PCI, or PCI-Express adapters) installed (embedded video on some models only) and a single monitor, the monitor must be plugged into the monitor connector on the source selected as the primary VGA adapter. During boot, the other monitor connectors are disabled and if the monitor is connected into these ports, the monitor will not function. You can select which source will be the default VGA source in Computer (F10) Setup.
- Press and hold any key. If the system beeps, then the keyboard is operating correctly.
- Check all cables for loose or incorrect connections.
- Reconfigure the computer after installing a non-Plug and Play expansion board or other option, such as a diskette drive.
- Are all of the necessary device drivers installed?
- Have all printer drivers been installed for each application?
- Remove all bootable media (diskette, CD, or USB device) from the system before turning on the system.
- Are all switches set correctly?
- Is the NIC Remote Wakeup cable (featured on some models) connected between the NIC and the riser/system board?

## Solving Minor Problems

### Solving Minor Problems

Problem	Cause	Possible Solution
Computer appears locked up and will not turn off when the power button is pressed.	Software control of the power switch is not functional.	<ol style="list-style-type: none"> <li>1. Press and hold the power button for at least four seconds until the computer turns off.</li> <li>2. Disconnect electrical plug from outlet.</li> </ol>
Computer will not respond to USB keyboard or mouse.	Computer is in <b>standby</b> mode.	Press the power button to resume from <b>standby</b> mode.
	System has locked up.	Restart computer.
<p> <b>CAUTION:</b> When attempting to resume from <b>standby</b> mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and you will lose any unsaved data.</p>		
Computer date and time display is incorrect.	RTC (real-time clock) battery may need to be replaced.	<ol style="list-style-type: none"> <li>1. Reset the date and time under <b>Control Panel</b>.</li> <li>2. Replace the RTC battery.</li> </ol>
Computer appears to pause periodically.	Network driver is loaded and no network connection is established.	Establish a network connection, or use Computer Setup or Microsoft Windows Device Manager to disable the network controller.
Cursor will not move using the arrow keys on the keypad.	The <b>Num Lock</b> key may be on.	Press the <b>Num Lock</b> key. The <b>Num Lock</b> key can be disabled (or enabled) in Computer Setup.
Cannot remove computer cover or access panel.	Smart Cover Lock, featured on some computers, is locked.	<ol style="list-style-type: none"> <li>1. Unlock the Smart Cover Lock using Computer Setup.</li> <li>2. Use the Smart Cover FailSafe Key in case of forgotten password, power loss, or computer malfunction.</li> </ol>
Poor performance is experienced.	Processor is hot.	<ol style="list-style-type: none"> <li>1. Ensure airflow to the computer is not blocked.</li> <li>2. Ensure the fans are connected and working properly (some fans only operate when needed).</li> <li>3. Ensure the processor heatsink is installed properly.</li> </ol>
	Hard drive is full.	Transfer data from the hard drive to create more space on the hard drive.
	Low on memory.	Add more memory.
	Hard drive fragmented.	Defragment hard drive.

**Solving Minor Problems** *(Continued)*

<b>Problem</b>	<b>Cause</b>	<b>Possible Solution</b>
Poor performance is experienced. (continued)	Program previously accessed did not release reserved memory back to the system	Restart the computer.
	Virus resident of the hard drive.	Run virus protection program.
	Too many applications running.	<ol style="list-style-type: none"> <li>1. Close unnecessary applications.</li> <li>2. Add more memory.</li> </ol>
	Some software applications, especially games, are stressful on the graphics subsystem.	<ol style="list-style-type: none"> <li>1. Lower the display resolution for the current application or consult the documentation that came with the application for suggestions on how to improve performance by adjusting parameters in the application.</li> <li>2. Add more memory.</li> <li>3. Upgrade the graphics solution.</li> </ol>
	Cause unknown.	Restart the computer.
Computer powered off automatically and the Power LED flashes Red two times, once every second, followed by a two second pause, and the computer beeps two times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	<p>Processor thermal protection activated: A fan may be blocked or not turning. OR The heatsink is not properly attached to the processor.</p>	<ol style="list-style-type: none"> <li>1. Ensure computer air vents are not blocked and the cooling fan is running.</li> <li>2. Open hood, press power button, and see if the processor fan spins. If not spinning, make sure the fan's cable is plugged onto the system board header. Ensure the fan is fully/properly seated or installed.</li> <li>3. Replace the processor heatsink-fan assembly.</li> <li>4. Reseat processor heatsink-fan assembly and verify that the fan is properly connected to the system board.</li> </ol>

### Solving Minor Problems (Continued)

Problem	Cause	Possible Solution
System does not power on and the LEDs on the front of the computer are not flashing.	System unable to power on.	<p>Press and hold the power button for less than 4 seconds. If the hard drive LED turns green, then:</p> <ol style="list-style-type: none"> <li>1. Check that the voltage selector (some models) is set to the appropriate voltage.</li> <li>2. Remove the expansion cards one at a time until the 5 V<sub>aux</sub> light on the system board turns on.</li> <li>3. Replace the system board.</li> </ol> <p>OR</p> <p>Press and hold the power button for less than 4 seconds. If the hard drive LED does not turn on green then:</p> <ol style="list-style-type: none"> <li>1. Check that the unit is plugged into a working AC outlet.</li> <li>2. Open hood and check that the power button harness is properly connected to the system board.</li> <li>3. Check that both power supply cables are properly connected to the system board.</li> <li>4. If the 5 V<sub>aux</sub> light on the system board is on, then replace the power button harness.</li> <li>5. If the 5 V<sub>aux</sub> light on the system board is off, then replace the power supply.</li> <li>6. Replace the system board.</li> </ol>

# Solving Power Supply Problems

## Solving Power Supply Problems


Problem	Cause	Solution
Power supply shuts down intermittently.	Voltage selector switch on rear of computer chassis (some models) is not switched to correct line voltage.	Select the proper AC voltage.
	Power supply fault.	Replace the power supply.
Computer powered off automatically and the Power LED flashes Red two times, once every second, followed by a two second pause, and the computer beeps two times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	Processor thermal protection activated: A fan may be blocked or not turning. OR The heatsink/fan assembly is not properly attached to the processor.	<ol style="list-style-type: none"> <li>1. Ensure that the computer air vents are not blocked and the cooling fan is running.</li> <li>2. Open hood, press the power button, and see if the processor fan spins. If the processor fan is not spinning, make sure the fan's cable is plugged onto the system board header. Ensure the fan is fully/properly seated or installed.</li> <li>3. If the fan is pugged in and seated but not spinning, replace the processor fan.</li> <li>4. Reseat processor heatsink and verify that the fan assembly is properly attached.</li> </ol>
	Power failure (power supply is overloaded).	<ol style="list-style-type: none"> <li>1. Check that the voltage selector (some models), is set to the appropriate voltage.</li> <li>2. Open the hood and ensure the 4- or 6-wire power supply cable is seated into the connector on the system board.</li> <li>3. Check if a device is causing the problem by removing ALL attached devices. Power on the system. If the system enters the POST, then power off and replace one device at a time and repeat this procedure until failure occurs. Replace the device causing the failure. Continue adding devices one at a time to ensure all devices are functioning properly.</li> <li>4. Replace the power supply.</li> <li>5. Replace the system board.</li> </ol>
Power LED flashes Red, four times, once every second, followed by a two second pause, and the computer beeps four times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.		

## Solving Diskette Problems

### Solving Diskette Problems

Problem	Cause	Solution
Diskette drive light stays on.	Diskette is damaged.	In Microsoft Windows XP, right-click <b>Start</b> , click <b>Explore</b> , and select a drive. Select <b>File &gt; Properties &gt; Tools</b> . Under <b>Error-checking</b> , click <b>Check Now</b> .
	Diskette is incorrectly inserted.	Remove diskette and reinsert.
	Drive button is not pushed in.	Push in drive button.
	Files on diskette are damaged.	Check the program diskettes.
	Drive cable is not properly connected.	Reconnect power cable. Ensure that all four pins are connected.
Drive not found.	Cable is loose.	Reseat diskette drive data and power cables.
	Removable drive is not seated properly.	Reseat the drive.
Diskette drive cannot write to a diskette.	Diskette is not formatted.	Format the diskette.
	Diskette is write-protected.	Use another diskette or remove the write protection.
	Writing to the wrong drive.	Check the drive letter in the path statement.
	Not enough space is left on the diskette.	Use another diskette.
	Diskette write control is enabled.	Use Computer Setup to check the storage security feature disabled settings.
	Diskette is damaged.	Replace the damaged diskette.
Cannot format diskette.	Invalid media reported.	When formatting a disk in MS-DOS, you may need to specify diskette capacity. For example, to format a 1.44-MB diskette, type the following command at the MS-DOS prompt: <b>FORMAT A: /F:1440</b>
	Diskette is write-protected.	Use another diskette or remove the write protection.
	Diskette write control is enabled.	Use Computer Setup to check the storage security feature disabled settings.

### Solving Diskette Problems (Continued)

Problem	Cause	Solution
A problem has occurred with a disk transaction.	The directory structure is bad, or there is a problem with a file.	In Windows XP, right-click <b>Start</b> , click <b>Explore</b> , and select a drive. <b>Select File &gt; Properties &gt; Tools</b> . Under <b>Error-checking</b> , click <b>Check Now</b> .
Diskette drive cannot read a diskette.	Diskette is not formatted.	Format the diskette.
	You are using the wrong diskette type for the drive type.	Check the type of drive that you are using and use the correct diskette type.
	You are reading the wrong drive.	Check the drive letter in the path statement.
	Diskette is damaged.	Replace the diskette with a new one.
"Invalid system disk" message is displayed.	A diskette that does not contain the system files needed to start the computer has been inserted in the drive.	When drive activity stops, remove the diskette and press the <b>Spacebar</b> . The computer should start up.
	Diskette error has occurred.	Restart the computer by pressing the power button.
Cannot Boot to Diskette.	Diskette is not bootable.	Replace with a bootable diskette.
	Diskette boot has been disabled in Computer Setup.	Run Computer Setup and enable diskette boot in <b>Storage &gt; Boot Order</b> . Run Computer Setup and enable Removable Media Boot in <b>Storage &gt; Storage Options &gt; Removable Media Boot</b> .  Both steps should be used as the <b>Removable Media Boot</b> function overrides the <b>Boot Order</b> enable command.
	Removable media boot has been disabled in Computer Setup.	Run Computer Setup and enable Removable Media Boot in <b>Storage &gt; Storage Options &gt; Removable Media Boot</b> .
	Network server mode is enabled in Computer Setup.	Run Computer Setup and disable <b>Network Server Mode</b> in <b>Security &gt; Password Options</b> .

## Solving Hard Drive Problems

Solving Hard Drive Problems		
Problem	Cause	Solution
Hard drive error occurs.	Hard disk has bad sectors or has failed.	Use a utility to locate and block usage of bad sectors. If necessary, reformat the hard disk.  In Windows XP, right-click <b>Start</b> , click <b>Explore</b> , and select a drive. Select <b>File &gt; Properties &gt; Tools</b> . Under <b>Error-checking</b> , click <b>Check Now</b> .
Disk transaction problem.	Either the directory structure is bad or there is a problem with a file.	In Windows XP, right-click <b>Start</b> , click <b>Explore</b> , and select a drive. Select <b>File &gt; Properties &gt; Tools</b> . Under <b>Error-checking</b> , click <b>Check Now</b> .
Drive not found (identified).	Loose cable.	Check cable connections.
	The system may not have automatically recognized a newly installed device.	<ol style="list-style-type: none"> <li>1. Check to see if the device is listed within Computer Setup. If it is listed, the probable cause is a driver problem. If it is not listed, the probable cause is a hardware problem.</li> <li>2. If this is a newly installed drive, enter Setup and try adding a POST delay under <b>Advanced &gt; Power-On</b>.</li> </ol>
	Drive's controller is disabled in Computer Setup.	Run Computer Setup and enable the SATA controllers in <b>Storage &gt; Storage Options</b> .
Nonsystem disk/NTLDR missing message	Drive responds slowly immediately after power-up.	Run Computer Setup and increase the POST Delay in <b>Advanced &gt; Power-On Options</b> .
	System is trying to start from a non bootable diskette or USB device.	Remove the media from the drive.
	System is trying to start from a damaged hard drive.	<ol style="list-style-type: none"> <li>1. Insert a bootable diskette into the diskette drive and restart the computer.</li> <li>2. Check hard drive format using fdisk: If NTFS formatting, use a third party reader to evaluate the drive. If FAT32 formatting, the hard drive cannot be accessed.</li> </ol>



**Solving Hard Drive Problems** *(Continued)*


<b>Problem</b>	<b>Cause</b>	<b>Solution</b>
Nonsystem disk/NTLDR missing message. (continued)	System files missing or not properly installed.	<ol style="list-style-type: none"> <li>1. Insert a bootable system diskette and restart.</li> <li>2. Check hard drive format using fdisk: If NTFS formatting, use a third party reader to evaluate the drive. If FAT32 formatting, the hard drive cannot be accessed.</li> <li>3. Install system files for the appropriate operating system if necessary.</li> </ol>
	Hard drive boot disabled in Computer Setup.	Run Computer Setup and enable the hard drive entry in the <b>Storage &gt; Boot Order</b> list.
	Bootable hard drive is not attached as first in a multi-hard drive configuration.	If attempting to boot from a hard drive, ensure it is attached to P60 SATA 0.
	Bootable hard drive's controller is not listed first in the Boot Order.	Enter Computer Setup and select <b>Storage &gt; Boot Order</b> and ensure the bootable hard drive's controller is listed immediately under the <b>Hard Drive</b> entry.
Computer will not start.	Hard drive is damaged.	Observe the beeps and LED lights on the front of the computer. See Appendix C "POST Error Messages".
Computer seems to be locked up.	Program in use has stopped responding to commands.	<ol style="list-style-type: none"> <li>1. Attempt the normal Windows "Shut Down" procedure.</li> <li>2. Press the power button for four or more seconds to turn off the power.</li> <li>3. Restart the computer using the power button.</li> </ol>

## Solving MultiBay Problems


Solving MultiBay Problems		
Problem	Cause	Solution
Drive not found.	You attempted to hot plug a removable hard drive that has DriveLock security enabled. (This feature supported on some models.)	Shut down Windows and turn off the computer. Insert the drive into the MultiBay, if it is not already inserted. Turn on the computer.
	MultiBay is hidden in Computer Setup.	Enter Computer Setup and set MultiBay to <b>Device Available</b> in <b>Security &gt; Device Security</b> .

## Solving Display Problems

Solving Display Problems		
Problem	Cause	Solution
Blank screen (no video).	Monitor is not turned on.	Turn on the monitor and check that the monitor light is on.
	The cable connections are not correct.	Check the cable connections from the monitor to the computer and to the electrical outlet.
	Bad monitor.	Try a different monitor.
	Screen blanking utility installed or energy saver features enabled.	Press any key or click the mouse button and, if set, type your password.
	System ROM is corrupted; system is running in Boot Block Emergency Recovery Mode (indicated by eight red blinks from the power LED and eight simultaneous beeps).	<ol style="list-style-type: none"> <li>1. Reflash the system ROM with the latest BIOS image.</li> <li>2. Replace the system board.</li> </ol>
	Fixed-sync monitor will not sync at the resolution chosen.	Ensure that the monitor can accept the same horizontal scan rate as the resolution chosen.
	Computer is in <b>standby</b> mode.	Press the power button to resume from <b>standby</b> mode.

 **CAUTION:** When attempting to resume from **standby** mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and you will lose any unsaved data.

## Solving Display Problems (Continued)

Problem	Cause	Solution
Blank screen (no video). (continued)	Monitor cable plugged into the wrong connector.	<p>If the computer system has both an integrated graphics connector and a graphics expansion card connector, plug the monitor cable into the expansion card connector.</p> <p> If the graphics card is a standard PCI expansion card, you can enable the integrated graphics in Computer Setup. If a PCI-Express graphics card is installed, the integrated graphics can not be enabled.</p>
	Monitor settings in the computer are not compatible with the monitor.	<ol style="list-style-type: none"> <li>Restart the computer and press <b>F8</b> during startup when you see "Press F8" in the bottom right corner of the screen.</li> <li>Using the keyboard arrow keys, select <b>Enable VGA Mode</b> and press <b>Enter</b>.</li> <li>In Windows Control Panel, double-click the <b>Display</b> icon and select the <b>Settings</b> tab.</li> <li>Use the sliding control to reset the resolution.</li> </ol>
Blank screen and the power LED flashes Red five times, once every second, followed by a two second pause, and the computer beeps five times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	Pre-video memory error.	<ol style="list-style-type: none"> <li>Reseat DIMMs. Power on the system.</li> <li>Replace DIMMs one at a time to isolate the faulty module.</li> <li>Replace third-party memory with HP memory.</li> <li>Replace the system board.</li> </ol>
Blank screen and the power LED flashes Red six times, once every second, followed by a two second pause, and the computer beeps six times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	Pre-video graphics error.	<p>For systems with a graphics card:</p> <ol style="list-style-type: none"> <li>Reseat the graphics card.</li> <li>Replace the graphics card.</li> <li>Replace the system board.</li> </ol> <p>For systems with integrated graphics, replace the system board.</p>

### Solving Display Problems (Continued)

<b>Problem</b>	<b>Cause</b>	<b>Solution</b>
Blank screen and the power LED flashes Red seven times, once every second, followed by a two second pause, and the computer beeps seven times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	System board failure (ROM detected failure prior to video.)	Replace the system board.
Monitor does not function properly when used with energy saver features.	Monitor without energy saver capabilities is being used with energy saver features enabled.	Disable monitor energy saver feature.
Dim characters.	The brightness and contrast controls are not set properly.	Adjust the monitor brightness and contrast controls.
	Cables are not properly connected.	Check that the graphics cable is securely connected to the graphics card and the monitor.
Blurry video or requested resolution cannot be set.	If the graphics controller was upgraded, the correct video drivers may not be loaded.	Install the video drivers included in the upgrade kit.
	Monitor is not capable of displaying requested resolution.	Change requested resolution.
	Graphics card is bad.	Replace the graphics card.
The picture is broken up, rolls, jitters, or flashes.	The monitor connections may be incomplete or the monitor may be incorrectly adjusted.	<ol style="list-style-type: none"> <li>1. Be sure the monitor cable is securely connected to the computer.</li> <li>2. In a two-monitor system or if another monitor is in close proximity, be sure the monitors are not interfering with each other's electromagnetic field by moving them apart.</li> <li>3. Fluorescent lights or fans may be too close to the monitor.</li> </ol>
	Monitor needs to be degaussed.	Degauss the monitor.

### Solving Display Problems (Continued)


Problem	Cause	Solution
Image is not centered.	Position may need adjustment.	Press the Menu button to access the OSD menu. Select <b>ImageControl/Horizontal Position</b> or <b>VerticalPosition</b> to adjust the horizontal or vertical position of the image.
"No Connection, Check Signal Cable" displays on screen.	Monitor video cable is disconnected.	Connect the video cable between the monitor and computer.   Ensure the computer power is off while connecting the video cable.
"Out of Range" displays on screen.	Video resolution and refresh rate are set higher than what the monitor supports.	Restart the computer and enter Safe Mode. Change the settings to a supported setting then restart the computer so that the new settings take effect.
Vibrating or rattling noise coming from inside a CRT monitor when powered on.	Monitor degaussing coil has been activated.	None. It is normal for the degaussing coil to be activated when the monitor is powered on.
Clicking noise coming from inside a CRT monitor.	Electronic relays have been activated inside the monitor.	None. It is normal for some monitors to make a clicking noise when turned on and off, when going in and out of standby mode, and when changing resolutions.
High pitched noise coming from inside a flat panel monitor.	Brightness and/or contrast settings are too high.	Lower brightness and/or contrast settings.
Fuzzy focus; streaking, ghosting, or shadowing effects; horizontal scrolling lines; faint vertical bars; or unable to center the picture on the screen. (flat panel monitors using an analog VGA input connection only)	Flat panel monitor's internal digital conversion circuits may be unable to correctly interpret the output synchronization of the graphics card.	<ol style="list-style-type: none"> <li>1. Select the monitor's Auto-Adjustment option in the monitor's on-screen display menu.</li> <li>2. Manually synchronize the Clock and Clock Phase on-screen display functions. Download SoftPq SP20930 or SP22333, depending on the monitor, to assist with the synchronization.</li> </ol>
	Graphics card is not seated properly or is bad.	<ol style="list-style-type: none"> <li>1. Reseat the graphics card.</li> <li>2. Replace the graphics card.</li> </ol>
Certain typed symbols do not appear correct.	The font you are using does not support that particular symbol.	Use the Character Map to locate the and select the appropriate symbol. Click <b>Start &gt; All Programs &gt; Accessories &gt; System Tools &gt; Character Map</b> . You can copy the symbol from the Character Map into a document.

## Solving Audio Problems

### Solving Audio Problems

Problem	Cause	Solution
Errors when installing audio drivers.	The HP audio codec requires that Microsoft Universal Architecture (UAA) drivers, which provide support for the HD audio bus, to be installed before the audio codec driver can be installed. (UAA drivers are different for each operating system (OS) and OS service pack.)	Install the Microsoft UAA driver before installing the Realtek driver.
Sound cuts in and out.	Processor resources are being used by other applications.  Direct sound latency, common in many media player applications.	Shut down all open processor-intensive applications.  In Windows XP: <ol style="list-style-type: none"> <li>1. From the <b>Control Panel</b>, select <b>Sounds and Audio Devices</b>.</li> <li>2. On the <b>Audio</b> tab, select a device from the <b>Sound Playback</b> list.</li> <li>3. Click the <b>Advanced</b> button and select the <b>Performance</b> tab.</li> <li>4. Set the <b>Hardware acceleration</b> slider to <b>None</b> and the <b>Sample rate conversion quality</b> slider to <b>Good</b> and retest the audio.</li> <li>5. Set the <b>Hardware acceleration</b> slider to <b>Full</b> and the <b>Sample rate conversion quality</b> slider to <b>Best</b> and retest the audio.</li> </ol>
Sound does not come out of the speaker or headphones.	Software volume control is turned down.	Double-click the <b>Speaker</b> icon on the taskbar and use the volume slider to adjust the volume.
	The external speakers are not turned on.	Turn on the external speakers.
	Audio is hidden in Computer Setup.	Enable the audio in Computer Setup: <b>Security &gt; Device Security &gt; Audio</b> .

### Solving Audio Problems (Continued)

Problem	Cause	Solution
Sound does not come out of the speaker or headphones. (continued)	External speakers plugged into the wrong audio jack.	See the sound card documentation for proper speaker connection.
	Digital CD audio is not enabled.	<p>Enable digital CD audio:</p> <ol style="list-style-type: none"> <li>1. From the <b>Control Panel</b>, select <b>System</b>.</li> <li>2. On the <b>Hardware</b> tab, click the <b>Device Manager</b> button.</li> <li>3. Right-click on the CD/DVD device and select <b>Properties</b>.</li> <li>4. On the <b>Properties</b> tab, make sure "<b>Enable digital CD audio for this CD-ROM device</b>" is checked.</li> </ol>
	Headphones or devices connected to the line-out connector mute the internal speaker.	Turn on and use headphones or external speakers, if connected, or disconnect headphones or external speakers.
	Volume is muted.	<ol style="list-style-type: none"> <li>1. From the <b>Control Panel</b> program, click <b>Sound, Speech and Audio Devices</b>, then click <b>Sounds and Audio Devices</b>.</li> <li>2. Click the <b>Mute</b> check box to remove the check mark from the box.</li> </ol>
	Computer is in <b>standby</b> mode.	Press the power button to resume from <b>standby</b> mode.
<p> <b>CAUTION:</b> When attempting to resume from <b>standby</b> mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and any unsaved data will be lost.</p>		
Sound from headphones is not clear or muffled.	Headphones are plugged into the rear audio output connector. The rear audio connector is for powered audio devices and is not designed for headphone use.	Plug the headphones into the headphone connector on the front of the computer.
Computer appears to be locked up while recording audio.	The hard disk may be full.	<ol style="list-style-type: none"> <li>1. Before recording, make sure there is enough free space on the hard disk.</li> <li>2. Try recording the audio file in a compressed format.</li> </ol>

## Solving Printer Problems

### Solving Printer Problems

Problem	Cause	Solution
Printer will not print.	Printer is not turned on and online.	Turn the printer on and make sure it is online.
	The correct printer driver for the application are not installed.	<ol style="list-style-type: none"> <li>1. Install the correct printer driver for the application.</li> <li>2. Try printing using the MS-DOS command: <b>DIR C:\ &gt; [printer port]</b> where <b>[printer port]</b> is the address of the printer being used. If the printer works, reload the printer driver.</li> </ol>
	If you are on a network, you may not have made the connection to the printer.	Make the proper network connections to the printer.
	Printer may have failed.	Run printer self-test.
Printer will not turn on.	The cables may not be connected properly.	Reconnect all cables.
Printer prints garbled information.	The correct printer driver is not installed.	Install the correct printer driver for the application.
	The cables may not be connected properly.	Reconnect all cables.
	Printer memory may be overloaded.	Reset the printer by turning it off for one minute, then turn it back on.
Printer is offline.	The printer may be out of paper.	<ol style="list-style-type: none"> <li>1. Check the paper tray and refill it if it is empty.</li> <li>2. Select online.</li> </ol>



## Solving Keyboard and Mouse Problems

### Solving Keyboard and Mouse Problems

Problem	Cause	Solution
Keyboard commands and typing are not recognized by the computer.	Keyboard connector is not properly connected.	<ol style="list-style-type: none"> <li>1. Turn off the computer.</li> <li>2. Reconnect the keyboard to the back of the computer and restart the computer.</li> </ol>
	Program in use has stopped responding to commands.	Shut down the computer using the mouse and then restart the computer.



## Solving Keyboard and Mouse Problems (Continued)

Problem	Cause	Solution
Keyboard commands and typing are not recognized by the computer. (continued)	Keyboard needs repairs.	Replace the keyboard.
	Wireless device error.	<ol style="list-style-type: none"> <li>1. Check software, if available, for device battery status.</li> <li>2. Replace device batteries.</li> <li>3. Reset receiver and keyboard.</li> </ol>
	Computer is in <b>standby</b> mode.	Press the power button to resume from <b>standby</b> mode.
<p> <b>CAUTION:</b> When attempting to resume from <b>standby</b> mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and any unsaved data will be lost.</p>		
Cursor will not move using the arrow keys on the keypad.	The <b>Num Lock</b> key may be on.	Press the <b>Num Lock</b> key. The Num Lock light should not be on if you want to use the arrow keys. The <b>Num Lock</b> key can be disabled (or enabled) in Computer Setup.
Mouse does not respond to movement or is too slow.	Mouse connector is not properly plugged into the back of the computer.	<ol style="list-style-type: none"> <li>1. Shut down the computer using the keyboard.</li> <li>2. Plug the mouse connector into the back of the computer (or the keyboard) and restart the computer.</li> </ol>
	Program in use has stopped responding to commands.	Shut down the computer using the keyboard and then restart the computer.
	Mouse may need cleaning.	Remove the roller ball cover on the mouse and clean it.
	Mouse needs repairs.	Replace the mouse.
	Wireless device error.	<ol style="list-style-type: none"> <li>1. Check software, if available, for device battery status.</li> <li>2. Replace device batteries.</li> <li>3. Reset receiver and mouse.</li> </ol>
	Computer is in <b>standby</b> mode.	Press the power button to resume from <b>standby</b> mode.
	<p> <b>CAUTION:</b> When attempting to resume from <b>standby</b> mode, do not hold down the power button for more than four seconds. Otherwise, the computer will shut down and you will lose any unsaved data.</p>	
Mouse will only move vertically or horizontally, or movement is jerky.	Mouse roller ball is dirty.	Remove roller ball cover from the bottom of the mouse and clean it.

## Solving Hardware Installation Problems

You may need to reconfigure the computer when you add or remove hardware, such as an additional diskette drive. If you install a plug and play device, Windows XP automatically recognize the device and configure the computer. If you install a non–plug and play device, you must reconfigure the computer after completing installation of the new hardware. In Windows XP, use the **Add Hardware Wizard** and follow the instructions that appear on the screen.

### Solving Hardware Installation Problems

Problem	Cause	Solution
A new device is not recognized as part of the system.	Device is not seated or connected properly.	Ensure that the device is properly and securely connected and that pins in the connector are not bent down.
	Cable(s) of new external device are loose or power cables are unplugged.	Ensure that all cables are properly and securely connected and that pins in the cable or connector are not bent down.
	Power switch of new external device is not turned on.	Turn off the computer, turn on the external device, then turn on the computer to integrate the device with the computer system.
	When the system advised you of changes to the configuration, you did not accept them.	Reboot the computer and follow the instructions for accepting the changes.
	A plug and play board may not automatically configure when added if the default configuration conflicts with other devices.	Use Windows XP Device Manager to deselect the automatic settings for the board and choose a basic configuration that does not cause a resource conflict. You can also use Computer Setup to reconfigure or disable devices to resolve the resource conflict.
Computer will not start.	Wrong memory modules were used in the upgrade or memory modules were installed in the wrong location.	<ol style="list-style-type: none"> <li>1. Review the documentation that came with the system to determine if you are using the correct memory modules and to verify the proper installation.</li> <li>2. Observe the beeps and LED lights on the front of the computer. See Appendix C “POST Error Messages” to determine possible causes.</li> </ol>


**Solving Hardware Installation Problems** *(Continued)*

<b>Problem</b>	<b>Cause</b>	<b>Solution</b>
Power LED flashes Red five times, once every second, followed by a two second pause, and the computer beeps five times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	Memory is installed incorrectly or is bad.	<ol style="list-style-type: none"> <li>1. Reseat DIMMs.</li> <li>2. Replace DIMMs one at a time to isolate the faulty module.</li> <li>3. Replace third-party memory with HP memory.</li> <li>4. Replace the system board.</li> </ol>
Power LED flashes Red six times, once every second, followed by a two second pause, and the computer beeps six times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	Video card is not seated properly or is bad, or system board is bad.	<p>For systems with a graphics card:</p> <ol style="list-style-type: none"> <li>1. Reseat the graphics card. Power on the system.</li> <li>2. Replace the graphics card.</li> <li>3. Replace the system board.</li> </ol> <p>For systems with integrated graphics, replace the system board.</p>
Power LED flashes Red ten times, once every second, followed by a two second pause, and the computer beeps ten times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	Bad option card.	<ol style="list-style-type: none"> <li>1. Check each option card by removing the cards one at time (if multiple cards), then power on the system to see if fault goes away.</li> <li>2. Once bad card is identified, remove and replace bad option card.</li> <li>3. Replace the system board.</li> </ol>

## Solving Network Problems

These guidelines do not discuss the process of debugging the network cabling.


### Solving Network Problems

Problem	Cause	Solution
Wake-on-LAN feature is not functioning.	Wake-on-LAN is not enabled.	Use the Network Connections application in Control Panel to enable Wake-on-LAN.
Network driver does not detect network controller.	Network controller is disabled.	<ol style="list-style-type: none"> <li>1. Run Computer Setup and enable network controller.</li> <li>2. Enable the network controller in the operating system via the Device Manager.</li> </ol>
	Incorrect network driver.	Check the network controller documentation for the correct driver or obtain the latest driver from the manufacturer's Web site.
<p>Network status link light does not turn on or it never flashes.</p> <p> The network status light should flash when there is network activity.</p>	No active network is detected.	Check cabling and network equipment for proper connection.
	Network controller is not set up properly.	Use the Network control application to verify that the device is working properly.
	Network controller is disabled.	<ol style="list-style-type: none"> <li>1. Run Computer Setup and enable network controller.</li> <li>2. Enable the network controller in the operating system via Device Manager.</li> </ol>
	Network driver is not properly loaded.	Reinstall network drivers.
	System cannot autosense the network.	Disable auto-sensing capabilities and force the system into the correct operating mode.
Diagnostics reports a failure.	The cable is not securely connected.	Ensure that both ends of the data cable are securely connected.
	The cable is attached to the incorrect connector.	Ensure that the cable is attached to the correct connector.
	There is a problem with the cable or a device at the other end of the cable.	Ensure that the cable and device at the other end are operating correctly.
	Network controller interrupt is shared with an expansion board.	Under the Computer Setup <b>Advanced</b> menu, change the resource settings for the board.
	The network controller is defective.	Replace the system board (NIC is integral to the system board).

**Solving Network Problems** (Continued)

<b>Problem</b>	<b>Cause</b>	<b>Solution</b>
Diagnostics passes, but the computer does not communicate with the network.	Network drivers are not loaded, or driver parameters do not match current configuration.	Make sure the network drivers are loaded and that the driver parameters match the configuration of the network controller. Make sure the correct network client and protocol is installed.
	The network controller is not configured for this computer.	Select the <b>Network</b> icon in the <b>Control Panel</b> and configure the network controller.
Network controller stopped working when an expansion board was added to the computer.	Network controller interrupt is shared with an expansion board.	Under the Computer Setup <b>Advanced</b> menu, change the resource settings for the board.
	The network controller requires drivers.	Verify that the drivers were not accidentally deleted when the drivers for a new expansion board were installed.
	The expansion board installed is a network card (NIC) and conflicts with the embedded NIC.	Under the Computer Setup <b>Advanced</b> menu, change the resource settings for the board.
Network controller stops working without apparent cause.	The files containing the network drivers are corrupted.	Reinstall the network drivers, using the <i>Restore Plus!</i> CD.
	The cable is not securely connected.	Ensure that the cable is securely attached to the network connector and that the other end of the cable is securely attached to the correct device.
	The network controller is defective.	Replace the system board.
New network card will not boot.	New network card may be defective or may not meet industry-standard specifications.	Install a working, industry-standard NIC, or change the boot sequence to boot from another source.
Cannot connect to network server when attempting Remote System Installation.	The network controller is not configured properly.	Verify Network Connectivity, that a DHCP Server is present, and that the Remote System Installation Server contains the NIC drivers for your NIC.
System setup utility reports unprogrammed EEPROM.	Unprogrammed EEPROM.	Flash the ROM.

## Solving Memory Problems

 **CAUTION:** For those systems that support ECC memory, HP does not support mixing ECC and non-ECC memory. Otherwise, the system will not boot the operating system.

### Solving Memory Problems

Problem	Cause	Solution
System will not boot or does not function properly after installing additional memory modules.	Memory module is not the correct type or speed or the new memory module is not seated properly.	Replace module with the correct industry-standard device for the computer.
		On some models, ECC and non-ECC memory modules cannot be mixed.
Out of memory error.	Memory configuration may not be set up correctly.	Use the Device Manager to check memory configuration.
	You have run out of memory to run the application.	Check the application documentation to determine the memory requirements.
Memory count during POST is wrong.	The memory modules may not be installed correctly.	Check that the memory modules have been installed correctly and that proper modules are used.
	Integrated graphics may use system memory.	No action required.
Insufficient memory error during operation.	Too many Terminate and Stay Resident programs (TSRs) are installed.	Delete any TSRs that you do not need.
	You have run out of memory for the application.	Check the memory requirements for the application or add more memory to the computer.
Power LED flashes Red five times, once every second, followed by a two second pause, and the computer beeps five times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	Memory is installed incorrectly or is bad.	<ol style="list-style-type: none"> <li>1. Reseat DIMMs.</li> <li>2. Replace DIMMs one at a time to isolate the faulty module.</li> <li>3. Replace third-party memory with HP memory.</li> <li>4. Replace the system board.</li> </ol>

## Solving Processor Problems

### Solving Processor Problems

Problem	Cause	Solution
Poor performance is experienced.	Processor is hot.	<ol style="list-style-type: none"> <li>1. Make sure the airflow to the computer is not blocked.</li> <li>2. Make sure the fans are connected and working properly (some fans only operate when needed).</li> <li>3. Make sure the processor heatsink is installed properly.</li> </ol>
Power LED flashes Red three times, once every second, followed by a two second pause, and the computer beeps three times. Beeps continue for five iterations after which the LED flashes will continue until the problem is resolved.	Processor is not seated properly or not installed.	<ol style="list-style-type: none"> <li>1. Check to see that the processor is present.</li> <li>2. Reseat the processor.</li> </ol>

## Solving CD-ROM and DVD Problems

### Solving CD-ROM and DVD Problems

Problem	Cause	Solution
System will not boot from CD-ROM or DVD drive.	Removable Media Boot is not enabled through the Computer Setup utility.	Run the Computer Setup utility and enable booting to removable media and verify boot order settings.
	Non-bootable CD in drive.	Try a bootable CD in the drive.
	Network Server Mode is enabled in Computer Setup.	Run Computer Setup and disable Network Server Mode in <b>Security &gt; Password Options</b> .
	Boot order not correct.	Run Computer Setup and change boot sequence in <b>Storage &gt; Boot Order</b> .
CD-ROM or DVD devices are not detected or driver is not loaded.	Drive is not connected properly or not properly configured.	<ol style="list-style-type: none"> <li>1. Reconnect power and data cables to the drive.</li> <li>2. Install correct device driver.</li> </ol>
Movie will not play in the DVD drive.	Movie may be regionalized for a different country.	See the documentation that came with the DVD drive.

### Solving CD-ROM and DVD Problems (Continued)

<b>Problem</b>	<b>Cause</b>	<b>Solution</b>
Movie will not play in the DVD drive. (continued)	Decoder software is not installed.	Install decoder software.
	Damaged media.	Replace media.
	Movie rating locked out by parental lock.	Use DVD software to remove parental lock.
	Media installed upside down.	Reinstall media.
Cannot eject compact disc (tray-load unit).	Disc not properly seated in the drive.	<ol style="list-style-type: none"> <li>1. Turn off the computer and insert a thin metal rod into the emergency eject hole and push firmly.</li> <li>2. Slowly pull the tray out from the drive until the tray is fully extended, then remove the disc.</li> </ol>
CD-ROM, CD-RW, DVD-ROM, or DVD-R/RW drive cannot read a disc or takes too long to start.	Media has been inserted upside down.	Re-insert the Media with the label facing up.
	The DVD-ROM drive takes longer to start because it has to determine the type of media played, such as audio or video.	Wait at least 30 seconds to let the DVD-ROM drive determine the type of media being played. If the disc still does not start, read the other solutions listed for this topic.
	CD or DVD disc is dirty.	Clean CD or DVD with a CD cleaning kit.
	Windows does not detect the CD-ROM or DVD-ROM drive.	<ol style="list-style-type: none"> <li>1. Use Device Manager to remove or uninstall the device in question.</li> <li>2. Restart the computer and let Windows detect the device.</li> </ol>
Recording audio CDs is difficult or impossible.	Wrong or poor quality media type.	<ol style="list-style-type: none"> <li>1. Try using a slower recording speed.</li> <li>2. Verify that you are using the correct media for the drive.</li> <li>3. Try a different brand of media. Quality varies widely between manufacturers.</li> </ol>



## Solving Drive Key Problems

### Solving Drive Key Problems

Problem	Cause	Solution
Drive Key is not seen as a drive letter in Windows XP.	The drive letter after the last physical drive is not available.	Change the default drive letter for the Drive Key in Windows XP.
The computer boots to DOS after making a bootable Drive Key.	Drive Key is bootable.	Install the Drive Key after the operating system boots.

## Solving Front Panel Component Problems

### Solving Front Panel Component Problems

Problem	Cause	Solution
A USB device, headphone, or microphone is not recognized by the computer.	It is not properly connected.	<ol style="list-style-type: none"> <li>1. Turn off the computer.</li> <li>2. Reconnect the device to the front of the computer and restart the computer.</li> </ol>
	The device does not have power.	If the USB device requires AC power, be sure one end is connected to the device and one end is connected to a live outlet.
	The correct device driver is not installed.	<ol style="list-style-type: none"> <li>1. Install the correct driver for the device.</li> <li>2. You might need to reboot the computer.</li> </ol>
	The cable from the device to the computer does not work.	<ol style="list-style-type: none"> <li>1. If possible, replace the cable.</li> <li>2. Restart the computer.</li> </ol>
	The device is not working.	<ol style="list-style-type: none"> <li>1. Replace the device.</li> <li>2. Restart the computer.</li> </ol>

## Solving Internet Access Problems

<b>Solving Internet Access Problems</b>		
<b>Problem</b>	<b>Cause</b>	<b>Solution</b>
Unable to connect to the Internet.	Internet Service Provider (ISP) account is not set up properly.	Verify Internet settings or contact the ISP for assistance.
	Modem is not set up properly.	Reconnect the modem. Verify the connections are correct using the quick setup documentation.
	Web browser is not set up properly.	Verify that the Web browser is installed and set up to work with your ISP.
	Cable/ DSL modem is not plugged in.	Plug in cable/DSL modem. You should see a "power" LED light on the front of the cable/DSL modem.
	Cable/DSL service is not available or has been interrupted due to bad weather.	Try connecting to the Internet at a later time or contact your ISP. (If the cable/DSL service is connected, the "cable" LED light on the front of the cable/DSL modem will be on.)
	The CAT5 UTP cable is disconnected.	Connect the CAT5 UTP cable between the cable modem and the computer's RJ-45 connector. (If the connection is good, the "PC" LED light on the front of the cable/DSL modem will be on.)
	IP address is not configured properly.	Contact the ISP for the correct IP address.
	Cookies are corrupted.	<i>Windows XP</i> <ol style="list-style-type: none"> <li>1. Select <b>Start &gt; Control Panel</b>.</li> <li>2. Double-click <b>Internet Options</b>.</li> <li>3. On the <b>General</b> tab, click the <b>Delete Cookies</b> button.</li> </ol>
Cannot automatically launch Internet programs.	You must log on to the ISP before some programs will start.	Log on to the ISP and launch the desired program.

---

**Solving Internet Access Problems** *(Continued)*

<b>Problem</b>	<b>Cause</b>	<b>Solution</b>
Internet takes too long to download Web sites.	Modem is not set up properly.	<p>Verify that the correct modem speed and COM port are selected.</p> <p><i>For Windows XP</i></p> <ol style="list-style-type: none"> <li>1. Select <b>Start &gt; Control Panel</b>.</li> <li>2. Double-click <b>System</b>.</li> <li>3. Click the <b>Hardware</b> tab.</li> <li>4. In the Device Manager area, click the <b>Device Manager</b> button.</li> <li>5. Double-click <b>Ports (COM &amp; LPT)</b>.</li> <li>6. Right-click the COM port your modem uses, then click <b>Properties</b>.</li> <li>7. Under <b>Device status</b>, verify that the modem is working properly.</li> <li>8. Under <b>Device usage</b>, verify the modem is enabled.</li> <li>9. If there are further problems, click the <b>Troubleshoot</b> button and follow the on-screen instructions.</li> </ol>

---



## System Board and Riser Board Reference Designators

These reference designators are used on most but not all HP system and riser boards.

<b>Designator</b>	<b>Component</b>
BAT	Battery socket/Battery
CR1	LED - 5V_Aux (on)
CR2	Health-LED
CR3	UID LED
CR4	Power LED
CR35	Hard drive activity LED
E14	Boot block header/jumper
E15	Boot block recovery header
E25	CPLD programming header
E49/JP49	Clear Password header/jumper
E50	Clear CMOS header
J7	RJ45 jack
J9	Stacked RJ45/Dual USB
J10	Quad stacked USB
J11	First IEEE 1394 connector
J12	Second IEEE 1394 connector
J13	SPDIF input
J14	SPDIF output
J20 - 29	PCI slots
J30	PCI extender slot (male)
J31 - J35	PCI Express slots
J37	Primary SCSI connector
J38	Secondary SCSI connector
J39	Stacked parallel/SCSI connector
J40	AGP slot
J41	x16 PCI Express slot for graphics
J50	First parallel port
J51	Second parallel port
J52	Double-stacked parallel port, Top = Port B, Bottom = Port A
J53	Parallel port over single Serial Port
J54	Parallel port over Serial Port and Video Port
J55	Parallel port over dual VGA ports
J65	DVI connector
J66	Keyboard connector, PS/2 (Closest to power supply)
J67	Mouse connector, PS/2

<b>Designator</b>	<b>Component</b> <i>(Continued)</i>
J68	Stacked mouse (Top)/keyboard (Bottom) connector
J69	Video connector, VGA
J70	Primary single USB connector
J71	Secondary single USB port
J72	Microphone jack
J73	Line-in jack
J74	Line-out jack
J75	Headphone jack
J76	Volume control
J77	Double-stacked headphone (Bottom)/microphone (Top) connector
J78	Double-stacked line-in (Top)/line-out (Bottom) connector
J80	Stacked serial/audio connector
J81	Primary double-stack USB, Top = Port 2, Bottom = Port 1
J82	Secondary double-stack USB, Top = Port 4, Bottom = Port 3
J83	Triple-stacked audio jack (line in, line out/headphone, microphone)
J101	Security board connector, daughter card
J9020-J9029	PCI slots on riser card
J9030-J9034	PCI express slots on riser card
JP49/E49	Clear password header/jumper
L1	USB front port choke (1st)
L2	USB rear port choke (1st)
L3	USB rear port choke (2nd)
L4	USB rear port choke (3rd)
L5	USB front port choke (2nd)
P1	P/S connector (20 or 24 pin)
P2	Second P/S connector (as required)
P3	VCCP 12V header
P4	Secondary Processor 12V header
P5	Main Power/HDD LED connector
P6	Speaker connector
P7	Audio connector (from CD-ROM)
P8	Primary chassis fan connector
P9	Secondary chassis fan connector
P10	Diskette drive connector
P11	Auxiliary Audio connector
P12	Alert on LAN NIC connector
P13	VRM module footprint
P15	AUI connector
P16	Fan command/fan sink header (may be 2 or 4 pin)
P17	Digital audio expansion header
P18	SPDIF internal input header
P19	SPDIF internal output header
P20	Primary IDE connector
P21	Secondary IDE/MultiBay connector
P22	Header for NEWCARD

<b>Designator</b>	<b>Component</b> <i>(Continued)</i>
P23	Header for front panel audio
P24	Header for front panel USB
P25	Internal USB connector 1
P26	Internal USB connector 2
P27	MultiBay header
P29	SCSI LED connector
P30	PCI extender slot (female)
P40	Blade PC graphics connector (outboard)
P41	Blade PC graphics connector (inboard)
P52	Second serial port
P54	Primary serial port
P55	Double stack serial port, Top = Serial B, Bottom = Serial A
P58	Riser edge connector (male-mates with J30)
P60	Primary Serial ATA (SATA) connector
P61	Second Serial ATA (SATA) connector
P62	Third Serial ATA (SATA) connector
P63	Fourth Serial ATA (SATA) connector
P64	VSFF expansion connector
P65	Graphics option connector
P66	Fifth Serial ATA (SATA) connector
P67	Sixth Serial ATA (SATA) connector
P68	Seventh Serial ATA (SATA) connector
P69	Eighth Serial ATA (SATA) connector
P70	Primary (CPU) fan header for fansink
P71	Secondary CPU fan header for fansink
P80	Primary Serial Attached SCSI (SAS) connector
P81	Second Serial Attached SCSI (SAS) connector
P82	Third Serial Attached SCSI (SAS) connector
P83	Fourth Serial Attached SCSI (SAS) connector
P84	Fifth Serial Attached (SAS) connector
P85	Sixth Serial Attached (SAS) connector
P86	Seventh Serial Attached (SAS) connector
P87	Eighth Serial Attached (SAS) connector
P101	Security board connector, system board
P106	Secondary speaker header
P124	Hood lock header
P125	Hood sensor header
P126	Flying parallel port header
P216	White box chassis fan header
SW2	Security hood switch on riser card
SW50	Clear CMOS switch/push button
U2	Single chip solution (combined north bridge/south bridge)
U3	North bridge
U4	South bridge
U5	Super I/O

<b>Designator</b>	<b>Component</b> <i>(Continued)</i>
U6	Clock chip
U7	64 bit Bridge
U10	LOM1
U11	LOM1 EEPROM
U12	LOM1 PHY
U13	Audio Codec
U14	Audio amplifier
U16	LOM2
U17	LOM2 EEPROM
U18	LOM2 PHY
U19	SPI ROM
U20	Fan controller
U29	TMDS controller
U30	Parallel port diode array
U31	First serial port transceiver
U32	Second serial port transceiver
U46	VRM controller
U50	USB front port power switch
U51	First USB rear port power switch
U52	Second USB rear port power switch
U53	Third USB rear port power switch
XBT	Battery retainer
XMM1	Memory slot. DIMM1 or RIMM1 populated and tested
XMM2 - XMM5	Following memory slots
XU1	Primary processor socket
XU2	Secondary processor socket
XU15/U15	System ROM and Socket (Socket = XU15, ROM = U15)
XU19/U19	SPI ROM and socket (XU19 = socket, U19 = SPI ROM)
Y1	Primary (TH) system clock crystal
Y2	Secondary (SMT) system clock crystal
Y3	Primary NIC clock crystal
Y4	Secondary NIC clock crystal
Y5/H5	RTC clock crystal/tie-down



---

## Memory

The dc7600 series computers with Intel-based processors come with double data rate 2 synchronous dynamic random access memory (DDR2-SDRAM) dual inline memory modules (DIMMs).



**CAUTION:** DDR and DDR2 memory modules are not interchangeable.

---

### DDR2-SDRAM DIMMs

The memory sockets on the system board can be populated with up to four industry-standard DIMMs. These memory module sockets are populated with at least one preinstalled memory module. To achieve the maximum memory support, you can populate the system board with up to 4GB of memory configured in a high-performing dual channel mode.

For proper system operation, the DDR2-SDRAM DIMMs must be:

- industry-standard 240-pin
- unbuffered PC2 4200 533 MHz-compliant or PC2 5300 667 MHz-compliant
- 1.8volt DDR2-SDRAM DIMMs

The DDR2-SDRAM DIMMs must also:

- support CAS latency 4 (CL = 4) for PC2 4200 533 MHz or CAS latency 5 (CL = 5) for PC2 5300 667 MHz
- contain the mandatory JEDEC SPD information


In addition, the computer supports:

- 256Mbit, 512Mbit, AND 1 Gbit non-ECC memory technologies (all three Mbit technologies may be used with each other with no performance degradation)
- single-sided and double-sided DIMMS
- DIMMs constructed with x8 and x16 DDR devices; DIMMs constructed with x4 SDRAM are not supported

### DIMM Sockets

There are four DIMM sockets on the system board, with two sockets per channel. The sockets are labeled XMM1, XMM2, XMM3, and XMM4. Sockets XMM1 and XMM2 operate in memory channel A. Sockets XMM3 and XMM4 operate in memory channel B.

The system board shown may differ from the one in your product.



Item	Description	Socket Color
❶	DIMM socket XMM1, Channel A	Black
❷	DIMM socket XMM2, Channel A	White
❸	DIMM socket XMM3, Channel B	Black
❹	DIMM socket XMM4, Channel B	White

The system will automatically operate in single channel mode, dual channel Asymmetric mode, or a higher-performing dual channel Interleaved mode, depending on how the DIMMs are installed.

To identify the operating mode, run Computer Setup and select the System Information menu item. The operating memory mode will appear in the line showing the system total memory.

- The system will operate in single channel mode if the DIMM sockets are populated in one channel only.
- The system will operate in dual channel Asymmetric mode if the total memory capacity of the DIMMs in Channel A is not equal to the total memory capacity of the DIMMs in Channel B.
- The system will operate in a higher-performing dual channel Interleaved mode if the total memory capacity of the DIMMs in Channel A is equal to the total memory capacity of the DIMMs in Channel B. However, the technology and device width can vary between the channels, For example, if Channel A is populated with two 256 MB DIMMS and Channel B is populated with one 512 MB DIMM, the system will operate in Interleaved mode.
- In any mode, the maximum operational speed is determined by the slowest DIMM in the system.

4-pin power pin assignments A-7  
24-pin MicroFit power pin assignments A-7  
24-pin power pin assignments A-7, A-11  
6-pin power pin assignments A-8

## A

access panel  
    MT removal and replacement 6-4  
    ST removal and replacement 7-8  
Altiris 3-2  
    Deployment Solution Agent 3-2  
    HP Client Management Solutions 3-4  
asset tracking 3-14  
ATA/ATAPI (IDE) drive cable pin assignments  
    A-6

## B

backing up files 1-2  
battery  
    disposal 5-9  
    MT removal and replacement 6-33  
    ST removal and replacement 7-40  
bezel insert  
    MT removal and replacement 6-8  
    ST removal and replacement 7-9  
blank screen D-10, D-11  
Boot Block Emergency Recovery Mode 3-7

## C

cable  
    MT removal and replacement 6-17  
    proper handling 5-8  
cable lock  
    MT 6-2  
    ST 7-6  
cable management  
    MT 6-9  
    ST 7-11  
cable pinouts  
    PATA data 4-3  
    PATA power 4-4  
    SATA data 4-2  
    SATA power 4-2

## cautions

AC power 5-1  
adding devices 1-1  
cables 5-8  
cooling fan 5-7  
cover lock security 3-22  
electrostatic discharge 5-3  
FailSafe Key 3-23  
keyboard cleaning 5-6  
keyboard keys 5-6  
operating system installation 1-1  
protecting ROM 3-7

change notification 3-6  
changing password 3-19

## chassis

    MT illustrated 5-1  
    ST illustrated 5-2  
chassis fan  
    MT removal and replacement 6-22  
    ST removal and replacement 7-28

## cleaning

    computer 5-6  
    keyboard 5-6  
    monitor 5-7  
    mouse 5-7  
clearing password 3-20

computer cleaning 5-6

## computer cover

    MT removal and replacement 6-4  
    ST removal and replacement 7-8  
computer pauses D-2

## Computer Setup

    accessing 2-3  
    Advanced menu 2-11  
    File menu 2-4  
    overview 2-2  
    Security menu 2-8  
    Storage menu 2-5

configuring power button 3-13

connector pin assignments A-1 to A-7

country-specific power cord set requirements B-2

cover lock, smart 3-22

**D**

- Dantz Retrospect Express 3–5
- date and time display problems D–2
- DDR2 memory F–1
- deleting password 3–19
- delimiter characters, table 3–20
- device drivers, installing/upgrading 1–1
- diagnostic tool for hard drives 3–24
- diagnostics utility 2–14
- DIMMs F–1
- disassembly preparation
  - MT 6–1
  - ST 7–1
- diskette drive
  - MT removal and replacement 6–17
  - ST removal and replacement 7–21
- diskette drive bezel
  - MT removal and replacement 6–8
  - ST removal and replacement 7–9
- drive
  - capacities 4–5
  - MT removal and replacement 6–17
  - partition size 4–5
  - protecting 3–24
  - ST external removal and replacement 7–21
  - ST hard drive removal and replacement 7–23
  - ST optical drive removal and replacement 7–19
- drive bezel
  - MT 3.5" 6–8
  - MT 5.25" 6–7
  - ST assorted 7–10
- drive positions
  - MT 6–16
  - ST 7–18
- Drivelock 3–20
- dual-state power button 3–13

**E**

- electrostatic discharge. *See* ESD
- entering
  - power-on password 3–18
  - setup password 3–18
- error messages, POST C–1 to C–7
- ESD (electrostatic discharge)
  - materials and equipment 5–4
  - preventing damage 5–3
- Ethernet
  - AUI pin assignments A–2
  - BNC pin assignments A–1
  - RJ-45 pin assignments A–2

- expansion card
  - MT PCI Express socket removal and replacement 6–14
  - MT standard socket removal and replacement 6–13
  - ST PCI Express socket removal and replacement 7–17
  - ST standard socket removal and replacement 7–15
- expansion card retainer
  - MT removal and replacement 6–12
  - ST removal and replacement 7–14
- expansion slot cover
  - MT removal and replacement 6–13
  - ST removal and replacement 7–15
- external 3.5-inch drive
  - ST removal and replacement 7–21
- external security
  - MT 6–2
  - ST 7–6

**F**

- FailSafe key, ST 7–3
- fan shroud, ST removal and replacement 7–27
- fan, chassis
  - MT removal and replacement 6–22
  - ST removal and replacement 7–28
- fan, power supply 5–7
- FAT or FAT32 to NTFS conversion 1–2
- fault notification 3–24
- flashing LEDs C–9
- front bezel
  - MT removal and replacement 6–5
  - ST removal and replacement 7–9
- front I/O devices
  - MT removal and replacement 6–24
  - ST removal and replacement 7–29
- front I/O panel
  - MT removal and replacement 6–23

**G**

- grounding methods 5–4

**H**

- hard drive
  - diagnostic tool 3–24
  - MT removal and replacement 6–17
  - proper handling 5–8
  - ST removal and replacement 7–23
- headphone pin assignments A–4
- heatsink

- MT removal and replacement 6–26
  - ST removal and replacement 7–31
  - hood sensor
    - ST removal and replacement 7–5
  - HP Client Management Solutions 3–4
  - HP Client Manager 3–3
  - HP Insight Diagnostics 2–14
  - HP Local Recovery 3–5
  - HP software. *See* software
  - HP System Software Manager 3–3
- I**
- image deployment methods 3–1
  - infrared (IR) transceiver, external, pin assignments
    - A–5
  - initial configuration 3–1
  - Insight Diagnostics 2–14
- K**
- keyboard
    - cleaning 5–6
    - delimiter characters, national 3–20
    - pin assignments A–1
- L**
- LEDs
    - blinking power C–9
    - blinking PS/2 keyboard C–9
  - line-in audio pin assignments A–4
  - line-out audio pin assignments A–4
  - Local Recovery 3–2
  - locking Smart Cover Lock 3–23
- M**
- memory
    - DDR2 specifications F–1
    - MT removal and replacement 6–10
    - socket assignments F–2
    - ST removal and replacement 7–12
  - microphone pin assignments A–3
  - Minitower *See* MT
  - monitor
    - blank screen D–10, D–11
    - blurry video D–12
    - cleaning 5–7
    - dim characters D–12
    - pin assignments A–5
  - mouse
    - cleaning 5–7
    - pin assignments A–1
  - MT
    - 3.5" drive bezel removal and replacement 6–8
    - 5.25" drive bezel removal and replacement 6–7
    - access panel removal and replacement 6–4
    - battery removal and replacement 6–33
    - cable lock 6–2
    - chassis fan removal and replacement 6–22
    - chassis, illustrated 5–1
    - disassembly preparation 6–1
    - diskette drive bezel removal and replacement 6–8
    - diskette drive cable connecting 6–20
    - diskette drive cable disconnecting 6–17
    - drive positions 6–16
    - drive removal and replacement 6–17
    - expansion slot cover 6–13
    - external security 6–2
    - front bezel removal and replacement 6–5
    - front I/O devices removal and replacement 6–24
    - front I/O panel removal and replacement 6–23
    - hard drive cable connecting 6–21
    - hard drive cable disconnecting 6–18
    - heatsink removal and replacement 6–26
    - memory removal and replacement 6–10
    - optical drive cable connecting 6–20
    - optical drive cable disconnecting 6–17
    - padlock 6–3
    - PCI expansion card removal and replacement 6–13
    - PCI Express expansion card removal and replacement 6–14
    - power supply removal and replacement 6–30
    - power switch assembly removal and replacement 6–25
    - preparation for disassembly 6–1
    - processor removal and replacement 6–27
    - speaker removal and replacement 6–29
    - system board removal and replacement 6–32
- MultiBay**
- CD-ROM adapter pin assignments A–6
  - security 3–20
- N**
- national keyboard delimiter characters 3–20
  - notification of hardware and software changes 3–6
- O**
- optical drive
    - MT removal and replacement 6–17
    - ST removal and replacement 7–19
  - overheating, prevention 5–5

**P**

## padlock

MT removal and replacement 6–3

ST removal and replacement 7–7

## parallel interface pin assignments A–3

## password

changing 3–19

clearing 3–20

deleting 3–19

options 2–8

power-on 2–8, 3–18

security 3–17

setup 2–8, 3–17, 3–18

## PATA

data cable pinouts 4–3

power cable pinouts 4–4

## PCI expansion card

MT removal and replacement 6–13

ST removal and replacement 7–15

## PCI Express expansion card

MT removal and replacement 6–14

ST removal and replacement 7–17

## PCI Express pin assignments A–9

## PCN (Proactive Change Notification) 3–6

## POST (Power-On Self-Test) 2–1

## POST error messages C–1 to C–7

## power button, configuring 3–13

## power cord set requirements

country specific B–2

general B–1

## power supply

fan 5–7

MT removal and replacement 6–30

ST removal and replacement 7–35

## power switch assembly

MT removal and replacement 6–25

ST removal and replacement 7–30

## power-on password

changing 3–19

deleting 3–19

entering 3–18

## Power-On Self-Test (POST) 2–1

## Preboot Execution Environment (PXE) 3–2

## Proactive Change Notification (PCN) 3–6

## problems, solving

audio D–14

CD-ROM and DVD D–23

diskette D–6

display D–10, D–11

drive key D–25

front panel components D–25

hard drive D–8

hardware installation D–18

Internet access D–26

keyboard D–16

memory D–22

mouse D–16

MultiBay D–10

network D–20

optical drives D–23

power supply D–5

printer D–16

processor D–23

## processor

MT removal and replacement 6–27

ST removal and replacement 7–32

## protecting ROM 3–7

## PXE (Preboot Execution Environment) 3–2

**R**

recovery, software 3–1

Remote ROM Flash 3–7

remote setup 3–2

## removal and replacement

MT 3.5" drive bezel 6–8

MT 5.25" drive bezel 6–7

MT access panel 6–4

MT battery 6–33

MT cable lock 6–2

MT chassis fan 6–22

MT diskette drive bezel 6–8

MT drive 6–17

MT front bezel 6–5

MT front I/O devices 6–24

MT front I/O panel 6–23

MT heatsink 6–26

MT memory 6–10

MT padlock 6–3

MT PCI expansion card 6–13

MT PCI Express expansion card 6–14

MT power supply 6–30

MT power switch assembly 6–25

MT processor 6–27

MT speaker 6–29

MT system board 6–32

ST battery 7–40

ST cable lock 7–6

ST chassis fan 7–28

ST computer cover 7–8

- ST expansion card retainer 7–14
- ST external 3.5-inch drive 7–21
- ST fan shroud 7–27
- ST front drive bezel 7–9
- ST front I/O devices 7–29
- ST hard drive 7–23
- ST heatsink 7–31
- ST hood sensor 7–5
- ST memory 7–12
- ST optical drive 7–19
- ST padlock 7–7
- ST PCI expansion card 7–15
- ST PCI Express expansion card 7–17
- ST power supply 7–35
- ST power switch assembly 7–30
- ST processor 7–32
- ST Smart Cover Lock 7–3
- ST speaker 7–34
- ST system board 7–37
- retired solutions 3–6
- riser board
  - reference designators E–1
- ROM flash 3–7
- S**
- safety precautions, cleaning 5–5
- SATA
  - data cable pinouts 4–2
  - power cable pinouts 4–2
- SATA pin assignments A–8
- screws, correct size 5–8
- SCSI pin assignments A–4
- SDRAM (synchronous dynamic random access memory) F–1
- security
  - DriveLock 3–20
  - embedded TPM chip 3–24
  - HP ProtectTools Security Manager 3–24
  - MT external 6–2
  - MultiBay 3–20
  - password 3–17
  - ST external 7–6
- security features
  - mechanical 3–17
  - Setup (F10) 3–14
- serial interface pin assignments A–3
- service considerations 5–7
- setup
  - software 1–2
  - Windows 1–1
- setup password
  - changing 3–19
  - deleting 3–19
  - entering 3–18
  - setting 3–17
- Slim Tower. *See* ST
- Smart Cover Lock
  - locking 3–23
  - ST removal and replacement 7–3
  - unlocking 3–23
- Smart Cover Sensor
  - protection levels 3–22
  - setting 3–22
- software
  - Altiris Deployment Solution Agent 3–2
  - asset tracking 3–14
  - Boot Block Emergency Recovery Mode 3–7
  - Computer Setup Utilities 2–1
  - Dantz Retrospect Express 3–5
  - Drive Protection System 3–24
  - Fault Notification and Recovery 3–24
  - HP Client Management Solutions using Altiris 3–4
  - HP Client Manger 3–3
  - HP Insight Diagnostics 2–14
  - HP Local Recovery 3–2
  - HP ProtectTools Security Manager 3–24
  - HP System Software Manager 3–3
  - image deployment 3–1
  - Proactive Change Notification 3–6
  - recovery 3–1
  - Remote ROM Flash 3–7
  - Remote System Installation 3–2
  - setup 1–2
  - Subscriber’s Choice 3–6
- spare part number
  - tamper resistant wrench 5–7
  - Torx T-15 screwdriver 5–7
- speaker
  - MT removal and replacement 6–29
  - ST removal and replacement 7–34
- ST
  - battery removal and replacement 7–40
  - cable lock removal and replacement 7–6
  - cable management 7–11
  - chassis fan removal and replacement 7–28
  - chassis, illustrated 5–2
  - computer cover removal and replacement 7–8
  - disassembly preparation 7–1
  - drive bezel inserts 7–10

- drive positions 7-18
  - expansion card removal and replacement 7-15
  - external 3.5-inch drive removal and replacement 7-21
  - external security 7-6
  - FailSafe key 7-3
  - fan shroud removal and replacement 7-27
  - front drive bezel removal and replacement 7-9
  - front I/O devices removal and replacement 7-29
  - hard drive removal and replacement 7-23
  - heatsink removal and replacement 7-31
  - hood sensor removal and replacement 7-5
  - memory removal and replacement 7-12
  - optical drive removal and replacement 7-19
  - padlock removal and replacement 7-7
  - PCI expansion card retainer removal and replacement 7-14
  - PCI Express expansion card removal and replacement 7-17
  - power supply removal and replacement 7-35
  - power switch assembly removal and replacement 7-30
  - preparation for disassembly 7-1
  - processor removal and replacement 7-32
  - Smart Cover Lock removal and replacement 7-3
  - speaker removal and replacement 7-34
  - system board removal and replacement 7-37
    - tamper-proof screws 7-3
    - ST removal and replacement 7-37
- T**
- tamper-proof screws
    - ST 7-3
    - tool 5-7
  - temperature control 5-5
  - Torx T-15 screwdriver 5-7
  - TPM Embedded Security Chip 3-24
  - Troubleshooting D-1
- U**
- Ultra SCSI pin assignments A-5
  - unlocking Smart Cover Lock 3-23
  - USB pin assignments A-3
- V**
- ventilation, proper 5-5
- W**
- Wake-on-LAN feature D-20
  - Web sites
    - HP 1-1
    - HPQFlash 3-7
    - PC Deployment 3-1
    - Proactive Change Notification 3-6
    - Remote ROM Flash 3-7
    - replicating setup, BIOS utility 3-10
    - ROM Flash 3-7
    - security 3-24
    - Subscriber's Choice 3-6
    - support software 3-13
    - support software CD subscription 1-1
  - wrench, tamper-resistant 7-3