

Notebook Tour

User Guide

© Copyright 2007 Hewlett-Packard
Development Company, L.P.

Microsoft and Windows are U.S. registered
trademarks of Microsoft Corporation.
Bluetooth is a trademark owned by its
proprietor and used by Hewlett-Packard
Company under license. SD Logo is a
trademark of its proprietor. Java is a U.S.
trademark of Sun Microsystems, Inc.

The information contained herein is subject
to change without notice. The only
warranties for HP products and services are
set forth in the express warranty statements
accompanying such products and services.
Nothing herein should be construed as
constituting an additional warranty. HP shall
not be liable for technical or editorial errors
or omissions contained herein.

First Edition: April 2007

Document Part Number: 438922-001

Product notice

This user guide describes features that are common to most models. Some features may not be available on your computer.

Table of contents

1 Identifying hardware

2 Components

Top components	3
Pointing devices	3
TouchPad	3
Lights	5
Buttons, switches, and fingerprint reader	7
Keys	9
Front components	10
Rear components	11
Right-side components	12
Left-side components	13
Bottom components	14
Wireless antennae	15
Additional hardware components	16

3 Labels

Index	18
-------------	----

1 Identifying hardware

To see a list of hardware installed in the computer, follow these steps:


1. Select **Start > My Computer**.
2. In the left pane of the System Tasks window, select **View system information**.
3. Select **Hardware** tab > **Device Manager**.

You can also add hardware or modify device configurations using Device Manager.

2 Components

Top components


Pointing devices



Component	Description
(1) Left pointing stick button	Functions like the left button on an external mouse.
(2) Pointing stick	Moves the pointer and selects or activates items on the screen.
(3) Right pointing stick button	Functions like the right button on an external mouse.

*This table describes factory settings. To view and change pointing device preferences, select **Start > Control Panel > Printers and Other Hardware > Mouse**.


TouchPad



Component	Description
(1) TouchPad*	Moves the pointer and selects or activates items on the screen.
(2) Left TouchPad button*	Functions like the left button on an external mouse.
(3) Right TouchPad button*	Functions like the right button on an external mouse.
(4) TouchPad scroll zone*	Scrolls up or down.

*This table describes factory settings. To view or change pointing device preferences, select **Start > Control Panel > Printers and Other Hardware > Mouse**.

Lights




Component	Description
(1) Wireless lights (2)†	<ul style="list-style-type: none"> On: An integrated wireless device, such as a wireless local area network (WLAN) device, the HP Broadband Wireless Module, and/or a Bluetooth® device, is on. Off: All wireless devices are off.
(2) Power lights (2)*	<ul style="list-style-type: none"> On: The computer is on. Blinking: The computer is in Standby. Blinking rapidly: An AC adapter with a higher power rating should be connected. Off: The computer is off or in Hibernation.
(3) Battery light	<ul style="list-style-type: none"> Amber: A battery is charging. Green: A battery is close to full charge capacity. Blinking amber: A battery that is the only available power source has reached a low battery level. When the battery reaches a critical battery level, the battery light begins blinking rapidly. Off: If the computer is plugged into an external power source, the light turns off when all batteries in the computer are fully charged. If the computer is not plugged into an external power source, the light stays off until the battery reaches a low battery level.
(4) Drive light	<ul style="list-style-type: none"> Blinking green: The hard drive or optical drive is being accessed. Amber: HP 3D DriveGuard has temporarily parked the internal hard drive.
(5) Caps lock light	On: Caps lock is on.
(6) Num lock light	On: Num lock is on or the embedded numeric keypad is enabled.

Component	Description
(7) Volume mute light	<ul style="list-style-type: none"> • Off: Computer sound is on. • On: Computer sound is off.
(8) Volume down light	Blinking: The volume scroll zone is being used to decrease speaker volume.
(9) Volume up light	Blinking: The volume scroll zone is being used to increase speaker volume.

*The 2 power lights display the same information. The light on the power button is visible only when the computer is open. The power light on the front of the computer is visible whether the computer is open or closed.

†The 2 wireless lights display the same information. The light on the wireless button is visible only when the computer is open. The wireless light on the front of the computer is visible whether the computer is open or closed.

Buttons, switches, and fingerprint reader



Component	Description
(1) Power button	<ul style="list-style-type: none"> When the computer is off, press the button to turn on the computer. When the computer is on, press the button to shut down the computer. When the computer is in Standby, press the button briefly to exit Standby. When the computer is in Hibernation, press the button briefly to exit Hibernation. <p>If the computer has stopped responding and Windows® shutdown procedures are ineffective, press and hold the power button for at least 5 seconds to turn off the computer.</p> <p>To learn more about your power settings, select Start > Control Panel > Performance and Maintenance > Power Options.</p>
(2) info button	<p>Launches Info Center, which enables you to open various software solutions.</p>
(3) Wireless button	<p>Turns the wireless feature on or off, but does not establish a wireless connection.</p>
(4) Presentation button	<p>Starts the presentation feature.</p>
(5) Volume mute button	<p>Mutes and restores speaker sound.</p>
(6) Volume scroll zone	<p>Adjusts speaker volume. Slide your finger to the left to decrease volume and to the right to increase volume. You can also press the left side of the volume slider to decrease volume, or press the right side of the volume slider to increase volume.</p>




NOTE: A wireless network must be set up in order to establish a wireless connection.

Component	Description
(7) Internal microphone	Records sound.
(8) HP Fingerprint Sensor (fingerprint reader)	Allows a fingerprint logon to Windows, instead of a password logon.

Keys




NOTE: Your computer may look slightly different from the illustration in this section.



Component	Description
(1) <code>esc</code> key	Displays system information when pressed in combination with the <code>fn</code> key.
(2) <code>fn</code> key	Executes frequently used system functions when pressed in combination with a function key or the <code>esc</code> key.
(3) Windows logo key	Displays the Windows Start menu.
(4) Windows applications key	Displays a shortcut menu for items beneath the pointer.
(5) Embedded numeric keypad keys	Can be used like the keys on an external numeric keypad.
(6) Function keys	Execute frequently used system functions when pressed in combination with the <code>fn</code> key.


Front components




Component	Description
(1) Wireless light	<ul style="list-style-type: none"> On: An integrated wireless device, such as a wireless local area network (WLAN) device, the HP Broadband Wireless Module, and/or a Bluetooth device, is on. Off: All wireless devices are off.
(2) Power light	<ul style="list-style-type: none"> On: The computer is on. Blinking: The computer is in Standby. Blinking rapidly: An AC adapter with a higher power rating should be connected. Off: The computer is off or in Hibernation.
(3) Battery light	<ul style="list-style-type: none"> Amber: A battery is charging. Green: A battery is close to full charge capacity. Blinking amber: A battery that is the only available power source has reached a low battery level. When the battery reaches a critical battery level, the battery light begins blinking rapidly. Off: If the computer is plugged into an external power source, the light turns off when all batteries in the computer are fully charged. If the computer is not plugged into an external power source, the light stays off until the battery reaches a low battery level.
(4) Drive light	<ul style="list-style-type: none"> Blinking green: The hard drive or optical drive is being accessed. Amber: HP 3D DriveGuard has temporarily parked the hard drive.
(5) Speakers (2)	Produce sound.
(6) Infrared port	Provides wireless communication between the computer and an optional IrDA-compliant device.
(7) Media Card Reader	Supports the Secure Digital (SD) Memory Card and MultiMediaCard (MMC) optional digital card formats.
(8) Display release latch	Opens the computer.
(9) Bluetooth compartment	Contains a Bluetooth device.

Rear components




Component	Description
(1) Security cable slot	Attaches an optional security cable to the computer.  NOTE: The security cable is designed to act as a deterrent, but it may not prevent the computer from being mishandled or stolen.
(2) Power connector	Connects an AC adapter.
(3) S-Video-out jack	Connects an optional S-Video device such as a television, VCR, camcorder, overhead projector, or video capture card.
(4) External monitor port	Connects an external VGA monitor or projector.



Right-side components




Component	Description
(1) Smart card reader	Supports smart cards and Java™ cards.
(2) MultiBay optical drive	Reads an optical disc.
(3) USB port	Connects an optional USB device.
(4) RJ-45 (network) jack	Connects a network cable.
(5) RJ-11 (modem) jack	Connects a modem cable.

Left-side components



Component	Description
(1) Vent	<p>Enables airflow to cool internal components.</p> <p> CAUTION: To prevent overheating, do not obstruct vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or thick rugs or clothing, to block airflow.</p> <p> NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.</p>
(2) USB ports (2)	Connect optional USB devices.
(3) 1394 port	Connects an optional IEEE 1394 or 1394a device, such as a camcorder.
(4) Audio-in (microphone) jack	Connects an optional computer headset microphone, stereo array microphone, or monaural microphone.
(5) Audio-out (headphone) jack	Produces sound when connected to optional powered stereo speakers, headphones, ear buds, a headset, or television audio.
(6) PC Card slot	Supports optional Type I or Type II 32-bit (CardBus) or 16-bit PC Cards.
(7) PC Card eject button	Ejects a PC Card from the PC Card slot.

Bottom components



Component	Description
(1) Bluetooth compartment	Contains a Bluetooth device.
(2) Vents (5)	Enable airflow to cool internal components. <p>CAUTION: To prevent overheating, do not obstruct vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or thick rugs or clothing, to block airflow.</p> <p>NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.</p>
(3) WLAN module compartment	Contains a WLAN module. <p>CAUTION: To prevent an unresponsive system and the display of a warning message, replace the device with only a WLAN module authorized for use in the computer by the governmental agency that regulates wireless devices in your country. If you replace the device and then receive a warning message, remove the device to restore computer functionality, and then contact technical support through Help and Support.</p>
(4) Battery release latches (2)	Release the battery from the battery bay.
(5) Battery bay	Holds the battery.
(6) Docking connector	Connects an optional docking device.
(7) Accessory battery connector	Connects an optional accessory battery.
(8) Memory module compartment	Contains the memory module slots.
(9) Hard drive bay	Holds the hard drive.

Wireless antennae



Component	Description
(1) WLAN antennae (3)*	Send and receive wireless signals to communicate with wireless local area networks (WLAN).
(2) WWAN antennae (2)*	Send and receive wireless signals to communicate with wireless wide-area networks (WWAN).

*The antennae are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennae free from obstructions.

Additional hardware components



Component	Description
(1) Power cord*	Connects an AC adapter to an AC outlet.
(2) AC adapter	Converts AC power to DC power.
(3) Battery*	Powers the computer when the computer is not plugged into external power.
(4) Modem cable*	Connects the internal modem to an RJ-11 telephone jack or to a country-specific modem adapter.

*Modem cables, batteries, and power cords vary in appearance by region and country.

3 Labels

The labels affixed to the computer provide information you may need when you troubleshoot system problems or travel internationally with the computer.

- Service tag—Provides the product brand and series name, serial number (s/n), and product number (p/n) of your computer. Have this information available when you contact technical support. The service tag label is affixed to the bottom of the computer.
- Microsoft® Certificate of Authenticity (select models only)—Contains the Windows® Product Key. You may need the Product Key to update or troubleshoot the operating system. This certificate is affixed to the bottom of the computer.
- Regulatory label—Provides regulatory information about the computer. The regulatory label is affixed to the business cardholder on the bottom of the computer.
- Modem approval label—Provides regulatory information about the modem and lists the agency approval markings required by some of the countries in which the modem has been approved for use. You may need this information when traveling internationally. The modem approval label is affixed to the business cardholder on the bottom of the computer.
- Wireless certification label(s) (select models only)—Provide information about optional wireless devices and the approval markings of some of the countries in which the devices have been approved for use. An optional device may be a wireless local area network (WLAN) device, an HP Broadband Wireless Module, or an optional Bluetooth® device. If your computer model includes one or more wireless devices, one or more certification labels are included with your computer. You may need this information when traveling internationally. Wireless certification labels are affixed to the business cardholder on the bottom of the computer.
- SIM (subscriber identity module) label (select models only)—Provides the ICCID (Integrated Circuit Card Identifier) of your SIM. This label is located inside the battery bay.
- HP Broadband Wireless Module serial number label (select models only)—Provides the serial number of your HP Broadband Wireless Module. This label is located inside the battery bay.

Index

Symbols/Numerics

1394 port, identifying 13

A

AC adapter, identifying 16
accessory battery connector,
identifying 14
applications key, Windows 9
audio-in (microphone) jack,
identifying 13
audio-out (headphone) jack,
identifying 13

B

battery bay 14, 17
battery light, identifying 5, 10
battery release latch,
identifying 14
battery, identifying 16
bays
battery 14, 17
hard drive 14
Bluetooth compartment,
identifying 10, 14
Bluetooth label 17
buttons
info 7
PC Card eject 13
power 7
presentation 7
TouchPad 4
volume mute 7
wireless 7

C

caps lock light, identifying 5
Certificate of Authenticity label 17
compartment, memory
module 14

components
additional hardware 16
bottom 14
front 10
left-side 13
rear 11
right-side 12
top 3
wireless antennae 15
connector, power 11
cord, power 16

D

display release latch,
identifying 10
docking connector, identifying 14
drive light, identifying 5, 10

E

esc key, identifying 9
external monitor port,
identifying 11

F

fingerprint reader, identifying 8
Fingerprint Sensor, identifying 8
fn key, identifying 9
function keys, identifying 9

H

hard drive bay, identifying 14
headphone (audio-out) jack 13
HP Broadband Wireless Module
label 17
HP Fingerprint Sensor,
identifying 8

I

IEEE 1394 port, identifying 13
info button, identifying 7

infrared port, identifying 10
internal microphone, identifying 8

J

jacks
audio-in (microphone) 13
audio-out (headphone) 13
RJ-11 (modem) 12
RJ-45 (network) 12
S-Video-out 11

K

keypad keys, identifying 9
keys
esc 9
fn 9
function 9
keypad 9
Windows applications 9
Windows logo 9

L

labels
Bluetooth 17
HP Broadband Wireless
Module 17
Microsoft Certificate of
Authenticity 17
modem approval 17
regulatory 17
service tag 17
SIM 17
wireless certification 17
WLAN 17
latch, battery release 14
lights
battery 5, 10
caps lock 5
drive 5, 10
mute 6

- num lock 5
- power 5, 10
- volume down 6
- volume mute 6
- volume up 6
- wireless 5, 10

M

- Media Card Reader, identifying 10
- memory module compartment, identifying 14
- microphone (audio-in) jack 13
- Microsoft Certificate of Authenticity label 17
- modem approval label 17
- monitor port, external 11
- mute button, identifying 7
- mute light, identifying 6

N

- num lock light, identifying 5

O

- operating system
 - Microsoft Certificate of Authenticity label 17
 - Product Key 17
- optical drive, identifying 12

P

- PC Card eject button, identifying 13
- PC Card slot, identifying 13
- ports
 - 1394 13
 - external monitor 11
 - USB 12, 13
- power button, identifying 7
- power connector, identifying 11
- power cord, identifying 16
- power light, identifying 10
- power lights, identifying 5
- presentation button, identifying 7
- Product Key 17
- product name and number, computer 17

R

- regulatory information
 - modem approval label 17

- regulatory label 17
 - wireless certification labels 17
- release latch, battery 14
- RJ-11 (modem) jack, identifying 12
- RJ-45 (network) jack, identifying 12

S

- S-Video-out jack, identifying 11
- scrolling regions, TouchPad 4
- security cable slot, identifying 11
- serial number, computer 17
- service tag 17
- SIM label 17
- slots
 - memory module 14
 - smart card reader 12
- smart card reader, identifying 12
- speaker, identifying 10

T

- TouchPad
 - buttons 4
 - identifying 4
 - scroll zone 4
- traveling with the computer
 - modem approval label 17
 - wireless certification labels 17

U

- USB ports, identifying 12, 13

V

- vent 13
- vents, identifying 14
- volume down light, identifying 6
- volume mute button, identifying 7
- volume mute light, identifying 6
- volume scroll zone, identifying 7
- volume up light, identifying 6

W

- Windows applications key, identifying 9
- Windows logo key, identifying 9
- wireless button, identifying 7
- wireless certification label 17
- wireless light, identifying 5, 10
- WLAN antennae, identifying 15
- WLAN device 17
- WLAN label 17
- WWAN antenna, identifying 15

