

HP Photosmart
E330 series
Digital Camera
User Guide




Legal and notice information

© Copyright 2007 Hewlett-Packard Development Company, L.P.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Windows® is a U.S. registered trademark of Microsoft Corporation.

 SD Logo is a trademark of its proprietor.

Contents


1 Getting started	
Camera top and back	3
Camera front, side, and bottom	4
Before taking pictures	4
Install the batteries	4
Turn on the camera	4
Choose the language	5
Set the region	5
Set the date and time	5
Install and format an optional memory card	6
Install the software	6
Using your camera	7
2 Taking pictures and recording video clips	
Taking pictures	8
Recording video clips	9
Instant Review	9
Digital zoom	9
3 Setting options for taking pictures and recording video clips	
Setting the flash	10
Flash Setting—Red-Eye	10
Using the Picture Capture Menu	11
Using the Self-Timer setting	12
Using the Burst setting	12
4 Reviewing images and video clips	
Deleting images	14
Using the Playback Menu	14
Removing red eyes	15
Magnifying images	15
Viewing thumbnails	15
Tagging images as Favorites	15
Viewing slideshows	16
5 Transferring and printing images	
Transferring images with HP Photosmart Software	17
Transferring images without HP Photosmart Software	18
Connecting to the computer	18
Using a memory card reader	19
Printing images directly to a printer	19
6 Using HP Photosmart Express	
Using the Photosmart Express Menu	21
Marking images for printing	21
Buying prints online	23

Sharing images	23
Setting up online destinations in the camera	23
Sending images to online destinations	24
7 Using the Camera Setup Menu	25
8 Troubleshooting	
Resetting the camera	26
Problems and solutions	26
Camera error messages	31
9 Product support	
Helpful websites	32
Getting assistance	32
A Managing batteries	
Top points about batteries	33
Extending battery life	33
Safety precautions for using batteries	33
Power indicators	34
Battery performance	34
Recharging NiMH batteries	35
B Specifications	
Memory capacity	37
Image quality	37
Index.....	38

1 Getting started


Use this section to get familiar with camera controls, set up your digital camera for use, and begin taking pictures.

Camera top and back



1	Power light.
2	ON/OFF button.
3	Shutter button.
4	Viewfinder.
5	Delete button—Accesses the Delete function while in Instant Review (see “Instant Review” on page 9) and Playback (see “Deleting images” on page 14).
6	Flash button— Accesses the flash settings while in Picture Capture (see “Setting the flash” on page 10).
7	selector—Switches between Picture Capture and Playback (see “Taking pictures” on page 8 and “Reviewing images and video clips” on page 13).
8	and buttons—Scroll through menus and images and access digital zoom. While in Picture Capture , press to zoom in; press to zoom out (see “Digital zoom” on page 9).
9	Menu/OK button—Displays camera menus, selects options, and confirms actions.
10	Back button—Returns you to the previous menu or view. Press and hold to back out of all menus.
11	Image Display.

Camera front, side, and bottom




1	Flash.
2	Viewfinder.
3	Self-Timer light (see “Using the Self-Timer setting” on page 12).
4	Tripod mount.
5	Dock/USB connector.
6	Battery/Memory Card door.


Before taking pictures

Complete the following procedures before taking pictures or recording video clips.

Install the batteries

1. Open the Battery/Memory Card door by sliding the latch as indicated on the Battery/Memory Card door.
2. Insert the two AA batteries.
3. Close the Battery/Memory Card door.

 **NOTE:** If using rechargeable NiMH batteries, fully charge the batteries before using them the first time (see [“Recharging NiMH batteries”](#) on page 35). Turn off the camera before removing the batteries.




Turn on the camera

To turn on the camera, press the ON/OFF button.

Choose the language

Use ▲▼ ◀▶ to choose the language you want, then press $\frac{\text{Menu}}{\text{OK}}$.


To change the language later, use the  **Camera Setup Menu** (see [“Using the Camera Setup Menu”](#) on page 25).



Set the region

Along with the language setting, the region setting determines the default date format.


Use ▲▼ to choose the region you want, then press $\frac{\text{Menu}}{\text{OK}}$.



Set the date and time

Accurately setting the date and time will help you locate images once you have transferred them to your computer, and will ensure that images are accurately marked if you use the date and time imprint feature. See **Date & Time Imprint** under [“Using the Picture Capture Menu”](#) on page 11.

1. Use ▲▼ to adjust the highlighted value.
2. Use ◀▶ to move to the other selections and repeat Step 1 until the date and time are set correctly.
3. Press $\frac{\text{Menu}}{\text{OK}}$ when the date, time, and format settings are correct, then press $\frac{\text{Menu}}{\text{OK}}$ again to confirm.

To change the date and time later, use the  **Camera Setup Menu** (see [“Using the Camera Setup Menu”](#) on page 25).



Install and format an optional memory card

This camera supports standard, high speed, and high capacity Secure Digital (SD and SDHC) memory cards, 32MB to 8GB.

1. Turn off the camera and open the Battery/Memory Card door.
2. Insert the memory card in the smaller slot as shown. Make sure the memory card snaps into place.
3. Close the Battery/Memory Card door and turn on the camera.



NOTE: When you turn on your camera with a memory card installed, the camera indicates the number of images you can store on the memory card at the current **Image Quality** setting. This camera supports storing a maximum of 2000 images on a memory card.

Always format new memory cards before first use. Formatting removes all images from the memory card, so make sure to transfer existing images before formatting (see [“Transferring and printing images” on page 17](#)).

1. With the camera turned on, slide to .
2. Press .
3. Use to select **Format Card**, then press .
4. Use to select **Yes**, then press to format the card.

NOTE: Once you install a memory card, all new images and video clips are stored on the card, rather than in internal memory. To use internal memory and view images stored there, turn off the camera then remove the memory card. To transfer images from internal memory to an optional memory card, see **Move Images to Card** under [“Using the Playback Menu” on page 14](#).

For information about supported memory cards, see [“Storage” on page 36](#).

Install the software

The HP Photosmart Software provides features for transferring images and video clips to your computer, as well as features for modifying stored images (remove red eyes, rotate, crop, resize, and more).

To install the HP Photosmart Software, your computer must meet the system requirements as stated on the camera packaging.

If you have trouble installing or using the HP Photosmart Software, see the Hewlett-Packard Technical Support website for more information: www.hp.com/support. Known issues are often fixed with new releases of firmware. To optimize your digital photography experience, periodically check this website for updates to your camera's firmware, software, and drivers.

To learn about Windows Vista support for your camera, see www.hp.com/go/windowsvista (English only).

Windows:

1. Close all programs and temporarily disable any virus protection software.
2. Insert the HP Photosmart Software CD into the CD drive and follow the on-screen instructions. If the installation screen does not appear, click **Start**, click **Run**, type **D:\Setup.exe**, where **D** is the letter of your CD drive, then click **OK**.
3. When the software has finished installing, re-enable virus protection software.

Macintosh:

1. Insert the HP Photosmart Software CD into the CD drive.
2. Double-click the CD icon on the computer desktop.
3. Double-click the installer icon, then follow the on-screen instructions.

Once installation is complete and you have restarted your computer, **System Preferences** automatically opens to the **HP Photosmart Camera** settings. You may change settings so the HP Photosmart Software starts automatically when you connect your camera to your Macintosh (click the help button on the **HP Photosmart Camera** settings dialog for more information).





Using your camera

Now that you've completed setup, you can take and review pictures and video clips.




For information on taking pictures and recording video clips	See " Taking pictures " on page 8 and " Recording video clips " on page 9
For information on setting picture capture and video record settings	See " Setting options for taking pictures and recording video clips " on page 10
For information on reviewing images and video clips on the camera	See " Reviewing images and video clips " on page 13
For information on transferring images from your camera to a computer	See " Transferring images with HP Photosmart Software " on page 17
For information on printing images	See " Printing images directly to a printer " on page 19

 **TIP:** To switch between  **Picture Capture** and  **Playback**, slide   to the desired option.

2 Taking pictures and recording video clips




You can take pictures and record video clips when you are in  **Picture Capture**. Slide   to  to take pictures or record video clips. The Image Display resembles the following:




1		Picture Capture indicator.
2	12	Pictures remaining count.
3		Battery level indicator (see “Power indicators” on page 34).
4		Memory card indicator.

Taking pictures





You can take a picture when the camera is set to  **Picture Capture**.


1. Slide   to .
2. Frame the subject for your picture in the Image Display or the viewfinder.
3. Press the **Shutter** button all the way down to take the picture.



Recording video clips

Your camera allows you to record video clips without sound.

1. Slide  to , then press $\frac{\text{Menu}}{\text{OK}}$.
2. In the  **Picture Capture Menu**, use \blacktriangle / \blacktriangledown to highlight $\frac{\text{Mode}}{\text{Shooting Mode}}$, then press $\frac{\text{Menu}}{\text{OK}}$.
3. In the $\frac{\text{Mode}}{\text{Shooting Mode}}$ menu, use \blacktriangle / \blacktriangledown to highlight  **Video**, press $\frac{\text{Menu}}{\text{OK}}$, then hold down ⏏ until the menu disappears.
4. Frame the subject in the Image Display or the viewfinder.
5. Press the **Shutter** button all the way down and release to begin recording video.
6. To stop recording video, press and release the **Shutter** button again.




Instant Review

After you have taken a picture or recorded a video clip, the camera displays it briefly in **Instant Review**. If you want to delete the image or video clip, press , select **This Image** from the  **Delete** menu, then press $\frac{\text{Menu}}{\text{OK}}$.



Digital zoom

In digital zoom, the Image Display shows a yellow frame around the scene and the image quality setting (MP value). As you zoom in, the scene expands to show what the camera will capture, and the MP value decreases to indicate the resolution at which the scene will be captured.

When capturing images using digital zoom, make sure that the MP value on the Image Display is appropriate for the size at which you want to print the captured image. For MP values and their recommended print sizes, see **Image Quality** under [“Using the Picture Capture Menu”](#) on page 11.

 **TIP:** The more you zoom in on the subject of your picture, the more small movements of the camera are magnified (this is called camera shake). To reduce potential blur caused by these movements, hold the camera still, add more light to the scene, or steady the camera by holding it closer to your body or against a steady object, or by setting it on a tripod or stable surface.

To use digital zoom:




1. Slide  to .
2. Press and hold \uparrow until the image you want fills the yellow frame. If you zoom too far, press $\downarrow\downarrow\downarrow$.





 **NOTE:** Digital zoom is not available when recording video clips.

3 Setting options for taking pictures and recording video clips



Your camera's default settings work well for most shooting situations. For some situations, however, the features described in this chapter can improve the pictures you take and the video clips you record. In addition to setting features that optimize the camera for lighting and motion, you can also set the camera to take a series of pictures rapidly or take images 10 seconds after you press the **Shutter** button, giving you time to place yourself in the image.

Setting the flash


To select a flash setting, press  while in  **Picture Capture**, use   to highlight the desired flash mode, then press . To exit without changing the flash setting, press .

	Auto Flash (Default)—The camera uses the flash if necessary.
	Red-Eye —The camera uses the flash with red-eye reduction, if necessary, to minimize the possibility of human eyes appearing red in the final image. For information about red-eye, see " Flash Setting—Red-Eye " on page 10.
	Flash On —The camera always uses flash. If the light is behind your subject, use this setting to increase the light on the front of your subject.
	Flash Off —The camera does not use flash. Use this setting to capture poorly lit subjects beyond the flash range or to capture scenes with the existing light.


The flash setting remains in effect until it is changed again, or you turn off the camera.




 **NOTE:** The flash is set to  **Flash Off** in  **Landscape**,  **Sunset**, and  **Theatre** shooting modes, and while recording video clips or using  **Burst**. The flash is set to  **Red-Eye** in  **Night Portrait** shooting mode.

Flash Setting—Red-Eye

The red-eye phenomenon is caused when light from the flash reflects off the subjects' eyes, which can make human eyes appear red in the captured image. Using  **Red-Eye** causes the camera to flash quickly up to three times to shrink the subject's pupils (reducing the effect of the red-eye phenomenon) before using the main flash and capturing the image. Since it takes longer to take a picture using this setting, make sure your subjects wait for the additional flashes.














Using the Picture Capture Menu

The  **Picture Capture Menu** allows you to adjust camera settings that affect the characteristics of the pictures you capture.







1. Slide   to , then press $\frac{\text{Menu}}{\text{OK}}$.
2. Use \blacktriangle / \blacktriangledown to highlight an option, then press $\frac{\text{Menu}}{\text{OK}}$ to display the option's menu.
3. Use \blacktriangle / \blacktriangledown to highlight a setting, then press $\frac{\text{Menu}}{\text{OK}}$ to change the setting or press \curvearrowright to exit without changing the setting.
4. To exit the menu, hold down \curvearrowright until the menu disappears.


For information about an option, use \blacktriangle / \blacktriangledown to highlight **? Help...** in the option's menu, then press $\frac{\text{Menu}}{\text{OK}}$.

Unless otherwise noted, the setting remains in effect until you turn off the camera. The next time you turn on the camera, the settings reset to their defaults.


	<p>Shooting Mode—For selecting a predefined setting optimized for particular types of scenes or shooting situations.</p> <ul style="list-style-type: none"> •  Auto Mode (Default)—For taking good shots quickly, when you do not have time to select a special shooting mode. •  Theatre—For capturing images at school programs, concerts, or indoor sporting events without using flash. •  Landscape—For scenes with deep perspective, such as mountain scenes. •  Portrait—For pictures that have one or more people as their primary subject. •  Action—For capturing sporting events, moving cars, or any scene where you want to stop the action. •  Night Portrait—For capturing images of people at night. This mode uses the flash and a long exposure. As a result, you must set the camera on a tripod or stable surface. •  Sunset—For capturing outdoor scenes at sunset. •  Video—For recording video clips. For information about recording video clips, see “Recording video clips” on page 9.
	<p>Self-Timer—For taking pictures or recording video after a 10-second delay (see “Using the Self-Timer setting” on page 12).</p>
	<p>Image Quality—Sets resolution and compression for pictures only. The greater the number, the higher the resolution. The setting remains in effect until it is changed, even when you turn off the camera.</p> <ul style="list-style-type: none"> • 5MP Best—For enlarging or printing images greater than 28 x 36 cm (11 by 14 in). • Normal (5MP) (Default)—For printing images up to 28 x 36 cm (11 by 14 in). • 3MP—For printing images up to 20 x 25 cm (8 by 10 in). • 1MP—For printing images up to 10 x 15 cm (4 by 6 in). • VGA—For sending images via e-mail or posting them to the Internet.
	<p>Burst—For taking up to two pictures quickly in succession (see “Using the Burst setting” on page 12).</p>
	<p>Color—Sets the color in which pictures will be captured. Full Color (Default), Black & White, Sepia</p>















(continued)

	<p>Date & Time Imprint—Imprints date in lower left corner of pictures only. The setting remains in effect until it is changed, even when you turn off the camera.</p> <ul style="list-style-type: none"> • Off (Default)—No date or time imprinted on the image. •  Date Only—Date permanently imprinted. •  Date & Time—Date and time permanently imprinted.
	<p>Camera Setup...—Displays the  Camera Setup Menu for setting camera behavior (see “Using the Camera Setup Menu” on page 25).</p>
	<p>Camera Help...—Displays a list of help topics for commonly used features.</p>

 **NOTE:** Some menu options are not available in certain shooting modes.


Using the Self-Timer setting







The  **Self-Timer** allows you to take an image or video clip 10 seconds after pressing the **Shutter** button.

1. If you want to record a video clip or change the shooting mode, access the  **Picture Capture Menu**, use  to highlight  **Shooting Mode**, press , highlight either  **Video** or another shooting mode, press , then press  to return to the  **Picture Capture Menu**.
2. In the  **Picture Capture Menu**, use  to highlight  **Self-Timer**, press , highlight **On**, press , then hold down  until the menu disappears.
3. Set the camera on a tripod or stable surface.
4. Frame the subject in the Image Display or the viewfinder.
5. Press the **Shutter** button all the way down. The camera begins the 10-second countdown, then takes the picture or begins recording the video clip.
6. If you are recording a video clip, press the **Shutter** button to stop recording.


The  **Self-Timer** setting resets to **Off** after the image is taken.

Using the Burst setting

 **Burst** allows you to take up to two pictures as quickly as possible when you press and hold the **Shutter** button all the way down.












1. While in the  **Picture Capture Menu**, use  to highlight  **Burst**, press , highlight **On**, press , then hold down  until the menu disappears.
2. Frame the subject, then press the **Shutter** button all the way down and hold it. The camera takes up to two pictures as quickly as possible until you release the **Shutter** button or the camera runs out of memory.

The Image Display remains off during the burst capture. After the burst images have been taken, each image appears one at a time in **Instant Review** (see [“Instant Review”](#) on page 9). You can delete the entire burst sequence in **Instant Review**. To delete individual images, see [“Deleting images”](#) on page 14.

The  **Burst** setting remains in effect until it is changed again, or until it resets to the default **Off** setting when you turn off the camera.








4 Reviewing images and video clips

You can review and manipulate images and video clips in **Playback** as described here.

1. Slide   to .
2. Use   to scroll through your images and video clips.
Press  to view video clips; press   to pause a clip. When paused, use   to scroll through the individual frames; press  to resume playing the video.





During **Playback**, the Image Display also indicates additional information about each image or video clip.











1		Playback indicator.
2		Battery indicator (see “Power indicators” on page 34).
3		Memory card indicator.
4	1 of 30	Number of this image or video clip out of the total number of stored images and video clips.
5		Image tagged as Favorite (see “Tagging images as Favorites” on page 15).
6		Image marked for printing via an online printing service (see “Buying prints online” on page 23).
7	 1	Number of electronic Photosmart Share destinations (see “Sharing images” on page 23).
8	 3	Number of copies to print (see “Marking images for printing” on page 21).















Deleting images

To delete a displayed image during **▶ Playback**:


1. Press .
2. Use   to select an option, then press .
 - **This Image**—Deletes the image or video clip.
 - **All Except Favorites**—Deletes all images except those tagged as **Favorites**. This menu option only appears if you have images tagged as **Favorites** (see [“Tagging images as Favorites” on page 15](#)).
 - **All Images (in Memory/on Card)**—Deletes all stored images and video clips.
 - **Format (Memory/Card)**—Deletes all stored files, then formats the internal memory or memory card.

Using the Playback Menu


1. While in **▶ Playback**, press .
2. Use   to highlight an option.
3. Use   to select an image or video clip, press , and follow the on-screen instructions.
4. To exit the selected **▶ Playback** option, press .
5. To exit the **▶ Playback Menu**, hold  until the menu disappears.


	Remove Red Eyes —Allows you to remove red eyes in images containing human subjects (see “Removing red eyes” on page 15).
	Rotate —Rotates images in 90-degree increments. Use   to rotate the image clockwise or counter-clockwise in 90-degree increments. Press  to save the image in the new orientation.
	Magnify —Allows you to magnify images (see “Magnifying images” on page 15).
	View Thumbnails —Allows you to view multiple images per screen on the Image Display for rapid review (see “Viewing thumbnails” on page 15).
	Photosmart Express... —Allows you to mark images for printing, sharing, and buying prints online (see “Using HP Photosmart Express” on page 21).
	Favorites —Allows you to tag images as Favorites (see “Tagging images as Favorites” on page 15).
	View Slideshow —Allows you to create and view slideshows of your images and video clips (see “Viewing slideshows” on page 16).
	Move Images to Card —Moves images from internal memory to memory card. Available only if there are images in internal memory and a memory card is inserted. To move images, select this option and follow the on-screen prompts.
	Camera Setup... —Displays the  Camera Setup Menu for setting camera behavior (see “Using the Camera Setup Menu” on page 25).
	Camera Help... —Displays a list of help topics for commonly used features.


Removing red eyes

When you select  **Remove Red Eyes**, the camera processes the current picture to remove red eyes from the subjects.

 **Remove Red Eyes** is only available for pictures taken with a flash.

 **NOTE:** To prevent red eyes in images, see [“Flash Setting—Red-Eye”](#) on page 10.








The red-eye removal process takes a few seconds, after which the magnified image displays with green boxes around corrected areas, along with the  **Remove Red Eyes** menu:


- **Save Changes** (Default)—Saves a copy of the original image with the changes and returns to the  **Playback Menu**.
- **View Changes**—Displays a magnified view of the image with green boxes around the corrected areas.

To exit the  **Remove Red Eyes** menu without saving changes, press .






Magnifying images

This feature is for viewing purposes only; it does not permanently alter the image.

1. From the  **Playback Menu**, select  **Magnify**. The currently displayed image is magnified 2x; press  to increase magnification to 4x.
2. Use  and  to pan around the magnified image.
3. Press  to return to the  **Playback Menu**.




Viewing thumbnails












1. From the  **Playback Menu**, select  **View Thumbnails**.
2. Use  and  to scroll through the thumbnails.
3. Press  to view the highlighted image on the Image Display.



Tagging images as Favorites


Tagging an image as a **Favorite** allows you to quickly select the group of images tagged as **Favorites** for printing or viewing as a group.




 **NOTE:** You can tag up to 200 images as **Favorites**.

1. While in  **Playback**, use   to display an image you want to tag as a **Favorite**.
2. From the  **Playback Menu**, select  **Favorites**, then select **This Image**. To untag the image as a **Favorite**, press  .
3. For each additional image you want to tag as a **Favorite**, use   to display the image, then repeat Step 2.
4. To exit the  **Playback Menu**, hold  until the menu disappears.

If you have the HP Photosmart Software installed on your computer, tagged images retain the tag when transferred to your computer (see [“Transferring and printing images”](#) on page 17).

Viewing slideshows


Select  **View Slideshow** to configure and run a slideshow of images and/or video clips on the camera Image Display.

From the  **View Slideshow** menu, use   to select a slideshow option.

- **Images**—Plays the specified images: **All** (default), **Favorites**, **Pictures Only**, **Videos Only**.
- **Interval**—Sets the amount of time each image is shown: **2 secs**, **5 secs** (Default), **10 secs**, **15 secs**, **60 secs**.
- **Loop**—Specifies how often the slideshow repeats: **Once** (Default), **2x**, **3x**, **Continuous**.

5 Transferring and printing images

Regularly transferring images to your computer and deleting them from the memory card will reduce the time it takes to turn on your camera, to review images, and to transfer images. You can transfer pictures and video clips with or without the HP Photosmart Software that came with your camera. However, the HP Photosmart Software has several features for transferring and managing your images and also guides you through the transfer process.


 **NOTE:** Transferring a large number of high-resolution images from a memory card to your computer may take up to two hours. Even if your Image Display turns off during the transfer process or it appears that nothing is happening on the computer, do not disconnect your camera from your computer until your computer indicates that image transfer is complete. When transferring a large number of images, be sure your camera batteries are fully charged or use an optional HP Photosmart dock or memory card reader.

Transferring images with HP Photosmart Software

If you have installed the HP Photosmart Software (see [“Install the software”](#) on page 6), use this method to transfer images and video clips to your computer.

When you connect your camera to a computer with the HP Photosmart Software installed:


- If you have tagged images as **Favorites** (see [“Tagging images as Favorites”](#) on page 15), the tags are transferred with the images to your computer.
- If you have marked images for printing (see [“Marking images for printing”](#) on page 21) and the computer is connected to a printer, the marked images are automatically printed.
- If you have marked images for sharing (see [“Sharing images”](#) on page 23) and the computer is connected to the Internet, the selected images are automatically sent to their destinations.
- If you have marked images to buy as prints (see [“Buying prints online”](#) on page 23) and the computer is connected to the Internet, you can follow the instructions on the computer screen to buy prints of those images you selected.
- You can transfer the images on the camera to the computer by following the instructions on the computer screen.


 **TIP:** You can also perform these tasks using an optional HP Photosmart dock (see the documentation that came with your dock).

To transfer images using the HP Photosmart software:

1. If you have marked images for sharing, printing, or buying prints online (see [“Using HP Photosmart Express”](#) on page 21), verify that the computer is connected to a printer and/or the Internet.
2. Turn off the camera.

3. Connect the camera and computer using the USB cable that came with your camera.
4. Turn on the camera. When the Image Display indicates that the camera is connected to the computer, follow the instructions on the computer screen. For more information, see the Help feature in the HP Photosmart Software.






 **NOTE:** If the camera does not successfully connect to the computer, see [“My camera stalls when establishing a connection to the computer.”](#) on page 30.

After you have transferred the images, you can then use the HP Photosmart Software to edit, print, or send the images from your computer.

Transferring images without HP Photosmart Software

If you do not install the HP Photosmart Software:


- You cannot use the  **Share** features or  **Buy Prints Online** on the camera's  **Photosmart Express Menu** (see [“Using HP Photosmart Express”](#) on page 21).
- Images marked for printing do not automatically print when the camera is connected to the computer.
- **Favorites** tags do not transfer to the computer.


However, you can still transfer images and video clips to your computer by:

- Connecting your camera directly to the computer (see [“Connecting to the computer”](#) on page 18)
- Using a memory card reader (see [“Using a memory card reader”](#) on page 19)

Connecting to the computer

1. Turn off the camera, connect the camera and computer using the USB cable that came with your camera, then turn on the camera. Your computer's provided image transfer software should start. Follow the on-screen instructions to transfer your images.
2. When you have finished transferring images, disconnect the camera from the computer.

If you encounter problems, set the camera's  **USB Configuration** to **Disk Drive** (see **USB Configuration** under [“Using the Camera Setup Menu”](#) on page 25) and reconnect to your computer.

 **NOTE:** On Macintosh computers, if you set the camera to **Disk Drive** and neither Image Capture nor iPhoto starts automatically, look on the desktop for a disk drive icon labeled with your camera model number and copy the images manually. For more information about how to copy files, visit Mac help.

Using a memory card reader

You can put your camera's optional memory card into a (separately purchased) memory card reader. Some computers and HP Photosmart printers have built-in memory card slots which act as a memory card reader.


1. Insert your camera's memory card into the memory card reader (or into your computer's memory card slot, if your computer has one).
2. Your computer's provided image transfer software starts automatically and guides you through the process of transferring images.
3. After verifying that the images were successfully transferred, return the memory card to your camera.

If no application starts automatically or if you want to copy the images manually, look for the disk drive for the memory card, then copy the images to your local hard drive. For more information about how to copy files, refer to your computer's help.


Printing images directly to a printer


You can print images directly from the camera to any PictBridge-certified printer. For information about printing images from your computer, see ["Transferring images with HP Photosmart Software"](#) on page 17.



 **NOTE:** You cannot print video clips using the method described in this section. You can, however, print a frame from a video clip using the HP Photosmart Software. For more information, see Help in the HP Photosmart Software.

1. Check that the printer is turned on, there is paper in the printer, and there are no printer error messages.
2. Turn off the camera, connect the camera and printer using the USB cable that came with your camera, then turn on the camera.
3. If the **Print marked pictures?** screen is displayed on the camera's Image Display, do one of the following:
 - If you want to print the pictures you marked for printing (see ["Marking images for printing"](#) on page 21), highlight **Yes**, press Menu OK, then follow the on-camera instructions to select print options and print the marked pictures.



 **NOTE:** After the printer prints the marked images, the Image Display on the camera shows an image. You can then select individual images to print by following the remaining steps in this procedure.

- If you want to select individual images to print, highlight **No**, then press Menu OK.


4. When the Image Display on the camera shows an image:
 - If you want to print one or more images, use ◀▶ to display an image you want to print, use ▲▼ to specify the number of copies, then press $\frac{\text{Menu}}{\text{OK}}$. In the **Print Options** menu, highlight **Print This Image Now**, and press $\frac{\text{Menu}}{\text{OK}}$.
 - If you want to print a group of images or modify the printer settings, press $\frac{\text{Menu}}{\text{OK}}$, highlight **Print Menu...**, then press $\frac{\text{Menu}}{\text{OK}}$ again. Highlight the option you want.
 - **Printer Settings**—Specifies paper size, print size and quality, and borderless printing. Use ▲▼ to select a print option and use ◀▶ to modify the selected print option. When you are done specifying print options, press $\frac{\text{Menu}}{\text{OK}}$.
 - **Print All**—Prints one copy of each image. Press $\frac{\text{Menu}}{\text{OK}}$ and follow the on-camera instructions to begin printing.
 - **Print Index**—Prints all images as thumbnails. Press $\frac{\text{Menu}}{\text{OK}}$ to begin printing.
 - **Print Favorites**—Prints one copy of each image tagged as a **Favorite**. Press $\frac{\text{Menu}}{\text{OK}}$ to begin printing. This option is available only if you have tagged at least one image as a **Favorite** (see [“Tagging images as Favorites” on page 15](#)).
 - **Cancel Printing**—Stops the printing of any images that have not yet printed. Press $\frac{\text{Menu}}{\text{OK}}$, highlight **Yes**, then press $\frac{\text{Menu}}{\text{OK}}$.
5. After the printer has printed all the images you selected, disconnect the camera from the printer.



NOTE: If you connect the camera to a non-HP printer and encounter problems with printing, contact your printer manufacturer. HP does not provide customer support for non-HP printers.

6 Using HP Photosmart Express




With **HP Photosmart Express**, you can select pictures in your camera to print automatically (see [“Marking images for printing”](#) on page 21), to buy prints online (see [“Buying prints online”](#) on page 23), or to send to custom destinations (see [“Sharing images”](#) on page 23) the next time you connect the camera to your computer or printer.




You must have the HP Photosmart Software installed on your computer to use some features in the  **Photosmart Express Menu**. For information about installing this software, see [“Install the software”](#) on page 6.



 **NOTE:** Available online services vary by country or region.

Using the Photosmart Express Menu

To display the  **Photosmart Express Menu**:

1. Slide  to  and press .
2. Use  to highlight  **Photosmart Express...**, then press .
3. Use  to highlight a menu option, then press .

	Print —Allows you to select images and specify number of copies to print. See “Marking images for printing” on page 21.
	Share —Allows you to add custom online destinations and share images to one or more destinations. See “Sharing images” on page 23.
	Buy Prints Online —Specifies images you want printed by an online printing service. See “Buying prints online” on page 23.


 **NOTE:** The features in the  **Photosmart Express Menu** are available only for pictures. They are not available for video clips.

Marking images for printing

Marked images are automatically printed when you connect the camera to a PictBridge-certified printer or a computer with the HP Photosmart Software installed. You can mark


individual images, all images, or groups of images tagged as **Favorites** (see [“Tagging images as Favorites”](#) on page 15).



1. While in the  **Photosmart Express Menu**, use \blacktriangle \blacktriangledown to highlight  **Print**, then press $\frac{\text{Menu}}{\text{OK}}$.


2. In the  **Print** menu, highlight an option, then press $\frac{\text{Menu}}{\text{OK}}$.

- **This Image**—Marks the image currently displayed. You can scroll to a different image using \blacktriangleleft \blacktriangleright .
- **All Favorites...**—Displays the **Print All Favorites** entry. Press $\frac{\text{Menu}}{\text{OK}}$. This option is available only if you have tagged more than one image as a **Favorite** (see [“Tagging images as Favorites”](#) on page 15).
- **All Images...**—Displays the **Print All Images** entry. Press $\frac{\text{Menu}}{\text{OK}}$. This option is available only if you have more than one image in the camera.



3. If you want to print more than one copy, highlight **Change Number of Copies**, then press $\frac{\text{Menu}}{\text{OK}}$. In the  **Print** menu for changing the number of copies, use \blacktriangle \blacktriangledown to specify the number of copies to print, then press $\frac{\text{Menu}}{\text{OK}}$.















4. From the main  **Print** menu, you can mark additional images for printing, using \blacktriangleleft \blacktriangleright to display an image, highlighting **This Image** in the  **Print** menu, pressing $\frac{\text{Menu}}{\text{OK}}$, then repeating Step 3.




5. When you are done marking images for printing, hold down OK until the menu disappears.
6. To print the marked images directly to a printer, see [“Printing images directly to a printer”](#) on page 19. To print them from a computer connected to a printer, see [“Transferring images with HP Photosmart Software”](#) on page 17.

Buying prints online

You can mark images you want to order as prints. The next time you connect the camera to a computer with the HP Photosmart Software installed, you can order prints of the marked images online.









1. While in the  **Photosmart Express Menu**, use  to highlight  **Buy Prints Online**, then press .
2. In the  **Buy Prints Online** menu, highlight an option, then press .
 - **This Image**—Marks the image currently displayed. You can scroll to a different image using .
 - **All Favorites...**—Displays the **Buy Prints of All Favorites** entry. Press , then press . This option is available only if you have tagged more than one image as a **Favorite** (see [“Tagging images as Favorites”](#) on page 15).
 - **All Images...**—Displays the **Buy Prints of All Images** entry. Press , then press . This option is available only if you have more than one image in the camera.
3. To mark additional images, use  to display an image, press , then repeat Step 2.
4. When you are done marking images for which you want to buy prints, hold down  until the menu disappears.
5. To buy prints of the images you selected, see [“Transferring images with HP Photosmart Software”](#) on page 17.


Sharing images

You can customize the  **Share** menu to include e-mail addresses, group distribution lists, or other online services. You can then select images to send to these destinations.

Setting up online destinations in the camera




You can specify up to 34 custom destinations (such as individual e-mail addresses or group distribution lists) in the  **Photosmart Express Menu**.

1. Verify that your computer is connected to the Internet.
2. While in the  **Photosmart Express Menu**, use  to highlight  **Share**, then press . If you have already created destinations, highlight **Share Menu Setup** and press  again.
3. Connect the camera to your computer. Follow the on-screen instructions to set up destinations in your camera.
4. Turn off the camera and disconnect the camera from the computer. Turn on the camera, access the  **Photosmart Express Menu**, then highlight  **Share** and press  to verify that the new destinations are now in the camera.







Sending images to online destinations












After you have set up online destinations in the camera, you can mark images to be sent to these custom destinations the next time you connect your camera to your computer.

1. While in the  **Photosmart Express Menu**, use \blacktriangle / \blacktriangledown to highlight  **Share**, then press $\frac{\text{Menu}}{\text{OK}}$.
2. In the  **Share** menu, highlight an option, then press $\frac{\text{Menu}}{\text{OK}}$.
 - **Custom Destinations**—Selects the destination to send the image displayed in the background. There may be multiple destinations depending on the number of them you created (see [“Setting up online destinations in the camera” on page 23](#)). You can scroll to a different image using \blacktriangle / \blacktriangledown .
 - **All Favorites...**—Displays a list of destinations. Highlight each destination to which you want to send all **Favorites**, pressing $\frac{\text{Menu}}{\text{OK}}$ to select each destination. After selecting destinations, press \blackrightarrow . This option is available only if you have tagged more than one image as a **Favorite** (see [“Tagging images as Favorites” on page 15](#)).
 - **All Images...**—Displays a list of destinations. Highlight each destination to which you want to send all images, pressing $\frac{\text{Menu}}{\text{OK}}$ to select each destination. After selecting destinations, press \blackrightarrow . This option is available only if you have more than one image in the camera.
3. To select additional images to share, use \blacktriangleleft / \blacktriangleright to display an image, then repeat Step 2.
4. When you are done marking images to share, hold down \blackrightarrow until the menu disappears.
5. To send the images to the destinations, see [“Transferring images with HP Photosmart Software” on page 17](#).









7 Using the Camera Setup Menu

The  **Camera Setup Menu** allows you to set preferences for the camera's behavior. The  **Camera Setup Menu** is available from the  **Picture Capture** and  **Playback** menus.

1. While in the  **Picture Capture** or  **Playback** menu, use  to highlight  **Camera Setup...**, then press .
2. Use  to highlight a menu option, then press  to display the menu option's menu.
3. Use  to highlight a setting, then press .
4. To exit the  **Camera Setup Menu**, hold down  until the menu disappears.

Settings you specify remain until you change them.

	Display Brightness —Adjusts the brightness of the Image Display. <ul style="list-style-type: none">• Low—For extending battery life.• Medium (Default)—For normal viewing conditions.• High—For very bright lighting conditions.
	Camera Sounds —Turns the camera sounds (such as button presses and shutter clicks) off and on. On (Default), Off .
	Date & Time —Sets the date and time. See “Set the date and time” on page 5.
	USB Configuration —Specifies how a computer recognizes the camera. See “Connecting to the computer” on page 18. <ul style="list-style-type: none">• Digital Camera (Default)—Recognizes the camera as a digital camera using PTP (Picture Transfer Protocol).• Disk Drive—Recognizes the camera as a disk drive using MSDC (Mass Storage Device Class).
	 (Language)—Sets the language. See “Choose the language” on page 5.

8 Troubleshooting

Use this section to find information on:

- Resetting the camera (see [“Resetting the camera”](#) on page 26)
- Possible problems and solutions (see [“Problems and solutions”](#) on page 26)

Resetting the camera


If your camera does not respond when you press buttons, reset the camera.

1. Turn off the camera.
2. Remove the memory card and batteries for at least 5 seconds.
3. Reinsert the batteries and close the Battery/Memory Card door.
4. Turn on the camera. On successful reset, you may be prompted to set the date and time (see [“Set the date and time”](#) on page 5).
5. Verify that the camera works without an optional memory card, turn off the camera, then reinstall the card.



When the camera is reset, any images or video clips stored in memory are retained.

Problems and solutions

Use this information to find solutions to common issues you may have using your camera.

 **NOTE:** Known issues are often fixed with new releases of firmware. To optimize your digital photography experience, periodically check the Hewlett-Packard Technical Support website (www.hp.com/support) for updates to your camera's firmware, software, and drivers.

How can I get professional-quality prints if I don't have a photo printer?

Use the  **Buy Prints Online** feature on the  **Photosmart Express Menu** (see [“Buying prints online”](#) on page 23).

The camera does not turn on.

- Install new or recharged batteries, ensuring that the batteries are inserted correctly (see [“Install the batteries”](#) on page 4). If you are using rechargeable batteries, ensure they are rechargeable Nickel Metal Hydride (NiMH) batteries.
- Reset the camera (see [“Resetting the camera”](#) on page 26).
- Ensure that the memory card is the proper type (see [“Storage”](#) on page 36). If so, remove the memory card and turn on the camera; if the camera turns on, format the memory card (see [“Install and format an optional memory card”](#) on page 6). If the camera still does not turn on, format the memory card using a memory card reader, or replace the memory card.


I have to recharge the NiMH batteries frequently.

- New batteries or batteries that have not been charged recently must be recharged to reach full capacity.
- If you have not used the batteries for two months or longer, recharge them.
- For tips on conserving battery life, see [“Extending battery life”](#) on page 33.

The NiMH batteries will not charge.

- Try charging the batteries again after they have drained awhile.
- If charging the batteries in an optional battery charger or when docked in an optional HP Photosmart dock does not work, replace the batteries.


It takes the camera a long time to turn on.

- Your camera may be slower to turn on if you have a high capacity (4GB or larger) memory card inserted.
- Having a large number of files (over 300) stored on a memory card affects the time it takes for the camera to turn on. Transfer stored files to your computer, then format the memory card.
- Power-on time in  **Playback** is slow if you have a large number of tagged images on your memory card. Transfer the images to your computer (see [“Transferring and printing images”](#) on page 17) and review them there.

The camera does not respond when I press a button.

- Turn on the camera.
- Most of the camera buttons do not respond when the camera is connected to a computer (directly or through an optional dock).
- Replace or recharge the batteries.
- Reset the camera (see [“Resetting the camera”](#) on page 26).
- The memory card may be defective. Remove the memory card and test the camera; if the camera works, replace the memory card.
- Format the internal memory and/or the memory card (see [“Install and format an optional memory card”](#) on page 6).




The camera does not take a picture when I press the Shutter button.

- Press the **Shutter** button all the way down.
- Make sure you are in  **Picture Capture**.
- The memory card or internal memory may be full. Transfer images from the camera to your computer, then format the internal memory or the memory card (see [“Install and format an optional memory card”](#) on page 6). Or replace the card with a new one.
- The camera may be processing. Wait a few seconds for the camera to finish processing the last image before taking another picture.

The Image Display is not working.

- The Image Display may have timed out. Press any camera button to wake up the camera.
- Reset the camera (see [“Resetting the camera”](#) on page 26).
- Replace or recharge the batteries.

My image is blurry.

- Use a tripod to hold the camera steady, or improve lighting conditions.
- Make sure the subject of your pictures or video clips is within the focus range (at least 1 m or 39.37 in away).
- Select a shooting mode appropriate for the scene you are capturing (see [“Using the Picture Capture Menu”](#) on page 11).
- Set the flash to  **Auto Flash** or  **Flash On** and set the shooting mode to  **Action**.

My image is too bright.

- Turn off the flash (see [“Setting the flash”](#) on page 10).
- Move back from the subject and use zoom.

My image is too dark.

- Wait for natural lighting conditions to improve, use the flash (see [“Setting the flash”](#) on page 10), or add indirect lighting.
- If the subject you are trying to capture is outside the flash range, turn off the flash. This causes a longer exposure time, so use a tripod or hold the camera steady. For information about flash working distance for this camera, go to www.hp.com/support, select your language and region, enter your camera model number in the **Search: Product** field, click **Product Information**, then click **Specifications**.

My image is grainy.

- Add indirect lighting, use the flash (see [“Setting the flash”](#) on page 10), or wait for natural lighting conditions to improve.
- You may have zoomed in too far using digital zoom (see [“Digital zoom”](#) on page 9).
- If the camera is warm, the effect will diminish as the camera cools. For best image quality, avoid storing the camera in very hot locations.


Images are missing on my camera.

Remove the memory card and see if the images are stored in internal memory. If so, transfer the images to the memory card (see **Move Images to Card** under [“Using the Playback Menu”](#) on page 14).

I have two memory cards that are the same size, but one stores many more pictures than the other.

- Your memory card may contain files that are not images or videos recognized by the camera. Save any data on the memory card that you want to keep, then format the memory card (see [“Install and format an optional memory card”](#) on page 6).
- If your memory cards are 4GB or larger, the card that stores fewer images may have been improperly formatted by a device that does not support 4GB or larger cards. A new type of High Capacity Secure Digital (marked SDHC) memory card is now available that prevents improper formatting and use by devices not supporting 4GB or larger cards. Try formatting the card in this camera, which supports High Capacity Secure Digital cards.
- Your memory card may be defective. If you have formatted your memory card in the camera and it does not show the expected capacity, consider replacing the memory card.


My camera indicates I can only store 2000 images regardless of the Image Quality setting.

When you turn on your camera with a memory card installed, the camera indicates the number of images you can store on the memory card at the current  Image Quality setting. This camera supports storing a maximum of 2000 images on a memory card.


It takes a long time to "Delete All" images from my memory card.

Having a large number of images stored on a memory card increases the time the camera takes to delete them. Instead of deleting them, format the memory card (see ["Install and format an optional memory card"](#) on page 6).

The Power light is on but the Image Display is off, or the camera seems stuck and won't operate.

- Slide  to a different position or press any camera button to reactivate the Image Display.
- Reset the camera (see ["Resetting the camera"](#) on page 26).

The camera responds sluggishly when trying to review images.

- Power-on time in  Playback is slow if you have a large number of tagged images on your memory card. Transfer the images to your computer (see ["Transferring and printing images"](#) on page 17) and review them there.
- See ["Storage"](#) on page 36 and ["Memory capacity"](#) on page 37 for tips about memory cards.

Video recording terminates abruptly. The video is saved successfully, but it is shorter than expected.

Replace your memory card with a faster card. Look for cards marked High Performance, Pro, Ultra, or High Speed.

Video recording terminates abruptly and the video will not play back.

If the video is stored on a memory card, transfer the video to your computer (see ["Transferring and printing images"](#) on page 17), then reformat the card (see ["Install and format an optional memory card"](#) on page 6).

The camera gets warm (or even hot) to the touch.

This is normal. However, if anything seems out of the ordinary, turn off the camera and allow the camera to cool. Then examine the camera and the batteries for signs of possible damage.

For best image quality, turn off the camera when not using. Always store the camera in a cool place.

My camera stalls when establishing a connection to the computer.

- Your memory card may have a large number of images stored on it. The more images you have on your card, the longer it takes to establish a connection to the computer (up to five minutes). If you have a large number of images on the memory card, be sure to allow this additional time to establish the connection.
- Ensure that the USB cable is properly connected to the camera and computer, either directly or via an optional dock.
- Try connecting the USB cable to another USB port on the computer.
- Turn the camera off, then on again. If that does not fix the problem, reset the camera (see [“Resetting the camera” on page 26](#)).
- If the problem persists, contact HP Support (see [“Product support” on page 32](#)).

I cannot transfer images from the camera to my computer.

- Either install the HP Photosmart Software (see [“Install the software” on page 6](#)), or see [“Transferring images without HP Photosmart Software” on page 18](#).
- Configure your camera preferences so the HP Photosmart software starts automatically when you connect your camera to your Macintosh. Open the **HP Photosmart Camera** settings in **System Preferences** to make changes, or to view the camera software help.
- Set your camera to act as a **Disk Drive** (see **USB Configuration** in [“Using the Camera Setup Menu” on page 25](#)), then follow the steps in [“Connecting to the computer” on page 18](#).

I get an error message when transferring images to my computer.

A power surge or electrostatic discharge may have affected the camera. Close the HP Photosmart Software, disconnect the camera from the computer, and reset the camera (see [“Resetting the camera” on page 26](#)). Then, restart the image transfer process (see [“Transferring images with HP Photosmart Software” on page 17](#)).

The HP Photosmart Software does not start automatically when I connect to my Macintosh.

Configure your camera preferences so the HP Photosmart software starts automatically when you connect your camera to your Macintosh. Open the **HP Photosmart Camera** settings in **System Preferences** to make changes, or to view the camera software help.

The HP Photosmart Software takes a long time before it is ready to transfer images from my camera.

Having a large number of files stored on an optional memory card affects the amount of time it takes for the HP Photosmart Software to start transferring images. For best results, transfer images to your computer frequently, and always format the card after transferring images (see [“Install and format an optional memory card” on page 6](#)).

My camera shuts down unexpectedly.

- A power surge or electrostatic discharge may have affected the camera. Remove the battery and reset the camera (see [“Resetting the camera” on page 26](#)). Then reinstall the battery and turn on the camera.
- Recharge the battery.
- Replace the battery.

I am having a problem installing or using the HP Photosmart Software.

- Make sure your computer meets the minimum system requirements as stated on the camera packaging.
- Refer to the HP Photosmart Software online help system.
- Refer to the Hewlett-Packard Technical Support website: www.hp.com/support.

Camera error messages

Should you receive one of the following error messages when using your camera, you can look up details about the message by visiting www.hp.com and searching on the specific code.

- **Unsupported card**—E330–200
- **Unable to format card**—E330–202
- **Error saving image**—E330–100
- **Error saving video**—E330–102
- **Batteries Low** (followed by data on battery types and performance)—AA–400

9 Product support

Use this section to find support information for your digital camera, including links to helpful websites and an overview of the support process.

Helpful websites

Camera tips, product registration, newsletter subscriptions, driver and software updates, purchase HP supplies and accessories	www.hp.com Under Learn about: , click Digital Photography
Customers with disabilities	www.hp.com/hpinfo/community/accessibility (English only)
Hewlett-Packard Technical Support; firmware, software, and driver updates; support information	www.hp.com/support
Windows Vista support	www.hp.com/go/windowsvista (English only)

Getting assistance

To get the best from your HP product, consult the following standard HP support offerings:

1. Consult the product documentation.
 - Review “[Troubleshooting](#)” on [page 26](#) in this document.
 - Review the electronic Help section within the software.
 - Refer to the camera's Help screens.
2. Visit the Hewlett-Packard Technical Support website at www.hp.com/support, or contact the store where you purchased this camera. The Hewlett-Packard Technical Support website is available to all HP customers. The Hewlett-Packard Technical Support website is the fastest source of up-to-date product information and expert assistance, including:
 - Fast e-mail access to qualified online support specialists.
 - Firmware, software, and driver updates for your camera.
 - Valuable product and troubleshooting information for technical issues.
 - Proactive product updates, support alerts, and HP newsletters (available when you register your camera).
3. HP support by phone. Support options and fees vary by product, country/region, and language. For a list of support conditions and phone numbers, visit www.hp.com/support.
4. Post-warranty period. After the limited warranty period, help is available online at www.hp.com/support.
5. Extending or upgrading your warranty. If you would like to extend or upgrade your camera's warranty, please contact the store where you bought the camera or check the HP Care Pack offers at www.hp.com/support.
6. If you already purchased an HP Care Pack Service, please check the support conditions on your contract.

A Managing batteries

Your camera uses two AA batteries, either Alkaline, Photo Lithium, or rechargeable Nickel Metal Hydride (NiMH). Photo Lithium and NiMH batteries provide longer battery life than Alkaline batteries.



Top points about batteries

- The batteries shipped with your camera are AA Alkaline. These batteries have a short life and are intended to let you begin using your camera immediately. When the camera warns that the battery charge is low (see [“Power indicators” on page 34](#)), HP recommends replacing them with Photo Lithium or rechargeable NiMH batteries for longer battery life.
- Fully charge NiMH batteries before using them for the first time.
- The first several times you recharge NiMH batteries, they may not provide the number of shots per charge that you expect. Their performance will improve after the batteries have been charged, then discharged completely four or five times. You can use the camera normally to discharge the batteries during this conditioning period.
- Always insert the batteries in the camera correctly (see [“Install the batteries” on page 4](#)). If the batteries are inserted improperly, the compartment door may close but the camera will not operate.
- If you do not intend to use your camera for more than one month, remove the batteries from the camera.
- The performance of all batteries will decrease as the temperature drops. To improve battery performance, store the camera and batteries in a warm inside pocket when in a cold environment. To prevent short-circuiting the batteries, never carry small metal items such as keys or coins in the same pocket with your batteries.

Extending battery life

To conserve battery power, the Image Display turns off after a period of inactivity. Pressing any button wakes up the camera. After five minutes of inactivity, the camera turns off.

To further extend battery life:

- Set  **Display Brightness to Low** (see **Display Brightness** under [“Using the Camera Setup Menu” on page 25](#)).
- Set your camera to  **Auto Flash** (see **Auto Flash** under [“Setting the flash” on page 10](#)).
- Use video recording sparingly.
- Use Image Display sparingly.
- When transferring or printing images, place your camera in an optional HP Photosmart dock connected to AC power.

Safety precautions for using batteries



- Always use two identical batteries of the same chemistry, brand, and age.
- Do not place batteries in fire or heat them. Always store charged batteries in a cool location.
- Do not connect the positive and negative terminals of the battery to each other with any metal object.
- Do not carry or store batteries with metal objects. Do not drop batteries into a change-filled pocket.
- Do not pierce batteries or subject them to strong impacts or shocks.
- Do not solder directly onto batteries.
- Do not allow batteries to get wet.
- Do not disassemble or modify batteries.

- Immediately discontinue use of a battery if, while using, charging, or storing the battery, the battery emits an unusual smell, feels excessively hot (note that it is normal for the battery to feel warm), changes color or shape, or appears abnormal in any other way.
- In the event batteries leak and the fluid gets into one’s eye, do not rub the eye. Rinse well with water and immediately seek medical care. If left untreated, the battery fluid could cause damage to the eye.

⚠ CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Power indicators


When the batteries are low or the camera is in a dock connected to AC power, one of the following icons appears in the Image Display. If no battery icon appears in the Image Display, the batteries have sufficient power to function normally.

Icon	Description
	Battery level is low. Camera will soon power down.
	Camera is operating on AC power.

📖 NOTE: If the camera is without batteries for a prolonged period, the clock may be reset and you may be prompted to update it the next time you power on the camera.

Battery performance

This graph shows the relative number of photos you can take using Photo Lithium, NiMH, and Alkaline batteries. Actual performance may vary based on usage, battery type, and battery manufacturer. Many additional factors affect the number of photos you can take (see “[Top points about batteries](#)” on page 33).



📖 NOTE: For more information about batteries, go to www.hp.com/support and search on the code **AA-400**.

The following table shows how Alkaline, Photo Lithium, and rechargeable NiMH batteries perform in different types of use scenarios:

Type of Use	Alkaline	Photo Lithium	NiMH
Most economical if you take more than 30 pictures per month	Poor	Fair	Good
Most economical if you take fewer than 30 pictures per month	Fair	Good	Fair


(continued)

Type of Use	Alkaline	Photo Lithium	NiMH
Heavy use of flash, frequent pictures	Poor	Good	Good
Heavy use of video	Poor	Good	Good
Heavy use of Image Display	Poor	Good	Good
Overall battery life	Poor	Good	Fair
Low temperature/winter use	Poor	Good	Fair
Infrequent use (without dock)	Fair	Good	Fair
Infrequent use (with dock)	Fair	Good	Good
Want to recharge battery	No	No	Good

Recharging NiMH batteries

You can recharge optional NiMH batteries with an optional HP quick recharger or with an optional HP Photosmart dock. For information about recharging NiMH batteries, as well as safety precautions when recharging, see the documentation that came with your HP quick recharger or HP Photosmart dock.

B Specifications

Resolution	<p>Pictures:</p> <ul style="list-style-type: none"> • 5.0MP (2576 by 1920) effective pixel count • 5.02MP (2592 by 1936) total pixel count <p>Video clips (QVGA): 320 by 240 total pixel count, 24 frames/sec</p>
Sensor	Diagonal 7.26 mm (1/2.5-inch, 4:3 format) CCD
Color depth	36 bit (12 bits by 3 colors). 36 bit images are transformed into an optimized 24 bit image and stored in the JPEG format. This transformation results in no discernible change to color or detail in the stored image, and allows the image to be read by computers.
Lens	Fixed focal length—f/4.5
Viewfinder	None
Zoom	5x digital zoom
Focus	Fixed focus—1 m (39.37 in) to infinity
Shutter speed	1/1000 to 2 seconds
Built-in flash	Yes, 6-second typical recharge time (8-second maximum recharge time at power-on)
Flash working range	To locate the flash working range for this camera, go to www.hp.com/support , select your language and region, enter your camera model number in the Search: Product field, click Product Information , then click Specifications .
Image Display	3.81 cm (1.5 in) color LTPS TFT LCD with backlight, 153,600 pixels (640 by 240) total pixel count
Storage	<ul style="list-style-type: none"> • 16MB internal flash memory. • Slot for memory card. • This camera supports standard, high speed, and high capacity Secure Digital (SD and SDHC) memory cards, 32MB to 8GB. • This camera supports storing a maximum of 2000 images on a memory card. • The number of images or video clips that can be saved in memory depends on the  Image Quality settings (see “Memory capacity” on page 37).
Compression format	<ul style="list-style-type: none"> • JPEG (EXIF) for pictures • Motion JPEG for video clips
Interfaces	USB mini-B
Standards	<ul style="list-style-type: none"> • USB—PTP and MSDC • JPEG • Motion JPEG • DPOF • EXIF • DCF • DPS


(continued)

External body dimensions	Measurements with camera off and lens retracted (width, depth, height): 92.5 mm (W) by 29.5 mm (D) by 62.0 mm (H) (3.64 in by 1.16 in by 2.44 in)
Weight	109 grams (3.84 ounces) without battery
Power	Power source: two AA batteries (Alkaline, Photo Lithium, or rechargeable NiMH)
Temperature range	Operational: 0° to 40° C (32° to 104° F) at 15% to 85% relative humidity Storage: –30° to 65° C (–22° to 149° F) at 15% to 90% relative humidity

Memory capacity

Not all 16MB of internal memory is available for storing images, because some memory is used for internal camera operations. The actual file sizes and number of still images that can be stored in internal memory or on a memory card will vary depending on the content of each still image or length of each video clip.

Image quality

To locate the approximate number and average size of still images that can be stored in internal memory when the camera is set to different  **Image Quality** settings (see **Image Quality** under “[Using the Picture Capture Menu](#)” on page 11), go to www.hp.com/support, select your language and region, enter your camera model number in the **Search: Product** field, click **Product Information**, then click **Specifications**.

Index

- A**
 - Action mode 11
 - arrow buttons 3
 - assistance 32
 - Auto mode 11
- B**
 - Back button 3
 - batteries
 - conserving 33
 - install 4
 - performance 34
 - top points about use 33
 - battery door 4
 - Burst setting 11, 12
- C**
 - camera
 - dimensions 37
 - parts 3, 4
 - specifications 36
 - turn on/off 4
 - weight 37
 - Camera Setup Menu 25
 - Camera Sounds 25
 - Color 11
 - color depth 36
 - compression format 36
 - computer, connect to 17, 18
- D**
 - Date & Time 5, 25
 - Date & Time Imprint 12
 - Delete button 3
 - digital zoom 9
 - dimensions 37
 - direct print 19
 - Display Brightness 25
- E**
 - e-mail images 23
- F**
 - Favorites 15
- G**
 - getting assistance 32
- H**
 - HP Photosmart Express 21
 - HP Photosmart Software 6
- I**
 - Image Display 3
 - Image Quality 11, 37
 - images
 - Date & Time Imprint 12
 - Image Quality 11
 - magnifying 15
 - sending 24
 - transfer to computer 17
 - install memory card 6
 - install software 6
 - Instant Review 9, 12
 - interfaces 36
 - internal memory 37
- L**
 - Landscape mode 11
 - Language 5, 25
- M**
 - magnifying images 15
 - memory
 - capacity 37
 - card 6, 8, 36
 - card door 4
 - Menu/OK button 3
 - menus
 - Camera Setup 25
 - Photosmart Express 21
 - Picture Capture 11
 - Playback 14
 - Move Images to Card 14
 - flash
 - red-eye reduction 10
 - setting 10
 - Flash button 3
 - focal length 36
 - format memory card 6
- N**
 - Night Portrait mode 11
 - number of
 - pictures 37
 - pictures remaining 8
- O**
 - on/off 4
 - ON/OFF button 3
 - online
 - destinations 23
 - print buying 23
- P**
 - parts of camera 3, 4
 - Photosmart Express Menu
 - buying prints online 23
 - marking images for printing 21
 - sharing images 23
 - Picture Capture Menu 11
 - pictures 8, 12
 - Playback 13
 - Playback Menu 14
 - Portrait mode 11
 - power
 - indicators 34
 - light 3
 - ON/OFF button 3
 - print images 19, 21
 - prints, buy online 23
 - problems and solutions 26
- R**
 - record video clips 9
 - red-eye removal 15
 - Region 5
 - removing red eyes 15
 - reviewing images 13
- S**
 - safety precautions for
 - batteries 33
 - selecting images for
 - destinations 23, 24
 - selecting images for printing 21

Index

Self-Timer

- light 4

- Self-Timer setting 11, 12

- sending individual images 23, 24

- set date and time 5

- setting up destinations 23

- share pictures 21

- Shutter button 3

- shutter speed 36

- slideshow 16

- software install 6

- solving problems 26

- sounds of camera 25

- specifications 36

- State Selector 3

- storage 36

- Sunset mode 11

- support process 32

T

- Theatre mode 11

- Thumbnails 15

- Time & Date 5, 25

- transfer images 17, 18

- troubleshooting 26

- turn on/off power 4

U

- USB configuration 18, 25

V

- video clips 9

- Video mode 11

- View Slideshow 16

- viewing thumbnails 15

- Vista support 32

W

- weight 37

- Windows Vista support 32

Z

- zoom 9

Regulatory / Geltende Richtlinien / Informations réglementaires

Geräuschemission
LpA < 70 dB
Am Arbeitsplatz
Normaler Betrieb
nach DIN 45635 T. 19

FCC statement

The United States Federal Communications Commission (in 47 CFR 15.105) has specified that the following notice be brought to the attention of users of this product.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For further information, contact:

Manager of Corporate Product Regulations
Hewlett-Packard Company
3000 Hanover Street
Palo Alto, Ca 94304
(650) 857-1501

HP Photosmart E330 series Digital Camera Declaration of Conformity (European Economic Area)

According to ISO/IEC 17050-1 and EN 17050-1

Supplier's name: Hewlett-Packard Singapore (Pte) Ltd
Imaging and Printing Manufacturing Operation Singapore
Supplier's address: 60 Alexandra Terrace #07-01, The Comtech
Singapore 118502

declares that the product:

Product name: HP Photosmart E330 series Digital Camera (may contain suffixes)
Product number(s): L2495A, L2496A, L2497A, L2498A, L2499A, L2500A
Regulatory model: SNPRB-0707
Product options: HP Photosmart 2200 Camera Charging Dock (product number Q6262A, Regulatory Model SDCAB-0703) .

Conforms to the following Product Specifications:

Safety IEC/EN 60950-1:2001
IEC/EN 60825-1:1994+A1:2002+A2:2001 Class 1 LED

Electromagnetic compatibility (EMC)

EN 55022:1998+A1:2000+A2:2003, Class B
IEC/EN 61000-3-2:2000
IEC/EN 61000-3-3:1995 + A1:2001
EN 55024:1998+A1:2001+A2:2003

Supplementary information:

The product herewith complies with the requirements of the Low Voltage Directive 2006/95/EC and the EMC Directive 2004/108/EC and carries the CE marking accordingly.

Canada

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.