
HP 22-in-1 Media Card Reader

Introduction

This document describes how to install the HP 22-in-1 Media Card Reader into an HP Workstations adapter bracket, and then install the media card reader and bracket into an HP computer. Basic troubleshooting information for the HP 22-in-1 Media Card Reader is also included.

Kit contents

- 3.5-inch media card reader with integrated USB cable
- HP Workstations adapter for 5.25-inch drive bays
- Four M3 guide screws
- Documentation CD
- Warranty information



516459-002

© 2009, 2010 Hewlett-Packard Development Company, L.P.

Microsoft, Windows, and Windows Vista are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Warnings and cautions

-
-  **WARNING!**  Any surface or area of the equipment marked with this symbol indicates the presence of a hot surface or hot component. If this surface is contacted, the potential for injury exists. To reduce the risk of injury from a hot component, enable the surface to cool before touching.
-
-  **WARNING!**  Any surface or area of the equipment marked with this symbol indicates the presence of an electrical shock hazard. To reduce the risk of injury from electrical shock, do not open any enclosed area marked with this symbol.
-
-  **WARNING!** To reduce the risk of electric shock or damage to your equipment:
- Do not disable the power cord grounding plug. The grounding plug is an important safety feature.
 - Plug the power cord in a grounded (earthed) outlet that is easily accessible at all times.
 - Disconnect power from the equipment by unplugging the power cord from the electrical outlet.
-
-  **WARNING!** To reduce the risk of serious injury, read the *Safety & Comfort Guide*. It describes proper computer setup, posture, health, and work habits for computer users, and provides important electrical and mechanical safety information. This guide is located at <http://www.hp.com/ergo> and on the documentation CD (if one is included with the product).
-
-  **WARNING!** If a product is shipped in packaging marked with this symbol,  the product must always be lifted by two persons to avoid personal injury due to product weight.
-
-  **CAUTION:** Static electricity can damage the electronic components of the computer. Before beginning these procedures, be sure you discharge static electricity by briefly touching a grounded metal object.
-
-  **CAUTION:** To prevent damage to the computer, observe the following Electrostatic Discharge (ESD) precautions while performing the system parts removal and replacement procedures:
- Work on a static-free mat.
 - Wear a static strap to ensure that any accumulated electrostatic charge is discharged from your body to the ground.
 - Create a common ground for the equipment you are working on by connecting the static-free mat, static strap, and peripheral units to that piece of equipment.
-
-  **NOTE:** HP accessories are for use in HP computer products. They have been extensively tested for reliability and are manufactured to high quality standards.
-

Installing the media card reader

Installing the 5.25-inch bay adapter

To install the 3.5-inch media card reader into a 5.25-inch drive bay, you must first install the reader into the 5.25-inch bay adapter.


1. If installing the media reader in an HP Z200 or Z400 Workstation, install four black M3 guide screws in the four lower holes of the bay adapter.

Figure 1 Installing the guide screws in the bay adapter for HP Z200 and Z400 Workstations



2. To install the media reader in the 5.25-inch optical bay adapter:
 - a. Leave the four preinstalled guide screws in the lower holes of the media reader (1) in place.
 - b. Use the four guide screws to align the media reader with the adapter (1).
 - c. Lower the media reader into the adapter (2).


Figure 2 Installing the media reader in the bay adapter



- d. Align the rear screws on the drive with the channel in the carrier (3).
- e. To fully seat the media reader in the carrier, the carrier cannot be in contact with a solid surface. Lift the carrier up as you slide the drive forward (4).

- f. The green carrier latch (5) snaps into place when fully seated.

Figure 3 Installing the media reader in the bay adapter



Preparing the computer

 **NOTE:** Computer models vary. All illustrations are examples only.

Accessing the internal components of the computer

1. If you need help preparing the computer for this installation, consult the removal and replacement procedures in the service guide for your computer at <http://www.hp.com/support/manuals>.
2. Power down the computer, and then disconnect the power cord.
3. Power down all external devices, and then disconnect them from the computer.
4. Remove the side access panel.

Removing components

1. If present, remove the card support to access the system board connectors.
2. If present, remove the airflow guide to access the optical bays.
3. Remove the front bezel, if required to install a device in the optical bay.


 **NOTE:** The front bezel does not need to be removed to install the media reader in HP Z600 and Z800 Workstations.

4. Remove the bezel blank cover or filler tray from the optical drive bay (or remove the drive from the bay if you are replacing an existing drive with the media card reader and do not have an empty drive bay).

Installing the media card reader in the computer

1. Install the media card reader into an optical drive bay.
2. Ensure that the adapter snaps securely into place.

Figure 4 Installing the media card reader in the optical bay




Connecting the media card reader

 **NOTE:** See the service label on the side access panel to locate connectors on the system board.

1. Connect the USB cable from the media card reader directly to a keyed, two-row, 9-pin USB connector on the system board.
2. Ensure the USB cable connector is positioned correctly on the system board connector.

Figure 5 Connecting to the system board



Reassembling the computer

To reassemble the computer after installation:


1. Reinstall the card support, if removed.
2. Reinstall the airflow guide, if removed.
3. Reinstall the side access panel.
4. Reconnect power to the computer and all external devices.
5. Restore power to the computer and all external devices.

Identifying media slots

Front panel components

The media slots accept the following cards:

Figure 6 HP 22-in-1 USB Media Card Reader



Slot ID	Media
①	xD-Picture Card (xD)
②	<ul style="list-style-type: none">• Micro SD (T-Flash)• Micro SDHC
③	Status Light
④	<ul style="list-style-type: none">• Secure Digital Card (SD)• Secure Digital High Capacity (SDHC)• MiniSD• MiniSDHC• MultiMediaCard (MMC)• Reduced Size MultiMediaCard (RS MMC)• MMC Micro (adapter required)• MultiMedia Card 4.2 (MMC Plus, including MMC Plus HC)• Reduced Size MultiMedia Card 4.2 (MMC Mobile, including MMC Mobile HC)
⑤	USB Connector

Slot ID	Media
⑥	<ul style="list-style-type: none"> • CompactFlash Card Type I • CompactFlash Card Type II • MicroDrive
⑦	<ul style="list-style-type: none"> • Memory Stick (MS) • MagicGate Memory Stick (MG) • MagicGate Memory Stick Duo • Memory Stick Select • Memory Stick Duo (MS Duo) • Memory Stick PRO (MS PRO) • Memory Stick PRO Duo (MS PRO Duo) • Memory Stick PRO-HG Duo • Memory Stick Micro (M2) (adapter required)

Compatible media cards

For a list of supported USB media cards for the HP 22-in-1 (USB) Media Card Reader, see the “Compatible Media Cards” document available on the CD included with this kit.

 **NOTE:** The HP 22-in-1 (USB) Media Card Reader is not compatible with 1394 devices.

Troubleshooting

Solving common problems

The following table lists possible problems, the possible cause of each problem, and the recommended solutions.

Table 1 Solving Common Problems

Problem	Possible Cause	Solution
USB connector is not available on the system board.	All USB ports on the computer are used or none are available.	Purchase and install a USB expansion card that is appropriate for your system.
Media card does not work in a digital camera after formatting it in Microsoft® Windows® XP.	By default, Windows XP formats any media card with a capacity greater than 32 MB with the FAT32 format. Most digital cameras use the FAT (FAT16 and FAT12) format and cannot operate with a FAT32 formatted card.	Either format the media card in the digital camera or select FAT file system to format the media card in a computer with Windows XP.
A write-protected or locked error occurs when attempting to write to the media card.	Media card is locked. Locking the media card is a safety feature that prevents writing to and deleting from an SD/Memory Stick/PRO card.	If using an SD card, make sure that the lock tab located on the right of the SD card is not in the locked position. If using a Memory Stick/PRO card, make sure that the lock tab located on the bottom of the Memory Stick/PRO card is not in the locked position.

Table 1 Solving Common Problems (continued)

Problem	Possible Cause	Solution
Media card reader cannot write to the media card.	The media card is a read-only memory (ROM) card.	Check the manufacturer's documentation included with your card to see if it is writable. See the "Compatible Media Cards" document available on the CD included with your reader.
Media card reader cannot access data on the media card after inserting it into a slot.	The media card is not inserted properly, is inserted in the wrong slot, or is not supported.	Ensure that the card is inserted properly with the gold contact on the correct side. The green LED illuminates if inserted properly. Refer to the "Compatible Media Cards" document available on the CD included with your reader.
Media card does not eject properly.	The computer software is used to safely eject the card.	Open <My Computer>. Right-click on the corresponding drive icon, and select <Eject>. Then pull the card out of the slot. Caution: Never remove the card when the green LED is flashing.
After installing the media card reader and booting to Windows, the reader and the inserted cards are not recognized by the computer.	The operating system needs time to recognize the device if the reader was just installed into the computer, and you are turning the computer on for the first time.	Wait a few seconds so that the operating system can recognize the reader and the available ports, and then recognize whatever media is inserted in the reader.
After inserting a media card in the reader, the computer attempts to boot from the media card.	The inserted media card has boot capability.	If you do not want to boot from the media card, remove it during boot or do not select the option to boot from the inserted media card during the boot process.
After installing the media card reader, the front USB ports on the computer do not work.	The USB cable for the front USB ports was disconnected so that the system board connector could be used for the reader.	Reconnect the cable for the front USB ports. Connect the media reader to an available USB connector on the system board.

Using the web

For online access to technical support information, self-solve tools, online assistance, community forums or IT experts, broad multivendor knowledge base, monitoring, and diagnostic tools, go to <http://www.hp.com/support>.

To contact HP customer service worldwide, see <http://www.hp.com/go/contacthp>.

Japanese 日本語

This document is available in Japanese. See <http://www.hp.com/support/manuals>, then select your product and select **Japanese** from the drop down **Manual Language** menu.

このドキュメントは日本語版が用意されています。<http://www.hp.com/support/manuals> にアクセスし、ご使用のワークステーション製品を選択し、**Manual Language** ドロップダウンメニューから **Japanese** を選択してください。