

Notebook Tour

User Guide

© Copyright 2009 Hewlett-Packard
Development Company, L.P.

Bluetooth is a trademark owned by its proprietor and used by Hewlett-Packard Company under license. Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation. SD Logo is a trademark of its proprietor.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: June 2009

Document Part Number: 532125-001

Product notice

This user guide describes features that are common to most models. Some features may not be available on your computer.

Safety warning notice

-
- ⚠ **WARNING!** To reduce the possibility of heat-related injuries or of overheating the computer, do not place the computer directly on your lap or obstruct the computer air vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or rugs or clothing, to block airflow. Also, do not allow the AC adapter to contact the skin or a soft surface, such as pillows or rugs or clothing, during operation. The computer and the AC adapter comply with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950).
-

Table of contents

1 Identifying hardware

2 Components

Display	3
Top components	4
Pointing devices	4
Lights	4
Buttons and fingerprint reader	6
Keys	8
Front components	9
Right-side components	10
Left-side components	11
Bottom components	12
Wireless antennas (select models only)	13
Additional hardware components	14

3 Labels

Index	17
-------------	----

1 Identifying hardware


To see a list of hardware installed in the computer, follow these steps:


1. Select **Start > My Computer**.
2. In the left pane of the System Tasks window, select **View system information**.
3. Select **Hardware** tab > **Device Manager**.

You can also add hardware or modify device configurations using Device Manager.

2 Components

Display

 **NOTE:** Your computer may look slightly different from the illustration in this section.



Component	Description
(1) Internal display switch	Turns off the display if the display is closed while the power is on.
(2) Internal microphones (2)	Record sound.
(3) Webcam light (select models only)	On: The webcam is in use.
(4) Webcam (select models only)	Records audio and video and captures still photographs.

Top components


Pointing devices




Component	Description
(1) TouchPad*	Moves the pointer and selects or activates items on the screen.
(2) Left TouchPad button*	Functions like the left button on an external mouse.
(3) TouchPad scroll zone	Scrolls up or down.
(4) Right TouchPad button*	Functions like the right button on an external mouse.

*This table describes factory settings. To view or change pointing device preferences, select **Start > Control Panel > Printers and Other Hardware > Mouse**.


Lights

 **NOTE:** Your computer may look slightly different from the illustration in this section.



Component	Description
(1) Caps lock light	On: Caps lock is on.
(2) Info Center/QuickLook light	<ul style="list-style-type: none"> • On: The computer is on. • Blinking (5 times): <ul style="list-style-type: none"> ◦ When the computer is on, press the button to launch Info Center. ◦ When the computer is off or in Hibernation, press the button to launch QuickLook. • Off: The computer is off or in Standby or Hibernation.
(3) Wireless light	<ul style="list-style-type: none"> • Blue: An integrated wireless device, such as a wireless local area network (WLAN) device and/or a Bluetooth® device, is on. • Amber: All wireless devices are off.
(4) Volume mute light	<ul style="list-style-type: none"> • Turquoise: Computer sound is on. • Amber: Computer sound is off.
(5) Volume down light	Blinking: The volume scroll zone is being used to decrease speaker volume.
(6) Volume up light	Blinking: The volume scroll zone is being used to increase speaker volume.
(7) Power light	<ul style="list-style-type: none"> • On: The computer is on. • Blinking: The computer is in Standby. • Off: The computer is off or in Hibernation.


Buttons and fingerprint reader




Component	Description
(1) Speakers (2)	Produce sound.
(2) Info Center/QuickLook button	Launches Info Center or QuickLook.
(3) Wireless button	Turns the wireless feature on or off but does not establish a wireless connection. NOTE: You must set up or access a wireless network to establish a wireless connection.
(4) Volume mute button	Mutes and restores speaker sound.
(5) Volume scroll zone	Adjusts speaker volume. Slide your finger to the left to decrease volume and to the right to increase volume. You can also press the left side of the volume slider to decrease volume, or press the right side of the volume slider to increase volume.
(6) Power button	<ul style="list-style-type: none"> When the computer is off, press the button to turn on the computer. When the computer is on, press the button to shut down the computer. When the computer is in Standby, press the button briefly to exit Standby. When the computer is in Hibernation, press the button briefly to exit Hibernation. <p>If the computer has stopped responding and Windows shutdown procedures are ineffective, press and hold the power button for at least 5 seconds to turn off the computer.</p>
(7) Fingerprint reader	

Component	Description
(7) Fingerprint reader (select models only)	To learn more about your power settings, select Start > Control Panel > Performance and Maintenance > Power Options. Allows a fingerprint logon to Windows instead of a password logon.

Keys

 **NOTE:** Your computer may look slightly different from the illustration in this section.




Component	Description
(1) esc key	Displays system information when pressed in combination with the fn key.
(2) fn key	Executes frequently used system functions when pressed in combination with a function key or the esc key.
(3) Windows logo key	Displays the Windows Start menu.
(4) Windows applications key	Displays a shortcut menu for items beneath the pointer.
(5) Embedded numeric keypad keys	Can be used like the keys on an external numeric keypad.
(6) Function keys	Execute frequently used system functions when pressed in combination with the fn key.

Front components




Component	Description
(1) Drive light	<ul style="list-style-type: none">Blinking turquoise: The hard drive or optical drive is being accessed.Amber: HP 3D DriveGuard has temporarily parked the hard drive.
(2) SD Card Reader	Supports the following optional digital card formats: <ul style="list-style-type: none">MultiMediaCardMultiMediaCard PlusSecure Digital Memory CardSecure Digital High Capacity Memory Card
(3) Audio-out (headphone) jack	Produces sound when connected to optional powered stereo speakers, headphones, ear buds, a headset, or television audio. NOTE: When a device is connected to the headphone jack, the computer speakers are disabled.
(4) Audio-in (microphone) jack	Connects an optional computer headset microphone, stereo array microphone, or monaural microphone.

Right-side components




Component	Description
(1) ExpressCard slot	Supports optional ExpressCards.
(2) USB port	Connects an optional USB device.
(3) HDMI port	Connects an optional HDMI device.
(4) External monitor port	Connects an external VGA monitor or projector.
(5) Vent	Enables airflow to cool internal components. NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.
(6) RJ-45 (network) jack	Connects a network cable.
(7) Security cable slot	Attaches an optional security cable to the computer. NOTE: The security cable is designed to act as a deterrent, but it may not prevent the computer from being mishandled or stolen.

Left-side components




Component	Description
(1) Power connector	Connects an AC adapter.
(2) Battery light	<ul style="list-style-type: none">• Amber: A battery is charging.• Turquoise: A battery is close to full charge capacity.• Blinking amber: A battery that is the only available power source has reached a low battery level. When the battery reaches a critical battery level, the battery light begins blinking rapidly.• Off: If the computer is plugged into an external power source, the light turns off when all batteries in the computer are fully charged. If the computer is not plugged into an external power source, the light stays off until the battery reaches a low battery level.
(3) Optical drive (select models only)	Reads optical discs and, on select models, also writes to optical discs.
(4) RJ-11 (modem) jack (select models only)	Connects a modem cable.
(5) USB ports (2)	Connect optional USB devices.

Bottom components



Component	Description
(1) Battery bay	Holds the battery.
(2) Battery release latch	Releases the battery from the battery bay.
(3) Vents (3)	Enable airflow to cool internal components. NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.
(4) Memory module compartment	Contains the memory module slots and a wireless LAN module slot. CAUTION: To prevent an unresponsive system and the display of a warning message, replace the WLAN module with only a module authorized for use in the computer by the governmental agency that regulates wireless devices in your country. If you replace the module and then receive a warning message, remove the module to restore computer functionality, and then contact technical support through Help and Support.
(5) Hard drive bay	Holds the hard drive and a Bluetooth device.
(6) SIM slot (select models only)	Contains a wireless subscriber identity module (SIM). The SIM slot is located inside the battery bay.

Wireless antennas (select models only)



Component	Description
(1) WWAN antennas (2)*	Send and receive wireless signals to communicate with wireless wide-area networks (WWAN).
(2) WLAN antennas (2)*	Send and receive wireless signals to communicate with wireless local area networks (WLAN).

*The antennas are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions.

To see wireless regulatory notices, refer to the section of the *Regulatory, Safety and Environmental Notices* that applies to your country or region. These notices are located in Help and Support.

Additional hardware components



Component	Description
(1) Power cord*	Connects an AC adapter to an AC outlet.
(2) AC adapter	Converts AC power to DC power.
(3) Battery*	Powers the computer when the computer is not plugged into external power.

*Batteries and power cords vary in appearance by country or region.

3 Labels

The labels affixed to the computer provide information you may need when you troubleshoot system problems or travel internationally with the computer.

- Service tag—Provides important information including the following:



- Product name **(1)**. This is the product name affixed to the front of your notebook.
- Serial number (s/n) **(2)**. This is an alphanumeric identifier that is unique to each product.
- Part number/Product number (p/n) **(3)**. This number provides specific information about the product's hardware components. The part number helps a service technician to determine what components and parts are needed.
- Model description **(4)**. This is the alphanumeric identifier you use to locate documents, drivers, and support for your notebook.
- Warranty period **(5)**. This number describes the duration (in years) of the warranty period for this computer.

Have this information available when you contact technical support. The service tag label is affixed to the bottom of the computer.

- Microsoft® Certificate of Authenticity—Contains the Windows® Product Key. You may need the Product Key to update or troubleshoot the operating system. This certificate is affixed to the bottom of the computer.
- Regulatory label—Provides regulatory information about the computer. The regulatory label is affixed inside the battery bay.
- Modem approval label—Provides regulatory information about the modem and lists the agency approval markings required by some of the countries or regions in which the modem has been approved for use. You may need this information when traveling internationally. The modem approval label is affixed inside the memory module compartment.
- Wireless certification label(s) (select models only)—Provide information about optional wireless devices and the approval markings of some of the countries or regions in which the devices have been approved for use. An optional device may be a wireless local area network (WLAN) device or an optional Bluetooth® device. If your computer model includes one or more wireless devices,

one or more certification labels are included with your computer. You may need this information when traveling internationally. Wireless certification labels are affixed inside the memory module compartment.

- SIM (subscriber identity module) label (select models only)—Provides the ICCID (Integrated Circuit Card Identifier) of your SIM. This label is located inside the battery bay.
- HP Mobile Broadband Module serial number label (select models only)—Provides the serial number of your HP Mobile Broadband Module. This label is located inside the memory module compartment.

Index

A

AC adapter, identifying 14
applications key, Windows 8
audio-in (microphone) jack,
identifying 9
audio-out (headphone) jack,
identifying 9

B

battery bay 12, 15
battery light, identifying 11
battery release latch,
identifying 12
battery, identifying 14
bays
 battery 12, 15
 hard drive 12
Bluetooth label 16
buttons
 Info Center 6
 power 6
 QuickLook 6
 TouchPad 4
 volume mute 6
 wireless 6

C

caps lock light, identifying 5
Certificate of Authenticity label 15
compartments
 memory module 12
components
 additional hardware 14
 bottom 12
 display 3
 front 9
 left-side 11
 right-side 10
 top 4
 wireless antennas 13

connector, power 11
cord, power 14

D

drive light, identifying 9

E

embedded numeric keypad keys,
identifying 8
esc key, identifying 8
ExpressCard slot, identifying 10
external monitor port,
identifying 10

F

fingerprint reader, identifying 7
fn key, identifying 8
function keys, identifying 8

H

hard drive bay, identifying 12
HDMI port, identifying 10
headphone (audio-out) jack 9
HP Mobile Broadband Module
 serial number label 16

I

Info Center button, identifying 6
Info/QuickLook light, identifying 5
internal display switch,
identifying 3
internal microphone, identifying 3

J

jacks
 audio-in (microphone) 9
 audio-out (headphone) 9
 RJ-11 (modem) 11
 RJ-45 (network) 10

K

keys
 embedded numeric keypad 8
 esc 8
 fn 8
 function 8
 Windows applications 8
 Windows logo 8

L

labels
 Bluetooth 16
 HP Mobile Broadband 16
 Microsoft Certificate of
 Authenticity 15
 modem approval 15
 regulatory 15
 service tag 15
 SIM 16
 wireless certification 16
 WLAN 16
latch, battery release 12

lights

battery 11
caps lock 5
drive 9
Info 5
mute 5
power 5
QuickLook 5
volume down 5
volume mute 5
volume up 5
webcam 3
wireless 5

M

memory module compartment,
identifying 12
microphone (audio-in) jack 9

Microsoft Certificate of Authenticity
label 15
modem approval label 15
monitor port, external 10
mute button, identifying 6
mute light, identifying 5

O

operating system
Microsoft Certificate of
Authenticity label 15
Product Key 15
optical drive, identifying 11

P

ports
external monitor 10
HDMI 10
USB 10, 11
power button, identifying 6
power connector, identifying 11
power cord, identifying 14
power light, identifying 5
Product Key 15
product name and number,
computer 15

Q

QuickLook button, identifying 6
QuickLook/Info light, identifying 5

R

regulatory information
modem approval label 15
regulatory label 15
wireless certification labels 16
release latch, battery 12
RJ-11 (modem) jack,
identifying 11
RJ-45 (network) jack,
identifying 10

S

scroll zone, TouchPad 4
SD Card Reader, identifying 9
security cable slot, identifying 10
serial number, computer 15
service tag 15
SIM label 16
SIM slot, identifying 12

slots
ExpressCard 10
memory module 12
security cable 10
SIM 12
speakers 6

T

TouchPad buttons,
identifying 4
TouchPad scroll zone,
identifying 4
TouchPad, identifying 4
traveling with the computer
modem approval label 15
wireless certification labels 16

U

USB ports, identifying 10, 11

V

vents, identifying 10, 12
volume down light, identifying 5
volume mute button, identifying 6
volume mute light, identifying 5
volume scroll zone, identifying 6
volume up light, identifying 5

W

webcam light, identifying 3
webcam, identifying 3
Windows applications key,
identifying 8
Windows logo key, identifying 8
wireless button, identifying 6
wireless certification label 16
wireless light, identifying 5
WLAN antennas, identifying 13
WLAN device 16
WLAN label 16
WWAN antennas, identifying 13

