

Notebook Tour

User Guide

© Copyright 2009 Hewlett-Packard
Development Company, L.P.

Bluetooth is a trademark owned by its proprietor and used by Hewlett-Packard Company under license. Microsoft and Windows are U.S. registered trademarks of Microsoft Corporation. SD Logo is a trademark of its proprietor.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Second Edition: September 2009

First Edition: April 2009

Document Part Number: 539922-002

Product notice

This user guide describes features that are common to most models. Some features may not be available on your computer.

Safety warning notice

-
- ⚠ **WARNING!** To reduce the possibility of heat-related injuries or of overheating the computer, do not place the computer directly on your lap or obstruct the computer air vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or rugs or clothing, to block airflow. Also, do not allow the AC adapter to contact the skin or a soft surface, such as pillows or rugs or clothing, during operation. The computer and the AC adapter comply with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950).
-

Table of contents

1 Identifying hardware

2 Components

Display	2
Top components	3
Pointing devices	3
Lights	3
Buttons, switches, and speakers	5
Keys	6
Front components	8
Right-side components	10
Left-side components	11
Bottom components	12
Wireless antennas	13
Additional hardware components	14

3 Labels


Index	17
-------------	----

1 Identifying hardware

To see a list of hardware installed in the computer:


▲ Select **Start > Control Panel > System and Security > Device Manager**.


You can also add hardware or modify device configurations using Device Manager.

 **NOTE:** Windows® includes the User Account Control feature to improve the security of your computer. You may be prompted for your permission or password for tasks such as installing software, running utilities, or changing Windows settings. Refer to Help and Support for more information.

2 Components

Display


 **NOTE:** Your computer may look slightly different from the illustration in this section.



Component	Description
(1) Internal display switch	Turns off the display if the display is closed while the power is on.
(2) Internal microphone	Records sound.
(3) Webcam light (select models only)	On: The webcam is in use.
(4) Webcam (select models only)	Records audio and video and captures still photographs.

Top components


Pointing devices



Component	Description
(1) TouchPad*	Moves the pointer and selects or activates items on the screen.
(2) Left TouchPad button*	Functions like the left button on an external mouse.
(3) TouchPad scroll zone	Scrolls up or down.
(4) Right TouchPad button*	Functions like the right button on an external mouse.

*This table describes factory settings. To view or change pointing device preferences, select **Start > Devices and Printers**. Then, right-click the device representing your computer, and select **Mouse settings**.


Lights


 **NOTE:** Your computer may look slightly different from the illustration in this section.



Component	Description
(1) Caps lock light	On: Caps lock is on.
(2) Info Center/QuickLook light	<ul style="list-style-type: none"> • On: The computer is on. • Blinking (5 times): <ul style="list-style-type: none"> ◦ When the computer is on, press button to launch Info Center. ◦ When the computer is off or in Hibernation, press button to launch QuickLook. • Off: The computer is off or in the Sleep or Hibernation state.
(3) Power light	<ul style="list-style-type: none"> • On: The computer is on. • Blinking: The computer is in the Sleep state. • Off: The computer is off or in Hibernation.

Buttons, switches, and speakers

 **NOTE:** Your computer may look slightly different from the illustration in this section.





Component	Description
(1) Speakers (2)	Produce sound.
(2) Internal display switch	Turns off the display if the display is closed while the power is on.
(3) Info Center/QuickLook button	Launches Info Center or QuickLook.
(4) Power button	<ul style="list-style-type: none">• When the computer is off, press the button to turn on the computer.• When the computer is on, press the button to shut down the computer.• When the computer is in the Sleep state, press the button briefly to exit Sleep.• When the computer is in Hibernation, press the button briefly to exit Hibernation.

If the computer has stopped responding and Windows shutdown procedures are ineffective, press and hold the power button for at least 5 seconds to turn off the computer.


To learn more about your power settings and how to change them, select **Start > Control Panel > System and Security > Power Options**.

Keys

 **NOTE:** Refer to the illustration that most closely matches your computer.




Component	Description
(1) <code>esc</code> key	Displays system information when pressed in combination with the <code>fn</code> key.
(2) <code>fn</code> key	Executes frequently used system functions when pressed in combination with a function key or the <code>esc</code> key.
(3) Windows logo key	Displays the Windows Start menu.
(4) Windows applications key	Displays a shortcut menu for items beneath the pointer.
(5) Embedded numeric keypad keys	Can be used like the keys on an external numeric keypad when pressed in combination with the <code>fn</code> and <code>num lk</code> keys.
(6) Function keys	Execute frequently used system functions when pressed in combination with the <code>fn</code> key.



Component	Description
(1) esc key	Displays system information when pressed in combination with the fn key.
(2) fn key	Executes frequently used system functions when pressed in combination with a function key or the esc key.
(3) Windows logo key	Displays the Windows Start menu.
(4) Windows applications key	Displays a shortcut menu for items beneath the pointer.
(5) Integrated numeric keypad keys	Can be used like the keys on an external numeric keypad.
(6) Function keys	Execute frequently used system functions when pressed in combination with the fn key.


Front components



Component	Description
(1) Drive light	<ul style="list-style-type: none">Blinking turquoise: The hard drive or optical drive is being accessed.Amber: HP 3D DriveGuard has temporarily parked the hard drive.
(2) Wireless switch	<p>Turns the wireless feature on or off but does not establish a wireless connection.</p> <p>NOTE: You must set up or access a wireless network to establish a wireless connection.</p>
(3) Wireless light	<ul style="list-style-type: none">Blue: An integrated wireless device, such as a wireless local area network (WLAN) device and/or a Bluetooth device, is on.Amber: All wireless devices are off.
(4) Media Card Reader	<p>Supports the following optional digital card formats:</p> <ul style="list-style-type: none">Memory Stick (MS)Memory Stick Pro (MSP)MultiMediaCard (MMC)MultiMediaCard 4.2 (MMC Plus, including MMC Plus HC)Secure Digital (SD) Memory CardSecure Digital High Capacity (SDHC) Memory CardSecure Digital High Speed (SDHS) Memory CardxD-Picture Card (XD)xD-Picture Card (XD) Type HxD-Picture Card (XD) Type M


Component	Description
(5) Audio-out (headphone) jack	Produces sound when connected to optional powered stereo speakers, headphones, ear buds, a headset, or television audio. NOTE: When a device is connected to the headphone jack, the computer speakers are disabled.
(6) Audio-in (microphone) jack	Connects an optional computer headset microphone, stereo array microphone, or monaural microphone.

Right-side components




Component	Description
(1) USB ports (2)	Connect optional USB devices.
(2) RJ-11 (modem) jack (select models only)	Connects a modem cable.
(3) Optical drive (select models only)	Reads optical discs and, on select models, also writes to optical discs.
(4) Optical drive light (select models only)	Blinking: The optical drive is being accessed.
(5) Battery light	<ul style="list-style-type: none">Amber: A battery is charging.Turquoise: A battery is close to full charge capacity.Blinking amber: A battery that is the only available power source has reached a low battery level. When the battery reaches a critical battery level, the battery light begins blinking rapidly.Off: If the computer is plugged into an external power source, the light turns off when all batteries in the computer are fully charged. If the computer is not plugged into an external power source, the light stays off until the battery reaches a low battery level.
(6) Power connector	Connects an AC adapter.

Left-side components




Component	Description
(1) ExpressCard slot	Supports optional ExpressCards.
(2) Security cable slot	Attaches an optional security cable to the computer. NOTE: The security cable is designed to act as a deterrent, but it may not prevent the computer from being mishandled or stolen.
(3) RJ-45 (network) jack	Connects a network cable.
(4) Vent	Enables airflow to cool internal components. NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.
(5) External monitor port	Connects an external VGA monitor or projector.
(6) HDMI port	Connect an optional HDMI device.
(7) USB ports (2)	Connect optional USB devices.

Bottom components



Component	Description
(1) Battery release latches (2)	Release the battery from the battery bay.
(2) Battery bay	Holds the battery.

Wireless antennas




Component	Description
(1) WWAN antennas (2)* (select models only)	Send and receive wireless signals to communicate with wireless wide-area networks (WWAN).
(2) WLAN antennas (2)*	Send and receive wireless signals to communicate with wireless local area networks (WLAN).

*The antennas are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions.

To see wireless regulatory notices, refer to the section of the *Regulatory, Safety and Environmental Notices* that applies to your country or region. These notices are located in Help and Support.

Additional hardware components



Component	Description
(1) Power cord*	Connects an AC adapter to an AC outlet.
(2) Battery*	Powers the computer when the computer is not plugged into external power.
(3) AC adapter	Converts AC power to DC power.

*Batteries and power cords vary in appearance by country or region.

3 Labels

The labels affixed to the computer provide information you may need when you troubleshoot system problems or travel internationally with the computer.

- Service tag—Provides important information including the following:



- Product name **(1)**. This is the product name affixed to the front of your notebook.
- Serial number (s/n) **(2)**. This is an alphanumeric identifier that is unique to each product.
- Part number/Product number (p/n) **(3)**. This number provides specific information about the product's hardware components. The part number helps a service technician to determine what components and parts are needed.
- Model description **(4)**. This is the alphanumeric identifier you use to locate documents, drivers, and support for your notebook.
- Warranty period **(5)**. This number describes the duration (in years) of the warranty period for this computer.

Have this information available when you contact technical support. The service tag label is affixed to the bottom of the computer.

- Microsoft® Certificate of Authenticity—Contains the Windows® Product Key. You may need the Product Key to update or troubleshoot the operating system. This certificate is affixed to the bottom of the computer.
- Regulatory label—Provides regulatory information about the computer. The regulatory label is affixed to the bottom of the computer.
- Modem approval label—Provides regulatory information about the modem and lists the agency approval markings required by some of the countries or regions in which the modem has been approved for use. You may need this information when traveling internationally. The modem approval label is affixed to the bottom of the computer.
- Wireless certification label(s) (select models only)—Provide information about optional wireless devices and the approval markings of some of the countries or regions in which the devices have been approved for use. An optional device may be a wireless local area network (WLAN) device or an optional Bluetooth® device. If your computer model includes one or more wireless devices,

one or more certification labels are included with your computer. You may need this information when traveling internationally. Wireless certification labels are affixed to the bottom of the computer.

- SIM (subscriber identity module) label (select models only)—Provides the ICCID (Integrated Circuit Card Identifier) of your SIM. This label is affixed to the bottom of the computer.
- HP Mobile Broadband Module serial number label (select models only)—Provides the serial number of your HP Mobile Broadband Module.

Index

A

AC adapter, identifying 14
applications key, Windows 6, 7
audio-in (microphone) jack,
identifying 9
audio-out (headphone) jack,
identifying 9

B

battery bay 12, 15
battery light, identifying 10
battery release latches,
identifying 12
battery, identifying 14
bays
 battery 12, 15
Bluetooth label 16
buttons
 Info Center 5
 power 5
 QuickLook 5
 TouchPad 3
 wireless 8

C

caps lock light, identifying 4
Certificate of Authenticity label 15
components
 additional hardware 14
 bottom 12
 display 2
 front 8
 left-side 11
 right-side 10
 top 3
 wireless antennas 13
connector, power 10
cord, power 14

D

drive light, identifying 8
drives
 optical 10

E

esc key, identifying 6, 7
ExpressCard slot, identifying 11
external monitor port,
identifying 11

F

fn key, identifying 6, 7
function keys, identifying 6, 7

H

headphone (audio-out) jack 9
HP Mobile Broadband Module
serial number label 16

I

Info Center/QuickLook button,
identifying 5
Info/QuickLook light, identifying 4
internal display switch,
identifying 2, 5
internal microphone, identifying 2

J

jacks
 audio-in (microphone) 9
 audio-out (headphone) 9
 RJ-11 (modem) 10
 RJ-45 (network) 11

K

keypad keys, identifying 6, 7
keys
 esc 6, 7
 fn 6, 7

function 6, 7
keypad 6, 7
Windows applications 6, 7
Windows logo 6, 7

L

labels
 Bluetooth 16
 HP Mobile Broadband 16
 Microsoft Certificate of
 Authenticity 15
 modem approval 15
 regulatory 15
 service tag 15
 SIM 16
 wireless certification 16
 WLAN 16
latches, battery release 12
lights
 battery 10
 caps lock 4
 drive 8
 Info 4
 optical drive 10
 power 4
 QuickLook 4
 webcam 2
 wireless 8

M

Media Card Reader, identifying 8
microphone (audio-in) jack 9
Microsoft Certificate of Authenticity
label 15
modem approval label 15
monitor port, external 11

- O**
 - operating system
 - Microsoft Certificate of Authenticity label 15
 - Product Key 15
 - optical drive light, identifying 10
 - optical drive, identifying 10
- P**
 - ports
 - external monitor 11
 - HDMI 11
 - USB 10, 11
 - power button, identifying 5
 - power connector, identifying 10
 - power cord, identifying 14
 - power light, identifying 4
 - Product Key 15
 - product name and number, computer 15
- Q**
 - QuickLook/Info Center button, identifying 5
 - QuickLook/Info light, identifying 4
- R**
 - regulatory information
 - modem approval label 15
 - regulatory label 15
 - wireless certification labels 16
 - release latches, battery 12
 - RJ-11 (modem) jack, identifying 10
 - RJ-45 (network) jack, identifying 11
- S**
 - scroll zone, TouchPad 3
 - security cable slot, identifying 11
 - serial number, computer 15
 - service tag 15
 - SIM label 16
 - slots
 - ExpressCard 11
 - security cable 11
 - speakers, identifying 5
- T**
 - TouchPad buttons, identifying 3
 - TouchPad scroll zone, identifying 3
 - TouchPad, identifying 3
 - traveling with the computer
 - modem approval label 15
 - wireless certification labels 16
- U**
 - USB ports, identifying 10, 11
- V**
 - vents, identifying 11
- W**
 - webcam light, identifying 2
 - webcam, identifying 2
 - Windows applications key, identifying 6, 7
 - Windows logo key, identifying 6, 7
 - wireless certification label 16
 - wireless light, identifying 8
 - wireless switch, identifying 8
 - WLAN antennas, identifying 13
 - WLAN device 16
 - WLAN label 16
 - WWAN antennas, identifying 13

