



HP SpectreXT TouchSmart

Maintenance and Service Guide

© Copyright 2012 Hewlett-Packard
Development Company, L.P.

Bluetooth is a trademark owned by its proprietor and used by Hewlett-Packard Company under license. Intel and Core are U.S. registered trademarks of Intel Corporation. Microsoft, Windows, and Windows Vista are U.S. registered trademarks of Microsoft Corporation. SD Logo is a trademark of its proprietor.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: November 2012

Document Part Number: 682637-001

Safety warning notice

⚠ WARNING! To reduce the possibility of heat-related injuries or of overheating the device, do not place the device directly on your lap or obstruct the device air vents. Use the device only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or rugs or clothing, to block airflow. Also, do not allow the AC adapter to contact the skin or a soft surface, such as pillows or rugs or clothing, during operation. The device and the AC adapter comply with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950).

Table of contents

| | |
|---|-----------|
| 1 Product description | 1 |
| 2 External component identification | 4 |
| Display | 4 |
| Buttons, speakers, and antennas | 5 |
| Keys | 6 |
| Lights | 7 |
| TouchPad | 8 |
| Left side | 9 |
| Right side | 10 |
| Bottom | 12 |
| 3 Illustrated parts catalog | 13 |
| Service tag | 14 |
| Computer major components | 15 |
| Display assembly subcomponents | 19 |
| Mass storage device | 21 |
| Miscellaneous parts | 21 |
| Sequential part number listing | 22 |
| 4 Removal and replacement procedures | 27 |
| Preliminary replacement requirements | 27 |
| Tools required | 27 |
| Service considerations | 27 |
| Plastic parts | 27 |
| Cables and connectors | 27 |
| Drive handling | 28 |
| Grounding guidelines | 28 |
| Electrostatic discharge damage | 28 |
| Packaging and transporting guidelines | 30 |
| Component replacement procedures | 32 |

| | |
|--------------------------------------|----|
| Service tag | 32 |
| Bottom cover | 33 |
| Battery | 35 |
| RTC battery | 36 |
| WLAN module | 37 |
| Fan | 39 |
| Solid-state drive | 40 |
| Power button board | 41 |
| Hard drive | 43 |
| Display assembly subcomponents | 45 |
| TouchPad | 52 |
| Front speakers | 54 |
| TouchPad LED board | 56 |
| Power connector cable | 57 |
| Multimedia board | 59 |
| Memory module | 60 |
| System board | 62 |
| Heat sink | 65 |
| RJ-45 jack cover | 67 |
| Keyboard | 69 |
| Rear speakers | 71 |
| WLAN antenna | 72 |

5 Using Setup Utility (BIOS) and System Diagnostics 74

| | |
|-------------------------------------|----|
| Starting Setup Utility (BIOS) | 74 |
| Updating the BIOS | 74 |
| Determining the BIOS version | 74 |
| Downloading a BIOS update | 75 |
| Using System Diagnostics | 76 |

6 Specifications 77

| | |
|--|----|
| Computer specifications | 77 |
| 15.6-inch SGA display specifications | 78 |
| Hard drive specifications | 79 |

7 Backing up, restoring, and recovering 80

| | |
|---|----|
| Creating recovery media and backups | 80 |
| Creating HP Recovery media | 81 |
| Restore and recovery | 82 |
| Using Windows Refresh for quick and easy recovery | 83 |

| | |
|--|-----------|
| Remove everything and reinstall Windows | 84 |
| Recovering using HP Recovery Manager | 84 |
| What you need to know | 85 |
| Using the HP Recovery partition to recover a minimized image (select models only) | 85 |
| Using HP Recovery media to recover | 86 |
| Changing the computer boot order | 86 |
| Removing the HP Recovery partition | 86 |
| 8 Power cord set requirements | 87 |
| Requirements for all countries | 87 |
| Requirements for specific countries and regions | 88 |
| 9 Recycling | 89 |
| Index | 90 |

1 Product description

| Category | Description |
|---------------------|--|
| Product Name | HP SpectreXT TouchSmart |
| Processors | <ul style="list-style-type: none">• Intel® Quad Core® i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W)• Intel Quad Core i7-3517U 1.900-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W)• Intel Dual Core i5-3337U 1.800-GHz processor (turbo up to 2.700-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W)• Intel Dual Core i5-3317U 1.700-GHz processor (turbo up to 2.600-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W) |
| Chipset | Mobile Intel HM77 PCH (platform controller hub) chipset |
| Graphics | Intel HD Graphics 4000 integrated universal memory architecture (UMA) graphics Support for BD playback with HD Decode and DX11 |
| Panel | 15.6-in full high-definition (FHD), wide light-emitting diode (WLED), BrightView (BV), UWVA (1920×1080), slim (3.2-mm) display with webcam and microphone Touchscreen and MultiTouch enabled Typical brightness: 300 nits |
| Memory | One customer-accessible/upgradable memory module slot + 4-GB on the system board Support for DDR3L (1600-MHz) dual channel Support for 8192-MB of system RAM in the following configurations: <ul style="list-style-type: none">• 8192-MB (4096-MB memory module + 4096-MB on system board)• 6144-MB (2048-MB memory module + 4096-MB on system board)• 4096-MB (4096-MB on system board) |

| Category | Description |
|--------------------------|---|
| Hard drive | <p>Support for 6.35-cm (2.5-in) hard drives in 7.0-mm (.28-in) thickness</p> <p>Serial ATA</p> <p>Support for hard drive configuration as cache 32-GB mSATA (installed with hard drive only)</p> <p>Support for Accelerometer hard drive protection</p> <p>Support for the following hard drives:</p> <ul style="list-style-type: none"> • 500-GB, 7200-rpm, 7.0-mm • 500-GB, 5400-rpm, 7.0-mm |
| Solid-state drive | <p>Support for mSATA solid-state drives</p> <p>Serial ATA III</p> <p>Support for the following single solid-state drive configurations:</p> <ul style="list-style-type: none"> • 256-GB mSATA • 128-GB mSATA <p>Support for Intel Smart Response Technology 32-GB solid-state drive</p> |
| Audio and video | <p>Two high-performance Premium-branded speakers mounted in bass reflex enclosures</p> <p>Dual-array microphones with appropriate beam-forming, echo-cancellation, noise-suppression software</p> <p>HD Audio (92HD99)</p> <p>Beats signature audio profile applied to both headphones and external speakers</p> <p>Separate discrete amplifiers for headphone and audio out jacks</p> <p>Supports Microsoft Premium requirements</p> <p>Integrated HP TrueVision HD slim webcam (fixed [no tilt], activity LED, 1280×720 by 24 frames per second)</p> <p>Dual array digital microphones with appropriate beam-forming, echo-cancellation, noise-suppression software</p> |
| Ethernet | <p>Integrated 10/100/1000 RTL8111F network interface card (NIC)</p> |
| Wireless | <p>Integrated wireless local area network (WLAN) options by way of wireless module</p> <p>Support for the Intel Centrino Advanced-N 6235 Combo Adapter</p> <p>Support for Intel Wireless Display (Wi-Di)</p> |

| Category | Description |
|----------------------------------|--|
| External media cards | <p>2-in-1 Digital Media Reader Slot Digital Media Slot with push-push technology, supporting the following digital card formats:</p> <ul style="list-style-type: none"> • Secure Digital (SD) Memory Card • Secure Digital High Capacity (SDHC) Memory Card • Secure Digital Extended Capacity (SDxC) Memory Card • MultiMediaCard (MMC) |
| Ports | <ul style="list-style-type: none"> • Audio-in (mono microphone)/audio-out (stereo headphone) combo jack • HDMI v1.4a supporting up to 1920×1200 @ 60Hz with HDCP key • AC adapter • RJ-45 (Ethernet) • USB 3.0 port (two ports on left side) • USB 2.0 port (one port on right side), supports USB sleep and charge |
| Keyboard/pointing devices | <p>Full-size, backlit, island-style keyboard</p> <p>Gesture support: MultiTouch gestures enabled, two-finger scrolling, and pinch-zoom as default</p> <p>Taps enabled by default</p> <p>Support for ImagePad with gesture support image sensor, scroll, pinch, zoom, rotate, and 3-finger flick)</p> |
| Power requirements | <p>Support for 65-W AC adapter (non-PFC, 3-wire)</p> <p>Support for 4-cell, 48-Wh, 3.27-Ah battery (Li-ion)</p> |
| Security | <p>Support for security cable lock</p> <p>Support for Trusted Platform Module (TPM)</p> <p>Support for Intel AT-p Ready (in BIOS)</p> |
| Operating system | Preinstalled: Windows® 8 Professional 64-bit and Windows 8 Standard 64-bit |
| Serviceability | End user replaceable part: AC adapter |

2 External component identification

Display



| Item | Component | Description |
|------|--------------------------|--|
| (1) | Internal display switch | Turns off the display and initiates Sleep if the display is closed while the power is on. NOTE: The internal display switch is not visible from the outside of the computer. |
| (2) | Internal microphones (2) | Record sound. |
| (3) | Webcam light | On: The webcam is in use. |
| (4) | Webcam | Records video, captures still photographs, and provides access to video conferences and online chat by means of streaming video. From the Start screen, type <code>c</code> , and then select CyberLink YouCam . |

Buttons, speakers, and antennas




| Item | Component | Description |
|------|--------------------|---|
| (1) | Power button | <ul style="list-style-type: none">• When the computer is off, press the button to turn on the computer.• When the computer is in the Sleep state, press the button briefly to exit Sleep.• When the computer is in Hibernation, press the button briefly to exit Hibernation. <p>CAUTION: Pressing and holding down the power button will result in the loss of unsaved information.</p> <p>If the computer has stopped responding and Microsoft Windows shutdown procedures are ineffective, press and hold the power button down for at least 5 seconds to turn off the computer.</p> <p>NOTE: For select models, the Intel Rapid Start Technology feature is enabled at the factory. Rapid Start Technology allows your computer to resume quickly from inactivity.</p> <p>To learn more about your power settings:</p> <ol style="list-style-type: none">1. From the Start screen, type <code>p</code>.2. In the search box, type <code>power</code>.3. Select Settings, and then select Power options. |
| (2) | WLAN antennas (2)* | Send and receive wireless signals to communicate with WLANs. |

| Item | Component | Description |
|------|--------------|----------------|
| (3) | Speakers (2) | Produce sound. |

*The antennas are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions. For wireless regulatory notices, see the section of the *Regulatory, Safety, and Environmental Notices* that applies to your country or region. To access this guide, select the **HP Support Assistant** app from the Start screen, select **My computer**, and then select **User guides**.

Keys



| Item | Component | Description |
|------|-------------------------|--|
| (1) | esc key | Displays system information when pressed in combination with the fn key. |
| (2) | fn key | Executes frequently used system functions when pressed in combination with the b key or the esc key. |
| (3) | Windows logo key | Returns you to the Start screen from an open app or the Windows desktop. NOTE: Pressing the Windows logo key again will return you to the previous screen. |
| (4) | Action keys | Execute frequently used system functions. |
| (5) | Windows application key | Displays options for a selected object. |


Lights



| Item | Component | Description |
|------|--------------------------|---|
| (1) | Power light | <ul style="list-style-type: none"> White: The computer is on. Blinking white: The computer is in the Sleep state, which is an energy-saving mode. The computer shuts off power to the display and other unneeded components. Off: The computer is off or in Hibernation. Hibernation is an energy-saving mode that uses the least amount of power to preserve your work. <p>NOTE: For select models, the Intel Rapid Start Technology feature is enabled at the factory. Rapid Start Technology allows your computer to resume quickly from inactivity.</p> |
| (2) | Keyboard backlight light | Identifies the keyboard backlight action key. |
| (3) | Mute light | <ul style="list-style-type: none"> Amber: Computer sound is off. Off: Computer sound is on. |
| (4) | Wireless light | <ul style="list-style-type: none"> White: An integrated wireless device, such as a WLAN device and/or a Bluetooth device, is on. Amber: All wireless devices are off. |

| Item | Component | Description |
|------|-----------------|--|
| (5) | Caps lock light | On: Caps lock is on, which switches the keys to all capital letters. |
| (6) | TouchPad light | <ul style="list-style-type: none"> On: The TouchPad is off. Off: The TouchPad is on. |

TouchPad



| Item | Component | Description |
|------|------------------------|--|
| (1) | TouchPad on/off button | Turns the TouchPad on or off. |
| (2) | TouchPad light | <ul style="list-style-type: none"> On: The TouchPad is off. Off: The TouchPad is on. |
| (3) | TouchPad zone | Moves the on-screen pointer and selects or activates items on the screen. NOTE: The TouchPad also supports gestures. |
| (4) | Left TouchPad button | Functions like the left button on an external mouse. |
| (5) | Right TouchPad button | Functions like the right button on an external mouse. |


Left side



| Item | Component | Description |
|------|---------------------------------|--|
| (1) | RJ-45 (network) jack lights (2) | <ul style="list-style-type: none"> White: The computer is connected to a network. Amber: The computer is connected to a network and activity is occurring on the network. |
| (2) | RJ-45 (network) jack | Connects a network cable. |
| (3) | HDMI port | Connects an optional video or audio device, such as a high-definition television, any compatible digital or audio component, or a high-speed HDMI device. |
| (4) | Thunderbolt DisplayPort | <p>Connects an optional high-resolution display device or a high-performance data device.</p> <p>NOTE: Thunderbolt is new technology. Install all the latest drivers for your Thunderbolt device before connecting the device to the Thunderbolt DisplayPort. Thunderbolt cable and Thunderbolt device (sold separately) must be compatible with Windows. To determine whether your device is Thunderbolt Certified for Windows, see https://thunderbolttechnology.net/products.</p> |
| (5) | USB 3.0 ports (2) | <p>Connect optional USB 3.0 devices and provide enhanced USB power performance.</p> <p>NOTE: The USB 3.0 port is also compatible with USB 1.0 and USB 2.0 devices.</p> |

| Item | Component | Description |
|------|------------------|---|
| (6) | Hard drive light | <ul style="list-style-type: none"> Blinking white: The hard drive is being accessed. Amber: HP 3D DriveGuard has temporarily parked the hard drive. |
| (7) | Power light | <ul style="list-style-type: none"> White: The computer is on. Blinking white: The computer is in the Sleep state, which is an energy-saving mode. The computer shuts off power to the display and other unneeded components. Off: The computer is off or in Hibernation. Hibernation is an energy-saving mode that uses the least amount of power to preserve your work. <p>NOTE: For select models, the Intel Rapid Start Technology feature is enabled at the factory. Rapid Start Technology allows your computer to resume quickly from inactivity.</p> |


Right side



| Item | Component | Description |
|------|---------------------------|---|
| (1) | Digital Media Card Reader | <p>Supports the following digital card formats:</p> <ul style="list-style-type: none"> Secure Digital (SD) Memory Card Secure Digital High Capacity (SDHC) Memory Card Secure Digital Extended Capacity (SDxC) Memory Card MultiMediaCard (MMC) |

| Item | Component | Description |
|------|---|---|
| (2) | Audio-out (headphone) jack/Audio-in (microphone) jack | <p>Connects an optional device such as a headset, power stereo speakers, headphones, earbuds, television audio, or a headset microphone.</p> <p>WARNING! To reduce the risk of personal injury, adjust the volume before putting on headphones, earbuds, or a headset. For additional safety information, refer to the <i>Regulatory, Safety, and Environmental Notices</i>. To access this guide, from the Start screen, select the HP Support Assistant app, select My computer, and then select User guides.</p> <p>NOTE: When a device is connected to the jack, the computer speakers are disabled.</p> |
| (3) | USB 2.0 charging port | <p>Connects an optional USB device. This port can also charge select models of cell phones and MP3 players, even when the computer is off.</p> <p>NOTE: A USB charging port (also referred to as a USB powered port) allows you to charge connected USB devices. Some USB devices require power and require you to use a powered port.</p> |
| (4) | AC adapter light | <ul style="list-style-type: none"> • White: The AC adapter is connected and the battery is charged. • Amber: The AC adapter is connected and the battery is charging. • Off: The computer is using battery power. |
| (5) | Power connector | Connects an AC adapter. |
| (6) | Security cable slot | <p>Attaches an optional security cable to the computer.</p> <p>NOTE: The security cable is designed to act as a deterrent, but it may not prevent the computer from being mishandled or stolen.</p> |

Bottom



| Item | Component | Description |
|------|--------------|--|
| (1) | Speakers (2) | Produce sound. |
| (2) | Vent | Enables airflow to cool internal components. |

NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.

3 Illustrated parts catalog


Service tag

When ordering parts or requesting information, provide the computer serial number and model number provided on the service tag.



| Item | Description | Function |
|------|----------------------------------|--|
| (1) | Product name | This is the product name affixed to the front of the computer. |
| (2) | Serial number (s/n) | This is an alphanumeric identifier that is unique to each product. |
| (3) | Part number/Product number (p/n) | This number provides specific information about the product's hardware components. The part number helps a service technician to determine what components and parts are needed. |
| (4) | Warranty period | This number describes the duration of the warranty period for the computer. |
| (5) | Model description | This is the alphanumeric identifier used to locate documents, drivers, and support for the computer. |

Computer major components




| Item | Component | Spare part number |
|-------------|--|--------------------------|
| (1) | Display assembly: The display assembly is spared at the subcomponent level only. For more display assembly spare part information, see Display assembly subcomponents on page 19 . | |
| (2) | Top cover: | |
| | Top cover for use only with keyboard spare part kits 700807-031, 700807-041, 700807-051, 700807-061, 700807-071, 700807-131, 700807-141, 700807-161, 700807-A41, 700807-BB1, 700807-BG1, 700807-DB1, and 700807-DH1. | 701824-001 |
| | Top cover for use only with keyboard spare part kits 700807-001, 700807-151, 700807-171, 700807-251, and 700807-B31. | 701823-001 |
| (3) | Power button board (includes cable) | 700891-001 |
| (4) | TouchPad LED board (includes cable) | 701819-001 |
| (5) | TouchPad (includes cable) | 701825-001 |
| (6) | Antenna Kit (includes left and right WLAN antenna cables and transceivers) | 700796-001 |
| (7) | Rear speakers (includes left and right rear speakers, cables, and 2 rubber isolators) | 701821-001 |
| | Keyboard with backlight and pointing stick (includes keyboard cable, keyboard backlight cable, keyboard shield, and pointing stick cable): | |
| | Includes: | |
| (8a) | Keyboard for use in Belgium | 700807-A41 |
| | For use in Canada | 700807-DB1 |
| | For use in Denmark, Finland, and Norway | 700807-DH1 |
| | For use in France | 700807-051 |
| | For use in Germany | 700807-041 |
| | For use in Greece | 700807-151 |
| | For use in Israel | 700807-BB1 |
| | For use in Italy | 700807-061 |
| | For use in Latin America | 700807-161 |
| | For use in the Netherlands | 700807-B31 |
| | For use in Portugal | 700807-131 |
| | For use in Russia | 700807-251 |
| | For use in Saudi Arabia | 700807-171 |
| | For use in Spain | 700807-071 |
| | For use in Switzerland | 700807-BG1 |
| | For use in Turkey | 700807-141 |
| | For use in the United Kingdom and Singapore | 700807-031 |
| | For use in the United States | 700807-001 |

| Item | Component | Spare part number |
|------|--|-------------------|
| (8b) | Keyboard shield | |
| (9) | System board (includes processor and replacement thermal material): | |
| | Equipped with an Intel Quad Core i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715044-601 |
| | Equipped with an Intel Quad Core i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715044-501 |
| | Equipped with an Intel Quad Core i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715044-001 |
| | Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia | 704055-501 |
| | Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia | 704055-001 |
| | Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700814-601 |
| | Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700814-501 |
| | Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 7 operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700814-001 |
| | Equipped with an Intel Dual Core i5-3337U 1.80-GHz processor (turbo up to 2.70-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715045-601 |
| | Equipped with an Intel Dual Core i5-3337U 1.80-GHz processor (turbo up to 2.70-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715045-501 |
| | Equipped with an Intel Dual Core i5-3337U 1.80-GHz processor (turbo up to 2.70-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715045-001 |

| Item | Component | Spare part number |
|-------------|--|--------------------------|
| | Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia | 704056-501 |
| | Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia | 704056-001 |
| | Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700816-601 |
| | Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700816-501 |
| | Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 7 operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700816-001 |
| (10) | RJ-45 jack cover | 701816-001 |
| (11) | Solid-state drive: | |
| | 256-GB | 700813-001 |
| | 128-GB | 700812-001 |
| | 32-GB | 700811-001 |
| (12) | Memory module (PC3-12800, 1666-MHz, DDR3): | |
| | 4-GB | 691740-001 |
| | 2-GB | 691739-001 |
| (13) | Memory shield | 701817-001 |
| (14) | Intel Centrino Advanced-N 6235 Combo Adapter | 670292-005 |
| (15) | Fan (includes cable) | 700803-001 |
| (16) | Heat sink (includes replacement thermal material) | 700804-001 |
| (17) | Multimedia board (includes audio port, Card Reader, USB port, and cable) | 701820-001 |
| (18) | Front speakers (includes left and right front speakers, cables, and 4 rubber isolators) | 700810-001 |
| (19) | RTC battery (includes cable and double-sided tape) | 686922-001 |
| (20) | Hard drive (does not include hard drive bracket, hard drive connector cable, or screws): | |
| | 500-GB, 7200-rpm, 7.0-mm hard drive | 703267-001 |
| | 500-GB, 5400-rpm, 7.0-mm hard drive | 683802-001 |

| Item | Component | Spare part number |
|------|---|-------------------|
| | Hard Drive Hardware Kit (not illustrated, includes hard drive bracket, hard drive connector cable, and screws) | 700805-001 |
| (21) | Power connector cable (includes bracket) | 700802-001 |
| (22) | 4-cell, 48-Wh, 3.27-Ah battery (Li-ion) | 697311-001 |
| (23) | Bottom cover (includes 4 rubber feet) | 700798-001 |


Display assembly subcomponents



| Item | Component | Spare part number |
|------|--|-------------------|
| (1) | Display bezel | 700799-001 |
| (2) | Display panel (15.6-in, HD, LED, BrightView [1920×1080], slim [3.2-mm], UWVA) | 700808-001 |
| (3) | Webcam/microphone module | 700818-001 |
| (4) | Display panel cable (includes webcam/microphone module cable) | 700800-001 |

| Item | Component | Spare part number |
|-------------|--|--------------------------|
| | Display panel touch cable (not illustrated) | 712412-001 |
| | Display enclosure , includes: | 700797-001 |
| (5) | Left and right display hinge covers | |
| (6) | Left and right display hinges | |
| (7) | Display enclosure | |

Mass storage device



| Item | Description | Spare part number |
|------|---|-------------------|
| (1) | Hard drive (does not include hard drive bracket, hard drive connector cable, or screws): | |
| | 500-GB, 7200-rpm, 7.0-mm hard drive | 703267-001 |
| | 500-GB, 5400-rpm, 7.0-mm hard drive | 683802-001 |
| | Hard Drive Hardware Kit , includes: | 700805-001 |
| (2) | Hard drive bracket | |
| (3) | Hard drive connector cable | |
| | Hard drive bracket screws (not illustrated) | |
| (4) | Hard drive space cover | 712413-001 |
| (5) | mSATA solid-state drive: | |
| | 256-GB | 700813-001 |
| | 128-GB | 700812-001 |
| | 32-GB | 700811-001 |

Miscellaneous parts

| Component | Spare part number |
|---|-------------------|
| 65-W AC adapter (non-PFC, 3-wire) | 693715-001 |
| HDMI-to-VGA adapter | 701943-001 |
| HP 15.6-in protective cover | 700801-001 |
| HP computer tote bag with zipper | 675458-001 |
| Power cord (3-pin, black, 1.83-m): | |
| For use in Denmark | 490371-081 |

| Component | Spare part number |
|---|-------------------|
| For use in Europe | 490371-021 |
| For use in Israel | 490371-BB1 |
| For use in North America | 490371-001 |
| For use in Switzerland | 490371-111 |
| For use in the United Kingdom and Singapore | 490371-031 |
| Screw Kit | 700809-001 |

Sequential part number listing

| Spare part number | Description |
|-------------------|--|
| 490371-001 | Power cord for use in North America (3-pin, black, 1.83-m) |
| 490371-021 | Power cord for use in Europe (3-pin, black, 1.83-m) |
| 490371-031 | Power cord for use in the United Kingdom and Singapore (3-pin, black, 1.83-m) |
| 490371-081 | Power cord for use in Denmark (3-pin, black, 1.83-m) |
| 490371-111 | Power cord for use in Switzerland (3-pin, black, 1.83-m) |
| 490371-BB1 | Power cord for use in Israel (3-pin, black, 1.83-m) |
| 670292-005 | Intel Centrino Advanced-N 6235 Combo Adapter |
| 675458-001 | HP computer tote bag with zipper |
| 683802-001 | 500-GB, 5400-rpm, 7.0-mm hard drive (does not include hard drive bracket, hard drive connector cable, or screws) |
| | NOTE: The hard drive bracket, hard drive connector cable, and screws are included in the Hard Drive Hardware Kit, spare part number 700805-001. |
| 686922-001 | RTC battery (includes cable and double-sided tape) |
| 691739-001 | 2-GB memory module (PC3, 12800, 1600-MHz) |
| 691740-001 | 4-GB memory module (PC3, 12800, 1600-MHz) |
| 693715-001 | 65-W AC adapter (non-PFC, 3-wire) |
| 697311-001 | 4-cell, 48-Wh, 3.27-Ah, Li-ion battery |
| 700796-001 | Antenna Kit (includes left and right WLAN antenna cables and transceivers) |
| 700797-001 | Display enclosure (includes left and right display hinges, left and right display hinge covers, and screws) |
| 700798-001 | Bottom cover |
| 700799-001 | Display bezel |
| 700800-001 | Display panel cable |

| Spare part number | Description |
|-------------------|--|
| 700801-001 | HP 15.6-in protective cover |
| 700802-001 | Power connector cable (includes bracket) |
| 700803-001 | Fan (includes cable) |
| 700804-001 | Heat sink (includes replacement thermal material) |
| 700805-001 | Hard Drive Hardware Kit (includes hard drive bracket, hard drive connector cable, and screws) |
| 700807-001 | Keyboard with backlight for use only in the United States (includes keyboard cable and keyboard backlight cable) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701823-001. |
| 700807-031 | Keyboard with backlight for use only in the United Kingdom and Singapore (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-041 | Keyboard with backlight for use only in Germany (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-051 | Keyboard with backlight for use only in France (includes keyboard cable and keyboard backlight cable) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-061 | Keyboard with backlight for use only in Italy (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-071 | Keyboard with backlight for use only in Spain (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-131 | Keyboard with backlight for use only in Portugal (includes keyboard cable and keyboard backlight cable) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-141 | Keyboard with backlight for use only in Turkey (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-151 | Keyboard with backlight for use only in Greece (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701823-001. |
| 700807-161 | Keyboard with backlight for use only in Latin America (includes keyboard cable and keyboard backlight cable) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |

| Spare part number | Description |
|-------------------|---|
| 700807-171 | Keyboard with backlight for use only in Saudi Arabia (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701823-001. |
| 700807-251 | Keyboard with backlight for use only in Russia (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701823-001. |
| 700807-A41 | Keyboard with backlight for use only in Belgium (includes keyboard cable and keyboard backlight cable) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-B31 | Keyboard with backlight for use only in the Netherlands (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701823-001. |
| 700807-BB1 | Keyboard with backlight for use only in Israel (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701823-001. |
| 700807-BG1 | Keyboard with backlight for use only in Switzerland (includes keyboard cable and keyboard backlight cable) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-DB1 | Keyboard with backlight for use only in Canada (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700807-DH1 | Keyboard with backlight for use only in Denmark, Finland, and Norway (includes keyboard cable, keyboard backlight cable, and keyboard shield) NOTE: This keyboard spare part kit is for use only with top cover spare part kit 701824-001. |
| 700808-001 | 15.6-in, BrightView (1920×1080), FHD, WLED, UWVA display panel |
| 700809-001 | Screw Kit |
| 700810-001 | Front speakers (includes cables and 2 rubber isolators) |
| 700811-001 | 32-GB solid-state drive |
| 700812-001 | 128-GB solid-state drive |
| 700813-001 | 256-GB solid-state drive |
| 700814-001 | System board equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 7 operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia (includes replacement thermal material) |
| 700814-501 | System board equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia (includes replacement thermal material) |

| Spare part number | Description |
|-------------------|---|
| 700814-601 | System board equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia (includes replacement thermal material) |
| 700816-001 | System board equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 7 operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia (includes replacement thermal material) |
| 700816-501 | System board equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia (includes replacement thermal material) |
| 700816-601 | System board equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia (includes replacement thermal material) |
| 700818-001 | Webcam/microphone module |
| 700891-001 | Power button board (includes cable) |
| 701816-001 | RJ-45 jack cover |
| 701817-001 | Memory shield |
| 701819-001 | TouchPad LED board (includes cable) |
| 701820-001 | Multimedia board (includes audio port, Card Reader, USB port, and cable) |
| 701821-001 | Rear speakers (includes cables and 2 rubber isolators) |
| 701823-001 | Top cover NOTE: This top cover spare part kit is for use only with keyboard spare part kits 700807-001, 700807-151, 700807-171, 700807-251, and 700807-B31. |
| 701824-001 | Top cover NOTE: This top cover spare part kit is for use only with keyboard spare part kits 700807-031, 700807-041, 700807-051, 700807-061, 700807-071, 700807-131, 700807-141, 700807-161, 700807-A41, 700807-BB1, 700807-BG1, 700807-DB1, and 700807-DH1. |
| 701825-001 | TouchPad (includes cable) |
| 701943-001 | HDMI-to-VGA adapter |
| 703267-001 | 500-GB, 7200-rpm, 7.0-mm hard drive (does not include hard drive bracket, hard drive connector cable, or screws) NOTE: The hard drive bracket, hard drive connector cable, and screws are included in the Hard Drive Hardware Kit, spare part number 700805-001. |
| 704055-001 | System board equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |

| Spare part number | Description |
|--------------------------|--|
| 704055-501 | System board equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |
| 704056-001 | System board equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |
| 704056-501 | System board equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |
| 712412-001 | Display panel touch cable |
| 712413-001 | Hard drive space cover |
| 715044-001 | System board equipped with an Intel Quad Core i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |
| 715044-501 | System board equipped with an Intel Quad Core i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |
| 715044-601 | System board equipped with an Intel Quad Core i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |
| 715045-001 | System board equipped with an Intel Dual Core i5-3337U 1.80-GHz processor (turbo up to 2.70-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |
| 715045-501 | System board equipped with an Intel Dual Core i5-3337U 1.80-GHz processor (turbo up to 2.70-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |
| 715045-601 | System board equipped with an Intel Dual Core i5-3337U 1.80-GHz processor (turbo up to 2.70-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system without trusted platform module security for use only in the People's Republic of China and Russia (includes replacement thermal material) |

4 Removal and replacement procedures

Preliminary replacement requirements

Tools required

You will need the following tools to complete the removal and replacement procedures:

- Flat-bladed screw driver
- Magnetic screw driver
- Phillips P0 and P1 screw drivers

Service considerations

The following sections include some of the considerations that you must keep in mind during disassembly and assembly procedures.

 **NOTE:** As you remove each subassembly from the computer, place the subassembly (and all accompanying screws) away from the work area to prevent damage.

Plastic parts

 **CAUTION:** Using excessive force during disassembly and reassembly can damage plastic parts. Use care when handling the plastic parts. Apply pressure only at the points designated in the maintenance instructions.

Cables and connectors

 **CAUTION:** When servicing the computer, be sure that cables are placed in their proper locations during the reassembly process. Improper cable placement can damage the computer.

Cables must be handled with extreme care to avoid damage. Apply only the tension required to unseat or seat the cables during removal and insertion. Handle cables by the connector whenever possible. In all cases, avoid bending, twisting, or tearing cables. Be sure that cables are routed in such a way that they cannot be caught or snagged by parts being removed or replaced. Handle flex cables with extreme care; these cables tear easily.

Drive handling

⚠ CAUTION: Drives are fragile components that must be handled with care. To prevent damage to the computer, damage to a drive, or loss of information, observe these precautions:

Before removing or inserting a hard drive, shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.

Before handling a drive, be sure that you are discharged of static electricity. While handling a drive, avoid touching the connector.

Before removing a diskette drive or optical drive, be sure that a diskette or disc is not in the drive and be sure that the optical drive tray is closed.

Handle drives on surfaces covered with at least one inch of shock-proof foam.

Avoid dropping drives from any height onto any surface.

After removing a hard drive, an optical drive, or a diskette drive, place it in a static-proof bag.

Avoid exposing an internal hard drive to products that have magnetic fields, such as monitors or speakers.

Avoid exposing a drive to temperature extremes or liquids.

If a drive must be mailed, place the drive in a bubble pack mailer or other suitable form of protective packaging and label the package "FRAGILE."

Grounding guidelines

Electrostatic discharge damage

Electronic components are sensitive to electrostatic discharge (ESD). Circuitry design and structure determine the degree of sensitivity. Networks built into many integrated circuits provide some protection, but in many cases, ESD contains enough power to alter device parameters or melt silicon junctions.

A discharge of static electricity from a finger or other conductor can destroy static-sensitive devices or microcircuitry. Even if the spark is neither felt nor heard, damage may have occurred.

An electronic device exposed to ESD may not be affected at all and can work perfectly throughout a normal cycle. Or the device may function normally for a while, then degrade in the internal layers, reducing its life expectancy.

⚠ CAUTION: To prevent damage to the computer when you are removing or installing internal components, observe these precautions:

Keep components in their electrostatic-safe containers until you are ready to install them.

Before touching an electronic component, discharge static electricity by using the guidelines described in this section.

Avoid touching pins, leads, and circuitry. Handle electronic components as little as possible.

If you remove a component, place it in an electrostatic-safe container.

The following table shows how humidity affects the electrostatic voltage levels generated by different activities.

⚠ CAUTION: A product can be degraded by as little as 700 V.

| Typical electrostatic voltage levels | | | |
|---|--------------------------|------------|------------|
| Event | Relative humidity | | |
| | 10% | 40% | 55% |
| Walking across carpet | 35,000 V | 15,000 V | 7,500 V |
| Walking across vinyl floor | 12,000 V | 5,000 V | 3,000 V |
| Motions of bench worker | 6,000 V | 800 V | 400 V |
| Removing DIPS from plastic tube | 2,000 V | 700 V | 400 V |
| Removing DIPS from vinyl tray | 11,500 V | 4,000 V | 2,000 V |
| Removing DIPS from Styrofoam | 14,500 V | 5,000 V | 3,500 V |
| Removing bubble pack from PCB | 26,500 V | 20,000 V | 7,000 V |
| Packing PCBs in foam-lined box | 21,000 V | 11,000 V | 5,000 V |

Packaging and transporting guidelines

Follow these grounding guidelines when packaging and transporting equipment:

- To avoid hand contact, transport products in static-safe tubes, bags, or boxes.
- Protect ESD-sensitive parts and assemblies with conductive or approved containers or packaging.
- Keep ESD-sensitive parts in their containers until the parts arrive at static-free workstations.
- Place items on a grounded surface before removing items from their containers.
- Always be properly grounded when touching a component or assembly.
- Store reusable ESD-sensitive parts from assemblies in protective packaging or nonconductive foam.
- Use transporters and conveyors made of antistatic belts and roller bushings. Be sure that mechanized equipment used for moving materials is wired to ground and that proper materials are selected to avoid static charging. When grounding is not possible, use an ionizer to dissipate electric charges.

Workstation guidelines

Follow these grounding workstation guidelines:

- Cover the workstation with approved static-shielding material.
- Use a wrist strap connected to a properly grounded work surface and use properly grounded tools and equipment.
- Use conductive field service tools, such as cutters, screw drivers, and vacuums.
- When fixtures must directly contact dissipative surfaces, use fixtures made only of static-safe materials.
- Keep the work area free of nonconductive materials, such as ordinary plastic assembly aids and Styrofoam.
- Handle ESD-sensitive components, parts, and assemblies by the case or PCM laminate. Handle these items only at static-free workstations.
- Avoid contact with pins, leads, or circuitry.
- Turn off power and input signals before inserting or removing connectors or test equipment.

Equipment guidelines

Grounding equipment must include either a wrist strap or a foot strap at a grounded workstation.

- When seated, wear a wrist strap connected to a grounded system. Wrist straps are flexible straps with a minimum of one megohm $\pm 10\%$ resistance in the ground cords. To provide proper ground, wear a strap snugly against the skin at all times. On grounded mats with banana-plug connectors, use alligator clips to connect a wrist strap.
- When standing, use foot straps and a grounded floor mat. Foot straps (heel, toe, or boot straps) can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use foot straps on both feet with a minimum of one megohm resistance between the operator and ground. To be effective, the conductive must be worn in contact with the skin.

The following grounding equipment is recommended to prevent electrostatic damage:

- Antistatic tape
- Antistatic smocks, aprons, and sleeve protectors
- Conductive bins and other assembly or soldering aids
- Nonconductive foam
- Conductive tabletop workstations with ground cords of one megohm resistance
- Static-dissipative tables or floor mats with hard ties to the ground
- Field service kits
- Static awareness labels
- Material-handling packages
- Nonconductive plastic bags, tubes, or boxes
- Metal tote boxes
- Electrostatic voltage levels and protective materials

The following table lists the shielding protection provided by antistatic bags and floor mats.

| Material | Use | Voltage protection level |
|-----------------------|------------|---------------------------------|
| Antistatic plastics | Bags | 1,500 V |
| Carbon-loaded plastic | Floor mats | 7,500 V |
| Metallized laminate | Floor mats | 5,000 V |


Component replacement procedures

This chapter provides removal and replacement procedures.

There are as many as 106 screws that must be removed, replaced, and/or loosened when servicing the computer. Make special note of each screw size and location during removal and replacement.

Service tag

When ordering parts or requesting information, provide the computer serial number and model number provided on the service tag. It is necessary to remove the battery to obtain these numbers. See [Battery on page 35](#) for battery removal instructions.



| Item | Component | Description |
|------|----------------------------------|---|
| (1) | Product name | This is the product name affixed to the front of the computer. |
| (2) | Serial number (s/n) | This is an alphanumeric identifier that is unique to each product. |
| (3) | Part number/Product number (p/n) | This number provides specific information about the product's hardware components. The part number helps a service technician determine what components and parts are needed. |

| Item | Component | Description |
|------|-------------------|--|
| (4) | Warranty period | This number describes the duration of the warranty period for the computer. |
| (5) | Model description | This is the alphanumeric identifier used to locate documents, drivers, and support for the computer. |

Bottom cover

| Description | Spare part number |
|--------------|-------------------|
| Bottom cover | 671731-001 |

Before disassembling the computer, follow these steps:


1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.

Remove the bottom cover:

1. Turn the computer upside down, with the front toward you.
2. Remove the four Phillips PM2.5×5.5 screws that secure the bottom cover to the computer.



3. Remove the ten Phillips PM2.5×9.5 screws that secure the bottom cover to the computer.



4. Lift the rear right corner **(1)** of the bottom cover until the cover detaches from the computer, and then remove the bottom cover **(2)** from the computer.



Reverse this procedure to install the bottom cover.

Battery


| Description | Spare part number |
|---|-------------------|
| 4-cell, 48-Wh, 3.27-Ah battery (Li-ion) | 697311-001 |

Before removing the battery, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).

Remove the battery:

1. Detach the multimedia cable **(1)** from the battery. (The multimedia cable is attached to the battery with double-sided tape.)
2. Disconnect the battery cable **(2)** from the system board.
3. Remove the four Phillips PM2.0×3.0 screws **(3)** that secure the battery to the top cover.
4. Remove the battery **(4)** from the computer.



Reverse this procedure to install the battery.

RTC battery


| Description | Spare part number |
|--|-------------------|
| RTC battery (includes cable and double-sided tape) | 686922-001 |

Before removing the RTC battery, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).

Remove the RTC battery:

1. Disconnect the RTC battery cable **(1)** from the system board.
2. Detach the RTC battery **(2)** from the top cover. (The RTC battery is attached to the top cover with double-sided tape.)



3. Remove the RTC battery.

Reverse this procedure to install the RTC battery.

WLAN module

| Description | Spare part number |
|--|-------------------|
| Intel Centrino Advanced-N 6235 Combo Adapter | 670292-005 |

 **CAUTION:** To prevent an unresponsive system, replace the wireless module only with a wireless module authorized for use in the computer by the governmental agency that regulates wireless devices in your country or region. If you replace the module and then receive a warning message, remove the module to restore device functionality, and then contact technical support.

Before removing the WLAN module, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).

Remove the WLAN module:


1. Disconnect the WLAN antenna cables **(1)** from the terminals on the WLAN module.




NOTE: The WLAN antenna cable labeled "1" connects to the WLAN module "Main" terminal labeled "1". The WLAN antenna cable labeled "2" connects to the WLAN module "Aux" terminal labeled "2".

2. Remove the two Phillips PM2.0×3.0 screws **(2)** that secure the WLAN module to the system board. (The WLAN module tilts up.)

3. Remove the WLAN module (3) by pulling the module away from the slot at an angle.



 **NOTE:** If the WLAN antenna cables are not connected to the terminals on the WLAN module, the protective sleeves must be installed on the antenna connectors, as shown in the following illustration.



Reverse this procedure to install the WLAN module.

Fan


| Description | Spare part number |
|----------------------|-------------------|
| Fan (includes cable) | 700803-001 |

Before removing the fan, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).

Remove the fan:

1. Disconnect the fan cable **(1)** from the system board.
2. Remove the two Phillips PM2.0×4.5 screws **(2)** that secure the fan to the top cover.
3. Remove the fan **(3)** from the top cover.



Reverse this procedure to install the fan.

Solid-state drive


| Description | Spare part number |
|-------------|-------------------|
| 256-GB | 700813-001 |
| 128-GB | 700812-001 |
| 32-GB | 700811-001 |

Before removing the solid-state drive, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).

Remove the solid-state drive:

1. Remove the two Phillips PM2.0×4.5 screws **(1)** that secure the solid-state drive to the top cover. (The solid-state drive tilts up.)
2. Remove the solid-state drive **(3)** by pulling the drive away from the slot at an angle.



Reverse this procedure to install the solid-state drive.

Power button board

| Description | Spare part number |
|-------------------------------------|-------------------|
| Power button board (includes cable) | 700891-001 |


Before removing the power button board, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).

Remove the power button board:

1. Release the zero insertion force (ZIF) connector **(1)** to which the power button board cable is attached, and then disconnect the power button board cable from the system board.
2. Detach the power button board cable **(2)** from the memory shield. (The power button board cable is attached to the memory shield with double-sided tape at 2 locations.)
3. Remove the Phillips PM2.0×4.5 screw **(3)** that secures the power button board to the top cover.

4. Remove the power button board (4).



Reverse this procedure to install the power button board.

Hard drive



NOTE: The hard drive spare part kit does not include the hard drive bracket, hard drive connector cable, or screws. These components are included in the Hard Drive Hardware Kit, spare part number 700805-001.

| Description | Spare part number |
|-------------------------------------|-------------------|
| 500-GB, 7200-rpm, 7.0-mm hard drive | 703267-001 |
| 500-GB, 5400-rpm, 7.0-mm hard drive | 683802-001 |

Before removing the hard drive, follow these steps:


1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).

Remove the hard drive:

1. Disconnect the hard drive cable **(1)** from the system board.
2. Remove the three Phillips PM2.5×5.5 screws **(2)** that secure the hard drive to the top cover.

3. Remove the hard drive **(3)**.


 **NOTE:** As the hard drive is being removed, make sure the hard drive cable is released from beneath the multimedia board cable **(4)**.



4. If it is necessary to disassemble the hard drive, perform the following steps:

- a.** Position the hard drive with the connector toward you.
- b.** Disconnect the hard drive connector cable **(1)** from the hard drive.
- c.** Remove the four Phillips PM3.0×3.3 screws **(2)** that secure the hard drive bracket to the hard drive.
- d.** Remove the hard drive bracket **(3)** from the hard drive.

The hard drive bracket, hard drive connector cable, and screws are available in the Hard Drive Hardware Kit, spare part number 700805-001.



Reverse this procedure to reassemble and install the hard drive.

Display assembly subcomponents

 **NOTE:** The display assembly is spared at the subcomponent level only. For more display assembly spare part information, see the individual removal subsections.


To remove the display assembly and access the display assembly subcomponents, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).

Remove the display assembly:


1. Open the computer and rest it on its keyboard.
2. Disconnect the display panel touch cable **(1)** from the system board.
3. Detach the display panel touch cable **(2)** from the system board. (The display panel touch cable is attached to the system board with double-sided tape.)
4. Disconnect the display panel cable **(3)** from the system board.
5. Release the display panel cable **(4)** from the retention clip **(5)** built into the right display hinge.

6. Remove the three Phillips PM2.5x5.5 screws **(6)** that secure the display assembly to the top cover.




7. Open the display hinges as far as they will open **(1)**.

8. Remove the display assembly **(2)** from the computer.



9. If it is necessary to replace the display bezel or any of the display assembly subcomponents:
 - a. Flex the inside edges of the bottom edge **(1)**, the left and right sides **(2)**, and the top edge **(3)** of the display bezel until the bezel disengages from the display enclosure.
 - b. Remove the display bezel **(4)**.


The display bezel is available using spare part number 700799-001.



10. If it is necessary to replace the display panel:

- a.** Remove the two Phillips PM1.5×2.0 screws **(1)** that secure the hinge covers to the display enclosure.
- b.** Remove the left and right hinge covers **(2)** from the display enclosure.


The hinge covers are included in the display enclosure spare part kit, spare part number 700797-001.



- c.** Remove the two Phillips PM2.0×2.5 screws **(1)** that secure the display panel to the display enclosure.
- d.** Slide the display panel **(2)** toward the bottom of the display enclosure until the tabs on the left and right sides of the panel disengage from the slots built into the display enclosure.

- e. Remove the display panel **(3)** from the display enclosure.

The display panel is available using spare part number 700808-001.




- 11.** If it is necessary to replace the display panel cable:

⚠ CAUTION: Before turning the display panel upside down, make sure the work surface is clear of tools, screws, and any other foreign objects. Failure to follow this caution can result in damage to the display panel.

- a. Turn the display panel upside down with top edge toward you.
- b. Release the adhesive support strip **(1)** that secures the display panel cable connector to the display panel.
- c. Disconnect the display panel cable **(2)** from the display panel.
- d. Detach the display panel cable **(3)** from the display panel. (The display panel cable is attached to the display panel with double-sided tape in two locations.)

- e. Disconnect the webcam/microphone module cable **(3)** from the webcam/microphone module.



- f. Remove the display panel cable.

The display panel cable is available using spare part number 700800-001.

12. If it is necessary to replace the webcam/microphone module:

CAUTION: Handle the webcam/microphone module with caution. This module has a thin profile and is susceptible to damage when not handled carefully.

- a. Release the webcam/microphone module **(1)** as far as the webcam/microphone module allows.

- b.** Disconnect the webcam/microphone module cable **(2)** from the webcam/microphone module.



- c.** Remove the webcam/microphone module.

The webcam/microphone module is available using spare part number 700818-001.

Reverse this procedure to reassemble and install the display assembly.

TouchPad


| Description | Spare part number |
|---------------------------|-------------------|
| TouchPad (includes cable) | 701825-001 |

Before removing the TouchPad, follow these steps:


1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Remove the battery (see [Battery on page 35](#)).

Remove the TouchPad:

1. Release the ZIF connector to which the TouchPad cable is attached, and then disconnect the TouchPad cable **(1)** from the TouchPad system board.
2. Detach the TouchPad cable **(2)** from the top cover. (The TouchPad cable is attached to the top cover with double-sided tape at two locations.)
3. Remove the seven Phillips PM2.0×3.0 screws **(3)** that secure the TouchPad to the top cover.



4. Remove the front speaker cables **(1)** from the clips built into the top cover and the top edge of the TouchPad.
5. Lift the top edge of the TouchPad **(2)** until it rests at an angle.
6. Slide the TouchPad **(3)** forward, and then remove the TouchPad.



Reverse this procedure to install the TouchPad.

Front speakers

| Description | Spare part number |
|---|-------------------|
| Front speakers (includes left and right front speakers, cables, and 4 rubber isolators) | 700810-001 |

Before removing the front speakers, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Remove the battery (see [Battery on page 35](#)).
6. Remove the TouchPad (see [TouchPad on page 52](#)).

Remove the front speakers:

1. Release the ZIF connector to which the TouchPad cable is attached, and then disconnect the TouchPad cable **(1)** from the system board.
2. Disconnect the front speaker cable **(2)** from the system board.
3. Release the front speaker cables **(3)** from the clips built into the top cover.




NOTE: Make sure the front speaker cables are released from underneath the TouchPad cable.

4. Remove the four Phillips PM2.0×3.0 broad head screws **(4)** that secure the front speakers to the top cover.

5. Remove the front speakers (5).

 **NOTE:** The front speakers include four rubber isolators (6). These isolators are crucial to the performance of the speakers.



Reverse this procedure to install the front speakers.

TouchPad LED board


| Description | Spare part number |
|-------------------------------------|-------------------|
| TouchPad LED board (includes cable) | 700012-001 |

Before removing the TouchPad LED board, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Remove the battery (see [Battery on page 35](#)).

Remove the TouchPad LED board:

1. Release the ZIF connector **(1)** to which the TouchPad LED board cable is attached, and then disconnect the TouchPad LED board cable from the system board.
2. Detach the TouchPad LED board cable **(2)** from the top cover. (The TouchPad LED board cable is attached to the top cover with double-sided tape.)
3. Release the TouchPad LED board **(3)** from the clips **(4)** built into the top cover.
4. Remove the TouchPad LED board and cable **(5)**, making sure to route the cable underneath the TouchPad cable.



Reverse this procedure to install the TouchPad LED board and cable.

Power connector cable

| Description | Spare part number |
|--|-------------------|
| Power connector cable (includes bracket) | 700802-001 |


Before removing the power connector cable, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).

Remove the power connector cable:

1. Disconnect the power cable **(1)** from the system board.
2. Release the power cable from the clips **(2)** and the routing channel built into the top cover.
3. Remove the two Phillips PM2.0×4.5 screws **(3)** that secure the power connector and bracket to the top cover.
4. Remove the power connector bracket **(4)**.

5. Remove the power connector **(5)** and cable.



Reverse this procedure to install the power connector cable and bracket.

Multimedia board


| Description | Spare part number |
|--|-------------------|
| Multimedia board (includes audio port, Card Reader, USB port, and cable) | 701820-001 |

Before removing the multimedia board, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).
6. Remove the power connector cable (see [Power connector cable on page 57](#)).

Remove the multimedia board:

1. Disconnect the multimedia board cable **(1)** from the system board.
2. Remove the Phillips PM2.0×4.5 screw **(2)** that secures the multimedia board to the top cover.
3. Remove the multimedia board **(3)** and cable.



Reverse this procedure to install the multimedia board.

Memory module

| Description | Spare part number |
|---|-------------------|
| 4-GB memory module (PC3, 12800, 1600-MHz) | 691740-001 |
| 2-GB memory module (PC3, 12800, 1600-MHz) | 691739-001 |
| Memory shield | 701817-001 |

Update BIOS before adding memory modules

Before adding new memory, make sure you update the computer to the latest BIOS.

CAUTION: Failure to update the computer to the latest BIOS prior to installing new memory may result in various system problems.

To update BIOS:

1. Navigate to www.hp.com.
2. Click **Support & Drivers > click Drivers & Software**.
3. In the **Enter a product name/number box**, type the computer model information, and then click **Search**.
4. Click the link for the computer model.
5. Select the operating system, and then click **Next**.
6. Under **Step 2: Select a Download**, click the **BIOS** link.
7. Click the link for the most recent BIOS.
8. Click the **Download** button, and then follow the on-screen instructions.


Before removing a memory module, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 35](#)).


Remove the memory module:

1. Remove the Phillips PM2.0×3.0 screw **(1)** and the Phillips PM2.0×4.5 screw **(2)** that secure the memory shield to the top cover.

2. Remove the memory shield (3).



3. Spread the retaining tabs (1) on each side of the memory module slot to release the memory module. (The memory module tilts up.)
4. Remove the memory module (2) by pulling the module away from the slot at an angle.



Reverse this procedure to install a memory module.

System board

| Description | Spare part number |
|--|-------------------|
| Equipped with an Intel Quad Core i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715044-601 |
| Equipped with an Intel Quad Core i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715044-501 |
| Equipped with an Intel Quad Core i7-3537U 2.00-GHz processor (turbo up to 3.10-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715044-001 |
| Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia | 704055-501 |
| Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia | 704055-001 |
| Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700814-601 |
| Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700814-501 |
| Equipped with an Intel Quad Core i7-3517U 1.90-GHz processor (turbo up to 3.00-GHz), 1600-MHz FSB, 4.00-MB L3 cache, 17 W, and the Windows 7 operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700814-001 |
| Equipped with an Intel Dual Core i5-3337U 1.80-GHz processor (turbo up to 2.70-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715045-601 |
| Equipped with an Intel Dual Core i5-3337U 1.80-GHz processor (turbo up to 2.70-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715045-501 |
| Equipped with an Intel Dual Core i5-3337U 1.80-GHz processor (turbo up to 2.70-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia | 715045-001 |
| Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system without trusted platform module security for use only in the People's Republic of China and Russia | 704056-501 |
| Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 7 operating system without trusted platform module security for use only in the People's Republic of China and Russia | 704056-001 |

| Description | Spare part number |
|--|-------------------|
| Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Professional operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700816-601 |
| Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 8 Standard operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700816-501 |
| Equipped with an Intel Dual Core i5-3317U 1.70-GHz processor (turbo up to 2.60-GHz), 1600-MHz FSB, 3.00-MB L3 cache, 17 W, and the Windows 7 operating system with trusted platform module security for use in all countries and regions except the People's Republic of China and Russia | 700816-001 |

Before removing the system board, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)).
5. Remove the battery (see [Battery on page 35](#)).
6. Remove the fan (see [Fan on page 39](#)).


 **NOTE:** When replacing the system board, be sure that the following components are removed from the defective system board and installed on the replacement system board:

- WLAN module (see [WLAN module on page 37](#))
- Solid-state drive (see [Solid-state drive on page 40](#))
- Memory module and shield (see [Memory module on page 60](#))
- Heat sink (see [Heat sink on page 65](#))
- RJ-45 jack cover (see [RJ-45 jack cover on page 67](#))

Remove the system board:


1. Disconnect the following cables from the system board:

- (1)** Display panel touch cable
- (2)** Rear speaker cable
- (3)** Power button board cable
- (4)** Display panel cable
- (5)** WLAN antenna cables
- (6)** Front speaker cable
- (7)** Hard drive connector cable
- (8)** Keyboard backlight cable
- (9)** Keyboard cable
- (10)** TouchPad LED board cable
- (11)** Multimedia board cable
- (12)** Power connector cable
- (13)** RTC battery cable
- (14)** TouchPad cable



2. Remove the five Phillips PM2.0×4.5 screws **(1)** and the three Phillips PM2.0×3.0 screws **(2)** that secure the system board to the top cover.

3. Remove the system board (3).



Reverse this procedure to install the system board.

Heat sink

| Description | Spare part number |
|---|-------------------|
| Heat sink (includes replacement thermal material) | 700804-001 |


Before removing the heat sink, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)), and then remove the following components:
 - a. Battery (see [Battery on page 35](#))
 - b. Fan (see [Fan on page 39](#))
 - c. System board (see [System board on page 62](#))



Remove the heat sink:

1. Following the 1, 2, 3, 4 sequence stamped into the heat sink, remove the four Phillips PM2.0×4.5 screws **(1)** that secure the heat sink to the system board.
2. Remove the heat sink **(2)**.

 **NOTE:** Due to the adhesive quality of the thermal material located between the heat sink and the system board components, it may be necessary to move the heat sink from side to side to detach it.



 **NOTE:** The thermal material must be thoroughly cleaned from the surfaces of the heat sink and the system board components each time the heat sink is removed. Replacement thermal material is included with the heat sink and system board spare part kits. Thermal paste is used on the processor **(1)** and the section of the heat sink **(2)** that services it.



Reverse this procedure to install the heat sink.

RJ-45 jack cover


| Description | Spare part number |
|------------------|-------------------|
| RJ-45 jack cover | 701816-001 |

Before removing the RJ-45 jack cover, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)), and then remove the following components:
 - a. Battery (see [Battery on page 35](#))
 - b. Fan (see [Fan on page 39](#))
 - c. System board (see [System board on page 62](#))

Remove the RJ-45 jack cover:

1. Turn the system board upside down, with the USB connectors toward you.
2. Remove the two Phillips PM2.0×4.5 screws **(1)** that secure the RJ-45 jack cover to the system board.
3. Turn the system board right side up, with the USB connectors toward you.
4. Remove the RJ-45 jack cover **(2)**.



Reverse this procedure to install the RJ-45 jack cover.

Keyboard

 **NOTE:** The keyboard spare part kit includes a keyboard, keyboard cable, keyboard backlight cable, keyboard shield, and pointing stick cable.


| For use in country/region | Spare part number | For use in country/region | Spare part number |
|---|-------------------|---|-------------------|
| Keyboard with backlight and pointing stick: | | | |
| For use in Belgium | 700807-A41 | For use in the Netherlands | 700807-B31 |
| For use in Canada | 700807-DB1 | For use in Portugal | 700807-131 |
| For use in Denmark, Finland, and Norway | 700807-DH1 | For use in Russia | 700807-251 |
| For use in France | 700807-051 | For use in Saudi Arabia | 700807-171 |
| For use in Germany | 700807-041 | For use in Spain | 700807-071 |
| For use in Greece | 700807-151 | For use in Switzerland | 700807-BG1 |
| For use in Israel | 700807-BB1 | For use in Turkey | 700807-141 |
| For use in Italy | 700807-061 | For use in the United Kingdom and Singapore | 700807-031 |
| For use in Latin America | 700807-161 | For use in the United States | 700807-001 |

Before removing the keyboard, follow these steps:


1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)), and then remove the following components:
 - a. Battery (see [Battery on page 35](#))
 - b. Fan (see [Fan on page 39](#))
 - c. System board (see [System board on page 62](#))

Remove the keyboard:


1. Remove the 20 Phillips PM2.0×3.0 screws that secure the keyboard shield to the top cover.




2. Remove the 8 Phillips PM1.5×2.0 screws that secure the keyboard shield to the top cover.



3. Remove the keyboard shield.



4. Remove the two Phillips PM2.0×3.0 screws **(1)** and the five Phillips PM1.5×2.0 screws **(2)** that secure the keyboard to the top cover.
5. Remove the keyboard **(3)**.



Reverse this procedure to install the keyboard.

Rear speakers

| Description | Spare part number |
|---|-------------------|
| Rear speakers (includes left and right rear speakers, cables, and 2 rubber isolators) | 701821-001 |


Before removing the rear speakers, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)), and then remove the following components:
 - a. Battery (see [Battery on page 35](#))
 - b. Fan (see [Fan on page 39](#))
 - c. System board (see [System board on page 62](#))

Remove the rear speakers:

1. Remove the two Phillips PM2.0×3.0 broad head screws **(1)** that secure the rear speakers to the top cover.
2. Remove the rear speakers **(2)** from the top cover.

 **NOTE:** The rear speakers include two rubber isolators **(6)**. These isolators are crucial to the performance of the speakers.



Reverse this procedure to install the rear speakers.

WLAN antenna

| Description | Spare part number |
|--|-------------------|
| Antenna Kit (includes left and right WLAN antenna cables and transceivers) | 700796-001 |


Before removing the WLAN antenna, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.

3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 33](#)), and then remove the following components:
 - a. Battery (see [Battery on page 35](#))
 - b. Fan (see [Fan on page 39](#))
 - c. System board (see [System board on page 62](#))

Remove the WLAN antenna:

1. Detach the WLAN antenna transceivers **(1)** from the top cover. (The WLAN antenna transceivers are attached to the top cover with double-sided tape.)
2. Release the WLAN antenna cables from the clips **(2)** and routing channel built into the top cover.
3. Remove the WLAN antenna cables and transceivers **(3)** from the top cover.



Reverse this procedure to install the WLAN antenna.

5 Using Setup Utility (BIOS) and System Diagnostics

Setup Utility, or Basic Input/Output System (BIOS), controls communication between all the input and output devices on the system (such as disk drives, display, keyboard, mouse, and printer). Setup Utility (BIOS) includes settings for the types of devices installed, the startup sequence of the computer, and the amount of system and extended memory.

Starting Setup Utility (BIOS)

To start Setup Utility (BIOS), turn on or restart the computer, quickly press **esc**, and then press **f10**.

Information about how to navigate in Setup Utility (BIOS) is located at the bottom of the screen.

 **NOTE:** Use extreme care when making changes in Setup Utility (BIOS). Errors can prevent the computer from operating properly.

Updating the BIOS

Updated versions of the BIOS may be available on the HP website.

Most BIOS updates on the HP website are packaged in compressed files called SoftPaqs.

Some download packages contain a file named `Readme.txt`, which contains information regarding installing and troubleshooting the file.

Determining the BIOS version

To determine whether available BIOS updates contain later BIOS versions than those currently installed on the computer, you need to know the version of the system BIOS currently installed.

BIOS version information (also known as *ROM date* and *System BIOS*) can be displayed by pressing **fn +esc** (if you are already in Windows) or by using Setup Utility (BIOS).

1. Start Setup Utility (BIOS).
2. Use the arrow keys to select **Main**.
3. To exit Setup Utility (BIOS) without saving your changes, use the arrow keys to select **Exit**, select **Exit Discarding Changes**, and then press **enter**.

Downloading a BIOS update

 **CAUTION:** CAUTION: To reduce the risk of damage to the computer or an unsuccessful installation, download and install a BIOS update only when the computer is connected to reliable external power using the AC adapter. Do not download or install a BIOS update while the computer is running on battery power, docked in an optional docking device, or connected to an optional power source. During the download and installation, follow these instructions:

Do not disconnect power from the computer by unplugging the power cord from the AC outlet.

Do not shut down the computer or initiate Sleep.

Do not insert, remove, connect, or disconnect any device, cable, or cord.

1. From the Start screen, select the **HP Support Assistant** app.
2. Select **Updates and tune-ups**, and then select **Check for HP updates now**.
3. Follow the on-screen instructions.
4. At the download area, follow these steps:
 - a. Identify the most recent BIOS update and compare it to the BIOS version currently installed on your computer. Make a note of the date, name, or other identifier. You may need this information to locate the update later, after it has been downloaded to your hard drive.
 - b. Follow the on-screen instructions to download your selection to the hard drive.

Make a note of the path to the location on your hard drive where the BIOS update is downloaded. You will need to access this path when you are ready to install the update.

 **NOTE:** If you connect your computer to a network, consult the network administrator before installing any software updates, especially system BIOS updates.

BIOS installation procedures vary. Follow any instructions that are displayed on the screen after the download is complete. If no instructions are displayed, follow these steps:

1. From the Start screen, type *e*, and then select **File Explorer**.
2. Click your hard drive designation. The hard drive designation is typically Local Disk (C:).
3. Using the hard drive path you recorded earlier, open the folder on your hard drive that contains the update.
4. Double-click the file that has an .exe extension (for example, *filename.exe*).

The BIOS installation begins.

5. Complete the installation by following the on-screen instructions.

 **NOTE:** After a message on the screen reports a successful installation, you can delete the downloaded file from your hard drive.

Using System Diagnostics

System Diagnostics allows you to run diagnostic tests to determine if the computer hardware is functioning properly.

To start System Diagnostics:

1. Turn on or restart the computer, quickly press `esc`, and then press `f2`.
2. Click the diagnostic test you want to run, and then follow the on-screen instructions.



NOTE: If you need to stop a diagnostic test while it is running, press `esc`.

6 Specifications

Computer specifications

| | Metric | U.S. |
|--|---------------------------|---------------------|
| Dimensions | | |
| Width | 37.79 cm | 14.88 in |
| Depth | 25.44 cm | 10.02 in |
| Height (front to rear) | 1.79 to 2.22 cm | 0.72 to 0.87 in |
| Weight | 2.25 kg | 4.86 lbs |
| Input power | | |
| Operating voltage and current | 19.5 V dc @ 3.33 A – 65 W | |
| Temperature | | |
| Operating | 5°C to 35°C | 41°F to 95°F |
| Nonoperating | -20°C to 60°C | -4°F to 140°F |
| Relative humidity (noncondensing) | | |
| Operating | 10% to 90% | |
| Nonoperating | 5% to 95% | |
| Maximum altitude (unpressurized) | | |
| Operating | -15 m to 3,048 m | -50 ft to 10,000 ft |
| Nonoperating | -15 m to 12,192 m | -50 ft to 40,000 ft |

NOTE: Applicable product safety standards specify thermal limits for plastic surfaces. The device operates well within this range of temperatures.

15.6-inch SGA display specifications

| | Metric | U.S. |
|--------------------------------|--|-------------|
| Dimensions | | |
| Height | 19.60 cm | 7.72 in |
| Width | 34.70 cm | 13.66 in |
| Diagonal | 39.80 cm | 15.67 in |
| Number of colors | Up to 16.8 million | |
| Contrast ratio | 200:1 (typical) | |
| Brightness | 300 nits (typical) | |
| Pixel resolution | | |
| Pitch | 0.197 × 0.197 mm | |
| Format | 1920 × 1080 | |
| Configuration | RGB vertical stripe | |
| Backlight | LED | |
| Character display | 80 × 25 | |
| Total power consumption | 3.46 W | |
| Viewing angle | ±65° horizontal, ±50° vertical (typical) | |

Hard drive specifications

| | 500-GB, 7200-rpm* | 500-GB, 5000-rpm* |
|--|-------------------|-------------------|
| Dimensions | | |
| Height | 7.0 mm | 7.0 mm |
| Length | 100.4 mm | 100.4 mm |
| Width | 69.9 mm | 69.9 mm |
| Weight | 110 g | 110 g |
| Interface type | SATA | SATA |
| Transfer rate | | |
| Synchronous (maximum) | 1.1 GB/sec | 1.1 GB/sec |
| Security | ATA security | ATA security |
| Seek times (typical read, including setting) | | |
| Single track | 1.5 ms | 1.5 ms |
| Average (read/write) | 11/13 ms | 11/13 ms |
| Maximum | 22 ms | 22 ms |
| Logical blocks | 500-GB* | 500-GB* |
| Disk rotational speed | 976,773,168 | 976,773,168 |
| Operating temperature | 7200 rpm | 5400 rpm |
| *1 GB = 1 billion bytes when referring to hard drive storage capacity. Actual accessible capacity is less. | | |
| NOTE: Certain restrictions and exclusions apply. Contact technical support for details. | | |

7 Backing up, restoring, and recovering

Your computer includes tools provided by HP and the operating system to help you safeguard your information and retrieve it if you ever need to. These tools will help you return your computer to a proper working state or even back to the original factory state, all with simple steps.

This chapter provides information about the following processes:

- Creating recovery media and backups
- Restoring and recovering your system



NOTE: This guide describes an overview of backing up, restoring and recovering options. For more details about the tools provided, see Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Creating recovery media and backups

Recovery after a system failure is only as good as your most recent backup.

1. After you successfully set up the computer, create HP Recovery media. This step creates a backup of the HP Recovery partition on the computer. The backup can be used to reinstall the original operating system in cases where the hard drive is corrupted or has been replaced.

HP Recovery media you create will provide the following recovery options:

- **System Recovery**—Reinstalls the original operating system and the programs that were installed at the factory.
- **Minimized Image Recovery**—Reinstalls the operating system and all hardware-related drivers and software, but not other software applications.
- **Factory Reset**—Restores the computer to the state its original factory state by deleting all information from the hard drive and re-creating the partitions. Then it reinstalls the operating system and the software that was installed at the factory.

See [Creating HP Recovery media on page 81](#).

2. As you add hardware and software programs, create system restore points. A system restore point is a snapshot of certain hard drive contents saved by Windows System Restore at a specific time. A system restore point contains information that Windows uses, such as registry settings. Windows creates a system restore point for you automatically during a Windows update and during other system maintenance (such as a software update, security scanning, or system diagnostics). You can also manually create a system restore point at any time. For more information and steps for creating specific system restore points, see Windows Help and Support. From the Start screen, type **h**, and then select **Help and Support**.
3. As you add photos, video, music, and other personal files, create a backup of your personal information. Windows File History can be set to regularly and automatically back up files from libraries, Desktop, contacts, and favorites. If files are accidentally deleted from the hard drive and they can no longer be restored from the Recycle Bin, or if files become corrupted, you can restore the files that you backed up using File History. Restoring files is also useful if you ever choose to reset the computer by reinstalling Windows or choose to recover using HP Recovery Manager.



NOTE: File History is not enabled by default, so you must turn it on.

For more information and steps for enabling Windows File History, see Windows Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Creating HP Recovery media

HP Recovery Manager is a software program that offers a way to create recovery media after you successfully set up the computer. HP Recovery media can be used to perform system recovery if the hard drive becomes corrupted. System recovery reinstalls the original operating system and the software programs installed at the factory, and then configures the settings for the programs. HP Recovery media can also be used to customize the system or aid in the replacement of a hard drive.

- Only one set of HP Recovery media can be created. Handle these recovery tools carefully, and keep them in a safe place.
- HP Recovery Manager examines the computer and determines the required storage capacity for the blank USB flash drive or the number of blank DVD discs that will be required.
- To create recovery discs, your computer must have an optical drive with DVD writer capability, and you must use only high-quality blank DVD-R, DVD+R, DVD-R DL, DVD+R DL discs. Do not use rewritable discs such as CD±RW, DVD±RW, double-layer DVD±RW, or BD-RE (rewritable Blu-ray) discs; they are not compatible with HP Recovery Manager software. Or instead you can use a high-quality blank USB flash drive.
- If your computer does not include an integrated optical drive with DVD writer capability, but you would like to create DVD recovery media, you can use an external optical drive (purchased separately) to create recovery discs, or you can obtain recovery discs for your computer from the HP website. For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html. If you use an external optical drive, it must be connected directly to a USB port on the computer; the drive cannot be connected to a USB port on an external device, such as a USB hub.

- Be sure that the computer is connected to AC power before you begin creating the recovery media.
- The creation process can take up to an hour or more. Do not interrupt the creation process.
- If necessary, you can exit the program before you have finished creating all of the recovery DVDs. HP Recovery Manager will finish burning the current DVD. The next time you start HP Recovery Manager, you will be prompted to continue, and the remaining discs will be burned.

To create HP Recovery media:

1. From the Start screen, type `recovery`, and then select **HP Recovery Manager**.
2. Select **Recovery Media Creation**, and follow the on-screen instructions to continue.

If you ever need to recover the system, see [Recovering using HP Recovery Manager on page 84](#).

Restore and recovery

There are several options for recovering your system. Choose the method that best matches your situation and level of expertise:

- If you need to restore your personal files and data, you can use Windows File History to restore your information from the backups you created. For more information and steps for using File History, see Windows Help and Support. From the Start screen, type `h`, and then select **Help and Support**.
- If you need to correct a problem with a preinstalled application or driver, use the Drivers and Applications Reinstall option of HP Recovery Manager to reinstall the individual application or driver.

From the Start screen, type `recovery`, select **HP Recovery Manager**, and then select **Drivers and Applications Reinstall**, and follow the on-screen instructions.

- If you want to restore the system to a previous state without losing any personal information, Windows System Restore is an option. System Restore allows you to restore without the requirements of Windows Refresh or a reinstallation. Windows creates system restore points automatically during a Windows update and other system maintenance events. Even if you did not manually create a restore point, you can choose to restore to a previous point, automatically created. For more information and steps for using Windows System Restore, see Windows Help and Support. From the Start screen, type `h`, and then select **Help and Support**.
- If you want a quick and easy way to recover the system without losing your personal information, settings, or apps that came preinstalled on your computer or were purchased from the Windows Store, consider using Windows Refresh. This option does not require backing up data to another drive. See [Using Windows Refresh for quick and easy recovery on page 83](#).
- If you want to reset your computer to its original state, Windows provides an easy way to remove all personal data, apps, and settings, and reinstall Windows.

For more information, see [Remove everything and reinstall Windows on page 84](#).

- If you want to reset your computer using a minimized image, you can choose the HP Minimized Image Recovery option from the HP Recovery partition (select models only) or HP Recovery media.

Minimized Image Recovery installs only drivers and hardware-enabling applications. Other applications included in the image continue to be available for installation through the Drivers and Applications Reinstall option in HP Recovery Manager.

For more information, see [Recovering using HP Recovery Manager on page 84](#).

- If you want to recover the computer's original factory partitioning and content, you can choose the System Recovery option from the HP Recovery media. For more information, see [Recovering using HP Recovery Manager on page 84](#).
- If you have replaced the hard drive, you can use the Factory Reset option of HP Recovery media to restore the factory image to the replacement drive. For more information, see [Recovering using HP Recovery Manager on page 84](#).
- If you wish to remove the recovery partition to reclaim hard drive space, HP Recovery Manager offers the Remove Recovery Partition option.

For more information, see [Removing the HP Recovery partition on page 86](#).

Using Windows Refresh for quick and easy recovery

When your computer is not working properly and you need to regain system stability, the Windows Refresh option allows you to start fresh and keep what is important to you.

 **IMPORTANT:** Refresh removes any traditional applications that were not originally installed on the system at the factory.

 **NOTE:** During Refresh, a list of removed traditional applications will be saved so that you have a quick way to see what you might need to reinstall. See Help and Support for instructions on reinstalling traditional applications. From the Start screen, type **h**, and then select **Help and Support**.

 **NOTE:** You may be prompted for your permission or password when using Refresh. See Windows Help and Support for more information. From the Start screen, type **h**, and then select **Help and Support**.

To start Refresh:

1. On the Start screen, point to the far-right upper or lower corner of the screen to display the charms.
2. Click **Settings**.
3. Click **Change PC settings** in the bottom-right corner of the screen, and then select **General** from the PC settings screen.
4. Under **Refresh your PC without affecting your files**, select **Get started**, and follow the on-screen instructions.

Remove everything and reinstall Windows

Sometimes you want to perform detailed reformatting of your computer, or you want to remove personal information before you give away or recycle your computer. The process described in this section provides a speedy, simple way to return the computer to its original state. This option removes all personal data, apps, and settings from your computer, and reinstalls Windows.



IMPORTANT: This option does not provide backups of your information. Before using this option, back up any personal information you wish to retain.

You can initiate this option by using the **F11** key or from the Start screen.

To use the **F11** key:

1. Press **F11** while the computer boots.
– or –
Press and hold **F11** as you press the power button.
2. Select **Troubleshoot** from the boot options menu.
3. Select **Reset your PC**, and follow the on-screen instructions.

To use the Start screen:

1. On the Start screen, point to the far-right upper or lower corner of the screen to display the charms.
2. Click **Settings**.
3. Click **Change PC settings** in the bottom-right corner of the screen, and then select **General** from the PC settings screen.
4. Under **Remove everything and reinstall Windows**, select **Get started**, and follow the on-screen instructions.

Recovering using HP Recovery Manager

HP Recovery Manager software allows you to recover the computer to its original factory state. Using the HP Recovery media you created, you can choose from one of the following recovery options:

- **System Recovery**—Reinstalls the original operating system, and then configures the settings for the programs that were installed at the factory.
- **Minimized Image Recovery**—Reinstalls the operating system and all hardware-related drivers and software, but not other software applications.
- **Factory Reset**—Restores the computer to the state its original factory state by deleting all information from the hard drive and re-creating the partitions. Then it reinstalls the operating system and the software that was installed at the factory.

The HP Recovery partition (select models only) allows Minimized Image Recovery.

What you need to know

- HP Recovery Manager recovers only software that was installed at the factory. For software not provided with this computer, you must either download the software from the manufacturer's website or reinstall the software from the media provided by the manufacturer.
- Recovery through HP Recovery Manager should be used as a final attempt to correct computer issues.
- HP Recovery media must be used if the computer hard drive fails.
- To use the Factory Reset or System Recovery options, you must use HP Recovery media.
- If the HP Recovery media do not work, you can obtain recovery media for your system from the HP website. For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html.



IMPORTANT: HP Recovery Manager does not automatically provide backups of your personal data. Before beginning recovery, back up any personal data you wish to retain.

Using the HP Recovery partition to recover a minimized image (select models only)

The HP Recovery partition (select models only) allows you to perform a minimized image recovery without the need for recovery discs or a recovery USB flash drive. This type of recovery can only be used if the hard drive is still working.

To start HP Recovery Manager from the HP Recovery partition:

1. Press **f11** while the computer boots.
– or –
Press and hold **f11** as you press the power button.
2. Select **Troubleshoot** from the boot options menu.
3. Select **HP Recovery Manager**, and follow the on-screen instructions.

Using HP Recovery media to recover

You can use HP Recovery media to recover the original system. This method can be used if your system does not have an HP Recovery partition or if the hard drive is not working properly.

1. If possible, back up all personal files.
2. Insert the first HP Recovery disc you created into the optical drive on your computer or into an optional external optical drive, and then restart the computer.

– or –

Insert the HP Recovery USB flash drive you created into a USB port on your computer, and then restart the computer.

 **NOTE:** If the computer does not automatically restart in HP Recovery Manager, change the computer boot order. See [Changing the computer boot order on page 86](#).

3. Follow the on-screen instructions.

Changing the computer boot order

If computer does not restart in HP Recovery Manager, you can change the computer boot order, which is the order of devices listed in BIOS where the computer looks for startup information. You can change the selection for an optical drive or a USB flash drive.

To change the boot order:

1. Insert the HP Recovery media you created.
2. Restart the computer.
3. Press and hold **esc** while the computer is restarting, and then press **f9** for boot options.
4. Select the optical drive or USB flash drive you want to boot from.
5. Follow the on-screen instructions.

Removing the HP Recovery partition

HP Recovery Manager software allows you to remove the HP Recovery partition to free up hard drive space.

 **IMPORTANT:** Removing the HP Recovery partition means you can no longer use Windows Refresh, the Windows Remove everything and reinstall Windows option, or the HP Recovery Manager option for minimized image recovery. Create HP Recovery media before removing the Recovery partition to ensure you have recovery options; see [Creating HP Recovery media on page 81](#).

Follow these steps to remove the HP Recovery partition:

1. From the Start screen, type `recovery`, and then select **HP Recovery Manager**.
2. Select **Remove Recovery Partition**, and follow the on-screen instructions to continue.

8 Power cord set requirements

The wide-range input feature of the computer permits it to operate from any line voltage from 100 to 120 volts AC, or from 220 to 240 volts AC.

The 3-conductor power cord set included with the computer meets the requirements for use in the country or region where the equipment is purchased.

Power cord sets for use in other countries and regions must meet the requirements of the country or region where the computer is used.

Requirements for all countries

The following requirements are applicable to all countries and regions:

- The length of the power cord set must be at least **1.0 m** (3.3 ft) and no more than **2.0 m** (6.5 ft).
- All power cord sets must be approved by an acceptable accredited agency responsible for evaluation in the country or region where the power cord set will be used.
- The power cord sets must have a minimum current capacity of 10 amps and a nominal voltage rating of 125 or 250 V AC, as required by the power system of each country or region.
- The appliance coupler must meet the mechanical configuration of an EN 60 320/IEC 320 Standard Sheet C13 connector for mating with the appliance inlet on the back of the computer.

Requirements for specific countries and regions

| Country/region | Accredited agency | Applicable note number |
|--------------------------------|-------------------|------------------------|
| Australia | EANSW | 1 |
| Austria | OVE | 1 |
| Belgium | CEBC | 1 |
| Canada | CSA | 2 |
| Denmark | DEMKO | 1 |
| Finland | FIMKO | 1 |
| France | UTE | 1 |
| Germany | VDE | 1 |
| Italy | IMQ | 1 |
| Japan | METI | 3 |
| The Netherlands | KEMA | 1 |
| Norway | NEMKO | 1 |
| The People's Republic of China | COC | 5 |
| South Korea | EK | 4 |
| Sweden | SEMKO | 1 |
| Switzerland | SEV | 1 |
| Taiwan | BSMI | 4 |
| The United Kingdom | BSI | 1 |
| The United States | UL | 2 |

1. The flexible cord must be Type HO5VV-F, 3-conductor, 1.0-mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.
2. The flexible cord must be Type SPT-3 or equivalent, No. 18 AWG, 3-conductor. The wall plug must be a two-pole grounding type with a NEMA 5-15P (15 A, 125 V) or NEMA 6-15P (15 A, 250 V) configuration.
3. The appliance coupler, flexible cord, and wall plug must bear a "T" mark and registration number in accordance with the Japanese Dentori Law. The flexible cord must be Type VCT or VCTF, 3-conductor, 1.00-mm² conductor size. The wall plug must be a two-pole grounding type with a Japanese Industrial Standard C8303 (7 A, 125 V) configuration.
4. The flexible cord must be Type RVV, 3-conductor, 0.75-mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.
5. The flexible cord must be Type VCTF, 3-conductor, 0.75-mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.

9 Recycling

When a non-rechargeable or rechargeable battery has reached the end of its useful life, do not dispose of the battery in general household waste. Follow the local laws and regulations in your area for battery disposal.

HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, see the HP Web site at <http://www.hp.com/recycle>.

Index

- A**
 - AC adapter light 11
 - AC adapter, spare part number 22
 - action keys 6
 - antenna
 - components 5
 - locations 5
 - removal 72
 - spare part number 16, 22, 72
 - Antenna Kit, spare part number 16, 22, 72
 - audio, product description 2
 - audio-in jack 11
 - audio-out jack 11
- B**
 - battery
 - removal 35
 - spare part number 19, 22, 35
 - bottom components 12
 - bottom cover
 - removal 33
 - spare part number 19, 22, 33
 - button components 5
 - buttons
 - power 5
 - TouchPad 8
 - TouchPad on/off 8
- C**
 - cables, service considerations 27
 - caps lock light 8
 - chipset, product description 1
 - components
 - antennas 5
 - bottom 12
 - buttons 5
 - display 4
 - keys 6
 - left-side 9
 - lights 7
 - right-side 10
 - speakers 5
 - TouchPad 8
 - WLAN antenna 5
 - computer
 - major components 15
 - part number 32
 - specifications 77
 - connectors, service considerations 27
- D**
 - Digital Media Card Reader 10
 - display
 - components 4
 - specifications 78
 - subcomponents 19
 - display assembly, removal 45
 - display bezel
 - removal 47
 - spare part number 19, 22, 47
 - display enclosure
 - illustrated 20
 - spare part number 20, 22
 - display panel
 - product description 1
 - removal 48
 - spare part number 19, 24, 49
 - display panel cable
 - removal 49
 - spare part number 19, 22, 50
 - display panel touch cable, spare part number 20, 26
 - display switch 4
 - DisplayPort 9
 - drives, preventing damage 28
- E**
 - electrostatic discharge 28
 - equipment guidelines 31
 - esc key 6
 - Ethernet, product description 2
- F**
 - fan
 - removal 39
 - spare part number 18, 23, 39
 - fn key 6
 - front speakers
 - removal 54
 - spare part number 18, 24, 54
- G**
 - graphics, product description 1
 - grounding guidelines 28
 - guidelines
 - equipment 31
 - grounding 28
 - packaging 30
 - transporting 30
 - workstation 30
- H**
 - hard drive
 - light 10
 - precautions 28
 - product description 2
 - removal 43
 - spare part numbers 18, 21, 22, 25, 43
 - specifications 79
 - hard drive bracket
 - illustrated 21
 - removal 44

- hard drive connector cable
 - illustrated 21
 - removal 44
- Hard Drive Hardware Kit
 - contents 21
 - spare part number 19, 21, 23
- hard drive space cover, spare part number 21, 26
- HDMI port 9
- HDMI-to-VGA adapter, spare part number 21, 25
- headphone jack 11
- heat sink
 - removal 65
 - spare part number 18, 23, 65
- hinge cover
 - illustrated 20
 - removal 48
- J**
- jacks
 - audio-in 11
 - audio-out 11
 - headphone 11
 - microphone 11
 - network 9
 - RJ-45 (network) 9
- K**
- key components 6
- keyboard
 - product description 3
 - removal 69
 - spare part numbers 16, 23, 24, 69
- keyboard backlight light 7
- keyboard shield, removal 69
- keys
 - action 6
 - esc 6
 - fn 6
 - Windows application 6
 - Windows logo key 6
- L**
- left-side components 9
- light components 7
- lights
 - AC adapter 11
 - caps lock 8
 - hard drive 10
- keyboard backlight 7
- mute 7
- power 7, 10
- RJ-45 (network) jack 9
- TouchPad 8
- webcam 4
- wireless 7
- M**
- mass storage device
 - illustrated 21
 - precautions 28
 - spare part numbers 21
- memory module
 - product description 1
 - removal 60
 - spare part numbers 18, 22, 60
- memory shield
 - removal 60
 - spare part number 18, 25, 60
- microphone
 - location 4
 - product description 2
- microphone jack 11
- model description 33
- model name 1
- multimedia board
 - removal 59
 - spare part number 18, 25, 59
- mute light 7
- N**
- network jack 9
- O**
- operating system, product description 3
- P**
- packaging guidelines 30
- plastic parts, service considerations 27
- pointing device, product description 3
- ports
 - DisplayPort 9
 - HDMI 9
 - product description 3
 - USB 2.0 11
 - USB 3.0 9
- power button 5
- power button board
 - removal 41
 - spare part number 16, 25, 41
- power connector 11
- power connector cable
 - removal 57
 - spare part number 19, 23, 57
- power cord
 - set requirements 87
 - spare part numbers 21, 22
- power light 7, 10
- power requirements, product description 3
- processor, product description 1
- product description
 - audio 2
 - chipset 1
 - display panel 1
 - Ethernet 2
 - external media cards 3
 - graphics 1
 - hard drive 2
 - keyboard 3
 - memory module 1
 - microphone 2
 - operating system 3
 - pointing device 3
 - ports 3
 - power requirements 3
 - processors 1
 - product name 1
 - security 3
 - serviceability 3
 - solid-state drive 2
 - video 2
 - wireless 2
- product name 1, 32
- product number 32
- protective cover, spare part number 21, 23
- R**
- rear speakers
 - removal 71
 - spare part number 16, 25, 71
- removal/replacement
 - preliminaries 27
 - procedures 32
- right-side components 10

- RJ-45 (network) jack 9
- RJ-45 (network) jack light 9
- RJ-45 jack cover
 - removal 67
 - spare part number 18, 25, 67
- RTC battery
 - removal 36
 - spare part number 18, 22, 36

S

- Screw Kit, spare part number 22, 24
- security cable slot, location 11
- security, product description 3
- serial number 32
- service considerations
 - cables 27
 - connectors 27
 - plastic parts 27
- service tag 14, 32
- serviceability, product description 3
- solid-state drive
 - product description 2
 - removal 40
 - spare part numbers 18, 21, 24, 40
- speaker components 5
- speakers
 - location 6, 12
 - removal 54, 71
 - spare part numbers 16, 18, 24, 25, 54, 71
- specifications
 - computer 77
 - display 78
 - hard drive 79
- system board
 - removal 62
 - spare part numbers 17, 24, 25, 26, 62

T

- tools required 27
- top cover, spare part numbers 16, 25
- tote bag, spare part number 21, 22

- TouchPad
 - removal 52
 - spare part number 16, 25, 52
- TouchPad button 8
- TouchPad components 8
- TouchPad LED board
 - removal 56
 - spare part number 16, 25, 56
- TouchPad light 8
- TouchPad on/off button 8
- TouchPad zone 8
- transporting guidelines 30

U

- USB 2.0 port 11
- USB 3.0 port 9

V

- vent 12
- video, product description 2

W

- warranty period 33
- webcam 4
- webcam light 4
- webcam/microphone module
 - removal 50
 - spare part number 19, 25, 51
- Windows application key 6
- Windows logo key 6
- wireless light 7
- wireless, product description 2
- WLAN antenna
 - components 5
 - locations 5
 - removal 72
 - spare part number 16, 22, 72
- WLAN module
 - removal 37
 - spare part number 18, 22, 37
- workstation guidelines 30

