



HP ENVY Notebook PC (model numbers 15-as000 through 15-as099)

Maintenance and Service Guide

**IMPORTANT! This document is intended for
HP authorized service providers only.**

© Copyright 2016 HP Development Company,
L.P.

Product notice

Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. Intel and Core are U.S. registered trademarks of Intel Corporation. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. SD Logo is a trademark of its proprietor.

This guide describes features that are common to most models. Some features may not be available on your computer.

Not all features are available in all editions of Windows 10. This computer may require upgraded and/or separately purchased hardware, drivers and/or software to take full advantage of Windows 10 functionality. See <http://www.microsoft.com> for details.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: April 2016

Document Part Number: 855524-001

Safety warning notice

 **WARNING!** To reduce the possibility of heat-related injuries or of overheating the device, do not place the device directly on your lap or obstruct the device air vents. Use the device only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or rugs or clothing, to block airflow. Also, do not allow the AC adapter to contact the skin or a soft surface, such as pillows or rugs or clothing, during operation. The device and the AC adapter comply with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950).

Table of contents

1 Product description	1
2 External component identification	4
Locating hardware	4
Locating software	4
Display	5
Button, speakers, and vent	7
Keys	8
Lights	9
TouchPad	10
Left side	11
Right side	12
Bottom	13
3 Illustrated parts catalog	14
Locating the product number, warranty information, model number, and serial number	14
Computer major components	15
Display components	18
Miscellaneous parts	19
4 Removal and replacement procedures preliminary requirements	21
Tools required	21
Service considerations	21
Plastic parts	21
Cables and connectors	22
Drive handling	22
Grounding guidelines	23
Electrostatic discharge damage	23
Packaging and transporting guidelines	24
Workstation guidelines	24
Equipment guidelines	25
5 Removal and replacement procedures	26
Component replacement procedures	26
Bottom cover	26
Battery	29

Hard drive	30
Memory module	31
Solid-state drive	33
RTC battery	34
WLAN module	35
Fan	37
TouchPad cable	38
TouchPad	39
Power connector cable	40
USB board cables	42
USB board	43
System board	45
Heat sink	48
Speakers	49
Display assembly	50
6 Using Setup Utility (BIOS)	61
Starting Setup Utility (BIOS)	61
Updating Setup Utility (BIOS)	61
Determining the BIOS version	61
Downloading a BIOS update	62
7 Using HP PC Hardware Diagnostics (UEFI)	63
Downloading HP PC Hardware Diagnostics (UEFI) to a USB device	63
8 Specifications	65
Computer specifications	65
9 Backing up, restoring, and recovering	67
Creating recovery media and backups	67
Creating HP Recovery media (select products only)	67
Using Windows tools	68
Restore and recovery	69
Recovering using HP Recovery Manager	69
What you need to know before you get started	69
Using the HP Recovery partition (select products only)	70
Using HP Recovery media to recover	70
Changing the computer boot order	71
Removing the HP Recovery partition (select products only)	72

10 Power cord set requirements	73
Requirements for all countries	73
Requirements for specific countries and regions	73
11 Recycling	75
Index	76

1 Product description

Category	Description
Product Name	HP ENVY Notebook PC (Model numbers used 15-as000 through 15-as099)
Processor	<ul style="list-style-type: none">Intel® Core™ i7-6500U 2.50-GHz (SC turbo up to 3.10-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W)Intel Core i5-6260U 1.80-GHz (SC turbo up to 2.90-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W)Intel Core i5-6200U 2.30-GHz (SC turbo up to 2.80-GHz) processor (1600-MHz FSB, 3.0-MB L3 cache, dual core, 15-W)
Chipset	Integrated soldered-on-circuit (SoC)
Graphics	Internal Graphics: Intel Iris™ Graphics 540 on computer models equipped with an Intel Core i7-6500U processor Intel HD Graphics 520 on computer models equipped with an Intel Core i5-6260U, Intel Core i5-6200U, or Intel Core i3-6100U processor Support for HD decode, DX12, and high-definition multimedia interface (HDMI) Support for Optimus Support for GPU performance scaling (GPS)
Panel	15.6-in, RGBW, ultrahigh-definition (UHD), white light-emitting diode (WLED), AntiGlare (3840×2160), slim-flat (3.2-mm), UWVA, eDP+PSR, 16:9 ultra wide aspect ratio, typical brightness: 300 nits; TouchScreen, MultiTouch-enabled 15.6-in, full high-definition (FHD), WLED, BrightView (1920×1080), slim-flat (3.2-mm), UWVA, eDP, 16:9 ultra wide aspect ratio, typical brightness: 220 nits; TouchScreen and non-TouchScreen, MultiTouch-enabled
Memory	Two memory slots, non-accessible Support for DDR4-2133 Dual Channel Support for up to 16-GB maximum on-board system memory <ul style="list-style-type: none">16384 MB (8192 MB × 2)12288 MB (8192 MB + 4096 MB)8192 MB (8192 MB × 1)8192 MB (4096 MB × 2)6144 MB (4096 MB + 2048 MB)4096 MB (4096 MB × 2)
Hard drive	Support for all 7.2-mm and 7.0-mm, SATA, 2.5-in hard drives Support for 1-TB, 5400-rpm, 7.2-mm hard drive and 500-GB, 7200-rpm, 7.2-mm hard drive Support for Accelerometer hard drive protection Support for hard drive and solid-state drive in the following combinations: <ul style="list-style-type: none">1-TB, 5400-rpm, 7.2-mm hard drive and 512-MB, M.2, PCIe, NVMe solid-state drive supporting TLC

Category	Description
Hard drive (continued)	<ul style="list-style-type: none"> • 1-TB, 5400-rpm, 7.2-mm hard drive and 256-MB, M.2, PCIe, NVMe solid-state drive supporting TLC • 1-TB, 5400-rpm, 7.2-mm hard drive and 256-MB, M.2, SATA solid-state drive supporting TLC
Solid-state drive	<p>Support for next generation form factor (NGFF), M.2 solid-state drive, default with SATA/PCIe co-layout port (assigned port 0 for solid-state drive to support hard drive/solid-state drive combination)</p>
	<p>Support for the following solid-state drives:</p>
	<ul style="list-style-type: none"> • 512-MB, M.2, PCIe, NVMe solid-state drive supporting triple-level cell (TLC) • 256-MB, M.2, PCIe, NVMe solid-state drive supporting TLC • 256-MB, M.2, SATA solid-state drive supporting TLC • 128-MB, M.2, solid-state drive
Audio and video	<p>HP TrueVision HD webcam with indicator light, 2 IR indicator lights, 720p by 30 frames per second, HD BSI sensor + IR sensor, f2.0</p>
	<p>HP Wide Vision HD webcam with indicator light, 720p by 30 frames per second, BSI sensor, f2.0, 88° wide field of vision</p>
	<p>Support for B & O Play</p>
	<p>Dual speakers</p>
	<p>HD Audio (Conexant CX7700)</p>
	<p>Integrated dual-array microphones with appropriate beam-forming, echo-cancellation, and noise suppression software</p>
	<p>Support for Smart Amp</p>
	<p>Support for voice recognition</p>
Ethernet	<p>Integrated 10/100/1000 network interface card (NIC)</p>
Sensors	<p>Accelerometer</p>
Wireless	<p>Integrated wireless local area network (WLAN) options by way of wireless module</p>
	<p>Two built-in WLAN antennas (M.2 / PCIe)</p>
	<p>Support for the Intel Dual Band Wireless-AC 7265 802.11 ac 2×2 WiFi + Bluetooth 4.2 Combo Adapter WLAN module</p>
	<p>Compatible with Miracast-certified devices</p>
	<p>Support for Intel WiDi</p>
	<p>Compatible with Miracast-certified devices</p>
External media cards	<p>Micro-Secure Digital (SD™) media reader slot</p>
Ports	<ul style="list-style-type: none"> • Audio-in (mono microphone)/audio-out (stereo headphone) combination • AC Smart Pin adapter plug • HDMI v1.4 supporting up to 1920×1080 @ 60 Hz • USB 3.0 ports (3) • USB 3.0 port Type-C
Keyboard/pointing devices	<p>Full-sized, backlit, island-style, backlit keyboard with numeric keypad</p>
	<p>TouchPad requirements:</p>

Category	Description
Keyboard/pointing devices <i>(continued)</i>	<ul style="list-style-type: none"> ● ClickPad with image sensor ● Multitouch gestures enabled ● Support for Windows modern trackpad gestures ● Taps enabled as default
Power requirements	<p>Support for a 3-cell, 52-WHr, 4.56-AHr, Li-ion battery</p> <p>Support for the following AC adapters</p> <ul style="list-style-type: none"> ● 65-W HP Smart AC adapter (non-PFC, EM, 4.5-mm) ● 45-W HP Smart AC adapter (non-PFC, RC, 4.5-mm) ● 45-W HP Smart AC adapter (non-PFC, with mount, 4.5-mm)
Security	<p>Trusted platform module (TPM) 2.0</p> <p>Security cable lock</p>
Operating system	<p>Preinstalled:</p> <ul style="list-style-type: none"> ● Windows 10 ● Windows 10 Professional ● Windows 7 Professional 64- and 32-bit <p>For Developed Market (ML): Windows 10 Home ML and Windows 10 Home High End ML</p> <p>For Emerging Market (EM/SL):</p> <ul style="list-style-type: none"> ● Windows 10 Home EM/SL ● Windows 10 Home High End EM/SL/China ● CPPP Windows 10 Home China Language Edition ● SEAP Windows 10 Home Single Language Edition ● SEAP Windows 10 Home High End
Serviceability	End user replaceable parts: AC adapter

2 External component identification

Locating hardware

To find out what hardware is installed on the computer:

- ▲ Type `device manager` in the taskbar search box, and then select the **Device Manager** app.

A list displays all the devices installed on the computer.

For information about system hardware components and the system BIOS version number, press **fn+esc** (select products only).

Locating software

To find out what software is installed on the computer:

- ▲ Select the **Start** button, and then select **All apps**.


– or –

Right-click the **Start** button, and then select **Programs and Features**.

Display



NOTE: Refer to the illustration that most closely matches the computer. [cad edit-need different image]




Item	Component	Description
(1)	WLAN antennas (2)*	Send and receive wireless signals to communicate with WLANs.
(2)	Internal microphones	Record sound.
(3)	Camera light	On: The camera is in use.
(4)	Camera	Allows you to video chat, record video, and record still images. To use the camera: ▲ Type camera in the taskbar search box, and then select Camera .
(5)	3D camera light (select products only)	On: The 3D camera is in use.
(6)	3D camera (select products only)	Allows you to video chat and scan or capture 3D images. 3D apps for gaming, security, and immersive collaboration are available to maximize the 3D camera experience. To use the 3D camera: ▲ On select products, type Intel RealSense in the taskbar search box to explore additional features, demos, and apps.

*The antennas are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions.

For wireless regulatory notices, see the section of the *Regulatory, Safety, and Environmental Notices* that applies to your country or region.

To access this guide:

- ▲ Select the **Start** button, select **All apps**, select **HP Help and Support**, and then select **HP Documentation**.



Item	Component	Description
(1)	WLAN antennas (2)*	Send and receive wireless signals to communicate with WLANs.
(2)	Internal microphones (2)	Record sound.
(3)	Camera light	On: The camera is in use.
(4)	Camera	Allows you to video chat, record video, and record still images. To use the camera: ▲ Type camera in the taskbar search box, and then select Camera .


*The antennas are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions.

For wireless regulatory notices, see the section of the *Regulatory, Safety, and Environmental Notices* that applies to your country or region.

To access this guide:

- ▲ Select the **Start** button, select **All apps**, select **HP Help and Support**, and then select **HP Documentation**.


Button, speakers, and vent



Item	Component	Description
(1)	Power button	<ul style="list-style-type: none">When the computer is off, press the button to turn on the computer.When the computer is on, press the button briefly to initiate Sleep.When the computer is in the Sleep state, press the button briefly to exit Sleep.When the computer is in Hibernation, press the button briefly to exit Hibernation. <p>CAUTION: Pressing and holding down the power button results in the loss of unsaved information.</p> <p>If the computer has stopped responding and shutdown procedures are ineffective, press and hold the power button down for at least 5 seconds to turn off the computer.</p> <p>To learn more about your power settings, see your power options.</p> <p>▲ Type power in the taskbar search box, and then select Power and sleep settings. – or – Right-click the Start button, and then select Power Options.</p>
(2)	Speakers	Product sound.
(3)	Vent	Enables airflow to cool internal components.


Item	Component	Description
		NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.

Keys




Item	Component	Description
(1)	esc key	Displays system information when pressed in combination with the fn key.
(2)	fn key	Displays system information when pressed in combination with the esc key.
(3)	Windows key	Opens the Start menu. NOTE: Pressing the Windows key again will close the Start menu.
(4)	Action keys	Execute frequently used system functions. NOTE: On select products, the f5 action key turns the keyboard backlight feature off or on.
(5)	num lock key (select products only)	Alternates between the navigational and numeric functions on the integrated numeric keypad.
(6)	Integrated numeric keypad	When num lock is on, the keypad can be used like an external numeric keypad.

Lights




Item	Component	Description
(1)	Power light	<ul style="list-style-type: none">On: The computer is on.Blinking: The computer is in the Sleep state, a power-saving state. The computer shuts off power to the display and other unneeded components.Off: The computer is off or in Hibernation. Hibernation is a power-saving state that uses the least amount of power.
(2)	Mute light	<ul style="list-style-type: none">Amber: Computer sound is off.Off: Computer sound is on.
(3)	Caps lock light	On: Caps lock is on, which switches the key input to all capital letters.

TouchPad




Item	Component	Description
(1)	TouchPad zone	Reads your finger gestures to move the pointer or activate items on the screen.
(2)	Left TouchPad button	Functions like the left button on an external mouse.
(3)	Right TouchPad button	Functions like the right button on an external mouse.

Left side



Item	Component	Description
(1)	Security cable slot	Attaches an optional security cable to the computer. NOTE: The security cable is designed to act as a deterrent, but it may not prevent the computer from being mishandled or stolen.
(2)	USB 3.0 ports (2)	Connects optional USB devices, such as a keyboard, mouse, external drive, printer, scanner, or USB hub.
(3)	Drive light	<ul style="list-style-type: none">Blinking white: The hard drive is being accessed.Amber: HP 3D DriveGuard has temporarily parked the hard drive.


Right side



Item	Component	Description
(1)	Audio-out (headphone)/Audio-in (microphone) combo jack	Connects optional powered stereo speakers, headphones, earbuds, a headset, or a television audio cable. Also connects an optional headset microphone. This jack does not support optional standalone microphones. WARNING! To reduce the risk of personal injury, adjust the volume before putting on headphones, earbuds, or a headset. For additional safety information, refer to the <i>Regulatory, Safety, and Environmental Notices</i> . To access this guide: <ul style="list-style-type: none">▲ Select the Start button, select All apps, select HP Help and Support, and then select HP Documentation. NOTE: When a device is connected to the jack, the computer speakers are disabled.
(2)	USB Type-C port	Connects an optional USB device with a Type-C connector.
(3)	Memory card reader	Reads optional memory cards that enable you to store, manage, share, or access information. To insert a card: <ol style="list-style-type: none">1. Hold the card label-side up, with connectors facing the computer.2. Insert the card into the memory card reader, and then press in on the card until it is firmly seated. To remove a card: <ul style="list-style-type: none">▲ Press in on the card, and then remove it from the memory card reader.
(4)	HDMI port	Connects an optional video or audio device, such as a high-definition television, any compatible digital or audio component, or a high-speed HDMI device.
(5)	USB 3.0 charging (powered) port	Connects an optional USB device, such as a keyboard, mouse, external drive, printer, scanner, or USB hub. Standard USB ports will not charge all USB devices or will charge using a low current. Some USB devices require power and require you to use a powered port. NOTE: USB charging ports can also charge select models of cell phones and MP3 players, even when the computer is off.
(6)	AC adapter and battery light	<ul style="list-style-type: none">● White: The AC adapter is connected and the battery is fully charged.

Item	Component	Description
(6)	AC adapter and battery light (<i>continued</i>)	<ul style="list-style-type: none"> • Blinking white: The AC adapter is disconnected and the battery has reached a low battery level. • Amber: The AC adapter is connected and the battery is charging. • Off: The battery is not charging.
(7)	Power connector	Connects an AC adapter.

Bottom



Component	Description
Vent	<p>Enables airflow to cool internal components.</p> <p>NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.</p>


3 Illustrated parts catalog




NOTE: HP continually improves and changes product parts. For complete and current information on supported parts for your computer, go to <http://partsurfer.hp.com>, select your country or region, and then follow the on-screen instructions.

Locating the product number, warranty information, model number, and serial number

The product number **(1)**, warranty information **(2)**, model number **(3)**, and serial number **(4)** are located on the bottom of the computer. This information may be needed when travelling internationally or when contacting support.



Computer major components




Item	Component	Spare part number
(1)	Display assembly: The TouchScreen display assembly is spared as an entire assembly. Spare part number information for TouchScreen display assemblies is listed immediately below. The non-TouchScreen display assembly is spared at the subcomponent level only. For more non-TouchScreen display assembly spare part information, see Display components on page 18 .	
	15.6-in, RGBW, UHD, WLED, AntiGlare (3840×2160), uslim-flat (2.68-mm), UWVA, eDP+PSR TouchScreen display assembly equipped with HDC and infrared webcam	858712-001
	15.6-in, RGBW, UHD, WLED, AntiGlare (3840×2160), uslim-flat (2.68-mm), UWVA, eDP+PSR TouchScreen display assembly equipped with HDC and non-infrared webcam	857440-001

Item	Component	Spare part number
	15.6-in, FHD, WLED, BrightView (1920×1080), slim-flat (3.0-mm), UWVA, eDP TouchScreen display assembly equipped with HDC and infrared webcam	858711-001
	15.6-in, FHD, WLED, BrightView (1920×1080), slim-flat (3.0-mm), UWVA, eDP TouchScreen display assembly equipped with HDC and non-infrared webcam	857439-001
(2)	Keyboard/top cover with backlight and pointing stick (includes backlight cable, keyboard cable, and pointing stick cable):	
	For use in Belgium	857799-A41
	For use in Bulgaria	857799-261
	For use in Canada	857799-DB1
	For use in the Czech Republic and Slovakia	857799-FL1
	For use in Denmark, Finland, and Norway	857799-DH1
	For use in France	857799-051
	For use in Germany	857799-041
	For use in Greece	857799-151
	For use in Hungary	857799-211
	For use in Israel	857799-BB1
	For use in Italy	857799-061
	For use in Japan	857799-291
	For use in Latin America	857799-161
	For use in the Netherlands	857799-B31
	For use in Portugal	857799-131
	For use in Romania	857799-271
	For use in Russia	857799-251
	For use in Saudi Arabia	857799-171
	For use in Slovenia	857799-BA1
	For use in South Korea	857799-AD1
	For use in Spain	857799-071
	For use in Switzerland	857799-BG1
	For use in Taiwan	857799-AB1
	For use in Thailand	857799-281
	For use in Turkey	857799-141
	For use in the United Kingdom	857799-031
	For use in the United States	857799-001
(3)	TouchPad	857801-001
	NOTE: The TouchPad spare part kit does not include the TouchPad bracket or TouchPad cable. The TouchPad bracket is available using spare part number 857796-001. The TouchPad cable is available using spare part number 857807-001.	

Item	Component	Spare part number
(4)	TouchPad bracket	857796-001
(5)	TouchPad cable (includes double-sided adhesive)	857807-001
(6)	Power connector cable (includes bracket, item 7)	857438-001
(7)	Power connector cable bracket (included with power connector cable spare part kit, spare part number 857438-001)	
(8)	Speakers (includes left and right speakers and cables)	857804-001
(9)	Solid-state drive:	
	512-GB, M2, PCIe, NVMe solid-state drive supporting TLC	857487-001
	256-GB, M2, SATA-3 solid-state drive supporting TLC	857485-001
	256-GB, M2, PCIe, NVMe solid-state drive supporting TLC	857486-001
	128-GB, M2, SATA-3 solid-state drive	857484-001
	I/O Bracket Kit , includes:	857795-001
(10)	System board short support bridge	
(11)	System board long support bridge	
(12)	Power connector cable bracket	
(13)	USB board bracket	
(14)	System board (includes graphic subsystem with UMA memory and replacement thermal material):	
	Equipped with an Intel Core i7-6500U 2.50-GHz (SC turbo up to 3.10-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W) and the Windows 10 operating system	857242-601
	Equipped with an Intel Core i7-6500U 2.50-GHz (SC turbo up to 3.10-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W) and a non-Windows operating system	857242-001
	Equipped with an Intel Core i5-6260U 1.80-GHz (SC turbo up to 2.90-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W) and the Windows 10 operating system	857241-601
	Equipped with an Intel Core i5-6260U 1.80-GHz (SC turbo up to 2.90-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W) and a non-Windows operating system	857241-001
	Equipped with an Intel Core i5-6200U 2.30-GHz (SC turbo up to 2.80-GHz) processor (1600-MHz FSB, 3.0-MB L3 cache, dual core, 15-W) and the Windows 10 operating system	857243-601
	Equipped with an Intel Core i5-6200U 2.30-GHz (SC turbo up to 2.80-GHz) processor (1600-MHz FSB, 3.0-MB L3 cache, dual core, 15-W) and a non-Windows operating system	857243-001
(15)	USB board (includes cables and 2 USB ports)	857794-001
	NOTE: The USB board cables are also available using spare part numbers 858701-001 and 857802-001.	
(16)	USB board cable (190mm)	858701-001
(17)	USB board cable (173mm)	857802-001
(18)	RTC battery (includes cable and double-sided adhesive)	857798-001
(19)	Memory modules (2):	
	8-GB (2133, 1.2-V, DDR4)	820448-858
	4-GB (2133, 1.2-V, DDR4)	820447-858

Item	Component	Spare part number
	2-GB (2133, 1.2-V, DDR4)	851227-857
(20)	Intel Dual Band Wireless-AC 7265 802.11 ac 2×2 WiFi + Bluetooth 4.2 Combo Adapter	793747-857
(21)	Heat sink (includes replacement thermal material)	857245-001
(22)	Fan (includes cable)	857805-001
(23)	Battery (3-cell, 52-WHr, 4.56-AHr, Li-ion; includes cable)	849313-856
(24)	Hard drive:	
	1-TB, 5400-rpm, SATA, 7.2-mm	762888-856
	500-GB, 5400-rpm, SATA, 7.0-mm	683839-856
(25)	Hard drive cable (includes double-sided adhesive)	857806-001
(26)	Hard drive rubber bracket	857797-001
(27)	Bottom cover (includes front rubber foot strip, shielding and vents)	857800-001
	Rubber Kit (not illustrated; includes bottom cover rubber foot strip)	858700-001

Display components



Item	Component	Spare part number
(1)	Display bezel	857813-001
(2)	Display panel:	
	15.6-in, RGBW, UHD, WLED, AntiGlare (3840×2160), uslim-flat (2.68-mm), UWVA, eDP+PSR display panel	857483-001
	15.6-in, FHD, WLED, BrightView (1920×1080), slim-flat (3.0-mm), UWVA, eDP display panel	857482-001
(3)	Webcam/microphone module (includes double-sided adhesive)	857441-001
(4)	Display hinge covers (2)	857803-001
(5)	Webcam/microphone module cable (includes double-sided adhesive)	857810-001
(6)	Display panel cable:	
	For use only on computer models equipped with a UHD display panel	857809-001
	For use only on computer models equipped with an FHD display panel	857808-001
(7)	Antenna Kit (includes antenna auxiliary and main cables and transceivers)	857817-001
(8)	Display hinges (2)	857815-001
(9)	Back cover	857812-001
	Display Bracket Kit (not illustrated)	857816-001

Miscellaneous parts

Component	Spare part number
AC adapter:	
65-W HP Smart AC adapter (non-PFC, EM, 4.5-mm)	714657-001
45-W HP Smart AC adapter (non-PFC, RC, 4.5-mm)	741553-850
45-W HP Smart AC adapter (non-PFC, with mount, 4.5-mm)	854116-850
Adapter:	
HP duck head adapter for use in South Korea	854703-001
HP duck head adapter for use in the United States	854702-001
HP HDMI-to-VGA adapter	701943-001
HP RJ45-to-USB adapter dongle	539614-001
HP USB-Type C-to-USB 3.0 adapter	814618-001
HP USB-to-Gigabit RJ45 adapter	829941-001
HP external DVD±RW DL SuperMulti Drive	747080-001
Power cord (C5 receptacle, 1.0-m (3.2-ft), 3-wire conductor):	
For use in Australia	213356-013
For use in Denmark	213353-013

Component	Spare part number
For use in Europe	213350-014
For use in India	404827-003
For use in Israel	398063-008
For use in Italy	213352-013
For use in Japan	349756-006
For use in North America	213349-015
For use in the People's Republic of China	286497-008
For use in South Africa	361240-007
For use in Switzerland	213354-013
For use in Taiwan	393313-007
For use in Thailand	285096-012
For use in the United Kingdom and Singapore	213351-013
Screw Kit	857820-001

4 Removal and replacement procedures preliminary requirements

Tools required

You will need the following tools to complete the removal and replacement procedures:

- Case utility tool or similar plastic, flat-edged tool
- Flat-bladed screwdriver
- Magnetic screwdriver
- Phillips P00, P0, and P1 screwdrivers
- Torx T4 screwdriver

Service considerations

The following sections include some of the considerations that you must keep in mind during disassembly and assembly procedures.



NOTE: As you remove each subassembly from the computer, place the subassembly (and all accompanying screws) away from the work area to prevent damage.

Plastic parts



CAUTION: Using excessive force during disassembly and reassembly can damage plastic parts. Use care when handling the plastic parts. Apply pressure only at the points designated in the maintenance instructions.

Cables and connectors

 **CAUTION:** When servicing the computer, be sure that cables are placed in their proper locations during the reassembly process. Improper cable placement can damage the computer.

Cables must be handled with extreme care to avoid damage. Apply only the tension required to unseat or seat the cables during removal and insertion. Handle cables by the connector whenever possible. In all cases, avoid bending, twisting, or tearing cables. Be sure that cables are routed in such a way that they cannot be caught or snagged by parts being removed or replaced. Handle flex cables with extreme care; these cables tear easily.

Drive handling

 **CAUTION:** Drives are fragile components that must be handled with care. To prevent damage to the computer, damage to a drive, or loss of information, observe these precautions:

Before removing or inserting a hard drive, shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.

Before handling a drive, be sure that you are discharged of static electricity. While handling a drive, avoid touching the connector.

Before removing a diskette drive or optical drive, be sure that a diskette or disc is not in the drive and be sure that the optical drive tray is closed.

Handle drives on surfaces covered with at least one inch of shock-proof foam.

Avoid dropping drives from any height onto any surface.

Avoid exposing an internal hard drive to products that have magnetic fields, such as monitors or speakers.

Avoid exposing an internal hard drive to products that have magnetic fields, such as monitors or speakers.

Avoid exposing a drive to temperature extremes or liquids.

If a drive must be mailed, place the drive in a bubble pack mailer or other suitable form of protective packaging and label the package "FRAGILE."

Grounding guidelines

Electrostatic discharge damage

Electronic components are sensitive to electrostatic discharge (ESD). Circuitry design and structure determine the degree of sensitivity. Networks built into many integrated circuits provide some protection, but in many cases, ESD contains enough power to alter device parameters or melt silicon junctions.

A discharge of static electricity from a finger or other conductor can destroy static-sensitive devices or microcircuitry. Even if the spark is neither felt nor heard, damage may have occurred.

An electronic device exposed to ESD may not be affected at all and can work perfectly throughout a normal cycle. Or the device may function normally for a while, then degrade in the internal layers, reducing its life expectancy.

⚠ CAUTION: To prevent damage to the computer when you are removing or installing internal components, observe these precautions:

Keep components in their electrostatic-safe containers until you are ready to install them.

Before touching an electronic component, discharge static electricity by using the guidelines described in this section.

Avoid touching pins, leads, and circuitry. Handle electronic components as little as possible.

If you remove a component, place it in an electrostatic-safe container.

The following table shows how humidity affects the electrostatic voltage levels generated by different activities.

⚠ CAUTION: A product can be degraded by as little as 700 V.

Typical electrostatic voltage levels

Event	10%	40%	55%
Walking across carpet	35,000 V	15,000 V	7,500 V
Walking across vinyl floor	12,000 V	5,000 V	3,000 V
Motions of bench worker	6,000 V	800 V	400 V
Removing DIPS from plastic tube	2,000 V	700 V	400 V
Removing DIPS from vinyl tray	11,500 V	4,000 V	2,000 V
Removing DIPS from Styrofoam	14,500 V	5,000 V	3,500 V
Removing bubble pack from PCB	26,500 V	20,000 V	7,000 V
Packing PCBs in foam-lined box	21,000 V	11,000 V	5,000 V

Packaging and transporting guidelines

Follow these grounding guidelines when packaging and transporting equipment:

- To avoid hand contact, transport products in static-safe tubes, bags, or boxes.
- Protect ESD-sensitive parts and assemblies with conductive or approved containers or packaging.
- Keep ESD-sensitive parts in their containers until the parts arrive at static-free workstations.
- Place items on a grounded surface before removing items from their containers.
- Always be properly grounded when touching a component or assembly.
- Store reusable ESD-sensitive parts from assemblies in protective packaging or nonconductive foam.
- Use transporters and conveyors made of antistatic belts and roller bushings. Be sure that mechanized equipment used for moving materials is wired to ground and that proper materials are selected to avoid static charging. When grounding is not possible, use an ionizer to dissipate electric charges.

Workstation guidelines

Follow these grounding workstation guidelines:

- Cover the workstation with approved static-shielding material.
- Use a wrist strap connected to a properly grounded work surface and use properly grounded tools and equipment.
- Use conductive field service tools, such as cutters, screwdrivers, and vacuums.
- When fixtures must directly contact dissipative surfaces, use fixtures made only of static safe materials.
- Keep the work area free of nonconductive materials, such as ordinary plastic assembly aids and Styrofoam.
- Handle ESD-sensitive components, parts, and assemblies by the case or PCM laminate. Handle these items only at static-free workstations.
- Avoid contact with pins, leads, or circuitry.
- Turn off power and input signals before inserting or removing connectors or test equipment.

Equipment guidelines

Grounding equipment must include either a wrist strap or a foot strap at a grounded workstation.

- When seated, wear a wrist strap connected to a grounded system. Wrist straps are flexible straps with a minimum of one megohm $\pm 10\%$ resistance in the ground cords. To provide proper ground, wear a strap snugly against the skin at all times. On grounded mats with banana-plug connectors, use alligator clips to connect a wrist strap.
- When standing, use foot straps and a grounded floor mat. Foot straps (heel, toe, or boot straps) can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use foot straps on both feet with a minimum of one megohm resistance between the operator and ground. To be effective, the conductive must be worn in contact with the skin.

The following grounding equipment is recommended to prevent electrostatic damage:

- Antistatic tape
- Antistatic smocks, aprons, and sleeve protectors
- Conductive bins and other assembly or soldering aids
- Nonconductive foam
- Conductive computerop workstations with ground cords of one megohm resistance
- Static-dissipative tables or floor mats with hard ties to the ground
- Field service kits
- Static awareness labels
- Material-handling packages
- Nonconductive plastic bags, tubes, or boxes
- Metal tote boxes
- Electrostatic voltage levels and protective materials

The following table lists the shielding protection provided by antistatic bags and floor mats.

Material	Use	Voltage protection level
Antistatic plastics	Bags	1,500 V
Carbon-loaded plastic	Floor mats	7,500 V
Metallized laminate	Floor mats	5,000 V

5 Removal and replacement procedures

 **CAUTION:** Components described in this chapter should only be accessed by an authorized service provider. Accessing these parts can damage the computer or void the warranty.

Component replacement procedures

 **NOTE:** Details about the computer, including product number, warranty information, model number, and serial number, are included on the service tag on the bottom of the computer. See [Locating the product number, warranty information, model number, and serial number on page 14](#) for details.

This chapter provides removal and replacement procedures.

There are as many as 69 screws that must be removed, replaced, and/or loosened when servicing the computer. Make special note of each screw size and location during removal and replacement.

Bottom cover

Description	Spare part number
Bottom cover (includes front rubber foot strip, shielding and vents)	857800-001

Before disassembling the computer, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.

Remove the bottom cover:

1. Close the computer.
2. Turn the computer upside down with the front toward you.
3. Remove the rear rubber foot strip **(1)**.


The rear rubber foot strip is included in the Rubber Kit, spare part number 858700-001.

- 4.** Remove the following screws that secure the bottom cover to the computer:

(2) Two Torx5 M2.0×7.3 screws in the rear corners of the bottom cover

(3) Four Phillips M2.5×7.8 screws under the rubber foot strip


(4) Four Torx5 M2.0×5.4 screws on the front edge of the bottom cover



- 5.** Insert a case utility tool **(1)** or similar plastic, flat-edged tool between the bottom cover and the computer near the display hinge areas.

- 6.** Release the bottom cover rear edge **(2)** and swing it up and forward until it releases.

7. Remove the bottom cover (3).



Reverse this procedure to install the bottom cover.

Battery


Description	Spare part number
Battery (3-cell, 52-WHr, 4.56-AHr, Li-ion; includes cable)	849313-856

Before removing the battery, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).

Remove the battery:

1. Disconnect the battery cable **(1)** from the system board.
2. Remove the seven Phillips M2.5×3.8 screws **(2)** that secure the battery to the keyboard/top cover.
3. Remove the battery **(3)**.



Reverse this procedure to install the battery.

Hard drive

 **NOTE:** The hard drive spare part kit does not include the hard drive rubber bracket or hard drive cable. The hard drive rubber bracket is available using spare part number 857797-001. The hard drive cable is available using spare part number 857806-001.


Description	Spare part number
1-TB, 5400-rpm, SATA, 7.2-mm hard drive	762888-856
500-GB, 5400-rpm, SATA, 7.0-mm hard drive	683839-856

Before removing the hard drive, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).


Remove the hard drive:

1. Release the zero insertion force (ZIF) connector (1) to which the hard drive cable is connected, and then disconnect the hard drive cable from the system board.
2. Remove the hard drive (2).



3. If it is necessary to replace the hard drive cable, disconnect the cable (1) from the hard drive.

- If it is necessary to replace the hard drive rubber bracket, release the left and right sides (2) of the rubber bracket from the hard drive, and then remove the rubber bracket (3).



Reverse this procedure to reassemble and install the hard drive.

Memory module

Description	Spare part number
8-GB (2133, 1.2-V, DDR4)	820448-858
4-GB (2133, 1.2-V, DDR4)	820447-858
2-GB (2133, 1.2-V, DDR4)	851227-857


Before removing a memory module, follow these steps:

- Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
- Disconnect the power from the computer by unplugging the power cord from the computer.
- Disconnect all external devices from the computer.
- Remove the bottom cover (see [Bottom cover on page 26](#)).
- Disconnect the battery cable from the system board (see [Battery on page 29](#)).

Remove the memory module:

- Spread the retaining tabs (1) on each side of the memory module slot to release the memory module. (The memory module tilts up.)

- 2.** Remove the memory module **(2)** by pulling it away from the slot at an angle.



Reverse this procedure to install a memory module.

Solid-state drive


Description	Spare part number
512-GB, M.2, PCIe, NVMe solid-state drive supporting TLC	857487-001
256-GB, M.2, SATA-3 solid-state drive supporting TLC	857485-001
256-GB, M.2, PCIe, NVMe solid-state drive supporting TLC	857486-001
128-GB, M.2, SATA-3 solid-state drive	857484-001

Before removing the solid-state drive, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).

Remove the solid-state drive:

1. Remove the Phillips M2.0×2.7 screw **(1)** that secures the solid-state drive to the computer. (The solid-state drive tilts up.)
2. Remove the solid-state drive **(2)** by pulling the drive away from the slot at an angle.



Reverse this procedure to install the solid-state drive.

RTC battery


Description	Spare part number
RTC battery (includes cable and double-sided adhesive)	857798-001

Before removing the USB board, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).

Remove the RTC battery:

1. Disconnect the RTC battery cable **(1)** from the system board.
2. Detach the RTC battery **(2)** from the keyboard/top cover. (The RTC battery is attached to the keyboard/top cover with double-sided adhesive.)



3. Remove the RTC battery.

Reverse this procedure to install the RTC battery.

WLAN module

Description	Spare part number
Intel Dual Band Wireless-AC 7265 802.11 ac 2×2 WiFi + Bluetooth 4.2 Combo Adapter	793747-857

⚠ CAUTION: To prevent an unresponsive system, replace the wireless module only with a wireless module authorized for use in the computer by the governmental agency that regulates wireless devices in your country or region. If you replace the module and then receive a warning message, remove the module to restore device functionality, and then contact technical support.

Before removing the WLAN module, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).


Remove the WLAN module:

1. Disconnect the WLAN antenna cables **(1)** from the terminals on the WLAN module.


📝 NOTE: The WLAN antenna cable labeled “1/MAIN” connects to the WLAN module “Main” terminal. The WLAN antenna cable labeled “2/AUX” connects to the WLAN module “Aux” terminal.

2. Remove the Phillips M2.0×2.7 screw **(2)** that secures the WLAN module to the computer. (The WLAN module tilts up.)

3. Remove the WLAN module **(3)** by pulling the module away from the slot at an angle.



NOTE: If the WLAN antenna cables are not connected to the WLAN module terminal, the protective sleeves should be installed on the antenna connectors, as shown in the following illustration.



Reverse this procedure to install the WLAN module.

Fan


Description	Spare part number
Fan (includes cable)	857805-001

Before removing the fan, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).

Remove the fan:

1. Disconnect the fan cable (1) from the system board.
2. Remove the Phillips M2.5×5.8 screw (2) that secures the fan to the keyboard/top cover.
3. Remove the Phillips M2.5×3.8 screw (3) that secures the fan to the keyboard/top cover.
4. Release the tape (4) that secures the fan to the keyboard/top cover.
5. Remove the fan (5).



Reverse this procedure to install the fan.

TouchPad cable


Description	Spare part number
TouchPad cable (includes double-sided adhesive)	857807-001

Before removing the TouchPad cable, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Remove the battery (see [Battery on page 29](#)).

Remove the TouchPad cable:

1. Release the ZIF connector **(1)** to which the TouchPad cable is connected, and then disconnect the TouchPad cable from the system board.
2. Release the ZIF connector **(2)** to which the TouchPad cable is connected, and then disconnect the TouchPad cable from the TouchPad board.
3. Detach the TouchPad cable **(3)** from the TouchPad. (The TouchPad cable is attached to the TouchPad with double-sided adhesive.)
4. Remove the TouchPad cable **(4)**.



Reverse this procedure to install the TouchPad cable.

TouchPad

 **NOTE:** The TouchPad spare part kit does not include the TouchPad bracket or TouchPad cable. The TouchPad bracket is available using spare part number 857796-001. The TouchPad cable is available using spare part number 857807-001.


Description	Spare part number
TouchPad	857801-001

Before removing the TouchPad, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Remove the battery (see [Battery on page 29](#)).

Remove the TouchPad:

1. Release the ZIF connector (1) to which the TouchPad cable is connected, and then disconnect the TouchPad cable from the system board.
2. Remove the seven Phillips M2.0×2.3 broad head screws (2) that secure the TouchPad and TouchPad bracket to the keyboard/top cover.
3. Remove the TouchPad bracket (3).
4. Remove the TouchPad (4).



Reverse this procedure to install the TouchPad.

Power connector cable


Description	Spare part number
Power connector cable	857438-010

Before removing the power connector cable, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).

Remove the power connector cable:


1. Remove the four Phillips M2.5×5.8 screws **(1)** that secure the right display hinge to the keyboard/top cover.
2. Swing the right display hinge **(2)** up and back until the power connector is accessible.



3. Disconnect the power connector cable **(1)** from the system board.
4. Remove the three Phillips M2.5×3.8 screws **(2)** that secure the power connector cable bracket to the keyboard/top cover.
5. Remove the power connector cable bracket **(3)**.

The power connector cable bracket is included in the I/O Bracket Kit, spare part number 857795-001.

6. Remove the power connector cable (4).



Reverse this procedure to install the power connector cable.

USB board cables


Description	Spare part number
USB board cable (190 mm, includes double-sided adhesive)	858701-001
USB board cable (173 mm, includes double-sided adhesive)	857802-001

Before removing the USB board cables, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).

Remove the USB board cables:

1. Release the ZIF connectors **(1)** to which the USB board cables are connected, and then disconnect the USB board cables from the system board.
2. Release the ZIF connectors **(2)** to which the USB board cables are connected, and then disconnect the USB board cables from the USB board.
3. Detach the USB board cables **(3)** from the keyboard/top cover. (The USB board cables are attached to the keyboard/top cover with double-sided adhesive.)
4. Remove the USB board cables **(4)**.



Reverse this procedure to install the USB board cables.

USB board

 **NOTE:** The USB board spare part kit includes the USB board cables. The USB board cables are also available using spare part numbers 858701-001 and 857802-001.


Description	Spare part number
USB board (includes cables and 2 USB ports)	857794-001

Before removing the USB board, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).

Remove the USB board:

1. Remove the four Phillips M2.5×5.8 screws **(1)** that secure the left display hinge to the keyboard/top cover.
2. Swing the left display hinge **(2)** up and back until the USB board bracket is accessible.




3. Release the ZIF connectors **(1)** to which the USB board cables are connected, and then disconnect the USB board cables from the system board.
4. Detach the USB board cables **(2)** from the keyboard/top cover. (The USB board cables are attached to the keyboard/top cover with double-sided adhesive.)
5. Remove the two Phillips M2.0×3.6 screws **(3)** that secure the USB board to the keyboard/top cover.

6. Remove the USB board bracket **(4)**.

The USB board bracket is included in the I/O Bracket Kit, spare part number 857795-001.

7. Remove the USB board **(5)**.



Reverse this procedure to install the USB board.

System board

 **NOTE:** The system board spare part kit includes a graphic subsystem with UMA memory and replacement thermal material.

Description	Spare part number
Equipped with an Intel Core i7-6500U 2.50-GHz (SC turbo up to 3.10-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W) and the Windows 10 operating system	857242-601
Equipped with an Intel Core i7-6500U 2.50-GHz (SC turbo up to 3.10-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W) and a non-Windows operating system	857242-001
Equipped with an Intel Core i5-6260U 1.80-GHz (SC turbo up to 2.90-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W) and the Windows 10 operating system	857241-601
Equipped with an Intel Core i5-6260U 1.80-GHz (SC turbo up to 2.90-GHz) processor (1600-MHz FSB, 4.0-MB L3 cache, dual core, 15-W) and a non-Windows operating system	857241-001
Equipped with an Intel Core i5-6200U 2.30-GHz (SC turbo up to 2.80-GHz) processor (1600-MHz FSB, 3.0-MB L3 cache, dual core, 15-W) and the Windows 10 operating system	857243-601
Equipped with an Intel Core i5-6200U 2.30-GHz (SC turbo up to 2.80-GHz) processor (1600-MHz FSB, 3.0-MB L3 cache, dual core, 15-W) and a non-Windows operating system	857243-001

Before removing the system board, follow these steps:


1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).
6. Remove the following components:
 - a. Solid-state drive (see [Solid-state drive on page 33](#))
 - b. WLAN module (see [WLAN module on page 35](#))
 - c. Fan (see [Fan on page 37](#))

 **NOTE:** When replacing the system board, be sure that the memory module(s) (see [Memory module on page 31](#)) and the heat sink (see [Heat sink on page 48](#)) are removed from the defective system board and installed on the replacement system board.

Remove the system board:


1. Disconnect the following cables from the system board:
 - (1) Power connector cable
 - (2) Speaker cable
 - (3) TouchScreen board cable
 - (4) USB board ZIF connector cables (2)
 - (5) RTC battery cable

- (6) Webcam/microphone module cable**
- (7) Display panel ZIF connector cable**
- (8) TouchPad ZIF connector cable**
- (9) Keyboard ZIF connector cable**
- (10) Keyboard backlight ZIF connector cable**
- (11) Hard drive ZIF connector cable**




2. Remove the two Phillips M2.5×3.1 broad head screws **(1)** that secure the system board to the keyboard/top cover.
3. Remove the Phillips M2.5×5.8 screw **(2)** that secures the system board to the keyboard/top cover.
4. Remove the four Phillips M2.5×3.8 screws **(3)** that secure the system board to the keyboard/top cover.
5. Remove the large plastic support bridge **(4)**.

6. Remove the small plastic support bridge (5).



7. Release the system board (1) by lifting the right side and swinging it up and to the left until it rests at an angle.
8. Remove the system board (2) by sliding it up and to the right at an angle.



Reverse this procedure to install the system board.

Heat sink


Description	Spare part number
Heat sink (includes replacement thermal material)	857245-001

Before removing the heat sink, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).
6. Remove the following components:
 - a. Solid-state drive (see [Solid-state drive on page 33](#))
 - b. WLAN module (see [WLAN module on page 35](#))
 - c. Fan (see [Fan on page 37](#))
 - d. System board (see [System board on page 45](#))

Remove the heat sink:


1. Remove the four Phillips M2.0×3.1 screws **(1)** that secure the heat sink to the system board.
2. Remove the heat sink **(2)**.





NOTE: The thermal material must be thoroughly cleaned from the surfaces of the heat sink and the system board each time the heat sink is removed.

Thermal material is used on the processor (**1**) and the heat sink section (**2**) that services it.



Reverse this procedure to install the heat sink.

Speakers


Description	Spare part number
Speakers (includes left and right speakers and cables)	857804-001

Before removing the speakers, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.
4. Remove the bottom cover (see [Bottom cover on page 26](#)).
5. Disconnect the battery cable from the system board (see [Battery on page 29](#)).
6. Remove the following components:
 - a. Solid-state drive (see [Solid-state drive on page 33](#))
 - b. WLAN module (see [WLAN module on page 35](#))
 - c. Fan (see [Fan on page 37](#))
 - d. System board (see [System board on page 45](#))

Remove the speakers:

1. Release the display panel cable (1) and the TouchScreen cable from the routing clips and channel built into the right speaker.
2. Detach the piece of tape (2) that secures the speaker cable to the keyboard/top cover.
3. Remove the three Phillips M2.5×3.8 screws (3) that secure the speakers to the keyboard/top cover.
4. Remove the speakers (4).



Reverse this procedure to install the speakers.

Display assembly

 **NOTE:** The TouchScreen display assembly is spared as an entire assembly. The non-TouchScreen display assembly is spared at the subcomponent level.

Description	Spare part number
15.6-in, RGBW, UHD, WLED, AntiGlare (3840×2160), uslim-flat (2.68-mm), UWVA, eDP+PSR TouchScreen display assembly equipped with HDC and webcam	858712-001
15.6-in, RGBW, UHD, WLED, AntiGlare (3840×2160), uslim-flat (2.68-mm), UWVA, eDP+PSR TouchScreen display assembly equipped with HDC and webcam	857440-001
15.6-in, FHD, WLED, BrightView (1920×1080), slim-flat (3.0-mm), UWVA, eDP TouchScreen display assembly equipped with HDC and webcam	858711-001
15.6-in, FHD, WLED, BrightView (1920×1080), slim-flat (3.0-mm), UWVA, eDP TouchScreen display assembly equipped with HDC and webcam	857439-001


Before removing the display assembly, follow these steps:

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.

- 3.** Disconnect all external devices from the computer.
- 4.** Remove the bottom cover (see [Bottom cover on page 26](#)).
- 5.** Disconnect the battery cable from the system board (see [Battery on page 29](#)).


Remove the display assembly:

- 1.** Disconnect the WLAN antenna cables **(1)** from the terminals on the WLAN module.
-
-  **NOTE:** The WLAN antenna cable labeled “1/MAIN” connects to the WLAN module “Main” terminal. The WLAN antenna cable labeled “2/AUX” connects to the WLAN module “Aux” terminal.
- 2.** Disconnect the TouchScreen board cable **(2)** from the system board.
 - 3.** Disconnect the webcam/microphone module cable **(3)** from the system board.
 - 4.** Release the ZIF connector **(4)** to which the display panel cable is connected, and then disconnect the display panel cable from the system board.
 - 5.** Release the display panel cable and the TouchScreen cable from the routing clips **(5)** and channel built into the right speaker.




- 6.** Remove the eight Phillips M2.5×5.8 screws **(1)** that secure the display assembly to the keyboard/top cover.

7. Release the display hinges **(2)** by swinging them up and back.




8. Swing the keyboard/top cover **(1)** up and away from the display assembly.
9. Slide the keyboard/top cover **(2)** forward and separate it from the display assembly.



10. If it is necessary to replace the display bezel:
 - a. Flex the inside edges of the top edge **(1)**, left **(2)** and right edges, and bottom edge **(3)** of the display bezel until the bezel disengages from the display back cover.
 - b. Lift the top edge of the display panel **(4)** and swing it up until it rests at an angle.


- c. Remove the display bezel (5).

The display bezel is available using spare part number 857813-001.



11. If it is necessary to replace the display panel:

- Remove the display bezel.
- Remove the four Phillips M2.0×2.9 screws that secure the display panel to the display back cover.




⚠ CAUTION: Before turning the display panel upside down, make sure the work surface is clear of tools, screws, and any other foreign objects. Failure to follow this caution can result in damage to the display panel.

- Lift the top edge of the display panel (1) and swing it up and forward until it rests upside down in front of the display back cover.
- Release the adhesive strip (2) that secures the display panel cable connector to the display panel.
- Disconnect the display panel cable (3) from the display panel.

f. Remove the display panel **(4)**.

The display panel is available using spare part numbers 857483-001 (15.6-in, RGBW, UHD, WLED, AntiGlare (3840×2160), uslim-flat (2.68-mm), UWVA, eDP+PSR display panel) and 857482-001 (15.6-in, FHD, WLED, BrightView (1920×1080), slim-flat (3.0-mm), UWVA, eDP display panel).




12. If it is necessary to replace the display panel cable:

- a. Remove the display bezel.
- b. Remove the display panel.
- c. Release the adhesive strip **(1)** that secures the display panel cable connector to the display panel.
- d. Disconnect the display panel cable **(1)** from the display panel.
- e. Detach the piece of tape **(3)** that secures the display panel cable to the display back cover.

- f. Remove the display panel cable (4).

The display panel cable is available using spare part numbers 857809-001 (for use only on computer models equipped with a UHD display panel) and 857808-001 (for use only on computer models equipped with an FHD display panel).




13. If it is necessary to replace the webcam/microphone module:

- Remove the display bezel.
- Remove the display panel.
- Disconnect the webcam/microphone module cable (1) from the webcam/microphone module.

 **NOTE:** Select computer models will have two cables connected to the webcam/microphone module.

- Detach the piece of tape (2) that secures the webcam/microphone module to the display back cover.

- e. Detach the webcam/microphone module **(3)** from the display back cover. (The webcam/microphone module is secured to the display back cover with double-sided adhesive.)



- f. Remove the webcam/microphone module.


The webcam/microphone module is available using spare part number 857441-001.

14. If it is necessary to replace the display hinge covers:

- a. Remove the display bezel.
- b. Remove the display panel.
- c. Press in on the outside edge of the hinge cover **(1)** until the tabs built into the hinge cover disengage from the display back cover.

- d. Press the hinge cover down **(2)**, and then remove the hinge cover.

The display hinge covers are available using spare part number 857803-001.




- 15.** If it is necessary to replace the antenna:

 **NOTE:** The antenna includes the auxiliary and main antenna cables and transceivers.

- a. Remove the display bezel.
- b. Remove the display panel.
- c. Remove the right hinge cover.
- d. Detach the antenna transceivers **(1)** from the display back cover. (The antenna transceivers are attached to the display back cover with double-sided adhesive.)
- e. Detach the pieces of tape **(2)** that secure the antenna cables to the display back cover.
- f. Release the antenna cables from the routing clips **(3)** and channels built into the top, right, and bottom edges of the display back cover.

- g.** Remove the antenna cables and transceivers **(4)**.

The antenna are available using spare part number 857817-001.




- 16.** If it is necessary to replace the display hinges:

- a.** Remove the display bezel.
- b.** Remove the display panel.
- c.** Remove the hinge covers.
- d.** Release the wireless antenna cables **(1)** from the retention clip built into the display back cover.
- e.** Detach the pieces of tape **(2)** that secure the display hinges to the display back cover.
- f.** Remove the two Phillips M2.0×2.8 screws **(3)** that secure the display hinges to the display back cover.
- g.** Remove the eight Phillips M2.5×3.1 screws **(4)** that secure the display hinges to the display back cover.

h. Remove the display hinges (5).

The display hinges are available using spare part number 857815-001.



17. If it is necessary to replace the webcam/microphone module cable:


- a. Remove the display bezel.
- b. Remove the display panel.
- c. Remove the hinge covers.
- d. Remove the hinges.
- e. Disconnect the webcam/microphone module cable (1) from the webcam/microphone module.

 **NOTE:** Select computer models will have two cables connected to the webcam/microphone module.

- f. Release the webcam/microphone module cable from the routing clips (2) and channels built into the top, left, and bottom edges of the display back cover.

- g.** Remove the webcam/microphone module cable **(3)**.

The webcam/microphone module cable is available using spare part number 857810-001.



Reverse this procedure to reassemble and install the display assembly.

6 Using Setup Utility (BIOS)

Setup Utility, or Basic Input/Output System (BIOS), controls communication between all the input and output devices on the system (such as disk drives, display, keyboard, mouse, and printer). Setup Utility (BIOS) includes settings for the types of devices installed, the startup sequence of the computer, and the amount of system and extended memory.

 **NOTE:** To start Setup Utility on convertible computers, your computer must be in notebook mode and you must use the keyboard attached to your notebook.

Starting Setup Utility (BIOS)

 **CAUTION:** Use extreme care when making changes in Setup Utility (BIOS). Errors can prevent the computer from operating properly.

- ▲ Turn on or restart the computer, quickly press **esc**, and then press **f10**.

Updating Setup Utility (BIOS)

Updated versions of Setup Utility (BIOS) may be available on the HP website.

Most BIOS updates on the HP website are packaged in compressed files called *SoftPaqs*.

Some download packages contain a file named *Readme.txt*, which contains information regarding installing and troubleshooting the file.

Determining the BIOS version

To decide whether you need to update Setup Utility (BIOS), first determine the BIOS version on your computer.

To reveal the BIOS version information (also known as *ROM date* and *System BIOS*), use one of these options.

- HP Support Assistant
 - 1. Type **support** in the taskbar search box, and then select the **HP Support Assistant** app.
– or –
Click the question mark icon in the taskbar.
 - 2. Select **My PC**, and then select **Specifications**.
- Setup Utility (BIOS)
 - 1. Start Setup Utility (BIOS) (see [Starting Setup Utility \(BIOS\) on page 61](#)).
 - 2. Select **Main**, select **System Information**, and then make note of the BIOS version.
 - 3. Select **Exit**, select **No**, and then follow the on-screen instructions.

To check for later BIOS versions, see [Downloading a BIOS update on page 62](#).

Downloading a BIOS update

 **CAUTION:** To reduce the risk of damage to the computer or an unsuccessful installation, download and install a BIOS update only when the computer is connected to reliable external power using the AC adapter. Do not download or install a BIOS update while the computer is running on battery power, docked in an optional docking device, or connected to an optional power source. During the download and installation, follow these instructions:

- Do not disconnect power from the computer by unplugging the power cord from the AC outlet.
- Do not shut down the computer or initiate Sleep.
- Do not insert, remove, connect, or disconnect any device, cable, or cord.

 **NOTE:** If your computer is connected to a network, consult the network administrator before installing any software updates, especially system BIOS updates.

1. Type **support** in the taskbar search box, and then select the **HP Support Assistant** app.
– or –
Click the question mark icon in the taskbar.
 2. Click **Updates**, and then click **Check for updates and messages**.
 3. Follow the on-screen instructions.
 4. At the download area, follow these steps:
 - a. Identify the most recent BIOS update and compare it to the BIOS version currently installed on your computer. If the update is more recent than your BIOS version, make a note of the date, name, or other identifier. You may need this information to locate the update later, after it has been downloaded to your hard drive.
 - b. Follow the on-screen instructions to download your selection to the hard drive.
- Make a note of the path to the location on your hard drive where the BIOS update is downloaded. You will need to access this path when you are ready to install the update.

BIOS installation procedures vary. Follow any instructions that appear on the screen after the download is complete. If no instructions appear, follow these steps:

1. Type **file** in the taskbar search box, and then select **File Explorer**.
 2. Click your hard drive designation. The hard drive designation is typically Local Disk (C:).
 3. Using the hard drive path you recorded earlier, open the folder that contains the update.
 4. Double-click the file that has an .exe extension (for example, *filename.exe*).
- The BIOS installation begins.
5. Complete the installation by following the on-screen instructions.

 **NOTE:** After a message on the screen reports a successful installation, you can delete the downloaded file from your hard drive.

7 Using HP PC Hardware Diagnostics (UEFI)

HP PC Hardware Diagnostics is a Unified Extensible Firmware Interface (UEFI) that allows you to run diagnostic tests to determine whether the computer hardware is functioning properly. The tool runs outside the operating system so that it can isolate hardware failures from issues that are caused by the operating system or other software components.

When HP PC Hardware Diagnostics (UEFI) detects a failure that requires hardware replacement, a 24-digit Failure ID code is generated. This ID code can then be provided to support to help determine how to correct the problem.

 **NOTE:** To start diagnostics on a convertible computer, your computer must be in notebook mode and you must use the keyboard attached.

To start HP PC Hardware Diagnostics (UEFI), follow these steps:

1. Turn on or restart the computer, and quickly press **esc**.
2. Press **f2**.

The BIOS searches three places for the diagnostic tools, in the following order:

- a. Connected USB drive
 **NOTE:** To download the HP PC Hardware Diagnostics (UEFI) tool to a USB drive, see [Downloading HP PC Hardware Diagnostics \(UEFI\) to a USB device on page 63](#).
 - b. Hard drive
 - c. BIOS
3. When the diagnostic tool opens, select the type of diagnostic test you want to run, and then follow the on-screen instructions.

 **NOTE:** If you need to stop a diagnostic test, press **esc**.

Downloading HP PC Hardware Diagnostics (UEFI) to a USB device

 **NOTE:** The HP PC Hardware Diagnostics (UEFI) download instructions are provided in English only, and you must use a Windows computer to download and create the HP UEFI support environment because only .exe files are offered.

There are two options to download HP PC Hardware Diagnostics to a USB device.

Download the latest UEFI version

1. Go to <http://www.hp.com/go/techcenter/pcdiags>. The HP PC Diagnostics home page is displayed.
2. In the HP PC Hardware Diagnostics section, select the **Download** link, and then select **Run**.

Download any version of UEFI for a specific product

1. Go to <http://www.hp.com/support>.
2. Select **Get software and drivers**.

3. Enter the product name or number.

– or –

Select **Identify now** to let HP automatically detect your product.
4. Select your computer, and then select your operating system.
5. In the **Diagnostic** section, follow the on-screen instructions to select and download the UEFI version you want.

8 Specifications

Computer specifications

The power information in this section may be helpful if you plan to travel internationally with the computer.

The computer operates on DC power, which can be supplied by an AC or a DC power source. The AC power source must be rated at 100–240 V, 50–60 Hz. Although the computer can be powered from a standalone DC power source, it should be powered only with an AC adapter or a DC power source that is supplied and approved by HP for use with this computer.

The computer can operate on DC power within the following specifications. Operating voltage and current varies by platform. The voltage and current for your computer is located on the regulatory label.

	Metric	U.S.
Dimensions		
Width	38.0 cm	14.96 in
Depth	25.5 cm	10.04 in
Height	1.80 cm	0.71 in
Weight (equipped with a hard drive and a non-TouchScreen display assembly)	2.08 kg	4.58 lbs
Weight (equipped with a hard drive and a TouchScreen display assembly)	2.26 kg	4.98 lbs
Weight (equipped with a solid-state drive and a non-TouchScreen display assembly)	2.00 kg	4.98 lbs
Weight (equipped with a solid-state drive and a TouchScreen display assembly)	2.18 kg	4.81 lbs
Input power		
Operating voltage and current	5 V dc @ 2 A / 12 V dc @ 3 A / 15 V dc @ 3 A – 45 W USB-C 5 V dc @ 3 A / 9 V dc @ 3 A / 10 V dc @ 3.75 A / 12 V dc @ 3.75 A / 15 V dc @ 3 A / 20 V dc @ 2.25 A - 45 W USB-C 5 V dc @ 3 A / 9 V dc @ 3 A / 10 V dc @ 5.0 A / 12 V dc @ 5.0 A / 15 V dc @ 4.33 A / 20 V dc @ 3.25 A - 65 W USB-C 5 V dc @ 3 A / 9 V dc @ 3 A / 10 V dc @ 5.0 A / 12 V dc @ 5.0 A / 15 V dc @ 5.0 A / 20 V dc @ 4.5 A - 90 W USB-C 19.5 V dc @ 2.31 A – 45 W 19.5 V dc @ 3.33 A – 65 W 19.5 V dc @ 4.62 A – 90 W 19.5 V dc @ 6.15 A – 120 W 19.5 V dc @ 7.70 A – 150 W 19.5 V dc @ 10.3 A – 200 W	

NOTE: This product is designed for IT power systems in Norway with phase-to-phase voltage not exceeding 240 V rms.

	Metric	U.S.
Temperature		
Operating	5°C to 35°C	41°F to 95°F
Non-operating	-20°C to 60°C	-4°F to 140°F
Relative humidity (non-condensing)		
Operating	10% to 90%	
Non-operating	5% to 95%	
Maximum altitude (unpressurized)		
Operating	-15 m to 3,048 m	-50 ft to 10,000 ft
Non-operating	-15 m to 12,192 m	-50 ft to 40,000 ft
NOTE: Applicable product safety standards specify thermal limits for plastic surfaces. The device operates well within this range of temperatures.		

9 Backing up, restoring, and recovering

This chapter provides information about the following processes. The information in the chapter is standard procedure for most products.

- Creating recovery media and backups
- Restoring and recovering your system

For additional information, refer to the HP support assistant app.

- ▲ Type `support` in the taskbar search box, and then select the **HP Support Assistant** app.
 - or –
 - Click the question mark icon in the taskbar.

 **IMPORTANT:** If you will be performing recovery procedures on a tablet, the tablet battery must be at least 70% charged before you start the recovery process.

IMPORTANT: For a tablet with a detachable keyboard, connect the keyboard to the keyboard dock before beginning any recovery process.

Creating recovery media and backups

The following methods of creating recovery media and backups are available on select products only. Choose the available method according to your computer model.

- Use HP Recovery Manager to create HP Recovery media after you successfully set up the computer. This step creates a backup of the HP Recovery partition on the computer. The backup can be used to reinstall the original operating system in cases where the hard drive is corrupted or has been replaced. For information on creating recovery media, see [Creating HP Recovery media \(select products only\) on page 67](#). For information on the recovery options that are available using the recovery media, see [Using Windows tools on page 68](#).
- Use Windows tools to create system restore points and create backups of personal information.

For more information, see [Recovering using HP Recovery Manager on page 69](#).

 **NOTE:** If storage is 32 GB or less, Microsoft System Restore is disabled by default.

Creating HP Recovery media (select products only)

If possible, check for the presence of the Recovery partition and the Windows partition. From the **Start** menu, select **File Explorer**, and then select **This PC**.

- If your computer does not list the Windows partition and the Recovery partition, you can obtain recovery media for your system from support. See the *Worldwide Telephone Numbers* booklet included with the computer. You can also find contact information on the HP website. Go to <http://www.hp.com/support>, select your country or region, and follow the on-screen instructions.

You can use Windows tools to create system restore points and create backups of personal information, see [Using Windows tools on page 68](#).

- If your computer does list the Recovery partition and the Windows partition, you can use HP Recovery Manager to create recovery media after you successfully set up the computer. HP Recovery media can be used to perform system recovery if the hard drive becomes corrupted. System recovery reinstalls the original operating system and software programs that were installed at the factory and then configures the settings for the programs. HP Recovery media can also be used to customize the system or restore the factory image if you replace the hard drive.
 - Only one set of recovery media can be created. Handle these recovery tools carefully, and keep them in a safe place.
 - HP Recovery Manager examines the computer and determines the required storage capacity for the media that will be required.
 - To create recovery discs, your computer must have an optical drive with DVD writer capability, and you must use only high-quality blank DVD-R, DVD+R, DVD-R DL, or DVD+R DL discs. Do not use rewritable discs such as CD±RW, DVD±RW, double-layer DVD±RW, or BD-RE (rewritable Blu-ray) discs; they are not compatible with HP Recovery Manager software. Or, instead, you can use a high-quality blank USB flash drive.
 - If your computer does not include an integrated optical drive with DVD writer capability, but you would like to create DVD recovery media, you can use an external optical drive (purchased separately) to create recovery discs. If you use an external optical drive, it must be connected directly to a USB port on the computer; the drive cannot be connected to a USB port on an external device, such as a USB hub. If you cannot create DVD media yourself, you can obtain recovery discs for your computer from HP. See the *Worldwide Telephone Numbers* booklet included with the computer. You can also find contact information on the HP website. Go to <http://www.hp.com/support>, select your country or region, and follow the on-screen instructions.
 - Be sure that the computer is connected to AC power before you begin creating the recovery media.
 - The creation process can take an hour or more. Do not interrupt the creation process.
 - If necessary, you can exit the program before you have finished creating all of the recovery DVDs. HP Recovery Manager will finish burning the current DVD. The next time you start HP Recovery Manager, you will be prompted to continue.

To create HP Recovery media:

 **IMPORTANT:** For a tablet with a detachable keyboard, connect the keyboard to the keyboard dock before beginning these steps.

1. Type **recovery** in the taskbar search box, and then select **HP Recovery Manager**.
2. Select **Create recovery media**, and then follow the on-screen instructions.

If you ever need to recover the system, see [Recovering using HP Recovery Manager on page 69](#).

Using Windows tools

You can create recovery media, system restore points, and backups of personal information using Windows tools.

 **NOTE:** If storage is 32 GB or less, Microsoft System Restore is disabled by default.

For more information and steps, see the Get started app.

- ▲ Select the **Start** button, and then select the **Get started** app.

Restore and recovery

There are several options for recovering your system. Choose the method that best matches your situation and level of expertise:



IMPORTANT: Not all methods are available on all products.

- Windows offers several options for restoring from backup, refreshing the computer, and resetting the computer to its original state. For more information see the Get started app.
 - ▲ Select the **Start** button, and then select the **Get started** app.
- If you need to correct a problem with a preinstalled application or driver, use the Reinstall drivers and/or applications option (select products only) of HP Recovery Manager to reinstall the individual application or driver.
 - ▲ Type `recovery` in the taskbar search box, select **HP Recovery Manager**, select **Reinstall drivers and/or applications**, and then follow the on-screen instructions.
- If you want to recover the Windows partition to original factory content, you can choose the System Recovery option from the HP Recovery partition (select products only) or use the HP Recovery media. For more information, see [Recovering using HP Recovery Manager on page 69](#). If you have not already created recovery media, see [Creating HP Recovery media \(select products only\) on page 67](#).
- On select products, if you want to recover the computer's original factory partition and content, or if you have replaced the hard drive, you can use the Factory Reset option of HP Recovery media. For more information, see [Recovering using HP Recovery Manager on page 69](#).
- On select products, if you want to remove the recovery partition to reclaim hard drive space, HP Recovery Manager offers the Remove Recovery Partition option.

For more information, see [Removing the HP Recovery partition \(select products only\) on page 72](#).

Recovering using HP Recovery Manager

HP Recovery Manager software allows you to recover the computer to its original factory state by using the HP Recovery media that you either created or that you obtained from HP, or by using the HP Recovery partition (select products only). If you have not already created recovery media, see [Creating HP Recovery media \(select products only\) on page 67](#).

What you need to know before you get started

- HP Recovery Manager recovers only software that was installed at the factory. For software not provided with this computer, you must either download the software from the manufacturer's website or reinstall the software from the media provided by the manufacturer.
-
- IMPORTANT:** Recovery through HP Recovery Manager should be used as a final attempt to correct computer issues.
- HP Recovery media must be used if the computer hard drive fails. If you have not already created recovery media, see [Creating HP Recovery media \(select products only\) on page 67](#).
 - To use the Factory Reset option (select products only), you must use HP Recovery media. If you have not already created recovery media, see [Creating HP Recovery media \(select products only\) on page 67](#).
 - If your computer does not allow the creation of HP Recovery media or if the HP Recovery media does not work, you can obtain recovery media for your system from support. See the *Worldwide Telephone Numbers* booklet included with the computer. You can also find contact information from the HP

website. Go to <http://www.hp.com/support>, select your country or region, and follow the on-screen instructions.

 **IMPORTANT:** HP Recovery Manager does not automatically provide backups of your personal data. Before beginning recovery, back up any personal data you want to retain.

Using HP Recovery media, you can choose from one of the following recovery options:

 **NOTE:** Only the options available for your computer display when you start the recovery process.

- System Recovery—Reinstalls the original operating system, and then configures the settings for the programs that were installed at the factory.
- Factory Reset—Restores the computer to its original factory state by deleting all information from the hard drive and re-creating the partitions. Then it reinstalls the operating system and the software that was installed at the factory.

The HP Recovery partition (select products only) allows System Recovery only.

Using the HP Recovery partition (select products only)

The HP Recovery partition allows you to perform a system recovery without the need for recovery discs or a recovery USB flash drive. This type of recovery can be used only if the hard drive is still working.

To start HP Recovery Manager from the HP Recovery partition:

 **IMPORTANT:** For a tablet with a detachable keyboard, connect the keyboard to the keyboard dock before beginning these steps (select products only).

1. Type **recovery** in the taskbar search box, select **Recovery Manager**, and then select **HP Recovery Environment**.

- or -

For computers or tablets with keyboards attached, press **f11** while the computer boots, or press and hold **f11** as you press the power button.

For tablets without keyboards:

Turn on or restart the tablet, and then quickly hold down the volume down button; then select **f11**.

- or -

Turn on or restart the tablet, and then quickly hold down the Windows button; then select **f11**.

2. Select **Troubleshoot** from the boot options menu.
3. Select **Recovery Manager**, and then follow the on-screen instructions.

Using HP Recovery media to recover

You can use HP Recovery media to recover the original system. This method can be used if your system does not have an HP Recovery partition or if the hard drive is not working properly.

1. If possible, back up all personal files.
2. Insert the HP Recovery media, and then restart the computer.

 **NOTE:** If the computer does not automatically restart in HP Recovery Manager, change the computer boot order. See [Changing the computer boot order on page 71](#).

3. Follow the on-screen instructions.

Changing the computer boot order

If your computer does not restart in HP Recovery Manager, you can change the computer boot order, which is the order of devices listed in BIOS where the computer looks for startup information. You can change the selection to an optical drive or a USB flash drive.

To change the boot order:



IMPORTANT: For a tablet with a detachable keyboard, connect the keyboard to the keyboard dock before beginning these steps.

1. Insert the HP Recovery media.

2. Access BIOS:

For computers or tablets with keyboards attached:

▲ Turn on or restart the computer or tablet, quickly press **esc**, and then press **f9** for boot options.

For tablets without keyboards:

▲ Turn on or restart the tablet, and then quickly hold down the volume down button; then select **f9**.

- or -

Turn on or restart the tablet, and then quickly hold down the Windows button; then select **f9**.

3. Select the optical drive or USB flash drive from which you want to boot.

4. Follow the on-screen instructions.

Removing the HP Recovery partition (select products only)

HP Recovery Manager software allows you to remove the HP Recovery partition to free up hard drive space.



IMPORTANT: After you remove the HP Recovery partition, you will not be able to perform System Recovery or create HP recovery media from the HP Recovery partition. So before you remove the Recovery partition, create HP Recovery media; see [Creating HP Recovery media \(select products only\) on page 67](#).



NOTE: The Remove Recovery Partition option is only available on products that support this function.

Follow these steps to remove the HP Recovery partition:

1. Type `recovery` in the taskbar search box, and then select **HP Recovery Manager**.
2. Select **Remove Recovery Partition**, and then follow the on-screen instructions.

10 Power cord set requirements

The wide-range input feature of the computer permits it to operate from any line voltage from 100 to 120 volts AC, or from 220 to 240 volts AC.

The 3-conductor power cord set included with the computer meets the requirements for use in the country or region where the equipment is purchased.

Power cord sets for use in other countries and regions must meet the requirements of the country or region where the computer is used.

Requirements for all countries

The following requirements are applicable to all countries and regions:

- The length of the power cord set must be at least **1.0 m** (3.2 ft) and no more than **1.8 m** (6 ft).
- All power cord sets must be approved by an acceptable accredited agency responsible for evaluation in the country or region where the power cord set will be used.
- The power cord sets must have a minimum current capacity of 10 amps and a nominal voltage rating of 125 or 250 V AC, as required by the power system of each country or region.
- The appliance coupler must meet the mechanical configuration of an EN 60 320/IEC 320 Standard Sheet C13 connector for mating with the appliance inlet on the back of the computer.

Requirements for specific countries and regions

Country/region	Accredited agency	Applicable note number
Australia	EANSW	1
Austria	OVE	1
Belgium	CEBC	1
Canada	CSA	2
Denmark	DEMKO	1
Finland	FIMKO	1
France	UTE	1
Germany	VDE	1
Italy	IMQ	1
Japan	METI	3
The Netherlands	KEMA	1
Norway	NEMKO	1
The People's Republic of China	COC	5
South Korea	EK	4

Country/region	Accredited agency	Applicable note number
Sweden	SEMKO	1
Switzerland	SEV	1
Taiwan	BSMI	4
The United Kingdom	BSI	1
The United States	UL	2
<p>1. The flexible cord must be Type H05VV-F, 3-conductor, 1.0-mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.</p> <p>2. The flexible cord must be Type SPT-3 or equivalent, No. 18 AWG, 3-conductor. The wall plug must be a two-pole grounding type with a NEMA 5-15P (15 A, 125 V) or NEMA 6-15P (15 A, 250 V) configuration.</p> <p>3. The appliance coupler, flexible cord, and wall plug must bear a "T" mark and registration number in accordance with the Japanese Dentori Law. The flexible cord must be Type VCT or VCTF, 3-conductor, 1.00-mm² conductor size. The wall plug must be a two-pole grounding type with a Japanese Industrial Standard C8303 (7 A, 125 V) configuration.</p> <p>4. The flexible cord must be Type RVV, 3-conductor, 0.75-mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.</p> <p>5. The flexible cord must be Type VCTF, 3-conductor, 0.75-mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.</p>		

11 Recycling

When a non-rechargeable or rechargeable battery has reached the end of its useful life, do not dispose of the battery in general household waste. Follow the local laws and regulations in your area for battery disposal.

HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, see the HP Web site at <http://www.hp.com/recycle>.

Index

Symbols/Numerics

- 3D camera 5
 - 3D camera light 5
- A**
- AC adapter light 12, 13
 - AC adapter, spare part numbers 19
 - action keys 8
 - adapter, spare part numbers 19
 - antenna
 - location 5, 6
 - removal 57
 - spare part number 19, 58
 - audio, product description 2
 - audio-in jack 12
 - audio-out jack 12

B

- back cover, spare part number 19
- backups 67
- battery
 - removal 29
 - spare part number 18, 29
- battery light 12, 13
- BIOS
 - determining version 61
 - downloading an update 62
 - starting the Setup Utility 61
 - updating 61
- boot order
 - changing 71
- bottom components 13
- bottom cover
 - removal 26
 - spare part number 18, 26
- button components 7
- buttons
 - power 7
 - TouchPad 10

C

- camera 5, 6
- camera light 5, 6
- caps lock light 9
- chipset, product description 1

components

- bottom 13
 - buttons 7
 - display 5
 - keys 8
 - left side 11
 - lights 9
 - right side 12
 - speakers 7
 - TouchPad 10
 - vents 7
- computer
- major components 15
 - specifications 65

D

- display assembly
 - removal 50
 - spare part numbers 15
- display bezel
 - removal 52
 - spare part number 19, 53
- Display Bracket Kit, spare part number 19
- display components 18
- display panel
 - product description 1
 - removal 53
 - spare part numbers 19, 54
- display panel cable
 - removal 54
 - spare part numbers 19, 55
- drive light 11
- duck head adapter, spare part numbers 19
- DVD±RW DL SuperMulti Drive, spare part number 19

E

- esc key 8

F

- fan
 - removal 37
 - spare part number 18, 37

fn key

- 8
- foot strip
 - removal 26
 - spare part number 18, 26

G

- graphics, product description 1

H

- hard drive
 - product description 1, 2
 - removal 30
 - spare part numbers 18, 30
- hard drive cable
 - removal 30
 - spare part number 18, 30

- hard drive rubber bracket
 - removal 31
 - spare part number 18, 30
- HDMI port 12
- HDMI-to-VGA adapter, spare part number 19
- headphone jack 12
- heat sink
 - removal 48
 - spare part number 18, 48

hinge

- removal 58
- spare part number 19, 59

hinge cover

- removal 56
 - spare part number 19, 57
- HP PC Hardware Diagnostics (UEFI)
using 63

- HP Recovery Manager
correcting boot problems 71
starting 70

HP Recovery media

- creating 67
- recovery 70

HP Recovery partition

- recovery 70
- removing 72

I	microphone location 5, 6 product description 2	microphone 2 operating system 3 pointing device 2, 3
I/O Bracket Kit	contents 17 spare part number 17	ports 2 power requirements 3
integrated numeric keypad	8	processors 1 product name 1 security 3 sensors 2 serviceability 3 solid-state drive 2 video 2 wireless 2
J	model name 1 mute light 9	product name 1
jacks	audio-in 12 audio-out 12 headphone 12 microphone 12	
K		
key components	8	
keyboard, product description	2, 3	
keyboard/top cover, spare part		
numbers	16	
keys		
action	8	
esc	8	
fn	8	
num lock	8	
Windows	8	
L		
left-side components	11	
light		
camera	6	
light components	9	
lights		
3D camera	5	
AC adapter	12, 13	
battery	12, 13	
camera	5	
caps lock	9	
drive	11	
mute	9	
power	9	
locating information		
hardware	4	
software	4	
M		
memory card	12	
memory card reader	12	
memory module		
removal	31	
spare part numbers	17, 31	
memory, product description	1	
microphone		
location	5, 6	
product description	2	
microphone jack	12	
minimized image recovery	70	
minimized image, creating	69	
model name	1	
mute light	9	
N		
num lock key	8	
numeric keypad	8	
O		
operating system, product		
description	3	
optical drive, spare part number	19	
original system recovery	69	
P		
pointing device, product		
description	2, 3	
ports		
HDMI	12	
product description	2	
USB 3.0	11, 12	
USB Type-C	12	
power button	7	
power connector	13	
power connector cable		
removal	40	
spare part number	17, 40	
power connector cable bracket		
removal	40	
spare part number	40	
power cord		
set requirements	73	
spare part numbers	19	
power light	9	
power requirements, product		
description	3	
processor, product description	1	
product description		
audio	2	
chipset	1	
display panel	1	
external media cards	2	
graphics	1	
hard drive	1, 2	
keyboard	2, 3	
memory	1	
S		
Screw Kit, spare part number	20	
security		
product description	3	
security cable slot	11	
sensors, product description	2	

serviceability, product description 3
slots
 memory card reader 12
 security cable 11

solid-state drive
 product description 2
 removal 33
 spare part numbers 17, 33

speaker components 7

speakers
 location 7
 removal 49
 spare part number 17, 49

specifications 65

supported discs, recovery 68

system board
 removal 45
 spare part numbers 17, 45

system recovery 69

system restore point
 creating 68

system restore point, creating 67

T

TouchPad
 buttons 10
 components 10
 removal 39
 spare part number 16, 39

TouchPad bracket
 removal 39
 spare part number 17, 39

TouchPad cable
 removal 38
 spare part number 17, 38

TouchPad zone 10

U

USB 3.0 port 11, 12

USB board
 removal 43
 spare part number 17, 43

USB board bracket
 removal 44
 spare part number 44

USB board cable
 removal 42
 spare part numbers 17, 42, 43

USB Type-C port 12

USB-to-Gigabit RJ45 adapter, spare
 part number 19

USB-Type C-to-USB 3.0 adapter,
 spare part number 19

V

vent components 7
vents 7, 13
video, product description 2

W

webcam/microphone module
 removal 55
 spare part number 19, 56

webcam/microphone module cable
 removal 59
 spare part number 19, 60

Windows
 system restore point 67, 68

Windows key 8

Windows tools
 using 68

wireless antenna
 location 5, 6
 removal 57
 spare part number 19, 58

wireless, product description 2

WLAN antenna
 location 5, 6
 removal 57
 spare part number 19, 58

WLAN module
 removal 35
 spare part number 18, 35