


SAMSUNG

User Guide • Benutzerhandbuch
Guide d'utilisation • Manuale per l'utente
Guía del usuario



Color Inkjet Multifunction CJX-1000 Series

All-in-One Printers • All-in-One Drucker • Imprimantes multifonctions
Stampanti multifunzione • Impresoras multifunción

SAMSUNG CJX-1000 All-in-One Printer

Your SAMSUNG All-in-One Printer combines ease-of-use and affordable inks to provide high-quality pictures and documents.

Resources

Support is available! Go to www.samsung.com/printer for:

- answers to questions
- software upgrades
- and more!

If you prefer, you can chat online, send us an e-mail, or call for technical support. Go to www.samsung.com/printer.

Contact SAMSUNG worldwide

If you have any comments or questions regarding Samsung products, contact the Samsung customer care center.

Country / Region	Customer Care Center	Web Site
FRANCE	01 48 63 00 00	www.samsung.com/printer
GERMANY	01805 - SAMSUNG (726-7864 € 0,14/min)	www.samsung.com/printer
ITALY	800-SAMSUNG (726-7864)	www.samsung.com/printer

Contents

1 Printer Overview	1
Components.....	1
Control panel.....	4
Print Manager Software.....	6
Configuring printer settings	6
Paper.....	7
Paper types.....	8
Paper sizes.....	8
Loading paper.....	9
2 Basic Functions	13
Printing.....	13
Printing documents.....	13
Printing pictures.....	16
Copying.....	27
Copying a document.....	27
Copying a photograph.....	32
Scanning.....	38
Before you begin scanning.....	38
Scanning from the computer.....	43
Scanning from the control panel.....	45
Ordering supplies	47

Contents

3 Maintaining Your Printer	49
General care and cleaning	50
Cleaning the scanner glass and document backing.....	50
Replacing ink cartridges.....	53
Updating the software and printer firmware	58
Updating if your printer is connected to a computer with WINDOWS OS	58
Updating if your printer is connected to a computer with MAC OS.....	60
Monitoring and adjusting printer performance.....	61
Checking ink levels.....	61
Resetting factory defaults	61
Replacing the printhead.....	62
4 Troubleshooting	69
Basic troubleshooting	69
Power light.....	72

Contents

5 Product and Safety Specifications	73
Specifications and features	73
Print performance	73
Photo printing features.....	73
Copy document features.....	74
Copy photo features.....	75
Scanning features.....	76
Paper input tray features	76
Ink cartridges	77
Connectivity	79
Software support.....	79
Physical specifications	80
System requirements	81
Computer with WINDOWS OS	81
Computer with MAC OS	81
Paper types supported	82
Paper sizes supported.....	83

Contents


6 Safety Information	85
Safety Information	85
LCD Screen Safety	88
Ink Cartridge Safety	88
Declaration of Conformity (European countries)	89
Correct Disposal of This Product (Waste Electrical & Electronic Equipment)	91
ENERGY STAR® Qualified	92

1

Printer Overview

This printer lets you print, copy, and scan pictures and documents.


Components



- 1 Left paper-edge guide
- 2 Paper guard
- 3 Paper input tray


- 4 Right paper-edge guide
- 5 Paper output tray
- 6 Output tray extender

Printer Overview



- 7 Scanner lid
- 8 Scanner glass

- 9 Control panel
- 10 Memory card slot




11 Access door

13 USB port

12 Printhead with ink cartridges installed

14 Power cord connection port

Control panel



	Feature	Description
1	LCD	Displays pictures, messages, and menus
2	Cancel button	Stops the current operation and returns to the menu
3	Menu button	Displays the main menu
4	Navigation buttons	Used to navigate menus, scroll through pictures
5	Start button	Begins copying, scanning, printing, maintenance tasks, and file transfer
6	OK button	Selects a menu item or allows you to continue with the current operation
7	Back button	Displays the higher level screen in the menu structure
8	Power button	Turns the printer on or off

Print Manager Software






SAMSUNG Print Manager Software is installed with your SAMSUNG All-in-One Printer Software unless you chose otherwise during installation. The Print Manager icon will appear on your desktop.

On a computer with WINDOWS Operating System (OS), you can use Print Manager Software to browse and edit pictures, print, copy, scan, order supplies, and configure your all-in-one printer from your computer.

On a computer with MAC OS, you can use Print Manager Software to order supplies and configure your printer from your computer.

Configuring printer settings

To set or change basic printer settings:

- 1 Press **Menu**.
- 2 Press  to select **Printer Settings**, then press **OK**.
- 3 Press  to select one of the following settings:
 - **Date and Time**
 - Press **OK**, then press  to select **Year, Month, Day, Hour, or Minute**.
 - Press  or  to change the values; press **OK** when you are done making changes.
 - Press **Back** to go back to the Printer Settings menu.

■ Time to Low Power

To conserve energy, your printer will enter a low power (sleep) mode after being idle for a default delay time of 1 hour. You can increase the delay time to low

power (in 0.5 hour increments) up to 4 hours. Increasing the delay time may result in reduced energy savings.

- Press **▶** to change the time to energy-saving sleep mode (select from 1 to 4 hours in 0.5 hour increments).

■ **Tagged Images Printing** (see [Printing tagged pictures, page 26](#))

- Press **▶** to select **Off** or **On**.

■ **Language**

- Press **OK**, press **▼** to select a language, then press **OK**.

■ **Country/Region**

- Press **OK**, press **▼** to select a country or region, then press **OK**.

■ **Reset All Settings** (see [Resetting factory defaults, page 61](#))

NOTE: Resetting factory defaults does not change the date and time, language, country/region, or network settings.

■ **Printer Info**

- Press **OK** to view the Firmware Version number; press **OK** when you are done.

4 Press **Back** to return to the Main Menu.

Paper

For the best photo printing results, use KODAK Photo Papers, which are optimized to work with SAMSUNG All-in-One Printers.

For the best document printing results, use KODAK Document Papers or a paper with the COLORLOK Technology logo on the package. Use only paper that is designed for inkjet printers.

Paper types

You can use:


- Plain paper — 16 to 24 lb / 60 to 90 gsm
- Photo paper — up to 12 mils
- Card stock — 110 lb / 200 gsm, max
- Envelopes — most standard types
- Labels — all commercially available inkjet varieties on 8.5 x 11-in. or A4 sheets
- Iron-on transfers — all inkjet varieties on 8.5 x 11-in. or A4 sheets

Paper sizes


	Minimum size	Maximum size
English units	4 x 6 in.	8.5 x 14 in.
Metric units	10 x 15 cm	22 x 36 cm

Loading paper

- 1 Lift the input tray.



- 2 Open the output tray, then pull out the extender until it is fully extended.




Loading plain paper


The input tray capacity is 100 sheets of plain paper.

To load plain paper:

- 1 Fan and stack the paper.



- 2 Make sure the left and right paper-edge guides are in the far left and far right positions, then insert the paper into the input tray.



Loading photo paper


The input tray capacity is 20 sheets of photo paper.

To load photo paper (smaller than 8.5 x 11 in.):

- 1 Remove any paper from the tray.
- 2 Insert the paper (short side first) into the center of the input tray with the **logo side toward the tray** and the glossy side toward you.

IMPORTANT: *If the photo paper is loaded the wrong way, print quality will be affected.*

- 3 Move the paper-edge guides until they touch the paper.



Printing

Printing documents

To print a document from your computer:

- 1 Open the document.
- 2 Select **File > Print**.
- 3 In the Print window, select your SAMSUNG Printer.
- 4 Choose the pages to print, number of copies, etc, then click **OK** (on a computer with WINDOWS OS) or **Print** (on a computer with MAC OS).

Printing two-sided documents

You can print two-sided documents on any size paper that the printer accepts (see [Paper sizes, page 8](#)) by rotating the paper manually as described below.

IMPORTANT: *Two-sided printing can only be done on media that can absorb ink on both sides, such as plain paper or two-sided photo paper. Two-sided printing will not work on bar-coded photo paper (the bar code is on the back side).*

Printing two-sided documents from a computer with WINDOWS OS

To print two-sided documents from a computer with WINDOWS OS:

- 1 Load paper into the paper input tray.
- 2 Open the document you want to print, then select **File > Print**.
- 3 In the Print dialog box, make sure that **SAMSUNG CJX-1000 Series AiO** is selected, then click **Properties**.
- 4 Select the **Layout** tab.
- 5 In the Two-sided printing field, select **Manual (Instructions provided)**, then click **OK**.
- 6 Click **OK**.
- 7 When a message appears on your computer or printer LCD, remove the printed pages from the output tray, and follow the instructions on the computer or LCD.
- 8 Turn the printed pages over, and place into the input tray (top edge down and printed side away from you).
- 9 Press **Start** on the printer.

Printing two-sided documents from a computer with MAC OS

To print two-sided documents from a computer with MAC OS:

- 1 Load paper into the paper tray.
- 2 Open the document you want to print, then select **File > Print**.
- 3 In the Print dialog box, make sure that **SAMSUNG CJX-1000** is selected.
- 4 In the **Copies & Pages** drop-down list, select **Paper Handling**.
- 5 In the **Pages to Print** drop-down list, select **Odd Only**.
- 6 In the **Page Order** drop-down list, select **Reverse**.
- 7 Click **Print**.
- 8 When the odd pages have finished printing, remove them from the output tray.
- 9 Turn the printed pages over, and place into the input tray (top edge down and printed side away from you).
- 10 Select **File > Print**.
- 11 In the **Copies & Pages** drop-down list, select **Paper Handling**.
- 12 In the **Pages to Print** drop-down list, select **Even Only**.
- 13 In the **Page Order** drop-down list, select **Normal**.
- 14 Click **Print**.

Printing pictures

You can print pictures with your all-in-one printer from a memory card inserted into the memory card slot.

You can also print pictures using Print Manager Software from your computer with WINDOWS OS. Print Manager Software lets you edit and enhance your pictures quickly. Open Print Manager Software, select **Print Pictures**, then follow the on-screen instructions.

On a computer with either MAC OS or WINDOWS OS, you can print pictures from any picture-editing or photo-management software.

Printing pictures from a memory card


Your printer accepts the following memory cards:

- SD Card
- SDHC Card
- MMC Card
- MEMORY STICK
- Variations of the memory cards above that require an adapter (for example, MEMORY STICK Duo, miniSD, and microSD)

IMPORTANT: *If you use a memory card with an adapter, make sure you insert and remove the adapter and the memory card as a unit; do not remove the memory card while leaving the adapter in the printer.*

To print a picture from a memory card:

- 1 Insert the memory card into the memory card slot.



- 2 Use ◀ or ▶ to browse to the picture you want to print, then press **OK**.
- 3 Repeat step 2 for each same-size picture you want to select for printing.
- 4 Select a print size.
 - a Press **Back**.
 - b Press ▼ to select **Print Size**.
 - c Press ▶ to navigate to the size picture you want to print.
- 5 Press **Start** to begin printing.

Viewing pictures on a memory card

When you insert a memory card into the memory card slot on your printer, the pictures on the card appear on the LCD. Press ◀ or ▶ to scroll through the pictures.

If the printer is idle for more than two minutes, the LCD will revert to the status display. To view the pictures again, press any button, then press ◀ or ▶.

Finding pictures on a memory card

Your printer can help you locate pictures on a memory card by the date the picture was taken or last saved.


To locate pictures:

- 1 Insert the memory card into the memory card slot.
- 2 Press **Menu**.
- 3 Press ▼ to select **View / Print Photos**, then press **OK**.
- 4 Press ▼ to select **Find Photos**, then press **OK**.
- 5 In the **View by Date** menu, press to select **Year, Month, or Day**; press ◀ or ▶ to select the specific year, month, or day.
The number of photos found for the date you specified appears under the menu name. To view these pictures, press **OK**.
- 6 To view these pictures, press **OK**.


Using default settings to print a picture

To print a picture from a memory card using the factory default settings:

- 1 Load photo paper (**short side first**) into the center of the input tray with the **glossy side toward you** (see [Loading photo paper](#), page 12), and move the paper-edge guides until they touch the paper.



- 2 Insert the memory card into the memory card slot.



- 3 Press ◀ or ▶ to display the picture you want to print.
- 4 Press **Start** to begin printing.
The printer prints one 4 x 6 in. / 10 x 15 cm picture.


IMPORTANT: *To prevent loss of data from your memory card, do not remove it from the printer while printing.*

Changing the settings and printing pictures

You can change the print photos options for an individual picture or group of pictures, or you can change the settings and save them as the default.

To print a picture or pictures using settings other than the default settings:

- 1 Load photo paper with the glossy side toward you (see [Loading photo paper](#), page 12), and move the paper-edge guides until they touch the paper.
- 2 Insert the memory card into the memory card slot. A picture appears on the LCD.



- 3 Press ◀ or ▶ to select the picture you want to print, then press **OK**.
- 4 Repeat step 3 for each picture you want to print.
- 5 Press **Back** for Print Photos Options.

Basic Functions

- 6 Press ▼ to select an option (see table below), then press ◀ or ▶ to change the setting.

Print Photos Option	Settings	Description
View Photos	--	Scroll through the pictures on the memory card; press OK to select the picture for printing; press Back to display the Print Photos Options menu.
Find Photos	--	Press OK , then select a year, month, and/or day to view photos by date that they were taken; press OK to view the photo(s); press Back to display the Print Photos Options menu.
Transfer All to PC	--	To transfer all the pictures on the memory card to your computer, press OK then Start . (Your printer and computer must be connected with a USB cable.)

Print Photos Option	Settings	Description
Rotate This Photo	--	Press OK , then press ◀ or ▶ to rotate the image on the LCD. (This is for viewing purposes only and does not affect how the picture prints.) Press Back to display the Print Photos Options menu.
Quantity	1 (default) to 99	The number of copies that print.
Color	Color (default)	Prints full color.
	Black & White	Prints black and white (grayscale).
Print Size	2 x 3 3.5 x 5 4 x 6 (default) 4 x 7 4 x 8 5 x 7 4 x 12 8 x 10 8.5 x 11 or A4	If the selected copy size is smaller than the paper in the paper tray, the printer automatically arranges the pictures to best fit the paper size.

Basic Functions

Print Photos Option	Settings	Description
Plain Paper Quality	Normal (default)	Good quality output; prints faster than Best.
	Best	The highest quality.
	Draft	The fastest print speed.
Photo Paper Quality	Auto. (default)	The printer detects photo paper in the paper tray and sets Best quality automatically.
Scene Balance	On (default) Off	Adjusts the image brightness to correct for underexposure and reduces the variation in contrast in different areas of the picture.
Add Date to Prints	No (default) Yes	Prints the date of the picture(s) (the date the picture was taken or last edited) in a corner of the print.
Save as Defaults	No / Yes	To save the settings as the new default, press OK . With Yes selected, press OK .


7 When you have finished changing settings, press **Start** to begin printing.

IMPORTANT: *To prevent loss of data from your memory card, camera, or portable drive, do not remove it from the printer while printing.*

Printing panoramic pictures

To print a panoramic picture, load 4 x 12 in. / 10 x 31 cm paper, or US letter or A4 paper in the main paper tray.

- 1 Insert the memory card into the memory card slot.



- 2 Press ◀ or ▶ to select the panoramic picture you want to print, then press **OK**.
- 3 Press **Back** for Print Photos Options.
- 4 Press ▼ to select **Print Size**, then press ▶ to select **4 x 12**.
- 5 Press **Start**.

IMPORTANT: To prevent loss of data from your memory card, do not remove it from the printer while printing.


Printing tagged pictures

Some digital cameras let you tag (or “mark”) pictures on the memory card for printing. This creates a tag that is recognized by the printer. If you choose to print tagged pictures, they will be printed according to the default settings on your printer (unless otherwise specified by the tag from the camera).

NOTE: Refer to your camera user guide to determine whether your camera supports tagged (also “marked” or “DPOF”) functionality.

To print tagged pictures:

- 1 Load photo paper with the glossy side toward you (see [Loading photo paper, page 12](#)), and move the paper-edge guides until they touch the paper.
- 2 Insert the memory card into the memory card slot.



- 3 When the “Print tagged images?” message appears, press **Start**.

Copying

You can copy documents and pictures with your all-in-one printer. The printer produces high-quality color or black-and-white copies on a variety of paper types (see [Paper types, page 8](#)).

Copying a document


You can copy a document using the default settings, or you can adjust the quantity, size, quality, and brightness of your copies.

Using the default settings to copy a document

The default settings are either the factory default settings (see [Resetting factory defaults, page 61](#)), or defaults that you have set on the printer (see [Save as Defaults, page 24](#)).

To copy a document using the current default settings:

- 1 Lift the scanner lid, and place the document face down in the right-front corner of the scanner glass.



- 2 Close the lid.
- 3 Press **Menu**.
- 4 Press **Start** to begin copying

Adjusting the settings and copying a document

To copy a document using settings other than the default settings:

- 1 Lift the scanner lid, and place the document face down in the right-front corner of the scanner glass.
- 2 Close the lid.
- 3 Press **Menu**.
- 4 With **Copy Document** selected, press **OK**.
- 5 Press ▼ to select an option, then press ◀ or ▶ to change the setting.

Copy Document Option	Settings	Description
Quantity	1 (default) to 99	The number of copies that print.
Color	Color (default)	Prints full color.
	Black & White	Prints black and white (grayscale).
Copy Size	Same Size (default)	The copy is the same size as the original.
	Fit to Page	The printer detects the size of the original on the scanner glass and the size of the paper in the paper tray, and automatically reduces or enlarges the original so that the copy fits on the paper.
	20% to 500%	Reduces down to 20% or enlarges up to 500% of the original size.

Basic Functions

Copy Document Option	Settings	Description
Plain Paper Quality	Normal (default)	Good quality output; prints faster than Best.
	Best	The highest quality, but the slowest print speed; eliminates the banding effect that sometimes occurs when printing Draft or Normal.
	Draft	The fastest print speed, but the lowest quality.
Photo Paper Quality	Auto. (default)	The printer detects photo paper in the paper tray and sets Best quality automatically.
Brightness	Normal, -3 to +3 (Normal is default)	Lightens or darkens the copy. Normal is no change from the original; -3 is the darkest; +3 is the lightest.
Save as Defaults	No / Yes	To save the settings as the new default, press OK . With Yes selected, press OK .

6 Press **Start** to begin copying.

Changing the number of copies of a document

To change the number of copies:

- 1 Lift the scanner lid, and place the document face down in the right-front corner of the scanner glass.
- 2 Close the lid.
- 3 Press **Menu**.
- 4 With **Copy Document** selected, press ◀ or ▶ to select a number.
- 5 Press **Start** to begin copying.

Enlarging or reducing a document

To enlarge or reduce the size of the copy:

- 1 Lift the scanner lid, and place the document face down in the right-front corner of the scanner glass.
- 2 Close the lid.
- 3 Press **Menu**.
- 4 With **Copy Document** selected, press **OK**.
- 5 Press to select **Copy Size**.
- 6 Press ◀ or ▶ to select an enlargement or reduction.
- 7 Press **Start** to begin copying.

Darkening or lightening a copy

To darken or lighten the copy:

- 1 Lift the scanner lid, and place the document face down in the right-front corner of the scanner glass.
- 2 Close the lid.
- 3 Press **Menu**.
- 4 With **Copy Document** selected, press **OK**.
- 5 Press ▼ to select **Brightness**.
- 6 Press ◀ to select a number below zero for a darker copy, or press ▶ to select a number above zero for a lighter copy.
- 7 Press **Start** to begin copying.

Copying a photograph

You can copy a photograph using the default settings, or you can adjust the quantity, size, quality, and brightness of your copies.

Using the default settings to copy a photograph

The default settings are either the factory default settings (see [Resetting factory defaults, page 61](#)), or defaults that you have set on the printer (see [Save as Defaults, page 24](#)).

To copy a photograph using the current default settings:

- 1 Load photo paper into the printer (see [Loading photo paper, page 12](#)).
- 2 Lift the scanner lid, and place the photograph face down in the right-front corner of the scanner glass.

- 3 Close the lid.
- 4 Press **Menu**.
- 5 Press ▼ to select **Copy Photo**.
- 6 Press **Start** to begin copying.

Adjusting the settings and copying a photograph

To copy a photograph using settings other than the default settings:

- 1 Lift the scanner lid, and place the photograph face down in the right-front corner of the scanner glass.
- 2 Close the lid.
- 3 Press **Menu**.
- 4 Press ▼ to select **Copy Photo**, then press **OK**.
- 5 Press ▼ to select an option, then press ◀ or ▶ to change the setting.

Copy Photo Option	Settings	Description
Quantity	1 (default) to 99	The number of copies that print.
Color	Color (default)	Prints full color.
	Black & White	Prints black and white (grayscale).

Basic Functions

Copy Photo Option	Settings	Description
Copy Size	2 x 3	The printer enlarges or reduces the original to make it the copy size you select. If the selected copy size is smaller than the paper in the paper tray, the printer automatically arranges the pictures to best fit the paper size.
	3.5 x 5	
	4 x 6 (default)	
	4 x 7	
	4 x 8	
	5 x 7	
	4 x 12	
	8 x 10	
8.5 x 11 or A4		
Plain Paper Quality	Normal (default)	Good quality output; prints faster than Best.
	Best	The highest quality, but the slowest print speed; eliminates the banding effect that sometimes occurs when printing Draft or Normal.
	Draft	The fastest print speed, but the lowest quality.

Copy Photo Option	Settings	Description
Photo Paper Quality ^a	Auto. (default)	The printer detects photo paper in the paper tray and sets Best quality automatically.
Brightness	Normal (default) -3 to +3	Lightens or darkens the copy. Normal is no change from the original; -3 is the darkest; +3 is the lightest.
Preview	No (default) Yes	To see a preview of the photograph on the LCD, select Yes .
Save as Defaults	No / Yes	To save the settings as the new default, press OK . With Yes selected, press OK .

- a. For photo paper quality copies, load photo paper into the printer (see [Loading photo paper](#), page 12)

6 Press Start to begin copying.

Changing the number of copies of a photograph

To change the number of copies:

- 1 Lift the scanner lid, and place the photograph face down in the right-front corner of the scanner glass.
- 2 Close the lid.
- 3 Press **Menu**.
- 4 Press ▼ to select **Copy Photo**, then press **OK**.
- 5 Make sure **Quantity** is selected.
- 6 Press ◀ or ▶ to select a number.
- 7 Press **Start** to begin copying.

Enlarging or reducing a photograph

To enlarge or reduce the size of the copy:

- 1 Lift the scanner lid, and place the photograph face down in the right-front corner of the scanner glass.
- 2 Close the lid.
- 3 Press **Menu**.
- 4 Press ▼ to select **Copy Photo**, then press **OK**.
- 5 Press ▼ to select **Copy Size**.
- 6 Press ◀ or ▶ to select the copy size.
- 7 Press **Start** to begin copying.

Darkening or lightening a photograph

To darken or lighten the copy:

- 1 Lift the scanner lid, and place the photograph face down in the right-front corner of the scanner glass.
- 2 Close the lid.
- 3 Press **Menu**.
- 4 Press ▼ to select **Copy Photo**, then press **OK**.
- 5 Press ▼ to select **Brightness**.
- 6 Press ◀ to select a number below zero for a darker copy, or press ▶ to select a number above zero for a lighter copy.
- 7 Press **Start** to begin copying.

Scanning

Scanning digitizes documents and pictures, and sends the digital files to your computer.

When you scan, the digital file can:

- Open in Print Manager Software (when connected to a computer with WINDOWS OS)
- Open in a third-party scanner software
- Be saved in a format and location that you determine (see [Changing the scan settings for scanning from the control panel, page 38](#)).

There are two ways to scan: From the control panel on the printer, or from a software program on the computer. Scanning from a software program on the computer (such as Print Manager Software) is recommended because it gives you more options.

Before you begin scanning

Make sure that the printer is connected to a computer using a USB cable. If you plan to scan directly from the printer control panel, change the scan settings as described below.

Changing the scan settings for scanning from the control panel

Adjust the scan settings that the printer uses before you scan from the printer control panel.

- 1 Open the Printer Tools window.
 - On a computer with WINDOWS OS, select **Start > All Programs > Samsung > Samsung AiO Printer Tools**.
 - On a computer with MAC OS, open Print Manager Software, then select the **Tools** tab.

- 2 Under the Tools heading, select Printer Scan Settings.
- 3 Adjust settings for scanning documents and pictures:
 - a To select a program that scanned images or documents will appear in when you scan from the printer control panel:
 - (1) Select the **General** tab.
 - (2) Under the Program List heading, click ▼ next to the currently selected program.
 - (3) From the drop-down list, select the program in which you want the scanned files to open.
 - b To adjust settings for scanning documents, select the Document tab, then select an option for each setting:

Setting	Options
Scan As	Black and white Color Grayscale
File format	.pdf .rtf (available only when connected to a computer with WINDOWS OS) .tif .jpg .bmp (available only when connected to a computer with MAC OS)

Setting	Options
Resolution (dpi)	75 150 200 300
File Save	Prompt for File Name and Location Automatically Save - specify: <ul style="list-style-type: none">■ Base name; by default, scanned files are names "scan1", "scan2", and so on.■ Location (folder) where the scanned files will be saved

- C** To adjust settings for scanning pictures, select the **Picture** tab, then select an option for each setting:

Setting	Options
Scan As	Color Black and white
File format	.jpg .bmp .tif

Setting	Options
Resolution (dpi)	75 150 200 300 600
Quality	When connected to a computer with WINDOWS OS: <input type="checkbox"/> Best for E-mail <input type="checkbox"/> Normal <input type="checkbox"/> High <input type="checkbox"/> Maximum When connected to a computer with MAC OS, a slider bar with: <input type="checkbox"/> Least <input type="checkbox"/> Medium <input type="checkbox"/> Best
Automatically Detect Pictures (when connected to a computer with WINDOWS OS) or Auto Crop (when connected to a computer with MAC OS)	When selected, multiple pictures placed on the scanner glass are saved as separate files.

Setting	Options
File Save	Prompt for File Name and Location Automatically Save - specify: <ul style="list-style-type: none">■ Base name; by default, scanned files are names "scan1", "scan2", and so on.■ Location (folder) where the scanned files will be saved

NOTE: Before you save a scanned file, you will be able to preview it in Print Manager Software, crop and sharpen the image, and adjust color, if desired. On a computer with WINDOWS OS, see the Print Manager Software Help (? icon) for instructions.

- 4 When you are finished making selections, click **OK** on the bottom right of the Printer Scan Settings window.
- 5 Close the Printer Tools window.

Scanning from the computer

To scan a document or a picture on a computer:

- 1 Lift the scanner lid, and place the document or picture face down on the glass.
- 2 Close the scanner lid.
- 3 Open Print Manager Software.
 - On a computer with WINDOWS OS, double-click **Scan Documents and Pictures**, then follow the on-screen instructions.
 - On a computer with MAC OS and Print Manager Software, select the **Tools** tab, click **Scan Application**, then follow the on-screen instructions.

NOTE: If you are not using Print Manager Software, open a program that allows you to scan, then follow the instructions.

Scanning multiple pictures simultaneously

Using Print Manager Software, you can scan multiple pictures simultaneously and save them as separate files.

When scanning multiple pictures, leave space between the pictures so that the printer can detect the separate pictures. Any pictures that overlap are interpreted as a single picture.

Scanning multiple pictures when connected to a computer with WINDOWS OS

To scan multiple pictures simultaneously, and save them as separate files:

- 1 Lift the scanner lid, and place the pictures face down on the glass, leaving space between the pictures.
- 2 Close the lid.
- 3 Open Print Manager Software, then double-click **Scan Documents and Pictures**.
- 4 Make sure that **Picture** is selected and **Collage - Combine all pictures** is cleared, then follow the on-screen instructions.

NOTE: Click the Help icon for additional instructions.

Scanning multiple pictures when connected to a computer with MAC OS

To scan multiple pictures simultaneously, and save them as separate files:


- 1 Lift the scanner lid, and place the pictures face down on the glass, leaving space between the pictures.
- 2 Close the lid.
- 3 Open Print Manager Software, then select your printer.
- 4 Select the **Tools** tab.
- 5 Click **Scan Application**.
- 6 Select **Color Picture** or **Black and White Picture**.
- 7 Select **Automatically detect multiple pictures**, if it is not selected.
- 8 Click **Preview** or **Scan All**, then follow the on-screen instructions.

NOTE: Click the Help icon for additional instructions.

Scanning from the control panel

To scan a document or a picture from the control panel:

- 1 Lift the scanner lid, and place the original document or picture face down in the right-front corner of the scanner glass.



- 2 Close the lid.
- 3 Press **Menu**.
- 4 Press \blacktriangledown to select **Scan**, then press **OK**.
The Scan Options menu appears on the LCD.
- 5 Press \blacktriangledown to select an option, then press \blacktriangleleft or \blacktriangleright to change the setting.

Scan Option	Settings	Description
Scan To	USB computer (default)	The scanned file is sent to the USB-connected computer.
	Name of computer (only if a computer is connected by wireless network)	The scanned file is sent to the computer on the wireless or Ethernet network.
	Memory Card	The scanned file is sent to the memory card in the memory card slot
Scan What	Document (default)	Sets the scan settings for scanning a document (see Changing the scan settings for scanning from the control panel, page 38).
	Photo	Sets the scan settings for scanning a photograph (see Changing the scan settings for scanning from the control panel, page 38).

Scan Option	Settings	Description
Scan Dest. (Destination)	File (default)	Sends the scanned file in the format and to the destination on your computer that you designate (see Changing the scan settings for scanning from the control panel, page 38).
	Application	Sends the scanned file to Print Manager Software.
Save as Defaults	No / Yes	To save the settings as the new default, press OK . With Yes selected, press OK .

- 6** Press Start to make a scan.
The scanned file appears at the destination you specified.

Ordering supplies

You can order ink cartridges online.

To order supplies, make sure that your computer is connected to the Internet, then:

- 1** Open Print Manager Software.
- 2** Select **Order Supplies**.
- 3** Select the item(s) you want to buy, then follow the on-screen instructions.

3

Maintaining Your Printer

Your printer requires little maintenance. However, Samsung recommends cleaning the scanner glass and lid regularly to remove dust and fingerprints, which affect the quality and accuracy of scanning.

Except while cleaning the printer, keep the printer plugged into an AC power outlet. If you use a power strip, don't turn off the power strip. (The printer does not need to be turned on but should be plugged in.)

For optimal performance, keep the printer connected to a computer that is powered on and has the SAMSUNG Print Manager Software installed, or keep the printer powered on and connected to the Internet through a wireless network.

Keep the printhead and ink cartridges in the printer at all times to help prevent damage to the printhead.

For recycling and/or disposal information, contact your local authorities. In the US, go to the Electronics Industry Alliance at www.eia.org.

General care and cleaning

 CAUTION:

Always disconnect the power to the printer before cleaning it. Do not use harsh or abrasive cleaners on any part of the printer.

- To clean the printer, wipe the outside with a clean, dry cloth.
- Keep the surrounding area vacuumed and litter-free.
- Protect the printer from tobacco smoke, dust, and liquid spills.
- Do not place objects on the printer.
- Keep the input tray free of dust, dirt, and other foreign objects.
- Keep the printer supplies away from direct sunlight and out of high-temperature environments.
- Do not allow chemicals to come into contact with the printer.

Cleaning the scanner glass and document backing

The scanner glass can get smudged and minor debris can accumulate on the white document backing under the scanner lid. Periodically clean the scanner glass and document backing.

 CAUTION:


Do not use harsh or abrasive cleaners on any part of the printer.

Do not spray liquid directly on the glass.


Do not use paper-based wipes on the document backing as they can scratch it.

To clean the scanner glass and document backing under the scanner lid:

- 1 Turn off the printer and unplug it from the power outlet.
- 2 Lift the scanner lid.




- 3 Wipe the glass with a soft cloth or sponge, slightly moistened with a nonabrasive glass cleaner.



Maintaining Your Printer

- 4 Dry the glass with a lint-free cloth.
- 5 Gently clean the document backing with a soft cloth or sponge, slightly moistened with mild soap and warm water.



- 6 Dry the document backing with a chamois or lint-free cloth.

NOTE: If the document backing needs further cleaning, use isopropyl (rubbing) alcohol on a soft cloth, then wipe thoroughly with a cloth moistened with water to remove any residual alcohol.

- 7 When you finish cleaning, plug in the printer and press the on/off button to power on the printer.


Replacing ink cartridges

Your printer uses both black and color ink cartridges. You can check the approximate ink levels on the LCD (see [Checking ink levels, page 61](#)). When an ink cartridge is out of ink, the printer LCD displays a message stating that the black or color ink cartridge needs replacing. You can order ink cartridges online. Open Print Manager Software and select Order Supplies.


IMPORTANT: *Do not use refilled ink cartridges.*

To replace an ink cartridge:


- 1 Make sure your printer is on.
- 2 Lift the printer access door, and wait for the carriage to move to a position where you can access it.




- 3** The ink cartridges are located in the printhead.




- 4** Pinch the tab on the ink cartridge.



- 5 Lift the ink cartridge out of the printhead.




- 6 Remove the new ink cartridge from its bag.




IMPORTANT: *To prevent the printhead from drying out, insert the ink cartridge into the printhead immediately.*


- 7** Remove the protective cap from the cartridge.



- 8** Insert the ink cartridge into the printhead.



- 9** Press down on the ink cartridge tab until you hear a click.



- 10** Close the printer access door.

Updating the software and printer firmware

Using the latest software and firmware helps ensure optimal performance of your printer.

NOTE: Firmware is the software that runs on your printer.

Although there is a background check for software and firmware updates, you may update manually using the following procedure.

Updating if your printer is connected to a computer with WINDOWS OS

To update the software:

- 1 Make sure that your computer is connected to the Internet.
- 2 Select **Start > All Programs > Samsung > Samsung AiO Printer Tools**.
- 3 Under Printer Resources, click **Check for Software Updates** to check whether software updates are available.
- 4 If there are updates, click **Next** and follow the on-screen instructions.

To update the printer firmware:

- 1 Make sure that your computer is connected to the Internet.
- 2 Connect the printer to the computer with a USB cable or wirelessly (if not currently connected).
- 3 Select **Start > All Programs > Samsung > Samsung AiO Printer Tools**.
- 4 Make sure that **Samsung CJX-1000 Series AiO - Connected** appears in the lower left corner of the Printer Tools window.

NOTE: If **Samsung CJX-1000 Series AiO - Connected** does not appear in the lower left corner, click **Select**, then click **Refresh List** and choose your printer from the list; click **Install Samsung Printer** and follow the on-screen instructions.

- 5 Under Printer Resources, click **Check for Printer (Firmware) Updates**.
- 6 If there are updates, click **Next** and follow the on-screen instructions.

IMPORTANT: *Do not turn off or unplug your printer or your computer during the update. Doing so may cause the printer to become inoperable. If the printer is connected wirelessly, make sure you have a stable connection when you perform the update.*

Updating if your printer is connected to a computer with MAC OS

To update the software:

- 1 Make sure that your computer is connected to the Internet.
- 2 Open Print Manager Software.
- 3 Select the **Tools** tab.
- 4 Click **Check for Software Updates**.
- 5 If there are software updates, follow the on-screen instructions for updating your software.

To update the firmware:

- 1 Make sure that your computer is connected to the Internet.
- 2 Connect the printer to the computer with a USB cable or wirelessly (if not currently connected).
- 3 Open Print Manager Software.
- 4 Select the **Tools** tab.
- 5 Click **Check for Printer (Firmware) Updates**.
- 6 If there are updates, follow the on-screen instructions.

IMPORTANT: *Do not turn off or unplug your printer or your computer during the update. Doing so may cause the printer to become inoperable.*

Monitoring and adjusting printer performance

From the control panel, you can perform tasks to help keep the printer functioning well.

Checking ink levels

To check the ink levels:

- 1 Press **Menu**.
- 2 Press ▼ to select **Maintenance**, then press **OK**.
- 3 With **Check Ink Levels** selected, press **OK**.
The LCD shows approximate levels of ink in the cartridges so you know when it's time to order replacement cartridges.

NOTE: You can order ink cartridges online. Open Print Manager Software and select **Order Supplies**.

Resetting factory defaults

To reset defaults to the factory default settings:

- 1 Press **Menu**.
- 2 Press ▼ to select **Printer Settings**, then press **OK**.
- 3 Press ▼ to select **Reset All Settings**, then press **OK**.
- 4 When you see the message, "This will reset printer settings to factory defaults," press **OK**.


NOTE: Resetting factory defaults does not change the date and time, language, country/region, or network settings.

Replacing the printhead


IMPORTANT: *Replacing the printhead is not a regular maintenance procedure. Replace the printhead only if you receive a new printhead from Samsung.*

To replace the printhead:


- 1 Make sure your printer is on.
- 2 Lift the printer access door, and wait for the carriage to move to the access position.




- 3 Remove both ink cartridges and set them aside.




- 4 Unlatch the used printhead by lifting the button in the center of the carriage.



- 5 Lift the used printhead out of the carriage.




- 6 Remove the new printhead from its bag.



⚠ CAUTION:


Do not touch the copper contacts on the printhead, as doing so may damage the printhead.

- 7 Remove the plastic protective cap.




IMPORTANT: *Be careful not to scratch or touch the copper contacts while inserting the printhead.*


- 8 Place the new printhead into the carriage.




- 9** Push firmly against the target label of the printhead until you hear a loud snap.





- 10** Insert the black ink cartridge into the printhead.



- 11** Press down on the ink cartridge until you hear it click into position.



- 12** Repeat steps 10 - 11 for the color ink cartridge.



- 13** Close the printer access door.
The printer detects the new printhead. Follow the instructions on the LCD to calibrate your printer.

Basic troubleshooting

Some problems can be resolved quickly by power cycling the printer: Turn off your printer. Wait five seconds. Turn on the printer.

Use the following information to help troubleshoot problems with your printer.

Problem	Possible Solutions
Printer does not power on	<ul style="list-style-type: none">■ Make sure you are using the power cord that came with your printer.■ Make sure the power cord is connected to the AC adapter, it is plugged into an outlet or power strip, and that the LED on the AC adapter is lit.
Printer not detected	<p>Make sure that:</p> <ul style="list-style-type: none">■ your printer is plugged in and turned on.■ your USB cable:<ul style="list-style-type: none">– is a USB 2.0 high-speed cable.– is connected to both your printer and your computer.■ you restart the computer if the USB cable was disconnected from the printer then reconnected, or if power to the printer was interrupted.

Problem	Possible Solutions
Carriage jam	<ul style="list-style-type: none">■ Open the printer access door and clear any obstructions.■ Check that the printhead and ink cartridges are installed correctly. (The printhead and ink cartridges are installed correctly when you hear them click into place.)
Print quality	<ul style="list-style-type: none">■ For best results, use KODAK Paper or a paper with the COLORLOK Technology logo on the package.■ Make sure the paper is loaded correctly. See Loading paper, page 8.■ Clean the printhead:<ul style="list-style-type: none">– Press Menu.– Press ▼ to select Maintenance, then press OK.– Press ▼ to select Clean Printhead, then press OK.■ Calibrate the printer:<ul style="list-style-type: none">– Press Menu.– Press ▼ to select Maintenance, then press OK.– Press ▼ to select Calibrate Printer, then press OK.

Problem	Possible Solutions
Ink cartridge errors	<ul style="list-style-type: none"> ■ Check that Ink Cartridge(s) are installed. Do not use refilled ink cartridges. ■ Remove, then install the cartridges again. Make sure the cartridges click into place.
Paper jam	<ul style="list-style-type: none"> ■ Open the printer access door and gently remove any paper from inside the printer. ■ Make sure the paper in the tray is free of tears or creases. ■ Make sure you do not overload the input paper tray. ■ If you cannot access the paper from the front, gently pull the jammed paper up from the paper input tray.
Error codes/ messages	<p>Go to http://www.samsung.com/uk/support/download/supportDownloadMain.do</p>

Power light

The power light (by the on/off button) indicates the condition of the printer.

Power light	What it means
Off	<ul style="list-style-type: none">■ The printer is turned off.<ul style="list-style-type: none">– Press the on/off button to turn on power.■ The printer does not have power.<ul style="list-style-type: none">– Make sure that the power cord is plugged into the■ back of the printer and into an electrical outlet, and that the electrical outlet has power.
Blinking	<ul style="list-style-type: none">■ The printer is busy.<ul style="list-style-type: none">– Wait for the printer to finish the task.
On	<ul style="list-style-type: none">■ The printer is ready.

5

Product and Safety Specifications

The following specifications are subject to change without notice.

Specifications and features

Print performance

ISO/IEC 24374 ESAT 7 ipm

ISO/IEC 24374 ESAT 4.6 ipm

Print technology Continuous-tone, thermal inkjet

Print quality modes Draft, Normal, and Best on plain paper Photo quality mode on photo paper

Photo printing features

Quantity 1 to 99

Print sizes 2 x 3 in. / 5 x 8 cm

3.5 x 5 in. / 9 x 13 cm

4 x 6 in. / 10 x 15 cm

4 x 7 in. / 10 x 18 cm

4 x 8 in. / 10 x 20 cm

4 x 12 in. / 10 x 30 cm (Panoramic)

Print sizes	5 x 7 in. / 13 x 18 cm 8 x 10 in. / 20 x 25 cm US Letter - 8.5 x 11 in. / 22 x 28 cm A4 - 8.3 x 11.7 in. / 21 x 30 cm
Quality	Best, Normal, Draft modes on plain paper Photo quality mode on photo paper
Auto-detect media	Auto-detect plain paper and photo papers Optimize image quality for KODAK Photo Papers with barcode
Image enhancement	Image Enhancement Technology with Print Manager Software
Add date to prints	No (default), Yes
Color	Black-and-white or color
Scene balance	On (default), Off

Copy document features

Color	Black-and-white or color
Quantity	1 to 99 copies
Copy sizes	Same Size, Fit-to-Page, 20% to 500%
Plain paper quality	Best, Normal, Draft

Brightness – 3 to + 3

Copy photo features

Color Black-and-white or color

Quantity 1 to 99 copies

Copy sizes 2 x 3 in. / 5 x 8 cm
3.5 x 5 in. / 9 x 13 cm
4 x 6 in. / 10 x 15 cm
4 x 7 in. / 10 x 18 cm
4 x 8 in. / 10 x 20 cm
4 x 12 in. / 10 x 30 cm (Panoramic)
5 x 7 in. / 13 x 18 cm
8 x 10 in. / 20 x 25 cm
US Letter - 8.5 x 11 in. / 22 x 28 cm
A4 - 8.3 x 11.7 in. / 21 x 30 cm

Quality Automatic

Brightness – 3 to + 3

Scanning features

Scanner type	Contact Image Sensor (CIS)
Maximum scan size	8.5 x 11.7 in. / 22 x 30 cm
Functions	Segmentation scanning Auto-destination OCR Auto picture detection

Paper input tray features

Paper capacity	100 sheets of 20 lb plain paper 20 sheets of photo paper, up to 12 mil (290 gsm) 20 envelopes
Tray size	4 x 6 in. to 8.5 x 14 in. / 10 x 15 cm to 22 x 36 cm

Ink cartridges

Ink life The number of pages may be affected by operating environment, printing interval, media type, and media size.

Based on ISO 24712 5% COVERAGE PATTERN

- See [A sample of 5% COVERAGE PATTERN \(reduced to 33%\)](#), page 78.

(supplied with the machine; INK-M210): About 250 sheets

(supplied with the machine; INK-M215): About 430 sheets

(supplied with the machine; INK-C210): About 250 sheets

A sample of 5% COVERAGE PATTERN (reduced to 33%)

Stephen J. Singel
Fahanda Singat Abarrus
Tendar, BSF
UKANGLE


30 November 2005

Johnathan Q. Maderia

Inpet Mampem Abures
2343 Stanton Dawer Lank
Benbibe, SDF

Mr. Maderia:

Nam liber tempor cum soluta nobis eleifend priam cogue nihil conseqat, velillum. Dolore eu zril feugiat nulla acillio at vero eros accusam et iust odio dignis sim qui blandi praecet litatum rii lobortis nisi ut aliquip exea commodo conseqat. Duis autem vel eum irure dolor in hendrerit ulputate velit esse molestie incidunt ut laoreet dolore magna aliquam erat volutpat. Ut wisi enim ad minim vhtiam, quis nostrud exerci tation ullam corporus cipi ts nisi



Amet, Amet, consectetur adipiscing eli, sed diam nonummy nibh veniam, excepte adipiscing elit, sed diam nonummy nibh laoreet dolore magnama allam erat volutpat. Ut wisi enim minim veniam, quisent nostrud. Solyom uta nobis eleifendopti cogue nihil inendiet domg id quod mrim plerat facer posim aum. Lorem ipsum dolor sit amet, conseqat. Duis autem vel eum irure dolor in hendrerit vulputate velit cesse ea commodo molestie. Nam liber tempor cum soluta nobis eleifend optiun cogue nihil conseqat, velillum. Dolore eu zril feugiat nulla facilisis at vero eros accusam et iusto odio dignissim qui blandi praesent domg id quod mrim plerat facer posim aum.

Integer sagittis lacus vel nulla. Morbi convallis hendrerit risus. Nullam interdum, enim non gravida feugiat, quam ante conseqat metus, sed molestie dolor tortor ea ipsum. Phasellus semper risus sit amet diam. Cras wisi arcu, pulvinar nec, molestie frangilla, vestibulum laculis, mi. Praesent nonummy pulvinar odio.

Duis vitae eros. Fusce suscipit. Etiam justo massa, semper feugiat, portitor sit amet, nonummy in, quam. Aenean nulla magna, elementum ut, eleifend ac, aliquam sit, risus. Morbi laoreet elementum dai. Vestibulum nibh sapien, rhocnus non, lobortis nec, ullamcorper a, enim. Praesent ultricies enim non lorem. Curabitur conseqatetur, diam et nonummy convallis, quam quam tristique nulla, pulvinar blandi ipsum arcu a tellus. Phasellus dolor. Ut ullamcorper venenatis quam. Quisque egestas erat.

Singabet.

Stephen J. Singel
Demperfa Ammerinum
Fahanda Singat Abarrus
SIS:dwg



Connectivity

- Protocols supported** USB 2.0 High Speed; DPOF
- Devices supported** WINDOWS OS-based and MACINTOSH Computers, memory cards (SD, MS/Duo, MMC, SDHC)
- Image Formats supported** Image printing supports JPEG (EXIF v2.2); does not support progressive JPEG format
- Number of USB ports** One rear device port (high speed)
- Protocols supported** USB 2.0 High Speed (for connection to computer only), DPOF (Tagged image printing)

Software support

- Application support** Third-party image management applications; optical character reader (OCR) support for documents
- Media support** Plain paper, photo paper, envelopes, greeting cards, and labels
- Scanner support** TWAIN and WIA, WIA2 (VISTA OS and WINDOWS 7), ICA (MAC OS), including segmentation scanning
- Update support** Software and firmware updates available through Web support

Physical specifications

Power Input: 100–240 V AC, 50–60 Hz

The printer shall only be used with the provided certified external power supply.

Manufacturer and model:
Chicony Power Technology Co., Ltd, model
A10-018N3A

Output: 36 V DC at 0.5 A

Dimensions 16.5. x 6.7. x 12.6 in. / 420 x 170 x 320 mm [L x H x D]

Weight 12.7 lb / 5.7 kg

Operating range 5°C (41°F) to 35°C (95°F), 15 to 85% RH

Full image quality environmental range 15°C (59°F) to 30°C (86°F), and 20 to 80% RH.

Energy efficiency ENERGY STAR® Qualified All-in-One Printer

System requirements

Computer with WINDOWS OS

Computer	Minimum
Operating system	WINDOWS 7, VISTA, or XP (SP2 or later)
CPU	INTEL CELERON Processor
Clock speed	1.2 GHz
Memory	512 MB RAM
Available hard disk space	500 MB available
Interface	USB 2.0 High Speed
Removable drive	CD-ROM

Computer with MAC OS

Computer	Minimum
Operating system	MAC OS X 10.5 or later
CPU	PowerPC G4, G5, or INTEL-based MAC
Clock speed	1.2 GHz
Memory	512 MB RAM
Available hard disk space	200 MB available

Computer	Minimum
Interface	USB 2.0 High Speed
Removable drive	CD-ROM

Paper types supported

Plain paper	16 to 24 lb (60 to 90 gsm)
Photo paper	Up to 12 mil (290 gsm)
Card stock	110 lb index max (200 gsm)
Envelopes	20 to 24 lb (75 to 90 gsm)
Labels	All commercially available inkjet varieties on 8.5 x 11 in. and A4 size sheets
Iron-on transfers	All commercially available inkjet varieties on 8.5 x 11 in. and A4 size sheets

Paper sizes supported

Plain paper	A4 (8.3 x 11.7 in. / 21 x 30 cm)
	A5 (5.8 x 8.3 in. / 15 x 21 cm.)
	A6 (4.1 x 5.8 in. / 11 x 15 cm)
	B5 (6.9 x 9.8 in. / 18 x 25 cm)
	US Executive (7.3 x 10.5 in. / 18 x 27 cm)
	US Letter (8.5 x 11 in. / 22 x 28 cm)
	US Legal (8.5 x 14 in. / 22 x 36 cm)
	Custom sizes from 4 to 8.5 in. / 10 to 22 cm wide and 6 to 14 in. / 15 to 36 cm long
Labels	A4 (8.3 x 11.7 in. / 21 x 30 cm)
	US Letter (8.5 x 11 in. / 22 x 28 cm)
Index card stock	4 x 6 in. / 10 x 15 cm cards
	5 x 7 in. / 13 x 18 cm index cards
Iron-on transfers	A4 (8.3 x 11.7 in. / 21 x 30 cm)
	US Letter (8.5 x 11 in. / 22 x 28 cm)

Envelopes	C5 (6.7 x 9 in. / 16 x 23 cm)
	C6 (4.5 x 6.4 in. / 11 x 16 cm)
	DL (designated long) (11 x 22 cm / 4.3 x 8.7 in.)
	US #7 $\frac{3}{4}$ (3.9 x 7.5 in. / 10 x 19 cm)
	US #9 (3.9 x 8.9 in. / 10 x 23 cm)
	US #10 (4.1 x 9.5 in. / 10.5 x 24 cm)
Photos	4 x 6 in. / 10 x 15 cm
	4 x 7 in. / 10 x 18 cm
	4 x 8 in. / 10 x 20 cm
	4 x 12 in. / 10 x 31 cm
	5 x 7 in. / 13 x 18 cm
	8 x 10 in. / 20 x 25 cm
	US Letter (8.5 x 11 in. / 22 x 28 cm)
	A4 (8.3 x 11.7 in. / 21 x 30 cm)

Safety Information

SAMSUNG CJX-1000 All-in-One Printers are Class 1 LED Products.

When using this machine, these basic safety precautions should always be followed to reduce risk of fire, electric shock, and injury to persons:

- 1** Read and understand all instructions.
- 2** Use common sense whenever operating electrical appliances.
- 3** Follow all warnings and instructions marked on the product and in the literature accompanying the product.
- 4** Use only the power source provided with the printer.
- 5** Use only the power cord that comes with the product (or an approved power cord greater or equal to H05W-F, 2G, 0.75mm²). Using another power cord may cause fire and/or shock. Do not use the included power cord with any other equipment.
- 6** If an operating instruction appears to conflict with safety information, heed the safety information. You may have misunderstood the operating instruction. If you cannot resolve the conflict, contact your sales or service representative for assistance.
- 7** Unplug the machine from the AC wall socket and telephone jack before cleaning. Do not use liquid or aerosol cleaners. Use only a damp cloth for cleaning.
- 8** Do not place the machine on an unstable cart, stand, or table. It may fall, causing serious damage.

Safety Information

- 9** Your machine should never be placed on, near, or over a radiator, heater, air conditioner, or ventilation duct.
- 10** Do not allow anything to rest on the power or telephone cords. Do not locate your machine where the cables may be damaged by people walking on them. Do not place the machine where the power or telephone cord may be bent. Any case of above may cause the hazardous result or malfunction.
- 11** Do not overload wall outlets and extension cords. This can diminish performance, and may result in the risk of fire or electric shock.
- 12** Do not allow pets to chew on the AC power, telephone, or PC interface cords.
- 13** Never push objects of any kind into the machine through case or cabinet openings. They may touch dangerous voltage points, creating a risk of fire or shock. Never spill liquid of any kind onto or into the machine.
- 14** To reduce the risk of electric shock, do not disassemble the machine. Take it to a qualified service technician when repair work is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly could cause electric shock when the unit is subsequently used.
- 15** Unplug the machine from the telephone jack, PC, and AC wall outlet, and refer servicing to qualified service personnel under the following conditions:
 - *When any part of the power cord, plug, or connecting cable is damaged or frayed.*
 - *If liquid has been spilled into the product.*
 - *If the product has been exposed to rain or water.*
 - *If the product does not operate properly after instructions have been followed.*
 - *If the product has been dropped, or the cabinet appears damaged.*
 - *If the product exhibits a sudden and distinct change in performance*

- 16** Adjust only those controls covered by the operating instructions. Improper adjustment of other controls may result in damage, and may require extensive work by a qualified service technician to restore the product to normal operation.
- 17** Avoid using this fax machine during a lightning storm. There may be a remote risk of electric shock from lightning. If possible, unplug the AC power and telephone for the duration of the lightning storm.
- 18** Do not install the machine on a wet place. This may raise a risk of fire or shock.
- 19** CAUTION: For electrical safety reasons disconnect from telecommunications network before touching metal/conductive parts.
- 20** CAUTION: To reduce the risk of fire, use only No.26 AWG or larger telecommunication line cord.
- 21** CAUTION: Use only the cords and other accessories supplied with the product. Using others may cause the hazardous result or malfunction.
- 22** SAVE THESE INSTRUCTIONS.

LCD Screen Safety

- Use only a dry, soft cloth to clean the LCD screen. Do not use any liquid or chemical cleaners.
- If the LCD screen is damaged, contact SAMSUNG immediately. If any of the solution from the display gets on your hands, wash them thoroughly with soap and water. If the liquid crystal solution gets into your eyes, flush your eyes immediately with water. If any discomfort or change in vision persists after washing, seek medical attention immediately.

Ink Cartridge Safety

- Keep all ink cartridges out of the reach of children.
- If ink gets on your skin, wash with soap and water. If ink gets into your eyes, flush your eyes immediately with water. If any discomfort or change in vision persists after washing, seek medical attention immediately.

Declaration of Conformity (European countries)

Approvals and Certifications



The CE marking applied to this product symbolises Samsung Electronics Co., Ltd. Declaration of Conformity with the following applicable 93/68/EEC Directives of the European Union as of the dates indicated:

January 1, 1995: Council Directive 73/23/EEC Approximation of the Member States related to low voltage equipment.

January 1, 1996: Council Directive 89/336/EEC (92/31/EEC), approximation of the Member States related to electromagnetic compatibility.

March 9, 1999: Council Directive 1999/5/EC on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity. A full declaration, defining the relevant Directives and referenced standards can be obtained from your Samsung Electronics Co., Ltd. representative.

German compliance statement

 CAUTION:

This device is not intended for use in the direct field of view at visual display workplaces. To avoid incommoding reflections at visual display workplaces this device must not be placed in the direct field of view.

 CAUTION:

Das Gerät ist nicht für die Benutzung im unmittelbaren Gesichtsfeld am Bildschirmarbeitsplatz vorgesehen. Um störende Reflexionen am Bildschirmarbeitsplatz zu vermeiden, darf dieses Produkt nicht im unmittelbaren Gesichtsfeld platziert werden.

Noise emissions for this equipment do not exceed 70 dBa.

This equipment is not intended for use in the workplace in accordance with Bildschirmarbeitsplatz regulations.

“Das Gerät ist nicht für die Benutzung am Bildschirmarbeitsplatz gemäß Bildschirmarbeitsplatz vorgeseher.“

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)



This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

ENERGY STAR® Qualified

To conserve energy, this printer will enter a reduced power (sleep) mode automatically after 1 hour. You can adjust the delay time (in 0.5 hour increments) up to 4 hours. Increasing the delay time may result in reduced energy savings.



ENERGY STAR and the ENERGY STAR mark are registered U.S. service marks. As an ENERGY STAR partner, SAMSUNG has determined that this product meets ENERGY STAR Guidelines for energy efficiency. For more information on the ENERGY STAR program, see www.energystar.gov.

