



Maintenance and Service Guide

SUMMARY

This guide provides information about spare parts, removal and replacement of parts, security, backing up, and more.

© Copyright 2021 HP Development Company, L.P.

Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. Chrome, Chrome OS, Chromebook, Google, and Google Drive are trademarks of Google LLC. SDHC, SDXC, and microSD are trademarks or registered trademarks of SD-3C LLC. Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Adreno, Qualcomm, and Snapdragon are trademarks or registered trademarks of Qualcomm Technologies International, Ltd., used with permission. USB Type-C and USB-C are registered trademarks of USB Implementers Forum. DisplayPort™ and the DisplayPort™ logo are trademarks owned by the Video Electronics Standards Association (VESA®) in the United States and other countries. Wi-Fi is a registered trademark of Wi-Fi Alliance®.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: August 2021

Document Part Number: M73806-001

Product notice

This guide describes features that are common to most models. Some features may not be available on your computer.

Software terms

By installing, copying, downloading, or otherwise using any software product preinstalled on this computer, you agree to be bound by the terms of the HP End User License Agreement (EULA). If you do not accept these license terms, your sole remedy is to return the entire unused product (hardware and software) within 14 days for a full refund subject to the refund policy of your seller.

For any further information or to request a full refund of the price of the computer, please contact your seller.

Safety warning notice

Reduce the possibility of heat-related injuries or of overheating the computer by following the practices described.

⚠ WARNING! To reduce the possibility of heat-related injuries or of overheating the computer, do not place the computer directly on your lap or obstruct the computer air vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or rugs or clothing, to block airflow. Also, do not allow the AC adapter to come into contact with the skin or a soft surface, such as pillows or rugs or clothing, during operation. The computer and the AC adapter comply with the user-accessible surface temperature limits defined by applicable safety standards.

Table of contents

1 Product description	1
2 Components	3
Right	3
Left	3
Display	4
Keyboard area	6
Touchpad	6
Top	6
Bottom	7
Rear	7
Labels	8
3 Illustrated parts catalog	10
Computer major components	10
Miscellaneous parts	12
4 Removal and replacement procedures preliminary requirements	14
Tools required	14
Service considerations	14
Plastic parts	14
Cables and connectors	14
Drive handling	14
Electrostatic discharge information	15
Generating static electricity	15
Preventing electrostatic damage to equipment	16
Personal grounding methods and equipment	16
Grounding the work area	17
Recommended materials and equipment	17
Cleaning your computer	18
Enabling HP Easy Clean (select products only)	18
Removing dirt and debris from your computer	18
Cleaning your computer with a disinfectant	19
Caring for wood veneer (select products only)	20
Packaging and transporting guidelines	20
Accessing support information	20

5 Removal and replacement procedures for authorized service provider parts	22
Component replacement procedures	22
Preparation for disassembly	22
Kickstand	22
Display assembly	23
Battery	25
Wireless charging module and board	27
Pogo connector and cable	28
Right speaker	29
Left speaker	30
Rear camera	31
Power button	32
Front camera	33
WLAN antennas and cables	34
WWAN antennas and cables (select products only)	35
System board	36
Keyboard with top cover	37
6 Backing up, resetting, and recovering	39
Backing up	39
Resetting	39
Recovering	39
Installing the Chromebook Recovery Utility	40
Creating recovery media	40
Recovering the Chrome operating system	40
Setting up your computer after a reset or recovery	41
Erasing and reformatting the recovery media	41
7 Specifications	42
Computer specifications	42
Display specifications	42
8 Power cord set requirements	44
Requirements for all countries	44
Requirements for specific countries and regions	44
9 Recycling	46
Index	47

1 Product description

This table provides detailed product information.

Table 1-1 Product components and their descriptions

Category	Description
Product Name	HP Chromebook™ x2 11 Model numbers: 11-da0xxx
Processor	Qualcomm® SC7180 Snapdragon™ (2.40 GHz, 1 MB cache, 8 cores)
Chipset	Qualcomm Integrated SoC
Graphics	Internal graphics Qualcomm Adreno™ 618 Supports HD decode, DX12, and HDMI
Display	27.8 cm (11.0 in), 2K (2160 × 1440), white light emitting diode (WLED), BrightView, UWVA (ultra wide view angle) sRGB 100%, 400 nits, bent panel, touch screen Multitouch enabled Supports active stylus
Memory	Onboard, nonupgradeable LPDDR4X-2133 Supports the following configurations: <ul style="list-style-type: none">• 8 GB• 4 GB
Primary storage	On-board embedded MultiMedia Controller (eMMC) v5.0 configuration 128 GB 64 GB
Audio and video	Dual speakers Bang & Olufsen Front-facing camera, 5 MP (MIPI Alliance) Rear-facing camera, 8 MP (MIPI Alliance) Dual-array microphone with appropriate software, echo cancellation, and noise suppression
Wireless	Integrated wireless options with dual antennas Qualcomm 802.11ac 2 × 2 Wi-Fi® + Bluetooth® 5.0 (MU-MIMO supported) with two antennas Integrated wireless wide-area network (WWAN) and Global Positioning System (GPS) function Qualcomm® X15 LTE-Advanced WWAN - LTE downlink: Cat12 up to 600 Mbps

Table 1-1 Product components and their descriptions (continued)

Category	Description
	- LTE uplink: Cat13 up to 150 Mbps
Media card reader	HP Multi-Format Digital Media Card Reader
	Supports microSD™, SDHC™, SDXC™
	Pin injection/user accessible
	SIM slot (WWAN models)
Ports	(2) USB 3.2 Type-C
	- Supports power delivery
	- Supports data transfer
	- Supports DisplayPort 1.2 out up to 2560 × 1440 @ 60 Hz
	Docking connector (5 pin)
Keyboard	HP USB Soft Cover Keyboard
Power requirements	Battery
	2 cell, 32 Whr, polymer
	Long life
	Fast charge
	AC adapter, USB Type-C®
	45 W, nPFC (non-power factor correcting), straight, 1.8 m (6.0 ft)
	Power cord
	C5, conventional, 1.0 m (3.3 ft)
Security	H1 Secure Microcontroller
	Integrated fingerprint reader
Sensors	Accelerometer
	Gyroscope
Operating system	Google Chrome™ 64
Serviceability	End user replaceable parts
	AC adapter

2 Components

Your computer features top-rated components. This chapter provides details about your components, where they are located, and how they work.

Right

Use the illustration and table to identify the components on the right side of the computer.



Table 2-1 Right-side component and description

Component	Description
Wireless charging and magnetic pen attachment area	When magnetically attached, charges the optional pen.

Left

Use the illustration and table to identify the components on the left side of the computer.






Table 2-2 Left-side components and their descriptions

Component	Description
(1) SD Memory card reader and SIM card tray	Reads optional memory cards that store, manage, share, or access information. To insert or remove a SIM card (select products only) or microSD™ card: <ol style="list-style-type: none">1. Position the computer display-side up on a flat surface.2. Insert the included ejection pin into the card tray access hole.

Table 2-2 Left-side components and their descriptions (continued)

Component	Description
	<ol style="list-style-type: none"> 3. Press in gently on the pin until the card tray is ejected. 4. Remove the tray from the computer and insert the card. 5. Replace the tray in the computer. Press in gently on the tray until it is firmly seated.
(2) Volume button	Controls speaker volume on the computer.
(3) 	<p>USB Type-C[®] power connector and SuperSpeed 5 Gbps port with DisplayPort™ output</p> <p>Connects an AC adapter that has a USB Type-C connector, supplying power to the computer and, if needed, charging the computer battery.</p> <p>– and –</p> <p>Connects a USB device, provides high-speed data transfer, and (for select products) charges small devices (such as a smartphone) when the computer is on or in Sleep mode.</p> <p>NOTE: Use a standard USB Type-C charging cable or cable adapter (purchased separately) when charging a small external device.</p>
(4) AC adapter and battery light	<ul style="list-style-type: none"> • White: The AC adapter is connected and the battery is fully charged. • Amber: The AC adapter is connected and the battery is charging. • Blinking amber: The battery has an error. • Blinking white: The computer is in Sleep mode. • Off: The battery is not charging.
(5) 	<p>USB Type-C power connector and SuperSpeed 5 Gbps port with DisplayPort output</p> <p>Connects an AC adapter that has a USB Type-C connector, supplying power to the computer and, if needed, charging the computer battery.</p> <p>– and –</p> <p>Connects a USB device, provides high-speed data transfer, and (for select products) charges small devices (such as a smartphone) when the computer is on or in Sleep mode.</p> <p>NOTE: Use a standard USB Type-C charging cable or cable adapter (purchased separately) when charging a small external device.</p>

Display

Use the illustration and table to identify the components on the display.




Table 2-3 Display components and their descriptions (keyboard attached)

Component	Description
(1) Speakers	Produce sound.
(2) WLAN antennas*	Send and receive wireless signals to communicate with wireless local area networks (WLANs).
(3) Camera	Allows you to video chat, record video, and record still images. NOTE: Camera functions vary depending on the camera hardware and software installed on your product.
(4) Camera light	On (white): The camera is in use. Off: The camera is turned off by the software.
(5) Optional pen (select products only)	Holds an optional pen. Place the pen tip down (facing the bottom of the computer) for optimal magnetic attachment. NOTE: For more information about the pen, see the documentation provided with the pen.
(6) Action keys	Execute frequently used system functions.
(7) Touchpad	Reads your finger gestures to move the pointer or activate items on the screen.
(8) Search key	Opens a search box.
(9) esc key	Activates certain computer functions when pressed in combination with other keys, such as <i>tab</i> or <i>shift</i> .

*The antennas are not visible from the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions.

For wireless regulatory notices, see the section of the *Regulatory, Safety, and Environmental Notices* that applies to your country or region.

Keyboard area

Keyboards can vary by language. The keyboard is detachable.

Touchpad

The touchpad settings and components are described here.




Table 2-4 Touchpad component and description

Component	Description
Touchpad zone	Reads your finger gestures to move the pointer or activate items on the screen.

Top

Use the illustration and table to identify the top components.




Table 2-5 Top components and their descriptions




Component	Description
(1) 	Power button and fingerprint reader <ul style="list-style-type: none">When the computer is off, press the button briefly to turn on the computer.

Table 2-5 Top components and their descriptions (continued)

Component	Description
	<ul style="list-style-type: none">• When the computer is on, press the button briefly to initiate Sleep.• When the computer is in the Sleep state, press the button briefly to exit Sleep. <p>IMPORTANT: Pressing and holding down the power button results in the loss of unsaved information.</p> <p>If the computer has stopped responding and shutdown procedures are ineffective, press and hold the power button for at least 10 seconds to turn off the computer.</p> <p>– and –</p> <p>The fingerprint reader allows a fingerprint logon, instead of a password logon.</p> <p>▲ Touch your finger to the fingerprint reader.</p> <p>IMPORTANT: To prevent fingerprint logon issues, be sure when you register your fingerprint that all sides of your finger are registered by the fingerprint reader.</p>
(2)  Internal microphones (2)	Record sound.

Bottom

Use the illustration and table to identify the bottom components.




Table 2-6 Bottom components and their descriptions

Components	Description
(1) Magnetic guide pin holes	Assist with correct positioning of tablet attachment to the removable keyboard.
(2) Pogo connector	Connects the computer to the removable keyboard.

Rear

Use the illustration and table to identify the rear components.




Table 2-7 Rear components and their descriptions

Component	Description
(1) Camera	Allows you to video chat, record video, and record still images. NOTE: Camera functions vary depending on the camera hardware and software installed on your product.
(2) Kickstand	Allows you to stand the tablet on a flat surface for hands-free use.

Labels

The labels affixed to the computer provide information that you might need when you troubleshoot system problems or travel internationally with the computer. Labels can be in paper form or imprinted on the product.

IMPORTANT: Check the following locations for the labels described in this section: the bottom of the computer, inside the battery bay, under the service door, on the back of the display, or on the bottom of a tablet kickstand.

- **Service label**—Provides important information to identify your computer. When contacting support, you may be asked for the serial number, the product number, or the model number. Locate this information before you contact support.

Your service label will resemble one of the following examples. Refer to the illustration that most closely matches the service label on your computer.




Table 2-8 Service label components

Component	
(1)	HP product name
(2)	Model number
(3)	Warranty period
(4)	Product ID
(5)	Serial number




Table 2-9 Service label components

Component	
(1)	HP product name
(2)	Product ID
(3)	Serial number
(4)	Warranty period



- Regulatory labels—Provide regulatory information about the computer.
- Wireless certification labels—Provide information about optional wireless devices and the approval markings for the countries or regions in which the devices have been approved for use.

3 Illustrated parts catalog

Use this table to determine the spare parts that are available for the computer.

Computer major components

To identify the computer major components, use this illustration and table.

-
-  **NOTE:** HP continually improves and changes product parts. For complete and current information about supported parts for your computer, go to <http://partsurfer.hp.com>, select your country or region, and then follow the on-screen instructions.
 -  **NOTE:** Details about your computer, including model, serial number, product key, and length of warranty, are on the service tag at the bottom of your computer.
-




Table 3-1 Computer major component descriptions and part numbers

Item	Component	Spare part number
(1)	Top cover with keyboard	
	Shade gray	M74463-xx1
	Night teal	M74464-xx1
(2)	Display assembly (touch)	M73465-001
(3)	Speaker Kit (includes left and right speakers)	M73457-001
(4)	Wireless charging module with cable	M73452-001
(5)	Wireless board	M73452-001

Table 3-1 Computer major component descriptions and part numbers (continued)

Item	Component	Spare part number
	NOTE: The wireless board cable is available as spare part number M73453-001.	
(6)	Front camera (includes cable)	M73447-001
(7)	Rear camera (includes cable)	M73446-001
(8)	WLAN antennas	M73455-001
(9)	WWAN antennas	M73456-001
(10)	System board (includes heat sink, integrated processor, system memory, and eMMC storage; includes replacement thermal material)	
	8 GB system memory, 128 GB eMMC memory	M73462-001
	8 GB system memory, 128 GB eMMC memory, models with WWAN	M73463-001
	8 GB system memory, 64 GB eMMC memory	M73461-001
	4 GB system memory, 64 GB eMMC memory	M73460-001
(11)	Battery (2 cell, 32 Whr)	M76710-001
(12)	Display back cover (includes lens)	
	WLAN models	M73449-001
	WWAN models	M73448-001
	Bottom cover	M73464-001
(13)	Kickstand	
	Night teal	M73440-001
	Shade gray	M73442-001
(14)	Pogo connector and cable	M73948-001
(15)	Wireless board cable	M73453-001
(16)	Power button	M73464-001
	NOTE: The switch holder is available as spare part number M73458-001.	
(17)	Display cable	M73451-001
(18)	Touch control board cable	M73450-001
(19)	SD card holder with SIM card holder	M73443-001
	SD card holder without SIM	M73444-001

Miscellaneous parts

To identify the miscellaneous parts, use this table.

Table 3-2 Miscellaneous part descriptions and part numbers

Component	Spare part number
AC adapter, USB Type-C (45 W, nPFC, 1.8 m [6.0 ft])	L43407-001

Table 3-2 Miscellaneous part descriptions and part numbers (continued)

Component	Spare part number
Screw Kit	M73445-001
USI Active Pen	M76708-001
Power adapter for use in Japan (C5)	226768-001
Duckhead power cord for use in Japan	L33157-001
Rubber Kit (includes the following rubber pieces: left side, right side, LED, power button, camera, and wireless door)	M73459-001
Protective Tape Kit	M81411-001
Power cord (C5, 1.0 m [3.3 ft])	
Australia	L19358-001
Europe (Austria, Belgium, Finland, France, Germany, the Netherlands, Norway, and Sweden)	L19361-001
India	L19363-001
Japan	L19365-001
North America	L19367-001
South Africa	L19369-001
The United Kingdom	L19373-001

4 Removal and replacement procedures preliminary requirements

Use this information to properly prepare to disassemble and reassemble the computer.

Tools required

You need the following tools to complete the removal and replacement procedures:

- Tweezers
- Nonconductive, nonmarking pry tool
- Magnetic Phillips P1 screwdriver

Service considerations

The following sections include some of the considerations that you must keep in mind during disassembly and assembly procedures.



NOTE: As you remove each subassembly from the computer, place the subassembly (and all accompanying screws) away from the work area to prevent damage.

Plastic parts

Using excessive force during disassembly and reassembly can damage plastic parts.

Cables and connectors

Handle cables with extreme care to avoid damage.




IMPORTANT: When servicing the computer, be sure that cables are placed in their proper locations during the reassembly process. Improper cable placement can damage the computer.

Apply only the tension required to unseat or seat the cables during removal and insertion. Handle cables by the connector whenever possible. In all cases, avoid bending, twisting, or tearing cables. Be sure that cables are routed so that they cannot be caught or snagged as you remove or replace parts. Handle flex cables with extreme care; these cables tear easily.

Drive handling

Note the following guidelines when handling drives.

 **IMPORTANT:** Drives are fragile components. Handle them with care. To prevent damage to the computer, damage to a drive, or loss of information, observe these precautions:

Before removing or inserting a hard drive, shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.

Before handling a drive, be sure that you are discharged of static electricity. While handling a drive, avoid touching the connector.

Before removing an optical drive, be sure that a disc is not in the drive, and be sure that the optical drive tray is closed.

Handle drives on surfaces covered with at least 2.54 cm (1 inch) of shock-proof foam.

Avoid dropping drives from any height onto any surface.

After removing a hard drive or an optical drive, place it in a static-proof bag.

Avoid exposing an internal hard drive to products that have magnetic fields, such as monitors or speakers.


Avoid exposing a drive to temperature extremes or liquids.

If a drive must be mailed, place the drive in a bubble pack mailer or other suitable form of protective packaging, and label the package "FRAGILE."

Electrostatic discharge information

A sudden discharge of static electricity from your finger or other conductor can destroy static-sensitive devices or microcircuitry. Often the spark is neither felt nor heard, but damage occurs. An electronic device exposed to electrostatic discharge (ESD) might not appear to be affected at all and can work perfectly throughout a normal cycle. The device might function normally for a while, but it has been degraded in the internal layers, reducing its life expectancy.

Networks built into many integrated circuits provide some protection, but in many cases, the discharge contains enough power to alter device parameters or melt silicon junctions.

 **IMPORTANT:** To prevent damage to the device when you remove or install internal components, observe these precautions:

Keep components in their electrostatic-safe containers until you are ready to install them.

Before touching an electronic component, discharge static electricity by using the guidelines described [Personal grounding methods and equipment on page 16](#).

Avoid touching pins, leads, and circuitry. Handle electronic components as little as possible.

If you remove a component, place it in an electrostatic-safe container.

Generating static electricity

Follow these static electricity guidelines.

- Different activities generate different amounts of static electricity.
- Static electricity increases as humidity decreases.

Table 4-1 Static electricity occurrence based on activity and humidity

Event	Relative humidity		
	55%	40%	10%
Walking across carpet	7,500 V	15,000 V	35,000 V

Table 4-1 Static electricity occurrence based on activity and humidity (continued)

Event	Relative humidity		
	55%	40%	10%
Walking across vinyl floor	3,000 V	5,000 V	12,000 V
Motions of bench worker	400 V	800 V	6,000 V
Removing DIPs (dual in-line packages) from plastic tube	400 V	700 V	2,000 V
Removing DIPs from vinyl tray	2,000 V	4,000 V	11,500 V
Removing DIPs from polystyrene foam	3,500 V	5,000 V	14,500 V
Removing bubble pack from PCB (printed circuit board)	7,000 V	20,000 V	26,500 V
Packing PCBs in foam-lined box	5,000 V	11,000 V	21,000 V

Multiple electric components can be packaged together in plastic tubes, trays, or polystyrene foam.

 **NOTE:** As little as 700 V can degrade a product.

Preventing electrostatic damage to equipment

Many electronic components are sensitive to ESD. Circuitry design and structure determine the degree of sensitivity. The following packaging and grounding precautions are necessary to prevent static electricity damage to electronic components.

- To avoid hand contact, transport products in static-safe containers such as tubes, bags, or boxes.
- Protect all electrostatic parts and assemblies with conductive or approved containers or packaging.
- Keep electrostatic-sensitive parts in their containers until they arrive at static-free stations.
- Place items on a grounded surface before removing them from their container.
- Always be properly grounded when touching a sensitive component or assembly.
- Avoid contact with pins, leads, or circuitry.
- Place reusable electrostatic-sensitive parts from assemblies in protective packaging or conductive foam.

Personal grounding methods and equipment

Using certain equipment can prevent static electricity damage to electronic components.

- **Wrist straps** are flexible straps with a maximum of $1\text{ M}\Omega \pm 10\%$ resistance in the ground cords. To provide proper ground, a strap must be worn snug against bare skin. The ground cord must be connected and fit snugly into the banana plug connector on the grounding mat or workstation.
- **Heel straps/Toe straps/Boot straps** can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use them on both feet with a maximum of $1\text{ M}\Omega \pm 10\%$ resistance between the operator and ground.

Table 4-2 Static shielding protection levels

Static shielding protection levels	
Method	Voltage
Antistatic plastic	1,500
Carbon-loaded plastic	7,500
Metallized laminate	15,000

Grounding the work area

To prevent static damage at the work area, follow these precautions.

- Cover the work surface with approved static-dissipative material.
- Use a wrist strap connected to a properly grounded work surface and use properly grounded tools and equipment.
- Use static-dissipative mats, foot straps, or air ionizers to give added protection.
- Handle electrostatic sensitive components, parts, and assemblies by the case or PCB laminate. Handle them only at static-free work areas.
- Turn off power and input signals before inserting and removing connectors or test equipment.
- Use fixtures made of static-safe materials when fixtures must directly contact dissipative surfaces.
- Keep the work area free of nonconductive materials, such as ordinary plastic assembly aids and polystyrene foam.
- Use conductive field service tools, such as cutters, screwdrivers, and vacuums.
- Avoid contact with pins, leads, or circuitry.

Recommended materials and equipment

HP recommends certain materials and equipment to prevent static electricity.

- Antistatic tape
- Antistatic smocks, aprons, or sleeve protectors
- Conductive bins and other assembly or soldering aids
- Conductive foam
- Conductive tabletop workstations with ground cord of $1\text{ M}\Omega \pm 10\%$ resistance
- Static-dissipative table or floor mats with hard tie to ground
- Field service kits
- Static awareness labels
- Wrist straps and footwear straps providing $1\text{ M}\Omega \pm 10\%$ resistance
- Material handling packages
- Conductive plastic bags
- Conductive plastic tubes

- Conductive tote boxes
- Opaque shielding bags
- Transparent metallized shielding bags
- Transparent shielding tubes

Cleaning your computer

Cleaning your computer regularly removes dirt and debris so that your device continues to operate at its best. Use the following information to safely clean the external surfaces of your computer.

Enabling HP Easy Clean (select products only)

HP Easy Clean helps you to avoid accidental input while you clean the computer surfaces. This software disables devices such as the keyboard, touch screen, and touchpad for a preset amount of time so that you can clean all computer surfaces.


1. Start HP Easy Clean in one of the following ways:
 - Select the **Start** menu, and then select **HP Easy Clean**.
– or –
 - Select the **HP Easy Clean** icon in the taskbar.
– or –
 - Select **Start**, and then select the **HP Easy Clean** tile.
2. Now that your device is disabled for a short period, see [Removing dirt and debris from your computer on page 18](#) for the recommended steps to clean the high-touch, external surfaces on your computer. After you remove the dirt and debris, you can also clean the surfaces with a disinfectant. See [Cleaning your computer with a disinfectant on page 19](#) for guidelines to help prevent the spread of harmful bacteria and viruses.

Removing dirt and debris from your computer


Here are the recommended steps to clean dirt and debris from your computer.

For computers with wood veneer, see [Caring for wood veneer \(select products only\) on page 20](#).


1. Wear disposable gloves made of latex (or nitrile gloves, if you are latex-sensitive) when cleaning the surfaces.
2. Turn off your device and unplug the power cord and other connected external devices. Remove any installed batteries from items such as wireless keyboards.

 **CAUTION:** To prevent electric shock or damage to components, never clean a product while it is turned on or plugged in.

3. Moisten a microfiber cloth with water. The cloth should be moist, but not dripping wet.

 **IMPORTANT:** To avoid damaging the surface, avoid abrasive cloths, towels, and paper towels.

4. Wipe the exterior of the product gently with the moistened cloth.

 **IMPORTANT:** Keep liquids away from the product. Avoid getting moisture in any openings. If liquid makes its way inside your HP product, it can cause damage to the product. Do not spray liquids directly on the product. Do not use aerosol sprays, solvents, abrasives, or cleaners containing hydrogen peroxide or bleach that might damage the finish.

5. Start with the display (if applicable). Wipe carefully in one direction, and move from the top of the display to the bottom. Finish with any flexible cables, like power cord, keyboard cable, and USB cables.
6. Be sure that surfaces have completely air-dried before turning the device on after cleaning.
7. Discard the gloves after each cleaning. Clean your hands immediately after you remove the gloves.

See [Cleaning your computer with a disinfectant on page 19](#) for recommended steps to clean the high-touch, external surfaces on your computer to help prevent the spread of harmful bacteria and viruses.


Cleaning your computer with a disinfectant

The World Health Organization (WHO) recommends cleaning surfaces, followed by disinfection, as a best practice for preventing the spread of viral respiratory illnesses and harmful bacteria.


After cleaning the external surfaces of your computer using the steps in [Removing dirt and debris from your computer on page 18](#), [Caring for wood veneer \(select products only\) on page 20](#), or both, you might also choose to clean the surfaces with a disinfectant. A disinfectant that is within HP's cleaning guidelines is an alcohol solution consisting of 70% isopropyl alcohol and 30% water. This solution is also known as rubbing alcohol and is sold in most stores.


Follow these steps when disinfecting high-touch, external surfaces on your computer:

1. Wear disposable gloves made of latex (or nitrile gloves, if you are latex-sensitive) when cleaning the surfaces.
2. Turn off your device and unplug the power cord and other connected external devices. Remove any installed batteries from items such as wireless keyboards.


 **CAUTION:** To prevent electric shock or damage to components, never clean a product while it is turned on or plugged in.

3. Moisten a microfiber cloth with a mixture of 70% isopropyl alcohol and 30% water. The cloth should be moist, but not dripping wet.

 **CAUTION:** Do not use any of the following chemicals or any solutions that contain them, including spray-based surface cleaners: bleach, peroxides (including hydrogen peroxide), acetone, ammonia, ethyl alcohol, methylene chloride, or any petroleum-based materials, such as gasoline, paint thinner, benzene, or toluene.

 **IMPORTANT:** To avoid damaging the surface, avoid abrasive cloths, towels, and paper towels.

4. Wipe the exterior of the product gently with the moistened cloth.

 **IMPORTANT:** Keep liquids away from the product. Avoid getting moisture in any openings. If liquid makes its way inside your HP product, it can cause damage to the product. Do not spray liquids directly on the product. Do not use aerosol sprays, solvents, abrasives, or cleaners containing hydrogen peroxide or bleach that might damage the finish.

5. Start with the display (if applicable). Wipe carefully in one direction, and move from the top of the display to the bottom. Finish with any flexible cables, like power cord, keyboard cable, and USB cables.
6. Be sure that surfaces have completely air-dried before turning the device on after cleaning.
7. Discard the gloves after each cleaning. Clean your hands immediately after you remove the gloves.

Caring for wood veneer (select products only)

Your product might feature high-quality wood veneer. As with all natural wood products, proper care is important for best results over the life of the product. Because of the nature of natural wood, you might see unique variations in the grain pattern or subtle variations in color, which are normal.

- Clean the wood with a dry, static-free microfiber cloth or chamois.
- Avoid cleaning products containing substances such as ammonia, methylene chloride, acetone, turpentine, or other petroleum-based solvents.
- Do not expose the wood to sun or moisture for long periods of time.
- If the wood becomes wet, dry it by dabbing with an absorbent, lint-free cloth.
- Avoid contact with any substance that might dye or discolor the wood.
- Avoid contact with sharp objects or rough surfaces that might scratch the wood.

See [Removing dirt and debris from your computer on page 18](#) for the recommended steps to clean the high-touch, external surfaces on your computer. After you remove the dirt and debris, you can also clean the surfaces with a disinfectant. See [Cleaning your computer with a disinfectant on page 19](#) for sanitizing guidelines to help prevent the spread of harmful bacteria and viruses.

Packaging and transporting guidelines

Follow these grounding guidelines when packaging and transporting equipment.

- To avoid hand contact, transport products in static-safe tubes, bags, or boxes.
- Protect ESD-sensitive parts and assemblies with conductive or approved containers or packaging.
- Keep ESD-sensitive parts in their containers until the parts arrive at static-free workstations.
- Place items on a grounded surface before removing items from their containers.
- Always be properly grounded when touching a component or assembly.
- Store reusable ESD-sensitive parts from assemblies in protective packaging or nonconductive foam.
- Use transporters and conveyors made of antistatic belts and roller bushings. Be sure that mechanized equipment used for moving materials is wired to ground and that proper materials are selected to avoid static charging. When grounding is not possible, use an ionizer to dissipate electric charges.


Accessing support information

Use this information to find the HP support that you need.

Table 4-3 Support information locations


Service consideration	Path to access information
Records of reported failure incidents stored on the computer	Windows: Pre-operating system failures are logged in the BIOS Event Log. To view the BIOS Event Log: <ol style="list-style-type: none">1. Press the power button.2. Immediately and repeatedly press <code>esc</code> when the power button light turns white.


Table 4-3 Support information locations (continued)

Service consideration	Path to access information
	<p>NOTE: If you do not press <code>esc</code> at the appropriate time, you must restart the computer and again repeatedly press <code>esc</code> when the power button light turns white to access the utility.</p> <ol style="list-style-type: none">3. Press <code>f10</code> to enter the BIOS setup.4. (On commercial products) Under the Main tab, select BIOS event log, and then select View BIOS Event Log. <p>- or -</p> <p>(On consumer products) Under the Main tab, select System Log.</p> <p>Post operating system failures are logged in the Event Viewer.</p> <ol style="list-style-type: none">1. Turn on the computer and allow the operating system to open.2. Click the search icon  in the taskbar.3. Type <code>Event Viewer</code>, and then press <code>enter</code>.4. Select the log from the left panel. Details display in the right panel. <p>Chrome:</p> <ol style="list-style-type: none">1. Go to support.google.com/chrome.2. Search <code>collect Chrome device logs</code>.
Technical bulletins	<p>To locate technical bulletins:</p> <ol style="list-style-type: none">1. Go to www.hp.com.2. Place the cursor over Problem solving to display more options.3. Select Support & Troubleshooting.4. Type the serial number, product number, or product name to go to the product support page.5. Select Advisories to view technical bulletins.
Repair professionals	<p>To locate repair professionals:</p> <ol style="list-style-type: none">1. Go to www.hp.com.2. Place the cursor over Support resources to display more options.3. Select Authorized service providers.
Component and diagnosis information, failure detection, and required action	<p>To locate diagnosis information and actions:</p> <ol style="list-style-type: none">1. Go to http://www.hp.com/go/techcenter/pcdiags.2. Select Get Support.3. Near the bottom of the window, select Notebook PCs, and then select your location.

5 Removal and replacement procedures for authorized service provider parts


This chapter provides removal and replacement procedures for authorized service provider parts.

 **IMPORTANT:** Components described in this chapter should be accessed only by an authorized service provider. Accessing these parts can damage the computer or void the warranty.

 **NOTE:** Details about your computer, including model, serial number, product key, and length of warranty, are on the service tag at the bottom of your computer.

Component replacement procedures

To remove and replace computer components, use these procedures.

 **NOTE:** HP continually improves and changes product parts. For complete and current information about supported parts for your computer, go to <http://partsurfer.hp.com>, select your country or region, and then follow the on-screen instructions.

You must remove, replace, or loosen as many as 46 screws when you service the parts described in this chapter. Make special note of each screw size and location during removal and replacement.

Preparation for disassembly

To remove and replace computer components, use these procedures.

See [Removal and replacement procedures preliminary requirements on page 14](#) for initial safety procedures.

1. Turn off the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect the power from the computer by unplugging the power cord from the computer.
3. Disconnect all external devices from the computer.

Kickstand

To remove the kickstand, use these procedures and illustrations.

Table 5-1 Kickstand description and part number


Description	Spare part number
Kickstand, night teal	M73440-001
Kickstand, shade gray	M73442-001

Before removing the kickstand, follow these steps:

- ▲ Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).

Remove the kickstand:

- ▲ Tilt the top of the stand upward **(1)**, and then remove the stand from the computer **(2)**.



Reverse this procedure to install the kickstand.

Display assembly

To remove and disassemble the display assembly, use these procedures and illustrations.

Table 5-2 Display assembly description and part number


Description	Spare part number
Display assembly (touch)	M73465-001
SD card holder	M73444-001
SD card with SIM card holder	M73443-001

Before removing the display panel, follow these steps:


- ▲ Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).

Remove the display assembly:

1. Remove the SIM/SD card holder by inserting a pin in the release hole **(1)**, and then pulling the holder out of the computer **(2)**.




2. Position a suction cup at the top of the display **(1)**.
3. Pull to release the display from the computer, and then place the display next to the computer **(2)**.



4. Disconnect the thinner display cable from the system board ZIF connector **(1)**.

5. Disconnect the thicker display cable from the system board connector (2).



Reverse this procedure to replace the display assembly.

Battery

To remove the battery, use this procedure and illustration.

Table 5-3 Battery description and part number

Description	Spare part number
Battery (2 cell, 32 Whr)	M76710-001
Protective tape kit	M81411-001

⚠ WARNING! To avoid personal injury and damage to the product:

- Do *not* puncture, twist, or crack the battery.
- Do *not* cause an external puncture or rupture to the battery. They can cause a short inside the battery, which can result in battery thermal runaway.
- Do *not* handle or touch the battery enclosure with sharp objects such as tweezers or pliers, which might puncture the battery.
- Do *not* compress or squeeze the battery case with tools or heavy objects stacked on top of the case. These actions can apply undue force on the battery.
- Do *not* touch the connectors with any metallic surface or object, such as metal tools, screws, or coins, which can cause shorting across the connectors.

Before removing the battery, follow these steps:


1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display assembly (see [Display assembly on page 23](#)).

⚠ WARNING! To reduce potential safety issues, use only the user-replaceable battery provided with the computer, a replacement battery provided by HP, or a compatible battery purchased from HP.


📄 IMPORTANT! Removing a battery that is the sole power source for the computer can cause loss of information. To prevent loss of information, save your work or shut down the computer through Windows before you remove the battery.

Remove the battery:

1. Peel the wireless module-to-wireless board cable off the battery **(1)**.
2. Peel the WLAN antenna off the battery **(2)**.
3. Peel the wireless board-to-system board cable off the battery **(3)**.




4. Disconnect the battery cable from the system board **(1)**.
5. Remove the five Phillips M1.6 × 3.0 screws **(2)** that secure the battery to the computer.
6. Remove the battery from the computer **(3)**.



To replace the battery, reverse the removal procedures.

When replacing the battery, be sure that the two protective strips **(1)** and foil **(2)** are installed as shown in the following illustration.



Wireless charging module and board

To remove the wireless charging module and board, use this procedure and illustration.

Table 5-4 Wireless charging module and board description and part number

Description	Spare part number
Wireless charging module with cable and board	M73452-001
Wireless board cable (system board-to-wireless board)	M73453-001


Before removing the wireless charging module, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display assembly (see [Display assembly on page 23](#)).
3. Remove the battery (see [Battery on page 25](#)).


Remove the wireless charging module and board:

1. Disconnect the module cable from the ZIF connector on the wireless board **(1)**.
2. Pull the cable up to release it from the adhesive that secures it to the computer **(2)**.

3. Use tweezers to peel the module off the side of the computer **(3)**.



4. If the system board cable is still connected to the wireless board, disconnect the cable.
5. Remove the Phillips PM 1.6 × 3.0 screw **(1)** that secures the board to the computer.
6. Remove the wireless board from the computer **(2)**.



Reverse this procedure to install the wireless charging module and board.

Pogo connector and cable

To remove the pogo connector and cable, use this procedure and illustration.

Table 5-5 Pogo connector and cable description and part number


Description	Spare part number
Pogo connector and cable	M73948-001

Before removing the pogo connector and cable, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display assembly (see [Display assembly on page 23](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 25](#)).

Remove the pogo connector and cable:

1. Remove the two Phillips M1.0 × 1.6 screws **(1)** that secure the pogo connector to the computer.
2. Disconnect the cable from the ZIF connector on the system board **(2)**.
3. Peel the cable off the computer **(3)**.



Reverse this procedure to install the pogo connector and cable.

Right speaker

To remove the right speaker, use this procedure and illustration.

Table 5-6 Right speaker description and part number


Description	Spare part number
Speaker Kit	M73457-001

Before removing the right speaker, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display assembly (see [Display assembly on page 23](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 25](#)).

Remove the right speaker:

1. Remove the two Phillips M1.6 × 3.0 screws **(1)** that secure the speaker to the computer.
2. Disconnect the speaker cable from the system board **(2)**.
3. Remove the speaker and cable from the computer **(3)**.



Reverse this procedure to install the right speaker.

Left speaker

To remove the right speaker, use this procedure and illustration.

Table 5-7 Left speaker description and part number

Description	Spare part number
Speaker Kit	M73457-001
Switch holder	M73458-001


Before removing the left speaker, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display assembly (see [Display assembly on page 23](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 25](#)).

Remove the left speaker:

1. Remove the two Phillips M1.6 × 3.0 screws **(1)** that secure the power button bracket to the computer.
2. Remove the bracket **(2)**.

3. Remove the two Phillips M1.6 × 3.0 screws (3) that secure the speaker to the computer.
4. Lift the switch holder straight up and out of the computer (4).
5. Disconnect the speaker cable from the system board (5).
6. Remove the speaker from the computer (6).



Reverse this procedure to install the left speaker.

Rear camera

To remove the rear camera, use this procedure and illustration.

Table 5-8 Rear camera descriptions and part numbers

Description	Spare part number
Rear camera	M73446-001


Before removing the rear camera, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display assembly (see [Display assembly on page 23](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 25](#)).
4. Remove the left speaker (see [Left speaker on page 30](#)).

Remove the rear camera:

1. Disconnect the camera cable from the system board (1).

2. Lift the camera module straight up to remove it **(2)**.



Reverse this procedure to install the rear camera.

Power button

To remove the power button, use this procedure and illustration.

Table 5-9 Power button descriptions and part numbers

Description	Spare part number
Power button with fingerprint reader	M73464-001
Switch holder	M73458-001
Rubber kit	M73459-001


Before removing the power button, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display assembly (see [Display assembly on page 23](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 25](#)).
4. Remove the left speaker (see [Left speaker on page 30](#)).

Remove the power button:

1. Disconnect the power button cable from the system board **(1)**.
2. Remove the rubber piece from each side of the power button **(2)**.

3. Remove the power button and cable from the computer **(3)**.



Reverse this procedure to install the power button.

Front camera

To remove the front camera, use this procedure and illustration.

Table 5-10 Front camera descriptions and part numbers

Description	Spare part number
Front camera (includes cable)	M73447-001


Before removing the front camera, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display (see [Display assembly on page 23](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 25](#)).

Remove the front camera:

1. Disconnect the camera cable from the system board **(1)**.

2. Lift the camera module straight up to remove it **(2)**.



Reverse this procedure to install the front camera.

WLAN antennas and cables

To remove the WLAN antennas and cables, use this procedure and illustration.

Table 5-11 WLAN antennas description and part number


Description	Spare part number
WLAN antennas	M73455-001

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display (see [Display assembly on page 23](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 25](#)).

Remove the WLAN antennas and cables:

1. Disconnect the two antenna cables from the system board **(1)**.
2. Peel the antennas off the computer **(2)**.

3. Remove the antennas and cables from the computer **(3)**.



To replace the WLAN antennas, reverse the removal procedures.

WWAN antennas and cables (select products only)

To remove the WWAN antennas and cables, use this procedure and illustration.

Table 5-12 WWAN antennas description and part number


Description	Spare part number
WWAN antennas	M73456-001

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display (see [Display assembly on page 23](#)).
3. Disconnect the battery cable from the system board (see [Battery on page 25](#)).

Remove the WWAN antennas and cables:

1. Disconnect the two antenna cables from the system board **(1)**.
2. Peel the antennas off the computer **(2)**.

3. Remove the antennas and cables from the computer **(3)**.



To replace the WWAN antennas, reverse the removal procedures.

System board

To remove the system board, use these procedures and illustrations.

Table 5-13 System board descriptions and part numbers

Description	Spare part number
8 GB system memory, 128 GB eMMC memory	M73462-001
8 GB system memory, 128 GB eMMC memory, models with WWAN	M73463-001
8 GB system memory and 64 GB eMMC memory	M73461-001
4 GB system memory, 64 GB eMMC memory	M73460-001


Before removing the system board, follow these steps:

1. Prepare the computer for disassembly (see [Preparation for disassembly on page 22](#)).
2. Remove the display (see [Display assembly on page 23](#)).
3. Remove the battery (see [Battery on page 25](#)).


Remove the system board:

1. Remove the two Phillips M1.6 × 3.0 screws **(1)** from the USB-C® bracket, and then remove the bracket **(2)**.

- Remove the two Phillips M1.6 × 3.0 screws from the system board (3), and then remove the system board from the computer (4).



- When installing a system board, be sure to remove the three rubber pieces (1) and silver sponge (2) from the old board and install them on the new board.



Reverse this procedure to install the system board.

Keyboard with top cover

The top cover with keyboard remains after removing all other spare parts from the computer. In this section, the first table provides the main spare part number for the top cover/keyboards. The second table provides the country codes.

Table 5-14 Keyboard with top cover descriptions and part numbers

Description	Spare part number
Shade gray	M74463-xx1
Night teal	M74464-xx1

Table 5-15 Spare part country codes

For use in country or region	Spare part number	For use in country or region	Spare part number	For use in country or region	Spare part number
Belgium	-A41	Germany	-041	Japan	-291
Denmark, Finland, and Norway	-DH1	International	-B31	Spain	-071
French Canada	-DB1	India	-002	United Kingdom	-031
France	-051	Italy	-061	United States	-001

6 Backing up, resetting, and recovering

This chapter provides information about the standard procedures of backing up your personal data, resetting your computer to original factory conditions, and recovering your operating system with the Chromebook Recovery Utility.

Backing up

You can back up your data to an optional USB flash drive or SD memory card or through Google Drive™.

For detailed information about creating a backup, go to <http://www.support.google.com>.

Resetting

A factory reset erases the information on your computer hard drive, including files in the Downloads folder. Before you reset, back up your files to an optional USB flash drive, to an SD memory card, or through Google Drive. The factory reset will not delete your files at these locations.

You might want to reset your computer in the following circumstances:

- You see the message "Reset this Chrome device."
- You are having problems with your user profile or settings.
- You restarted your computer, and it still doesn't work properly.
- You want to change the owner of your computer.

To reset your computer:


1. Under the **Settings** menu, select **Advanced**.
2. Under **Reset settings**, in the **Powerwash** section, select **Reset**.
3. In the window that appears, select **Powerwash**, and then select **Continue**.
4. Follow the on-screen instructions to reset your computer, and sign in with your Google Account.

 **NOTE:** The account you sign in with after you reset your computer is recognized as the owner account.

5. After you complete the reset, you can set up your computer and check to see whether the problem is fixed.

Recovering

When your Chrome OS™ doesn't work properly, you can perform a recovery. A recovery reinstalls the operating system, software programs, and original factory settings. It deletes locally saved files and saved networks for all accounts. A system recovery does not affect Google Accounts and data synced to Google Drive.

 **IMPORTANT:** Recovery permanently erases everything on your computer hard drive, including your downloaded files. If possible, back up your files before you recover your computer.



NOTE: For more information about performing a system recovery on your computer, go to <http://www.support.google.com>.

Before you begin the recovery process, you need the following prerequisites:

- A USB flash drive or SD memory card with a capacity of 4 GB or greater. All data is erased from this storage device when the recovery media is created, so back up all files from the device before you begin.
- A computer with internet access. You must also have administrative rights to the computer.
- Computer AC adapter. The computer must be plugged into AC power during recovery.
- The “Chrome OS is missing or damaged” screen displaying on your computer. If this message is not already displayed:
 - Turn on the computer, press and hold the **esc+f3** keys, and then press the power button. The computer restarts, and the screen shows the “Chrome OS is missing or damaged” screen.

Installing the Chromebook Recovery Utility

The Chromebook™ Recovery Utility recovers the original operating system and software programs that were installed at the factory. You can install this utility from the Chrome Web Store on any computer.

To install the Chromebook Recovery Utility:

- ▲ Open the Chrome Web Store, search for `chrome recovery`, select **Chromebook Recovery Utility** from the Apps list, and follow the on-screen instructions.

Creating recovery media

You can use recovery media to recover the original operating system and software programs that were installed at the factory.

To create recovery media:

1. Turn on a computer that has internet access.
-
2. Select the **Launcher** icon, and then select **All Apps**.
 3. In the Apps window, select **Recovery**, and then select **Get started**.
 4. Follow the on-screen instructions to create the recovery media.





NOTE: All data and partitions on your recovery media will be deleted. Do not remove the USB flash drive or SD memory card until the process is complete.

Recovering the Chrome operating system

Use these instructions to recover the Chrome operating system on your computer using the recovery media that you created.

1. Disconnect any external devices connected to your computer, plug in the power cord, and then turn on the computer.
2. To enter recovery mode, press and hold **esc+f3**, and then press the power button. When the “Chrome OS is missing or damaged” screen appears, insert the recovery media into your computer. The recovery process begins immediately.
3. Wait while Chrome verifies the integrity of the recovery media.

 **NOTE:** If you need to cancel the recovery during the verification process, press and hold the power button until the computer turns off. Do not disrupt the system recovery process after the verification step is complete.

 **NOTE:** If an error message is displayed, you might need to run the Chrome Recovery Utility again or use a different USB flash drive or SD memory card.

4. When the “System Recovery is complete” message appears, remove the recovery media.

The computer restarts with Chrome OS reinstalled.

Setting up your computer after a reset or recovery

After a reset or recovery is complete, perform the initial setup process.

For details about setting up the computer, go to <http://www.support.google.com>.

Erasing and reformatting the recovery media

When you create recovery media, the USB flash drive or SD memory card is formatted as a recovery tool. After recovery, you must erase the recovery media to reuse your storage device. Follow these steps to use the Chromebook Recovery Utility to erase the recovery media.

1. Select the **Launcher** icon, and then select **All Apps**.
2. In the apps window, select **Recovery**.
3. Select the **Settings** icon, and then select **Erase recovery media**.
4. Select the USB flash drive or SD memory card that you inserted, select **Continue**, and then select **Erase now**.
5. After the recovery media is erased, select **Done** to close the Chromebook Recovery Utility, and then remove the USB flash drive or SD memory card.

The media is ready to be formatted using a formatting tool provided by your operating system.

7 Specifications

This chapter provides specifications for your computer.

Computer specifications

This section provides specifications for your computer. When traveling with your computer, the computer dimensions and weights, as well as input power ratings and operating specifications, provide helpful information.

Table 7-1 Computer specifications

	Metric	U.S.
Dimensions		
Width	252.5 mm	9.9 in
Depth	176.7 mm	7.0 in
Height	7.6 mm	0.3 in
Weight (lowest configuration)	648 g	1.43 lb
Temperature		
Operating	5°C to 35°C	41°F to 95°F
Nonoperating	-20°C to 60°C	-4°F to 140°F
Relative humidity (noncondensing)		
Operating	10% to 90%	
Nonoperating	5% to 95%	
Maximum altitude (unpressurized)		
Operating	-15 m to 3,048 m	-50 ft to 10,000 ft
Nonoperating	-15 m to 12,192 m	-50 ft to 40,000 ft
NOTE: Applicable product safety standards specify thermal limits for plastic surfaces. The device operates well within this range of temperatures.		

Display specifications

This section provides specifications for your display.

Table 7-2 Display specifications

	Metric	U.S.
Active diagonal size	27.8 cm	11.0 in
Resolution	2160 × 1440	
Surface treatment	BrightView	

Table 7-2 Display specifications (continued)

	Metric	U.S.
Brightness	400 nits	
Viewing angle	UWVA	
Backlight	WLED	
Display panel interface	sRGB	

8 Power cord set requirements

This chapter provides power cord requirements for countries and regions.

The wide-range input feature of the computer permits it to operate from any line voltage from 100 V ac to 120 V ac, or from 220 V ac to 240 V ac.

The three-conductor power cord set included with the computer meets the requirements for use in the country or region where the equipment is purchased.

Power cord sets for use in other countries or regions must meet the requirements of the country and region where the computer is used.

Requirements for all countries

These power cord requirements are applicable to all countries and regions.

- The length of the power cord set must be at least **1.0 m** (3.3 ft) and no more than **2.0 m** (6.5 ft).
- All power cord sets must be approved by an acceptable accredited agency responsible for evaluation in the country or region where the power cord set will be used.
- The power cord sets must have a minimum current capacity of 10 A and a nominal voltage rating of 125 V ac or 250 V ac, as required by the power system of each country or region.
- The appliance coupler must meet the mechanical configuration of an EN 60 320/IEC 320 Standard Sheet C13 connector for mating with the appliance inlet on the back of the computer.

Requirements for specific countries and regions

To determine power cord requirements for specific countries and regions, use this table.

Table 8-1 Power cord requirements for specific countries and regions

Country/region	Accredited agency	Applicable note number
Argentina	IRAM	1
Australia	SAA	1
Austria	OVE	1
Belgium	CEBEC	1
Brazil	ABNT	1
Canada	CSA	2
Chile	IMQ	1
Denmark	DEMKO	1
Finland	FIMKO	1
France	UTE	1
Germany	VDE	1

Table 8-1 Power cord requirements for specific countries and regions (continued)

Country/region	Accredited agency	Applicable note number
India	BIS	1
Israel	SII	1
Italy	IMQ	1
Japan	JIS	3
Netherlands	KEMA	1
New Zealand	SANZ	1
Norway	NEMKO	1
People's Republic of China	CCC	4
Saudi Arabia	SASO	7
Singapore	PSB	1
South Africa	SABS	1
South Korea	KTL	5
Sweden	SEMKO	1
Switzerland	SEV	1
Taiwan	BSMI	6
Thailand	TISI	1
United Kingdom	ASTA	1
United States	UL	2

1. The flexible cord must be Type H05VV-F, three-conductor, 0.75 mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.
2. The flexible cord must be Type SVT/SJT or equivalent, No. 18 AWG, three-conductor. The wall plug must be a two-pole grounding type with a NEMA 5-15P (15 A, 125 V ac) or NEMA 6-15P (15 A, 250 V ac) configuration. CSA or C-UL mark. UL file number must be on each element.
3. The appliance coupler, flexible cord, and wall plug must bear a T mark and registration number in accordance with the Japanese Dentori Law. The flexible cord must be Type VCTF, three-conductor, 0.75 mm² or 1.25 mm² conductor size. The wall plug must be a two-pole grounding type with a Japanese Industrial Standard C8303 (7 A, 125 V ac) configuration.
4. The flexible cord must be Type RVV, three-conductor, 0.75 mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the CCC certification mark.
5. The flexible cord must be Type H05VV-F three-conductor, 0.75 mm² conductor size. KTL logo and individual approval number must be on each element. Approval number and logo must be printed on a flag label.
6. The flexible cord must be Type HVCTF three-conductor, 1.25 mm² conductor size. Power cord set fittings (appliance coupler, cable, and wall plug) must bear the BSMI certification mark.
7. For 127 V ac, the flexible cord must be Type SVT or SJT 3-conductor, 18 AWG, with plug NEMA 5-15P (15 A, 125 V ac), with UL and CSA or C-UL marks. For 240 V ac, the flexible cord must be Type H05VV-F three-conductor, 0.75 mm² or 1.00 mm² conductor size, with plug BS 1363/A with BSI or ASTA marks.

9 Recycling

When a nonrechargeable or rechargeable battery has reached the end of its useful life, do not dispose of the battery in general household waste. Follow the local laws and regulations in your area for battery disposal.

HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, see the HP website at <http://www.hp.com/recycle>.

Index

A

AC adapter light 4
Action keys
 identifying 5

B

backing up 39
battery
 light 4
Bluetooth label 8
buttons
 power 6

C

camera 5, 8
 identifying 5, 8
camera light, identifying 5
caring for your computer 18
cautions
 electrostatic discharge 14, 15
Chromebook Recovery Utility,
 installing 40
cleaning your computer 18
 caring for wood veneer 20
 disinfecting 19
 HP Easy Clean 18
 removing dirt and debris 18
components
 bottom 7
 display 4
 keyboard area 6
 left side 3
 rear 7
 right side 3
 top 6
computer major components 10
computer specifications 42
connectors
 power 4

D

display
 specifications 42

E

electrostatic discharge (ESD) 14, 15
 preventing damage 14, 15, 16

F

fingerprint reader, identifying 6
front camera
 removal 33
 spare part numbers 33

G

grounding methods 14, 15, 16
guidelines
 packaging 14, 20
 transporting 14, 20
 workstation 14

H

hard drive
 specifications 42

I

illustrated parts catalog 10
Internal microphones, identifying 7

K

keyboard
 product description 2
keyboard with top cover
 spare part numbers 37
keys
 Search 5
kickstand
 removal 22
 spare part numbers 22
kickstand, identifying 8

L

labels
 Bluetooth 8
 regulatory 8
 serial number 8
 service 8
 wireless certification 8
 WLAN 8

left speaker
 removal 30
 spare part numbers 30
lights
 AC adapter and battery 4
 camera 5

M

memory card reader, identifying 3
miscellaneous parts, spare part
 numbers 12

P

packaging guidelines 14, 20
pogo connector and cable
 removal 28
 spare part numbers 28
POGO connector, identifying 7
pointing device, product
 description 2
ports
 product description 2
 USB Type-C power connector and
 SuperSpeed 5 Gbps port with
 DisplayPort output 4
power button
 removal 32
 spare part numbers 32
power button, identifying 6
power connector
 identifying 4
power cord
 requirements for all countries
 44
 requirements for specific
 countries and regions 44
 set requirements 44
product description
 keyboard 2
 pointing device 2
 ports 2
product name and number,
 computer 8

R

- rear camera
 - removal 31
 - spare part numbers 31
- recovery media
 - creating 40
 - erase 41
- recovery, performing 39
- regulatory information
 - regulatory label 8
 - wireless certification labels 8
- removal and replacement
 - procedures 22
- resetting 39
- right speaker
 - removal 29
 - spare part numbers 29

S

- Search key
 - identifying 5
- serial number, computer 8
- service labels, locating 8
- spare part country codes 37
- specifications
 - computer 42
 - display 42
 - hard drive 42
- static electricity 14, 15
- support information 20
- system board
 - removal 36
 - spare part numbers 36
- system recovery
 - Chrome operating system 40
 - Chromebook Recovery Utility 40
 - recovery media 40

T

- Touchpad
 - identifying 5
- touchpad zone, identifying 6
- transporting guidelines 14, 20
- traveling with the computer 8

U

- USB Type-C power connector and SuperSpeed 5 Gbps port with DisplayPort output, identifying 4

V

- volume button, identifying 4

W

- wireless certification label 8
- wireless charging module
 - removal 27
 - spare part numbers 27
- WLAN antennas
 - removal 34
 - spare part number 34
- WLAN antennas, identifying 5
- WLAN device 8
- WLAN label 8
- workstation guidelines 14
- WWAN antennas
 - removal 35
 - spare part number 35