

# HP Notes

13 May 2002

This file contains up-to-date information for your HP notebook PC on these topics:

- Known issues using Windows XP
  - Using an Internet Proxy Server
- Accessing Local Area Networks
- 75-watt AC adapter Caution
- One Touch Buttons and Hibernation
- **DVD+RW Video CD**
- **One Touch Buttons with Multiple Users**

You can find additional current information about your notebook on the HP Notebook web site, [www.hp.com/notebooks](http://www.hp.com/notebooks).

## Known issues using Windows XP

When playing a DVD using Media Player in Windows XP, several display issues may appear. Below are two techniques for improving this inconsistency:

- Press the Window key once or twice.
- Press Fn+Page Up or Fn+ Page Down once or twice.

To avoid this issue completely, HP recommends you use Win DVD for uninterrupted DVD playing.

## Using an Internet Proxy Server

If you set up an Internet connection that uses a LAN proxy server, you should enable the option for bypassing the proxy server for local addresses. Otherwise, you may experience delays accessing local computers or other resources on your network.

## Accessing Local Area Networks

HP recommends checking the bypass proxy for local addresses to accelerate accessing local network. To check this, do the following:

1. Click Start, Control Panel, Network and Internet Connections, Internet Options.
2. On the Connections tab, click LAN Settings. Make sure the option for bypassing proxy server for local addresses is **not** checked.
3. Restart the notebook and attempt to access your LAN
4. View your workgroup computers and access one of them.

When you try to access a folder the hourglass icon appears. It can take 15 minutes or more to access a folder. If you view the Task Manager during this time, it will say that the network neighborhood is not responding.

Also, if you interrupt the task during this time, you will lose all desktop icons, the taskbar, and the Start menu, and will need to restart the notebook.

5. If the option for bypassing proxy server for local addresses **is** checked, you may experience a 15-second delay.

### **75-watt - AC adapter Caution**

**Use only the HP AC adapter included with your notebook, or another approved HP adapter. Using any other AC adapter can damage the adapter, and may void your warranty.**

**The pre-installed electronic online manual on your notebook may refer to the use of a 60-watt AC adapter designed for an earlier released product. A 60-watt AC adapter **SHOULD NOT** be used with this current product.**

Plug the AC adapter into the power source (the adapter's LED lights), then connect it to the AC adapter jack on the back of the notebook. The notebook's battery then begins charging.

You must fully charge your battery before first using your notebook. The battery indicator light will turn green when fully charged.

### **One Touch Button and Hibernation**

If you force your system to go into hibernate mode manually, when using the one touch button to resume, it will take about one minute to launch the associated one touch application.

### **DVD+RW Video CD**

When using WinDVD to play DVD+RW video CD in full screen, the CPU usage is at 100% resulting in a lagging video to audio output.

### **One Touch Buttons with Multiple Users**

If one user launches any One Touch program, then switches to another user, the One Touch buttons and volume control will not function.