

Pointing Devices and Keyboard User Guide

© Copyright 2007 Hewlett-Packard
Development Company, L.P.

Microsoft and Windows are registered
trademarks of Microsoft Corporation.

The information contained herein is subject
to change without notice. The only
warranties for HP products and services are
set forth in the express warranty statements
accompanying such products and services.
Nothing herein should be construed as
constituting an additional warranty. HP shall
not be liable for technical or editorial errors
or omissions contained herein.

First Edition: June 2007

Document Part Number: 443984-001

Product notice

This user guide describes features that are common to most models. Some features may not be available on your computer.

Table of contents

1 Using pointing devices

Setting pointing device preferences	1
Using the TouchPad	2
Using the pointing stick	3
Connecting an external mouse	3

2 Using the keyboard

Using hotkeys	4
Displaying system information (fn+esc)	5
Initiating Sleep (fn+f3)	5
Switching the screen image (fn+f4)	6
Viewing battery charge information (fn+f8)	6
Decreasing screen brightness (fn+f9)	6
Increasing screen brightness (fn+f10)	6
Activating the ambient light sensor (fn+f11)	6


3 HP Quick Launch buttons

Using QuickLook (select models only)	9
Installing QuickLook	9
Using the HP Quick Launch Buttons control panel	10
Opening the Quick Launch Buttons control panel	10
Displaying the Q Menu	10

4 Cleaning the TouchPad and keyboard

Index	12
-------------	----

1 Using pointing devices



Component		Description
(1)	Pointing stick*	Moves the pointer and selects or activates items on the screen.
(2)	Left pointing stick button*	Functions like the left button on an external mouse.
(3)	TouchPad*	Moves the pointer and selects or activates items on the screen.
(4)	Left TouchPad button*	Functions like the left button on an external mouse.
(5)	Center TouchPad button*	Functions like the center button on an external mouse.
(6)	Right TouchPad button*	Functions like the right button on an external mouse.
(7)	TouchPad scroll zone	Scrolls up or down.
(8)	Right pointing stick button*	Functions like the right button on an external mouse.
(9)	Center pointing stick button*	Functions like the center button on an external mouse.

*This table describes factory settings. To view or change pointing device preferences, select **Start > Control Panel > Hardware and Sound > Mouse**.

Setting pointing device preferences

To access Mouse Properties, select **Start > Control Panel > Hardware and Sound > Mouse**.

Use Mouse Properties in Windows® to customize settings for pointing devices, such as button configuration, click speed, and pointer options.

Using the TouchPad

To move the pointer, slide your finger across the TouchPad surface in the direction you want the pointer to go. Use the TouchPad buttons like the corresponding buttons on an external mouse. To scroll up and down using the TouchPad vertical scroll zone, slide your finger up or down over the lines.

 **NOTE:** If you are using the TouchPad to move the pointer, you must lift your finger off the TouchPad before moving it to the scroll zone. Simply sliding your finger from the TouchPad to the scroll zone will not activate the scrolling function.

Using the pointing stick

Press the pointing stick in the direction you want to move the pointer on the screen. Use the left, center, and right pointing stick buttons as you would use the buttons on an external mouse.

Connecting an external mouse

You can connect an external USB mouse to the computer using one of the USB ports on the computer. An external mouse can also be connected to the system using the ports on an optional docking device

2 Using the keyboard

Using hotkeys

Hotkeys are combinations of the **fn** key (1) and either the **esc** key (2) or one of the function keys (3).

The icons on the **f3**, **f4**, and **f8** through **f11** keys represent the hotkey functions. Hotkey functions and procedures are discussed in the following sections.

 **NOTE:** Your computer may look slightly different from the illustration in this section.



Function	Hotkey
Display system information.	fn+esc
Initiate Sleep.	fn+f3
Alternate between computer display and external display.	fn+f4
Display battery information.	fn+f8
Decrease screen brightness.	fn+f9
Increase screen brightness.	fn+f10
Activate and deactivate the ambient light sensor.	fn+f11

To use a hotkey command on the computer keyboard, follow either of these steps:

- Briefly press the **fn** key, and then briefly press the second key of the hotkey command.
– or –
- Press and hold down the **fn** key, briefly press the second key of the hotkey command, and then release both keys at the same time.

Displaying system information (fn+esc)

Press **fn+esc** to display information about system hardware components and the system BIOS version number.

In the Windows **fn+esc** display, the version of the system BIOS (basic input-output system) is displayed as the BIOS date. On some computer models, the BIOS date is displayed in decimal format. The BIOS date is sometimes called the system ROM version number.

Initiating Sleep (fn+f3)

△ **CAUTION:** To reduce the risk of information loss, save your work before initiating Sleep.

Press **fn+f3** to initiate Sleep.

When Sleep is initiated, your information is stored in system memory, the screen is cleared, and power is conserved. While the computer is in the Sleep state, the power lights blink.

The computer must be on before you can initiate Sleep.

 **NOTE:** If a critical battery level occurs while the computer is in the Sleep state, the computer initiates Hibernation and the information stored in memory is saved to the hard drive. The factory setting for critical battery action is Hibernate, but this setting can be changed using Power Options in Windows Control Panel.

To exit Sleep, briefly slide the power switch to the right.

The function of the **fn+f3** hotkey can be changed. For example, you can set the **fn+f3** hotkey to initiate Hibernation instead of Sleep.

 **NOTE:** In all Windows operating system windows, references to the *sleep button* apply to the **fn+f3** hotkey.

Switching the screen image (fn+f4)

Press **fn+f4** to switch the screen image among display devices connected to the system. For example, if a monitor is connected to the computer, pressing **fn+f4** alternates the screen image from computer display to monitor display to simultaneous display on both the computer and the monitor.

Most external monitors receive video information from the computer using the external VGA video standard. The **fn+f4** hotkey can also alternate images among other devices receiving video information from the computer.

The following video transmission types, with examples of devices that use them, are supported by the **fn+f4** hotkey:

- LCD (computer display)
- External VGA (most external monitors)
- S-Video (televisions, camcorders, DVD players, VCRs, and video capture cards with S-Video-in jacks)
- HDMI (televisions, camcorders, DVD players, VCRs, and video capture cards with HDMI ports)
- Composite video (televisions, camcorders, DVD players, VCRs, and video capture cards with composite-video-in jacks)



NOTE: Composite video devices can be connected to the system only by using an optional docking device.

Viewing battery charge information (fn+f8)

Press **fn+f8** to display charge information for all installed batteries. The display indicates which batteries are charging and reports the amount of charge remaining in each battery.

Decreasing screen brightness (fn+f9)

Press **fn+f9** to decrease screen brightness. Hold down the hotkey to decrease the brightness level incrementally.

Increasing screen brightness (fn+f10)

Press **fn+f10** to increase screen brightness. Hold down the hotkey to increase the brightness level incrementally.

Activating the ambient light sensor (fn+f11)

Press **fn+f11** to activate and deactivate the ambient light sensor.

3 HP Quick Launch buttons

Use the HP Quick Launch buttons to open frequently used programs. The HP Quick Launch buttons include the info button (1) and the presentation button (2).



Component		Description
(1)	Info button	Launches Info Center, which enables you to open preset software programs. You can reprogram the button to perform one of the following actions: • Open the Q Menu or the presentation feature • Open an e-mail editor • Open a search box that allows you to search for a Web site
(2)	Presentation button	Starts the presentation feature. You can set this button to perform one of the following actions: • Open a program, folder, file, or Web site that you specify • Choose a power plan • Choose a display setting The image simultaneously displays on the computer screen and on an external device that is connected to the computer.

Component	Description
	You can reprogram the button to perform one of the following actions: • Open the Q Menu or Info Center • Open an e-mail editor • Open a search box that allows you to search for a Web site
(3) Calculator button	Launches the Windows calculator.

Using QuickLook (select models only)

 **NOTE:** QuickLook must be installed before you can view the QuickLook information.

QuickLook saves Inbox e-mails and calendar, contact, and task information from Microsoft® Outlook to your computer's hard drive. When the computer is off, in the Sleep state, or in Hibernation, you can quickly view this information by pressing the info button on the computer.

 **NOTE:** If you have set a Windows logon password, you will be prompted to enter your password when you press the info button while the computer is off, in the Sleep state, or in Hibernation.

NOTE: For additional information about QuickLook and setting preferences, refer to the online Help.

Installing QuickLook

To install QuickLook:

1. Select **Start > All Programs > Software Setup**.
2. Clear all check boxes.
3. Expand **Optional Software Applications**, and then select **HP QuickLook**.
4. Click **Install**.

Using the HP Quick Launch Buttons control panel

 **NOTE:** Quick Launch button features listed in this section may not be available on all computers.

The HP Quick Launch Buttons control panel allows you to manage several tasks, including the following:

- Program and set preferences for the info button and the presentation button
- Add, modify, and remove items on the Q Menu
- Set tiling preferences

 **NOTE:** For on-screen information about any item in the Quick Launch buttons control panel, click the Help button in the upper-right corner of the window.

Opening the Quick Launch Buttons control panel

You can open the HP Quick Launch Buttons control panel in any of the following ways:

- Select **Start > Control Panel > Hardware and Sound > Quick Launch Buttons**.
- Double-click the **HP Quick Launch Buttons** icon in the notification area, at the far right of the taskbar.
- Right-click the **HP Quick Launch Buttons** icon in the notification area, and click **Adjust HP Quick Launch Buttons Properties**.

 **NOTE:** On some models, an icon is displayed on the desktop.

Displaying the Q Menu

The Q Menu provides quick access to many of the system tasks accessed with the buttons, keys, or hotkeys found on most computers.

To display the Q Menu on the desktop:

- ▲ Right-click the **HP Quick Launch Buttons** icon and select **Launch Q Menu**.

4 Cleaning the TouchPad and keyboard

Dirt and grease on the TouchPad can cause the pointer to jump around on the screen. To avoid this, clean the TouchPad with a damp cloth, and wash your hands frequently when using the computer.

⚠ **WARNING!** To reduce the risk of electric shock or damage to internal components, do not use a vacuum cleaner attachment to clean the keyboard. A vacuum cleaner can deposit household debris on the keyboard surface.

Clean the keyboard regularly to prevent keys from sticking and to remove dust, lint, and particles that can become trapped beneath the keys. A can of compressed air with a straw extension can be used to blow air around and under the keys to loosen and remove debris.



Index

A

ambient light sensor
hotkey 6

B

battery charge information 6
buttons
pointing stick 1
Quick Launch 7
TouchPad 1

C

composite video 6

D

display
image, switching 6
screen brightness hotkeys 6

F

fn key 4
function keys 4

H

HDMI 6
hotkeys
ambient light sensor 6
battery charge information 6
decreasing screen
brightness 6
description 4
displaying system
information 5
increasing screen
brightness 6
initiating Sleep 5
switching screen image 6
using 5

K

keyboard hotkeys, identifying 4

M

mouse, external
connecting 3
setting preferences 1

P

pointing devices
identifying 1
setting preferences 1
using 3
pointing stick
using 3
pointing sticks, identifying 1

Q

Q Menu 10
Quick Launch buttons 7

S

S-Video 6
screen brightness hotkeys 6
screen image, switching 6
scrolling regions, TouchPad 1
Sleep hotkey 5
system information hotkey 5

T

TouchPad
scrolling regions 1
using 2
TouchPad buttons, identifying 1
TouchPad, identifying 1

V

video transmission types 6

