

Administrator's Guide

HP ThinPro



© Copyright 2008 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice.

Windows is a trademark of Microsoft Corporation in the U.S. and other countries.

The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

This document contains proprietary information that is protected by copyright. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of Hewlett-Packard Company.

Administrator's Guide

HP ThinPro

Second Edition (March 2009)

First Edition (October 2008)

Document Part Number: 509692-002

About This Book




-  **WARNING!** Text set off in this manner indicates that failure to follow directions could result in bodily harm or loss of life.
 -  **CAUTION:** Text set off in this manner indicates that failure to follow directions could result in damage to equipment or loss of information.
 -  **NOTE:** Text set off in this manner provides important supplemental information.
-

Table of contents

1 Introduction

Using HP ThinPro	2
------------------------	---

2 Installation

Connections	6
Connect	6
Disconnect	7
General Settings	7
Firefox	7
General	8
Tabbed Browsing	9
Security	10
Citrix ICA	11
Options	12
Local Resources	13
Window	14
Firewall	15
Server Location	16
Keyboard Shortcuts	17
RDP	17
Add	18
Citrix ICA	19
Network	20
Connection	22
Window	23
Application	24
Firewall	25
Smart Ping	27
Common Settings	28
RDP	29
Network	29
Window	30
Options	31
Local Resources	32

Experience	33
Advanced	34
Teemtalk	34
Adding a Teemtalk Connection using the Teemtalk Creation Wizard	35
Adding a Teemtalk Connection Manually	38
Firefox	40
Configuration	41
Advanced	42
PNAgent	42
Configuration	43
Advanced	44
Leostream	44
Network	45
Advanced	46
Provision	46
Network	47
Window	48
Options	49
Local Resources	51
Experience	52
Advanced	53
VMware View	54
Network	54
Options	56
Advanced	57
Xdmcp	58
Configuration	58
Advanced	59
SSH	59
Configuration	60
Advanced	62
Telnet	63
Configuration	63
Advanced	64
Custom	65
Configuration	65
Advanced	66
Copy	66
Delete	66
Edit	67
Control Panel	68
Boot Logo	69
Create a Theme	70

Install a Theme	71
Select this Theme	71
Remove this Theme	71
HP Agent Config	72
Altiris Configuration	73
Date and Time	74
Desktop Background	74
Display Preferences	75
ezUpdate	76
ezUpdate Server Deployment	78
DHCP Server Deployment	80
Language	80
Network	81
Interfaces Tab	81
General Tab	83
DNS Tab	84
Printer	85
Printers Tab	85
Add Printers	86
Modify Printers	87
Delete Printers	87
Jobs Tab	87
Profile Manager	88
Screensaver	90
Display Modes Tab	90
Advanced Tab	91
Security	91
ThinPrint	92
HP ThinState Utility	92
Capture Thin Client Settings to USB Drive	93
Deploy Captured Settings from a USB Drive	95
Capture a Thin Client Full Image to a USB Drive	96
Deploy a Full Image to an FTP Site	97
Touch Screen	99
Software Update	99
User Permissions	100
Shadowing	101
Keyboard	102
Sound	103
Mouse	104
Window Manager	105
System Information	107
General	107
Network	108

Net Tools	109
Software Information	110


Index	111
--------------------	------------

1 Introduction

This guide provides the network administrator with instructions for configuring the thin client and explains the various configuration utilities.

The HP ThinPro operating system provides access to Windows, Citrix, mainframes, mid-range servers, Unix/Linux hosts, and Web applications. A single console provides a streamlined and customizable user interface. Integrated support for virtualization brokers such as HP SAM, Citrix XDI, Leostream, VMware View, and Provision Networks improve resource allocation when accessing HP blades, VMware View, or XenDesktop environments.

HP ThinPro interface is displayed by default when you turn on the thin client. The desktop includes a taskbar that provides access to open applications, a volume icon, and a clock.



Using HP ThinPro

HP ThinPro allows you to launch and manage host and remote application connections by creating an ICA, PNAgent, RDP, TeemTalk, Leostream, Provision Networks, VMware View, X Windows, or Firefox connection. When logged in as Administrator, you can define which connections and connection types are visible when in User mode. The Administrator can further restrict Users from deleting connections or creating new ones.




NOTE: You must log in with administrator permissions to access all components of the HP ThinPro window. If the banner at the top of the console window is red, then the operating system is in Administrative Mode. If the banner is blue, then the console is in User Mode.

HP ThinPro opens by default in the User Mode. To switch to the Administrative Mode:





1. Click the HP logo in the bottom left of the screen and select **Shutdown**.



2. Click **Switch to Admin** and click **OK**.

3. Type the **Administrative password** in the field and click **OK**.


 **NOTE:** The default password for Administrative Mode is `root`.



2 Installation

HP ThinPro allows you to access and manage remote connections such as ICA, PNAgent, RDP, TeamTalk, Leostream, Provision Networks, VMware View, X Windows, Firefox, etc. To access all HP ThinPro functionality, you must log in as an Administrator. As a User, you can run connections and have limited access to HP ThinPro functionality.

The HP ThinPro display, when configured, lists all server and/or application connections assigned to the user currently logged on to the terminal. For each connection, the display shows the name, type, and status of the connection.

 **NOTE:** Double-click any displayed connection to activate that connection.

A pink field indicates required information. You may not finish or advance to a new page without supplying information in this field.

Connections

You can configure and assign connections using the Connections tab.

- ▲ Click **Connections**.



The **Connections** window lists all connections that you can assign to users. You can add, edit, and delete connections from this window.

- **Connection Name:** Displays the name of the connection. You cannot change the connection name from this column.
- **Type:** Displays the type of connection (ICA, PNAgent, RDP, TeemTalk, X Windows, Leostream, Provision Networks, VMware View, Firefox, etc.). You cannot change the connection type from this column.
- **Status:** Displays the status, active or inactive, of the connection.

There are seven buttons across the top of the connection list:

- [Connect on page 6](#): Click to start a selected connection.
- [Disconnect on page 7](#): Click to disconnect a selected connection.
- [General Settings on page 7](#): Click to manage connection settings.
- [Add on page 18](#): Click to create a new connection and add it to the list of available connections.
- [Copy on page 66](#): Click to copy a connection and add it to the list of available connections.
- [Delete on page 66](#): Click to delete the selected connection. The connection is deleted from the lists of connections assigned to all users, not just the user currently logged on to the terminal.
- [Edit on page 67](#): Click to edit the selected connection.

Connect

- ▲ To open a connection, click a selection under **Connection Name** that has a **Status** of **inactive** and click **Connect**.

Disconnect

- ▲ To close a connection, click a selection under **Connection Name** that has a **Status** of **active** and click **Disconnect**.

General Settings

General settings are shared by all connections of a given connection type.


Three types of connections are available:

- [Firefox on page 7](#)
- [Citrix ICA on page 11](#)
- [RDP on page 17](#)

Firefox


1. Go to **Connections > General Settings**.
2. Select **Firefox** and set the following options:
 - [General on page 8](#)
 - [Tabbed Browsing on page 9](#)
 - [Security on page 10](#)

General




1. Set the following options:
 - **Remember signons**
 - **Block pop-up windows**
 - **Let the user change Firefox settings**
2. Click **Apply** to apply your settings.
3. Click **Ok** when you have finished configuring connecting settings.

Tabbed Browsing



1. Set the following options:
 - **Tab display**
 - **Hide the tabbar when only one tab is open**
 - **Load links in the background**
 - **Open tabs instead of windows for**
 - **Middle-click or control-click of links in a web page**
 - **Control + Enter in the location bar**
 - **When opening a bookmark folder in tabs**
 - **Replace the current set of tabs**
2. Click **Apply** to apply your settings.
3. Click **Ok** when you have finished configuring connecting settings.



1. Set the following options:
 - **Enable cookies**
 - **Cookies**
 - **for the originating web site only**
 - **for the current session only**
 - **SSL/TLS**
 - **Enable SSL2**
 - **Enable SSL3**
 - **Enable TLS**
 - **Warn when ...**
 - entering a secure site
 - entering a secure site using weak protection
 - leaving a secure site
 - entering a secure site containing unencrypted information


—submitting information to an unsecure site

2. Click **Apply** to apply your settings.
3. Click **Ok** when you have finished configuring connecting settings.

Citrix ICA


1. Go to **Connections > General Settings**.
2. Select **Citrix ICA** and set the following options:
 - [Options on page 12](#)
 - [Local Resources on page 13](#)
 - [Window on page 14](#)
 - [Firewall on page 15](#)
 - [Server Location on page 16](#)
 - [Keyboard Shortcuts on page 17](#)

Options




1. Set the following options:
 - **Options**
 - **Enable Windows Alert Sound**
 - **ICA Acceleration (LAN Only)**
 - **Allow Backing Store**
 - **Use Server Redraw**
 - **Disable Info Box Before Connecting**
 - **Use Asynchronous COM-port Polling**
 - **Allow Smart Card Logon**
 - **Enable Off Screen Surface**
 - **Enable Session Reuse**
 - **Enable Auto Reconnect**
 - **Minimum Bitmap Cache Size**
2. Click **Apply** to apply your settings.
3. Click **Ok** when you have finished configuring connecting settings.

Local Resources




1. Set the following options:
 - **Allow Audio Input**
 - **Enable Drive Mapping**
 - **Drive Mapping**
 - **Auto Printer Creation**
2. Click **Apply** to apply your settings.
3. Click **Ok** when you have finished configuring connecting settings.

Window




1. Set the following options:
 - **Enable Seamless Window**
 - **Default Window Size**
 - **Default Window Colors**
 - **Default 256 Color Mapping**
2. Click **Apply** to apply your settings.
3. Click **Ok** when you have finished configuring connecting settings.

Firewall




1. Set the following options:
 - **Proxy**
 - **Proxy Type**
 - **Proxy Address**
 - **Proxy Port**
 - **Username**
 - **Password**
 - **Use Alternate Address for Firewall Connection**
2. Click **Apply** to apply your settings.
3. Click **Ok** when you have finished configuring connecting settings.

Server Location



1. Set the following options:
 - **Default Protocol**
 - **TCP Address**
 - **HTTP Address**
2. Click **Apply** to apply your settings.
3. Click **Ok** when you have finished configuring connecting settings.


Keyboard Shortcuts



1. Set the following options:
 - **Handling of keyboard shortcuts**
 - **Stop Direct key handling**
 - **Alt+F1 through F12**
2. Click **Apply** to apply your settings.
3. Click **Ok** when you have finished configuring connecting settings.

RDP

1. Go to **Connections > General Settings**.
2. Select **RDP** and select the appropriate setting for **Send hostname as**.
3. Click **Apply** to apply your setting.
4. Click **Ok**.



Add


You have the option of adding the following connections:

- [Citrix ICA on page 19](#)
- [RDP on page 29](#)
- [Teemtalk on page 34](#)
- [Firefox on page 40](#)
- [PNAgent on page 42](#)
- [Leostream on page 44](#)
- [Provision on page 46](#)
- [VMware View on page 54](#)
- [Xdmcp on page 58](#)
- [SSH on page 59](#)

- [Telnet on page 63](#)
- [Custom on page 65](#)

Citrix ICA

1. To add a Citrix ICA connection, click **Connections** > **Add**.
2. Select **Citrix ICA** and set the following options:
 - [Network on page 20](#)
 - [Connection on page 22](#)
 - [Window on page 23](#)
 - [Application on page 24](#)
 - [Firewall on page 25](#)
 - [Smart Ping on page 27](#)
 - [Common Settings on page 28](#)



The image shows a screenshot of the 'ICA Connection Session Settings Manager' window, specifically the 'Network' tab. The window has a title bar with the text 'ICA Connection Session Settings Manager' and standard window controls. Below the title bar, there is a header area with a red sphere icon, the word 'Network', and the HP logo with the word 'invent' below it. The main content area is divided into two sections: 'Network' and 'Credentials'. The 'Network' section contains a 'Connection Name' text box with the value 'New ICA', a 'Server Type' dropdown menu set to 'Server' with a 'Browse' button next to it, a 'Server' text box with a pink background, a 'Protocol' dropdown menu set to 'TCP/IP HTTP Browser', and an 'Application' text box. The 'Credentials' section contains three text boxes for 'Username', 'Password', and 'Domain'. Below these sections is a checkbox labeled 'Allow Smart Card Logon'. At the bottom of the window are four buttons: 'Previous', 'Next', 'Finish' (which is highlighted with a dashed border), and 'Cancel'.

ICA Connection Session Settings Manager

Network

Connection Name: New ICA

Network

Server Type: Server [Browse]

Server: [Pink field]

Protocol: TCP/IP HTTP Browser

Application:

Credentials


Username:

Password:

Domain:


Allow Smart Card Logon: ☐

Previous Next Finish Cancel

 **NOTE:** A pink field indicates required information. You may not finish or advance to a new page without supplying information in this field.

1. Set the following options:
 - **Connection Name**
 - **Network**
 - **Server Type**
 - **Server**
 - **Protocol**
 - **Application**

- **Credentials**
 - **Username**
 - **Password**
 - **Domain**
 - **Allow Smart Card Logon**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.



1. Set the following options:
 - **Enable Audio Input**
 - **Use Data Compression**
 - **Enable Middle Button Paste**
 - **Use Disk Cache for Bitmaps**
 - **Enable Drive Mapping**
 - **Sound**
 - **Speed Screen**

- **Mouse Click Feedback**
 - **Local Text Echo**
 - **Encryption Level**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.


Window



1. Set the following options:
- **Enable Seamless Window**
 - **Window Size**

- **Window Colors**
 - **256 Color Mapping**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.


Application



The image shows a Windows-style dialog box titled "ICA Connection Session Settings Manager". Inside the dialog, there is a section titled "Application" with a red sphere icon. Below this title, there are two text input fields: "Application" and "Directory". At the bottom of the dialog, there are four buttons: "Previous", "Next" (which is highlighted with a dashed border), "Finish", and "Cancel". The HP logo is visible in the top right corner of the dialog.

1. Set the following options:
- **Application**
 - **Directory**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Firewall



The screenshot shows a window titled "ICA Connection Session Settings Manager" with a "Firewall" tab. The HP logo is in the top right. The "Proxy" section contains a dropdown for "Proxy Type" set to "None - direct", and text boxes for "Proxy Address", "Proxy Port" (set to 1080), "Username", and "Password". Below this is a checkbox for "Use Alternate Address for Firewall Connection". At the bottom are buttons for "Previous", "Next" (highlighted with a dashed border), "Finish", and "Cancel".

ICA Connection Session Settings Manager

Firewall

Proxy

Proxy Type: None - direct

Proxy Address:

Proxy Port: 1080

Username:

Password:

Use Alternate Address for Firewall Connection ☐

Previous Next Finish Cancel

1. Set the following options:

- **Proxy**
 - **Proxy Type:** Select a proxy type
 - **Proxy Address:** Type the proxy host name
 - **Proxy Port:** Type the proxy host port

- **Username:** Type the proxy username for the account to use to connect to a remote computer.
 - **Password:** Type a password for the account to use to connect to a remote computer.
 - **Use Alternate Address for Firewall Connection**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Smart Ping



The image shows a Windows-style dialog box titled "ICA Connection Session Settings Manager". Inside the dialog, there is a section titled "Smart Ping" with the HP logo and the word "invent" to its right. The "Smart Ping" section contains three settings: "Smart Ping" with a dropdown menu set to "Don't Ping", "Smart Ping Port" with a text box containing "0", and "Smart Ping Timeout" with a text box containing "1". At the bottom of the dialog, there are four buttons: "Previous", "Next" (which is highlighted with a dashed border), "Finish", and "Cancel".

1. Set the following options:
 - **Smart Ping:** Allows you to enable HP ThinPro to ping the server before attempting a connection. If the server name fails to resolve or the server fails to respond to the ping, the thin client aborts the connection attempt.
 - **Smart Ping Port:** Allows you to specify a port for Smart Ping.
 - **Smart Ping Timeout:** Allows you to specify a time period for Smart Ping to keep pinging.
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Common Settings



1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**




NOTE: This option is only available in the Administrative Mode.

2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

RDP

1. To add an RDP connection, click **Connections > Add**.
2. Select **RDP** and set the following options:
 - [Network on page 29](#)
 - [Window on page 30](#)
 - [Options on page 31](#)
 - [Local Resources on page 32](#)
 - [Experience on page 33](#)
 - [Advanced on page 34](#)

Network

The screenshot shows the 'RDesktop Connection Manager' window with the 'Network' tab selected. The window has a title bar with standard Windows controls and the HP logo. The 'Network' tab is indicated by a network icon and the word 'Network'. The form contains several input fields: 'Name' (containing 'New RDesktop'), 'Address' (a redacted field), 'Port' (set to 3389), 'Application', 'Directory', 'Username', 'Password', and 'Domain'. There is a 'Browse' button next to the 'Name' field and a 'Finish' button at the bottom right. A checkbox for 'Allow Smartcard Login' is also present.

RDesktop Connection Manager

Network

Name:

Address: Port:

Application:

Directory:

Username:

Password:

Domain:

☐ Allow Smartcard Login

1. Set the following options:
 - **Name**
 - **Address**
 - **Port**
 - **Application**

- **Directory**
- **Username**
- **Password**
- **Domain**
- **Allow Smartcard Login**

2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Window

RDesktop Connection Manager

Window

Window type: full

Percentage Size: 85 %

Fixed Size:

Width: 800

Height: 600

Window colors: auto


Previous Next Finish Cancel

1. Set the following options:
 - **Window type**
 - **Percentage Size**
 - **Fixed Size**
 - Width

—Height

- **Window colors**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Options



RDesktop Connection Manager

Options

☒ Enable motion events

☒ Enable data compression

☒ Enable encryption

☒ Force bitmap updates

☒ Use private colormap

☒ System beep

☐ Attach to console

Protocol level: auto

Hostname to send:

Previous Next Finish Cancel

1. Set the following options:
 - **Enable motion events**
 - **Enable data compression**
 - **Enable encryption**
 - **Force bitmap updates**
 - **Use private colormap**
 - **System beep**
 - **Attach to console**


- **Protocol level**
 - **Hostname to send**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Local Resources




1. Set the following options:
 - **Sound redirecting**
 - **Enable sound redirecting**
 - **Devices mapping**
 - **Enable USB storage mapping**
 - **Enable serial port mapping**
 - **Enable printer mapping**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Experience



1. Set the following options:
 - **Enable desktop background**
 - **Show window while dragging**
 - **Enable menu and window animations**
 - **Enable themes**
 - **Enable bitmap caching**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced



1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**



NOTE: This option is only available in the Administrative Mode.


2. Click **Finish** save your settings and close the dialog box.

Teemtalk

You can add a new Teemtalk connection in two ways:

- [Adding a Teemtalk Connection using the Teemtalk Creation Wizard on page 35](#)
- [Adding a Teemtalk Connection Manually on page 38](#)

For more information on Teemtalk, see *HP TeemTalk Terminal Emulator 7.0 User Guide* at <http://bizsupport.austin.hp.com/bc/docs/support/SupportManual/c01534810/c01534810.pdf>.



Adding a Teemtalk Connection using the Teemtalk Creation Wizard

1. To add a Teemtalk connection using the wizard, click **Connections > Add**.
2. Select **Teemtalk** and click **Teemtalk creation wizard**.

Connection Information



The image shows a screenshot of the 'TeemTalk Session Wizard - Step 1 of 3' window. The window has a title bar with the TeemTalk logo (a blue 't' and 't') and a close button. The main content area is titled 'Connection Information'. It contains four input fields with corresponding 'Configure' buttons:

- Session Name:** A text input field.
- Transport:** A dropdown menu showing 'Tcp/Ip' with a 'Configure' button.
- Connection:** A dropdown menu showing 'Telnet' with a 'Configure' button.
- Emulation:** A dropdown menu showing 'VT Series' with a 'Configure' button.

At the bottom of the window, there are three buttons: '<Back', 'Next>', and 'Cancel'.

1. Select and configure the **Connection Information**:

- **Session Name**
- **Transport** type
- **Connection** type
- **Emulation** type

2. Click **Next**.

Advanced Options




1. Set the **Advanced Options**:

- **Emulation Printer**
- **Auto Logon**
- **Key Macros**
- **Mouse Actions**
- **Soft Buttons**
- **Attributes**

2. Click **Next**.

Finalization




1. Select whether or not to create an icon on the desktop and click **OK**.
2. Click **Finish** to save your settings and close the dialog box.

Adding a Teemtalk Connection Manually

1. To add a Teemtalk connection manually, click **Connections > Add**.
2. Select **Teemtalk** and set the following options:
 - Configuration
 - Advanced


Configuration



The screenshot shows a Windows-style dialog box titled "Teemtalk Connection Manager". Inside the dialog, there is a section titled "Configuration" with the Teemtalk logo on the left and the HP logo on the right. Below the title, there is a text input field labeled "Name:" containing the text "New Teemtalk". Underneath the input field is a button labeled "Teemtalk creation wizard". At the bottom of the dialog, there are four buttons: "Previous", "Next", "Finish", and "Cancel". The "Finish" button is highlighted with a dashed border.

1. Set the following option:
 - **Name**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced



1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**



NOTE: This option is only available in the Administrative Mode.

2. Click **Finish** save your settings and close the dialog box.

Firefox

1. To add a connection, click **Connections > Add**.
2. Select **Firefox** and set the following options:
 - [Configuration on page 41](#)
 - [Advanced on page 42](#)


Configuration



The screenshot shows a Windows-style dialog box titled "Firefox Connection Manager". Inside the dialog, there is a section titled "Configuration" with the Firefox logo on the left and the HP logo with the word "invent" on the right. Below the title, there are two text input fields: "Name:" with the value "New Firefox" and "URL:" with the value "www.hp.com". Below these fields are three checkboxes, all of which are unchecked: "Enable full screen", "Enable kiosk mode", and "Enable print dialog". At the bottom of the dialog, there are four buttons: "Previous", "Next", "Finish" (which is highlighted with a dashed border), and "Cancel".

1. Set the following options:
 - **Name**
 - **URL**
 - **Enable full screen**
 - **Enable kiosk**
 - **Enable print dialog**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced



1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**




NOTE: This option is only available in the Administrative Mode.

2. Click **Finish** save your settings and close the dialog box.

PNAgent

1. To add a PNAgent connection, click **Connections > Add**.
2. Select **PNAgent** and set the following options:
 - [Configuration on page 43](#)
 - [Advanced on page 44](#)


Configuration



The image shows a Windows-style dialog box titled "PNagent Connection Manager". Inside the dialog, there is a section titled "Configuration" with the HP logo and the word "invent" below it. The configuration section contains several input fields: "Name:" with the text "New PNA Connection", "Server URL:" with a redacted field, "Username:", "Password:", "Domain:", and "Folder:". At the bottom of the dialog, there are four buttons: "Previous", "Next", "Finish" (which is highlighted with a dashed border), and "Cancel".

1. Set the following options:
 - **Name**
 - **Server URL**
 - **Username**
 - **Password**
 - **Domain**
 - **Folder**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced



1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**




NOTE: This option is only available in the Administrative Mode.

2. Click **Finish** save your settings and close the dialog box.

Leostream

1. To add a Leostream connection, click **Connections > Add**.
2. Select **Leostream** and set the following options:
 - [Network on page 45](#)
 - [Advanced on page 46](#)


Network



The screenshot shows a window titled "Leostream Connection Manager" with a "Network" tab selected. The window contains several input fields for configuration: "Name" (with the text "New Leostream"), "Broker" (with a redacted field), "Username", "Password", "Domain", and "Folder". At the bottom, there are four buttons: "Previous", "Next", "Finish" (which is highlighted with a dashed border), and "Cancel". The HP logo is visible in the top right corner.

1. Set the following options:
 - **Name**
 - **Broker**
 - **Username**
 - **Password**
 - **Domain**
 - **Folder**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced



1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**



NOTE: This option is only available in the Administrative Mode.


2. Click **Finish** save your settings and close the dialog box.

Provision

1. To add a Provision connection, click **Connections > Add**.
2. Select **Provision** and set the following options:
 - [Network on page 47](#)
 - [Window on page 48](#)
 - [Options on page 49](#)
 - [Local Resources on page 51](#)

- [Experience on page 52](#)
- [Advanced on page 53](#)

Network



The screenshot shows the 'Provision Connection Manager' window with the 'Network' tab selected. The window has a blue title bar and a header area with a network icon and the HP logo. The main area contains several input fields and checkboxes. The 'Name' field is filled with 'New Provision Connection'. The 'Broker IP' field is redacted with a pink box, and the 'Port' is set to '8080'. The 'User name', 'Password', 'Domain', and 'Folder' fields are empty. The 'Retry attempts' field is set to '1' and the 'Retry interval' is set to '5'. There are two checkboxes at the bottom: 'Passthrough credentials' and 'Allow Smartcard login', both of which are unchecked. At the bottom of the window are four buttons: 'Previous', 'Next', 'Finish' (which is highlighted with a dashed border), and 'Cancel'.

Provision Connection Manager

Network

hp invent

Name: New Provision Connection

Broker IP: [Redacted] Port: 8080

User name:

Password:

Domain:

Retry attempts: 1

Retry interval: 5

Folder:

☐ Passthrough credentials

☐ Allow Smartcard login

Previous Next Finish Cancel

1. Set the following options:

- **Name**
- **Broker IP**
- **User name**
- **Password**
- **Domain**
- **Retry attempts**
- **Retry interval**

- **Folder**
 - **Passthrough credentials**
 - **Allow Smartcard login**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Window

Provision Connection Manager

Window

hp invent

Window size: full

Window Size

Width: 800

Height: 600

Percentage: 85


Window Colors: 16

Previous Next Finish Cancel

1. Set the following options:
- **Window size**
 - **Window Size**
 - **Width**
 - **Height**

- **Percentage**
 - **Window Colors**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Options



The screenshot shows the 'Provision Connection Manager' window with the 'Options' tab selected. The window has a blue title bar and a header area with the HP logo and the word 'invent'. The main area contains a list of options with checkboxes, a 'Protocol level' dropdown menu, and a 'Hostname to send' text field. At the bottom, there are four buttons: 'Previous', 'Next', 'Finish', and 'Cancel'.

Provision Connection Manager

Options

☒ Enable motion events

☒ Enable data compression

☒ Enable encryption

☒ Force bitmap updates

☒ Use private colormap

☒ System beep

☐ Attach to console


Protocol level: auto

Hostname to send:

Previous Next Finish Cancel


1. Set the following options:
- **Enable motion events**
 - **Enable data compression**
 - **Enable encryption**
 - **Force bitmap updates**
 - **Use private colormap**
 - **System beep**

- **Attach to console**
 - **Protocol level**
 - **Hostname to send**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.



1. Set the following options:
 - **Sound**
 - **Redirect sound**
 - **Devices**
 - **Enable drive mapping**
 - **Map serial ports**
 - **Enable printer autocreation**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.


Experience



1. Set the following options:
 - **Enable desktop background**
 - **Show window while dragging**
 - **Enable menu and window animations**
 - **Enable themes**
 - **Enable bitmap caching**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced

Provision Connection Manager

Advanced  invent

Fallback Connection:

Auto start priority:

Auto reconnect: ☐

Show in user's list: ☒

Previous Next Finish Cancel

1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**




NOTE: This option is only available in the Administrative Mode.

2. Click **Finish** save your settings and close the dialog box.

VMware View

1. To add a VMware View connection, click **Connections > Add**.
2. Select **VMware View** and set the following options:
 - [Network on page 54](#)
 - [Options on page 56](#)
 - [Advanced on page 57](#)

Network



The screenshot shows the 'VMware View Connection Manager' window with the 'Network' tab selected. The window has a title bar with standard Windows controls and the HP logo. The main area contains several input fields for configuration: 'Name' (pre-filled with 'New VMware View'), 'Broker' (pre-filled with 'https://'), 'Username', 'Password', 'Domain', and 'Desktop'. At the bottom, there are four buttons: 'Previous', 'Next', 'Finish' (highlighted with a dashed border), and 'Cancel'.

Name:	New VMware View
Broker:	https://
Username:	
Password:	
Domain:	
Desktop:	

Previous Next **Finish** Cancel

1. Set the following options:
 - **Name**
 - **Broker**
 - **Username**
 - **Password**

- **Domain** (case-sensitive)
 - **Desktop**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Options

VMware View Connection Manager

Options

hp
invent

Login options

- ☐ Automatic login
- ☐ Allow Smartcard login

Sound redirection

- ☐ Enable sound redirection local


Device mappings

- ☐ Enable USB storage mapping Z
- ☐ Enable serial port mapping
- ☒ Enable printer mapping

Previous Next Finish Cancel

1. Set the following options:
 - Login options
 - Automatic login
 - Allow Smartcard login
 - Sound redirection
 - Enable sound redirection
 - Device mappings
 - Enable USB storage mapping
 - Enable serial port mapping
 - Enable printer mapping
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.


Advanced



The screenshot shows the 'Advanced' tab of the 'VMware View Connection Manager' dialog box. The window has a blue title bar with the VMware logo and the text 'VMware View Connection Manager'. Below the title bar, there is a header area with the VMware logo on the left, the word 'Advanced' in large bold letters in the center, and the HP logo with the word 'invent' below it on the right. The main area of the dialog contains four settings: 'Fallback Connection:' with a dropdown menu, 'Auto start priority:' with a dropdown menu showing '0', 'Auto reconnect:' with an unchecked checkbox, and 'Show in user's list:' with a checked checkbox (indicated by an 'x' in the box). At the bottom of the dialog, there are four buttons: 'Previous', 'Next', 'Finish', and 'Cancel'.

1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**


 **NOTE:** This option is only available in the Administrative Mode.

2. Click **Finish** save your settings and close the dialog box.

Xdmcp

1. To add an Xdmcp connection, click **Connections > Add**.
2. Select **Xdmcp** and set the following options:
 - [Configuration on page 58](#)
 - [Advanced on page 59](#)

Configuration

The image shows a Windows-style dialog box titled "Xdmcp Connection Manager". Inside the dialog, there is a section titled "Configuration" with the HP logo and the word "invent" below it. The configuration fields include: "Name:" with a text box containing "New Xdmcp"; "Type:" with a dropdown menu showing "chooser"; "Address:" with an empty text box; and a "Font Server" section containing a "Use font server:" checkbox (which is unchecked) and a "Font server:" text box. At the bottom of the dialog are four buttons: "Previous", "Next", "Finish" (which is highlighted with a dashed border), and "Cancel".

Xdmcp Connection Manager

Configuration

Name:

Type:

Address:


Font Server

Use font server: ☐

Font server:


1. Set the following options:
 - **Name**
 - **Type**
 - **Address** (required if the **Type** is **query**)
 - **Font Server**
 - **Use font server**
 - **Font server**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced



1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**

 **NOTE:** This option is only available in the Administrative Mode.

2. Click **Finish** save your settings and close the dialog box.

SSH

1. To add an SSH connection, click **Connections > Add**.
2. Select **SSH** and set the following options:
 - [Configuration on page 60](#)
 - [Advanced on page 62](#)

Ssh Connection Manager

Configuration

Name: New Ssh

Network

Address: [redacted] Port: 22

User name:

Run application:

Options

- ☐ Compression
- ☐ X11 connection forwarding
- ☐ Force TTY allocation
- ☐ Fork into background

Style

Foreground color: black

Background color: white

Font: 7x14


Previous Next Finish Cancel

1. Set the following options:

- **Name**
- **Network**
 - **Address**
 - **Port**


- **User name**
 - **Run application**
 - **Options**
 - **Compression**
 - **X11 connection forwarding**
 - **Force TTY allocation**
 - **Fork into background**
 - **Style**
 - **Foreground color**
 - **Background color**
 - **Font**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced



1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**


 **NOTE:** This option is only available in the Administrative Mode.

2. Click **Finish** save your settings and close the dialog box.

Telnet

1. To add a Telnet connection, click **Connections > Add**.
2. Select **Telnet** and set the following options:
 - [Configuration on page 63](#)
 - [Advanced on page 64](#)

Configuration




The screenshot shows the 'Telnet Connexion Manager' window with the 'Configuration' tab selected. The window has a blue title bar and a white background. On the left is a computer icon, and on the right is the HP logo with the word 'invent' below it. The main area contains the following fields and controls:


- Name:** A text box containing 'New Telnet'.
- Address:** A redacted text box (pink background).
- Port:** A spinner box set to '23'.
- Style:** A group box containing three settings:
 - Foreground color:** A dropdown menu set to 'black'.
 - Background color:** A dropdown menu set to 'white'.
 - Font:** A dropdown menu set to '7x14'.
- Buttons:** 'Previous', 'Next', 'Finish' (highlighted with a dashed border), and 'Cancel'.

1. Set the following options:
 - **Name**
 - **Address**

- **Port**
 - **Style**
 - **Foreground color**
 - **Background color**
 - **Font**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced




1. Set the following options:
- **Fallback Connection**
 - **Auto start priority**
 - **Auto reconnect**
 - **Show in user's list**
-
-  **NOTE:** This option is only available in the Administrative Mode.
2. Click **Finish** save your settings and close the dialog box.

Custom

1. To add a Custom connection, click **Connections > Add**.
2. Select **Custom** and set the following option:
 - [Configuration on page 65](#)


Configuration



The screenshot shows a Windows-style dialog box titled "Custom Script Connection Manager". Inside the dialog, there is a section titled "Configuration" with the HP logo and the word "invent" below it. Below the title bar, there is a text input field labeled "Name:" containing the text "New Custom Connection". Below this, there is a label "Enter command to run" followed by a large, empty text area for entering a command. At the bottom of the dialog, there are four buttons: "Previous", "Next", "Finish" (which is highlighted with a dashed border), and "Cancel".

1. Set the following options:
 - **Name**
 - **Enter command to run**
2. Click **Next** to advance to the next window or click **Finish** save your settings and close the dialog box.

Advanced



1. Set the following options:

- **Fallback Connection**
- **Auto start priority**
- **Auto reconnect**
- **Show in user's list**



NOTE: This option is only available in the Administrative Mode.

2. Click **Finish** save your settings and close the dialog box.

Copy

- ▲ To copy a connection, click a selection under **Connection Name** and then click **Copy**.
A copy of the connection appears in the list under **Connection Name**.


Delete

- ▲ To delete a connection, click a selection under **Connection Name** and then click **Delete**.
The connection is removed from the list under **Connection Name**.

Edit

1. To edit a connection, click a selection under **Connection Name** and then click **Edit**.
The connection settings window for that connection opens.
2. Edit the connection and click **Apply**.
3. Click **Ok**.


Control Panel



- [Boot Logo on page 69](#)
- [HP Agent Config on page 72](#)
- [Altiris Configuration on page 73](#)
- [Date and Time on page 74](#)
- [Desktop Background on page 74](#)
- [Display Preferences on page 75](#)
- [ezUpdate on page 76](#)
- [Language on page 80](#)
- [Network on page 81](#)
- [Printer on page 85](#)
- [Profile Manager on page 88](#)
- [Screensaver on page 90](#)
- [Security on page 91](#)
- [ThinPrint on page 92](#)
- [HP ThinState Utility on page 92](#)
- [Touch Screen on page 99](#)
- [Software Update on page 99](#)

- [User Permissions on page 100](#)
- [Shadowing on page 101](#)
- [Keyboard on page 102](#)
- [Sound on page 103](#)
- [Mouse on page 104](#)
- [Window Manager on page 105](#)


Boot Logo



This feature allows you to design and select boot logo themes.

 **NOTE:** Theme files must be .png files.

Create a Theme




The screenshot shows a window titled "Create theme" with a standard Windows-style title bar (minimize, maximize, close buttons). Inside the window, there are four tabs: "Info", "Background", "Progress bar", and "Text box". The "Info" tab is currently selected. Below the tabs, there are five text input fields with labels to their left: "Name:", "Version:", "Description:", "Urls:", and "Author:". The "Name" field has a vertical cursor inside it. At the bottom right of the window, there are two buttons: "Cancel" (with a red X icon) and "Apply" (with a green checkmark icon).

To create a theme:

- ▲ Click **Control Panel > Boot Logo > Create a theme**.

Use the **Info**, **Background**, **Progress bar**, and **Text box** tabs to identify and create a theme.

Install a Theme



To install a theme:

- ▲ Click **Control Panel > Boot Logo > Install a theme.**

Select this Theme

To select a theme:


1. Click **Control Panel > Boot Logo.**
2. Select the theme you want from the list and click **Select this theme.**

Remove this Theme

To remove a theme:


1. Click **Control Panel > Boot Logo.**
2. Select the theme you want from the list and click **Remove this theme.**

HP Agent Config





Configure the HP Device Management Agent using this feature.

1. Click **Control Panel > HP Agent Configuration** to access this screen.
2. Use the **General** tab to set the following
 - **Backup Gateway**
 - **Pull Interval**
 - **Log Level**
 - **Delay Scope**
3. Set the groups using the **Groups** tab. You can select pre-assigned groups from the DHCP tab or you can use static custom groups.
4. Click **Ok** to save your changes.

 **NOTE:** Changes will take effect after the Agent is restarted.

Altiris Configuration




 **NOTE:** Altiris is disabled by default. It can be activated automatically if the local area network DHCP server provides Altiris server information through DHCP Tag 190.

To configure or disable Altiris Agent:

1. Click **Control Panel > Altiris Configuration**.
2. Specify the Altiris settings in the fields shown.
Or
Select **Disable Altiris Agent** to disable Altiris.
3. Select **Use Multicast**: if you want to use the default Altiris server address.
4. The default **Multicast Address**: is displayed. Type your installation address if necessary.
5. Type or select the **Multicast Port**: (Altiris server port).
6. If **Use Multicast** is not selected, type the specific Altiris server address in the **TCP Address** field.
7. Type or select the **TCP Port**: (Altiris server port).
8. Click **OK** to save your changes and close the dialog box.


Date and Time



To set date, time, and time zone information:

1. Click **Control Panel > Date and Time**.
2. Specify the date, time, and time zone.
3. Click **Apply**, and then click **OK** to save your changes and close the dialog box.


Desktop Background



To change the desktop background:


1. Click **Control Panel > Desktop Background**.
2. Click **Change**, and then navigate to the image file you want to use as the desktop background.
3. Next to **Style**, select **center**, **tile**, or **fullscreen**.
4. Click **Restore Default** to discard changes and return to the factory image
5. To change the color, select **Color** and select a color in the **Color** field.
6. Click **Apply**, and then click **Ok** to save your changes and close the dialog box.

Display Preferences



To add a profile:

1. Click **Control Panel > Display Preferences**.
2. Click **New**.
3. Under **Profile Settings**, type a name in the **Profile Name** field.
4. Select the appropriate **Resolution** for your monitor.

 **NOTE:** If you select a low resolution, you may need to reboot your thin client for the change to take effect.

5. Select the **Depth**
6. Select the appropriate **Orientation** for your monitor.
7. Click **Save** to keep your changes or **Revert** to discard them.
8. Under **Screen Profiles**, select **Swap Primary/Secondary video output**, if desired.
9. Select the **Primary Display Profile** and the **Secondary Display Profile**.
10. Set the **Mode**.
11. Click **Test Settings** to check the profile.
12. Click **Apply**, and then click **Close** to save your changes and close the dialog box.

To edit a profile:

1. Click **Control Panel > Display Preferences**.
2. Select a profile in the **Profiles** list.
3. Edit the **Profile Settings** and **Screen Profiles** as desired.
4. Click **Test Settings** to check the profile.
5. Click **Apply**, and then click **Close** to save your changes and close the dialog box.

To delete a profile:


1. Click **Control Panel > Display Preferences**.
2. Select a profile in the **Profiles** list and click **Delete**.
3. Click **Apply**, and then click **Close** to save your changes and close the dialog box.

ezUpdate

This is a passive management solution based on a specific directory layout on an ftp/http or nfs location. This directory layout can contain specific instructions for the ThinPro image. If ezUpdate is enabled, when ThinPro is booted up, it checks this ftp/http/nfs server for new instructions and then carries out those instructions.



To use ezUpdate:

 **NOTE:** You must set up your ezUpdate server before you can use ezUpdate.

1. Click **Control Panel > ezUpdate**.
2. Select **Enable ezUpdate on system startup**, or clear the check box to disable this feature.
3. If you enable ezUpdate, either select **Use DHCP tag to detect ezUpdate server**
Or
Specify the **Protocol** and type the **Server**, **Path**, **User name**, and **Password** in the fields.
4. Click **Ok** to save your changes and close the dialog box.

ezUpdate Server Deployment

Currently, ezUpdate supports four protocols:

- ftp
- http
- nfs
- local

The following procedures uses an ftp server to describe deployment of the ezUpdate server.

To deploy an ezUpdate server:

1. Create a directory to hold the update packages: /ftproot/ezupdate.
2. Under the root directory, create a file named client_triggers.
3. Put the hostname of the clients that are going to be updated in this file, one hostname per line. This file is used to control which hosts will receive updates.

Besides the exact hostname, you may also list regular expressions in this file, for example:

- HP.* matches all hostnames that start with "HP".
 - HP[0-9]* matches all hostnames that start with "HP" followed by zero or more digits, e.g., HP12345 matches but HP12345A does not.
 - HP[0-9]\++ matches all hostnames that start with "HP" followed by one or more digits.
4. Create four directories named "CUSTOM", "FIRMWARE", "PACKAGES", and "PROFILE" under ezUpdate root directory. You may classify the updates and put the packages and .2do files to the proper directories according to their properties.
 5. Create (ezUpdate-root)/update_list. This is a plain text file which lists paths to the .2do files that should be installed on the clients, for example:
 - PACKAGES/acrobat/install.2do
 - PACKAGES/flash/install.2do
 - PACKAGES/firefox/uninstall.2do
 - PROFILE/install.2do

For details of the .2do file, please refer to "xpe_snapin_ref.pdf". Here is an simple example:

```
# The name and the version of the package, *required*.
# PACKAGE_NAME=acrobat
# VERSION=1
#
# This file is processed by Remote Manager as part
# of the update procedure.
#
```

```
# Install the snapin via the install_snapin script. SCRIPT
install_snapin.sh <<< adobe-acrobat.hpk

# END OF .2DO
```

Pay attention to "PACKAGE_NAME" and "VERSION" entries, as they are both mandatory and very important to the ezUpdate version control mechanism.

install_snapin.sh and acrobat-acrobat.hpk are stored in the same directory with this .2do file. When performing update, they are downloaded by the client to the local storage. Then install_snapin.sh is executed locally, and the real installation is performed.

Here is an example of an install_snapin.sh script:

```
# This script is downloaded to an HP appliance
# in order to install a hpk snapin.
# This script should work as part of a complete installation
# or as part of an installation to a running system.
#
RAMDIR=/tmp
echo Installing adobe acrobat...
#
# Copy the "snapin.tgz" file to the ramdisk.
/bin/cat - > ${RAMDIR}/snapin.hpk
echo installing ${RAMDIR}/snapin.hpk
IPKFILE="${RAMDIR}/snapin.hpk"
# Install the "snapin.hpk" file
/usr/bin/hpkg -i "${IPKFILE}"
if [ $? -ne 0 ] ; then
    echo ERROR - Snapin install failed.
    exit 1
if
echo OK
exit 0
# END OF SCRIPT
```

DHCP Server Deployment

The code for ezUpdate server option is 137, and the tag string can be constructed in three ways:


- proto://user:passwd@host/directory
- nfs:host:fullpath
- local:fullpath

Language



1. Click **Control Panel** > **Language**.
2. Select the language you want to use.
3. Click **Ok** to save your changes and close the dialog box.

Network



To set **Network** attributes:

- ▲ Click **Control Panel > Network**.

Interfaces Tab

To activate a connection:

- ▲ Select an inactive connection from the list and click **Activate**.

To delete a connection:

- ▲ Select an active connection from the list and click **Deactivate**.

To add a connection:

- ▲ Click **Add**, and then supply the connection specifications.

To modify a connection:

1. Select a connection from the list and click **Modify**.
2. Click **Active on boot** if you want the connection to be active upon boot.
3. Click **Apply** to confirm the configuration changes.
4. Click **OK** on the confirmation notice to close the notice and dialog box.

To delete a connection:

1. Select a connection from the list and click **Delete**.
2. Click **OK** to confirm.


To close the dialog box:

- ▲ Click **OK**.



NOTE: Restart the Xserver if you have changed the device name under the **General** tab.

General Tab



The image shows a screenshot of the HP Network Manager application window. The title bar reads "HP Network Manager". Inside the window, there is a "Network" icon and the word "Network". Below this, there are four tabs: "Interfaces", "General", "DNS", and "About". The "General" tab is currently selected. The "General" tab contains two sections: "Network Identification" and "Network Settings".

Network Identification

- Device Name : HP001D72A16A16
- Device Description :


Network Settings

- Network Card : eth0
- MAC Address : 00:1d:72:a1:6a:16
- IP Address : 16.100.161.14 DHCP : Enabled
- Gateway : 16.100.160.1 Lease : 1296000
- Subnet Mask : 255.255.252.0
- Default Domain : "americas.hpqcorp.net"
- DNS Server(s) : 16.110.135.51

At the bottom of the dialog box, there are two buttons: "OK" and "Exit".

Specify or change network identification or settings in this dialog box.

DNS Tab



To add a DNS name:

1. Type a DNS IP address in the **Add DNS Name** field.
2. Click **Add**.

The new DNS name appears in the **DNS Names** list.

To delete a DNS name:

- ▲ Select a name in the **DNS Names** list and click **Delete**.

To add a DNS domain:

1. Type a search domain in the **Add DNS Search Domain** field.
2. Click **Add**.


The new search domain appears in the **DNS Domains** list.

To delete a DNS domain:


- ▲ Select a name in the **DNS Domains** list and click **Delete**.

To close the dialog box:

- ▲ Click **OK**.

 **NOTE:** Restart the Xserver if you have changed the device name under the **General** tab.

Printer



Use this dialog box:

- Printers tab: to add, modify, or delete printers
- Jobs tab: to select printers or delete print jobs


Printers Tab

Use the **Printers** tab to add, modify, and delete printers from the thin client.

Add Printers

The following **Add New Printer** options are available:

- Parallel Printer
- Serial Printer
- USB Printer
- Network Printer
- Samba Printer



The screenshot shows the 'Add New Printer' window. Under 'Printer Type', 'Parallel Printer' is selected. Under 'Printer Info', the 'Device Port' is set to '/dev/lp0' and the 'Use Filter' is set to '/usr/lib/lprng/filters/lpf'. The 'Ok', 'Test', and 'Cancel' buttons are at the bottom.

To add a printer:

1. Click **Control Panel > Printer**.
2. On the **Printers** tab, click **Add**.
3. Select **Parallel Printer**.
4. Type the **Printer Name**, **Description**, and **Windows Driver** in the corresponding fields.
5. Select **Use Form Feed** if desired.

6. Select **Make Default** if you want this to be your default printer.
7. If you want to test your specifications, click **Test**.
8. Click **Ok** to add the printer and close the **Add New Printer** dialog box.

Modify Printers

To modify a printer:

1. Select the printer from the list and click **Modify**.
2. Modify the printer attributes as desired.
3. Click **Exit** to close the dialog box.

Delete Printers

To delete a printer:

1. Select the printer from the list and click **Delete**.
2. Click **OK** to confirm.
3. Click **Exit** to close the dialog box.

Jobs Tab



To delete print jobs:

1. Select a printer from the **Select Printer** list.
2. Select a job from the list and click **Delete**.
3. To delete all jobs, click **Delete All**.
4. Click **Refresh** to refresh the view.

Profile Manager



In Profile Manager, you can

- Restore factory defaults
- Save the current configuration

- Import a profile
- Export the current profile

To restore factory defaults:

1. Click **Control Panel > Profile Manager**.
2. Click **restore factory defaults**.

To save the current configuration:

1. Click **Control Panel > Profile Manager**.
2. Click **Save current configuration**.

To import a profile:


1. Click **Control Panel > Profile Manager**.
2. Click **Import a Profile**.
3. Browse to the profile you wish to import and click **Open**.
4. Click **Import Profile**.

The thin client will import the selected profile and restart.

To export the current profile:

1. Click **Control Panel > Profile Manager**.
2. Click **Export current Profile**.
3. Browse to the location where you would like to save the profile, type a profile name in the **File name** field, and click **Save**.
4. Click **OK** to confirm export success.

Screensaver



 **NOTE:** Help is not available.


Display Modes Tab

To set display modes:

1. Click **Control Panel > Screensaver**.
2. Select the mode:
 - Disable Screen Saver
 - Blank Screen Only
 - Only One Screen Saver
 - Random Screen Saver
3. If you have selected **Only One Screen Saver**, select one screen saver from the list and clear the check boxes of all other screen savers.

If you have selected **Random Screen Saver**, select all screen savers you would like to appear randomly.
4. To view screen savers,
 - Click on a screen saver name and it appears in a window in the dialog box.
 - Click on the up or down arrow below the screen saver box to view the previous or next screen saver on the full screen. Click your cursor to return to the normal view.
5. Set the period of inactivity to activate the screen saver in minutes in the **Blank After** field. Use the up and down arrows next to the field or type the number in the field.

6. If you selected **Random Screen Saver**, set the time for each screen saver to run before changing in the **Cycle After** field. Use the up and down arrows next to the field or type the number in the field.
7. If you want the screen to blank and a password to be required to unlock the computer after a period of inactivity, set the time in the **Lock Screen After** field. Use the up and down arrows next to the field or type the number in the field.

 **NOTE:** If the screen is locked while in Administrative Mode, type the user password in the field.

8. Click **Preview** to view a full-screen preview of your selected screen saver.
9. Click **Settings** to see settings for that screen saver.

Advanced Tab

Use this tab to set additional attributes for the display:

- Image Manipulation
- Text Manipulation
- Display Power Management
- Fading and Colormaps

Security




This feature allows you to change Administrator and User passwords.

To change your password:

1. Click **Control Panel > Security**.
2. Select **Administrator** or **User** and click **Change password**.
3. Type the new password in the **New password** and **Confirmation** fields and click **Ok**.
4. Click **Ok**.

ThinPrint

The image shows the 'Thinprint configuration' window. At the top, there's a title bar with the text 'Thinprint configuration' and standard window controls. Below the title bar, the window has a header area with the 'ThinPrint .print' logo on the left and the 'hp invent' logo on the right. The main content area contains two text input fields: 'Bandwidth:' with the value '65535' and 'Packet size:' with the value '8192'. Below these is a section titled 'Printers settings' which contains a table. The table has three columns: 'Class', 'Name', and 'Max Keep Alive(in mn)'. There are two rows in the table. The first row is for 'Paraprint' with a checkbox, and the second row is for 'seriprint' with a checkbox. At the bottom right of the window are 'Ok' and 'Cancel' buttons.

	Class	Name	Max Keep Alive(in mn)
<input type="checkbox"/>	Paraprint	Paraprint	10
<input type="checkbox"/>	seriprint	seriprint	10


To use ThinPrint:

1. Select the printer you want to use and click **Ok**.
2. Reboot the computer so that the setting will become effective.

HP ThinState Utility

HP ThinState allows you to copy and deploy thin client settings to another HP thin client of identical model and hardware.

- [Capture Thin Client Settings to USB Drive on page 93](#)
- [Deploy Captured Settings from a USB Drive on page 95](#)
- [Capture a Thin Client Full Image to a USB Drive on page 96](#)
- [Deploy a Full Image to an FTP Site on page 97](#)


 **NOTE:** HP ThinState is not a standalone tool and can only be accessed by the administrator from within the thin client image.

What do I need to have?


- An HP thin client unit that contains the latest HP provided image.
- An HP-approved USB flash drive.

Capture Thin Client Settings to USB Drive


To use HP ThinState to capture thin client settings to a USB drive:

 **NOTE:** If using a USB flash drive to capture settings and the flash drive contains previously captures settings, you must format the USB flash drive prior to using the ThinState utility.

1. Attach a USB flash drive to the thin client.
2. Go to **Control Panel > ThinState**.
3. Click **OK** on the notification message. The following window is displayed:




4. Select **Capture Settings**, and then click **Next**. The following window is displayed:




5. Select the target USB flash drive from the list.

(Optional Destination) Select **Capture the settings and save it on FTP server** to save settings to a FTP server and type the FTP Server Address, File Path, Username, Password, and New Filename.



6. Click **Capture**.
7. Click **OK** on the information message.

Settings capture is complete. Remove the USB flash drive.

 **NOTE:** You must remove the USB drive prior to system reboot.


8. Close the window.

Use the capture settings on the USB drive to replicate (deploy) on different systems or to restore the current capture back to its original setting after settings are altered.

Deploy Captured Settings from a USB Drive

To Use HP ThinState to Deploy Captured Settings from a USB drive:

1. Attach the USB flash drive on which you captured settings.
2. On the thin client to which you want to deploy captured settings, click **Control Panel > ThinState**.
3. Click **OK** on the warning message. The following window is displayed.




4. Select **Deploy Settings**.
5. Click **Next**.
6. Select the target USB flash drive from the list.
7. Click **Deploy**.

After image setting settings have been deployed successfully, you may remove the USB flash drive.

8. Click **OK** on the information message.


The thin client immediately reboots deploying settings.

 **NOTE:** If you do not remove the USB flash drive, during reboot, you are prompted to press any key. Simply remove the flash drive and press any key to continue reboot.

Capture a Thin Client Full Image to a USB Drive


To use HP ThinState to capture a thin client full image to a USB drive:

1. Attach a USB flash drive to the thin client.


 **NOTE:** HP ThinState, when capturing a full image, automatically formats the USB flash drive and makes the flash drive bootable.

2. Go to **Control Panel > ThinState**.

3. Click **OK** on the notification message. The following window is displayed:



4. Select **Capture Full Image**, and then click **Next**. The following window is displayed:




5. By default, all settings are captured. Click **Customize Captured Settings** to select only settings you want captured.
6. Click **Capture**.
7. Click **OK** on the warning message.

When full image capture is complete, you are instructed to remove the USB drive.
8. Remove the USB flash drive and click **OK**.
9. Close the **HP ThinState** window.

Use the capture full image on the USB drive to replicate on different systems or to restore the current thin client back to its original image.

To install a full image from a USB drive, simply attach a USB drive to the target thin client, reboot the unit, and follow the onscreen instructions.


Deploy a Full Image to an FTP Site

 **NOTE:** You must have at least 1 GB RAM to perform this procedure.


To use HP ThinState to deploy a full image to an FTP site:

1. On the thin client from which you want to deploy a captured full image, click **Control Panel > ThinState**.

2. Click **OK** on the warning message. The following window is displayed.



3. Select **Capture Full Image**.
4. Click **Next**.
5. Select **Capture the image and save it on FTP server**. The following window is displayed.



6. Click **Capture**.
7. Click **OK** on the notification message.
8. Close the **hpthinststate** customized settings dialog box.

Touch Screen




Touch Screen allows you to operate the thin client by touching the display screen.

To enable touch screen:

1. Click **Control Panel > Touch Screen** and select **Enable Touch Screen**.
2. Click **Ok** to save your changes and close the dialog box.
3. Restart the desktop.
 - a. Click the HP logo in the bottom left of the screen and select **Shutdown**.
 - b. Click **Restart the Desktop**.
4. Click **Control Panel > Touch Screen** and click **Calibrate** to calibrate the touch screen.


Software Update

Software update allows you to upgrade the HP ThinPro image by providing the URL of a ftp or a http server containing ThinPro firmware.



1. Click **Control Panel > Software Update**.
2. Type the URL in the **Firmware directory URL** field and click **Upgrade**.

User Permissions




You can customize user permissions:

- Authorized connections
- Authorized applications
- Desktop options

To set user permissions:

1. Click **Control Panel > User Permissions**.
2. Click **Connections** in the left panel and select authorized connections by selecting or clearing check boxes.
3. Click **Control Panel** in the left panel and select authorized applications by selecting or clearing check boxes.
4. Click **Desktop** in the left panel and select desktop options by selecting or clearing check boxes.
5. Click **Apply**, then click **Ok** to close the dialog box.


Shadowing




Virtual Network Computing (VNC) is a remote control program that allows you to see the desktop of a remote machine and control it with your local mouse and keyboard, just as if you were sitting in the front of that computer.

To allow a thin client to be accessed from another location:

1. Click **Control Panel > Shadowing**.
2. Select **Enable VNC Shadow** to enable the thin client to be accessed using VNC.
3. Select **VNC Read Only** to make the VNC session read only.
4. Select **VNC Use Password** to require a password to access the thin client using VNC.
5. Select **VNC Notify User to Allow Refuse** to display a message when someone uses VNC to access the thin client and allow a user to refuse VNC access.
6. Select **Re-set VNC server right now** and click **Ok** to reset the VNC server.
7. Click **Ok** to save the settings and exit the dialog box.

 **NOTE:** You will need to restart the thin client for the changes to take effect.

Keyboard



This allows you to set various keyboard preferences:

- Settings: set typing and cursor speeds
- Shortcuts: add or remove keyboard shortcuts
- Accessibility: enable and set parameters for sticky keys, slow keys, and bounce keys
- Layouts: set the keyboard model and layouts

To set keyboard preferences

1. Click **Control Panel > Keyboard**.
2. Set your preferences and click **Close** to save your preferences and close the dialog box.

Sound



This allows you to specify audio parameters.

1. Click **Control Panel > Sound**.
2. Set your device and control parameters, and click **Close** to save your preferences and close the dialog box.


Mouse



To set the mouse behavior and cursor size:

1. Click **Control Panel > Mouse**.
2. Set your preferences on the three tabs:
 - **Behavior**
 - **Cursor**
 - **Accessibility**
3. Click **Close** to save your settings and close the dialog box.

Window Manager



To set window management specifications:

1. Click **Control Panel > Window Manager**.
2. Set your specifications on the following tabs:
 - **Style**
 - **Keyboard**
 - **Focus**
 - **Advanced**
3. Click **Close** to save your settings and close the dialog box.

On the **Style** tab, you can set the following

- **Title font**
- **Title Alignment**
- **Button layout**

On the **Keyboard** tab, you can set **Window shortcuts**.


Use the **Focus** tab to specify focus parameters:

- **Focus model**
- **New window focus**
- **Raise on focus**
- **Raise on click**

You can also specify the following **Advanced** settings:

- **Windows snapping**
- **Wrap workspaces**
- **Opaque move and resize**
- **Double click action**

System Information



The System Information screen has four tabs:

- [General on page 107](#)
- [Network on page 108](#)
- [Net Tools on page 109](#)
- [Software Information on page 110](#)


General

This screen displays the following information:

- BIOS and OS
 - Serial Number
 - BIOS Version
 - BIOS Release Date

- OS Build ID
- OS Kernel Version
- CPU
 - Processor
 - Speed
 - Cache
- Flash and Memory
 - Free
 - Used
 - Installed

Network




The Network screen displays the following information:

- Interface
 - Name
 - State
 - Type
 - IP Address
 - Network Mask

- DHCP Server Address
- Interface Statistics
- Network
 - Default Gateway
- DNS Settings
 - Hostname
 - Default Domain
 - Nameservers


Net Tools



The Net Tools tab allows you to set parameters for the following:

- Ping
- DNS Lookup
- Trace Route

Software Information



The Software Information screen displays the following information:

- Connection clients installed
- Main software installed
- Addons installed

Index

A

- add printers 86
- adding connection
 - Citrix ICA 18
 - Custom 19
 - Firefox 18
 - ICA 18
 - Leostream 18
 - PNAgent 18
 - Provision 18
 - RDP 18
 - SSH 18
 - Teemtalk 18
 - Telnet 19
 - VMware View 18
 - Xdmcp 18
- administrator, log in as 5
- Agent Config 68
- Altiris configuration 68

B

- boot logo
 - create theme 70
 - install theme 71
 - remove theme 71
 - select theme 71

C

- Citrix ICA
 - adding connection 18
 - Application options 19
 - Common Settings options 19
 - configuring connection 7
 - Connection options 19
 - Firewall options 19
 - Firewall settings 11
 - Keyboard Shortcuts settings 11
 - Local Resources settings 11
 - Network options 19

- options 18
- Options settings 11
- Server Location settings 11
- Smart Ping options 19
- Window options 19
- Window settings 11
- connect 6
- connection, adding
 - Citrix ICA 18
 - Custom 19
 - Firefox 18
 - ICA 18
 - Leostream 18
 - PNAgent 18
 - Provision 18
 - RDP 18
 - SSH 18
 - Teemtalk 18
 - Telnet 19
 - VMware View 18
 - Xdmcp 18
- connections
 - add 6
 - configuring 6
 - delete 6
 - edit 6
 - list of 6
- control panel
 - Altiris configuration 68
 - boot logo 68
 - date and time 68
 - desktop background 68
 - display preferences 68
 - ezUpdate 68
 - HP Agent Config 68
 - HP ThinState 68
 - keyboard 69
 - language 68
 - mouse 69
 - network 68
 - printer 68
 - profile manager 68
 - screen saver 68
 - security 68
 - shadowing 69
 - software update 68
 - sound 69
 - ThinPrint 68
 - touch screen 68
 - user permissions 69
 - window manager 69
- copy, connections 6
- Custom
 - adding connection 19
 - Configuration options 65
 - options 19

D

- date and time 68
- delete printers 87
- delete, connections 6
- desktop background 68
- disconnect 6
- display preferences 68
- display s screen saver 90
- DNS, network 84

E

- edit, connections 6
- ezUpdate
 - DHCP server deployment 80
 - server deployment 78

F

- Firefox
 - adding connection 18
 - Advanced options 40
 - Configuration options 40
 - configuring connection 7

- General settings 7
- options 18
- Security settings 7
- Tabbed Browsing settings 7

G

- general settings 6
- general system information 107

H

- HP ThinPro 1
- HP ThinState 68

I

- ICA
 - adding connection 18
 - Application options 19
 - common Settings options 19
 - configuring connection 7
 - Connection options 19
 - Firewall options 19
 - Firewall settings 11
 - Keyboard Shortcuts settings 11
 - Local Resources settings 11
 - Network options 19
 - options 18
 - Options settings 11
 - Server Location settings 11
 - Smart Ping options 19
 - Window options 19
 - Window settings 11
- image
 - thin client 1
- image, thin client 1
- installation 5
- interfaces, network 81

J

- jobs, printer 87

K

- keyboard 69

L

- language 68
- Leostream
 - adding connection 18
 - Advanced options 44
 - Network options 44
 - options 18

M

- modify printers 87
- mouse 69
- Multicast 73

N

- net tools, system information 107
- network
 - DNS 84
 - general 83
 - interfaces 81
 - system information 107

O

- options
 - Citrix ICA 18
 - Custom 19
 - Firefox 18
 - ICA 18
 - Leostream 18
 - PNAgent 18
 - Provision 18
 - RDP 18
 - SSH 18
 - Teemtalk 18
 - Telnet 19
 - VMware View 18
 - Xdmcp 18

P

- PNAgent
 - adding connection 18
 - Advanced options 42
 - Configuration options 42
 - options 18
- printer 68
- printer jobs 87
- printers
 - add 86
 - delete 87
 - list of 86
 - modify 87
- profile manager 68
- Provision
 - adding connection 18
 - Advanced options 47
 - Experience options 47
 - Local Resources options 46
 - Network options 46
 - Options 46

- options 18
- Window options 46

R

RDP

- adding connection 18
- Advanced options 29
- configuring connection 7
- Experience options 29
- Local Resources options 29
- Network options 29
- Options 29
- options 18
- settings 7
- Window options 29

S

- screen saver
 - advanced 91
 - display s 90
- security 68
- shadowing 69
- software information, system information 107
- software update 68
- sound 69
- SSH
 - adding connection 18
 - Advanced options 59
 - Configuration options 59
 - options 18
- system information
 - general 107
 - net tools 107
 - network 107
 - software information 107

T

- TCP 73

- Teemtalk

- adding connection 18
- adding connection
 - manually 34
- adding connection with wizard 34
- advanced options 37, 40
- configuration options 39
- connection information 36
- finalization 38
- options 18

- Telnet
 - adding configuration 19
 - Advanced options 63, 66
 - Configuration options 63
 - options 19
- thin client image 1
- thin client, installation 5
- ThinPrint 68
- ThinPro 1
- ThinState
 - capture full image to USB drive 92
 - capture thin client settings to USB drive 92
 - deploy captured settings from USB drive 92
 - deploy full image to FTP site 92
- time and date 68
- touch screen 68

U

- user
 - interface, HP ThinPro 1
 - log in as 5
 - permissions 69

V

- VMware View
 - adding connection 18
 - Advanced options 54
 - Network options 54
 - options 18, 54

W

- window manager 69

X

- Xdmcp
 - adding connection 18
 - Advanced options 58
 - Configuration options 58
 - options 18