



ENGLISH

! ATTENTION

If your photos are cropped incorrectly, follow these steps.

1. Open the scanner lid and place your photo(s) in one or more corners of the glass.
2. Place a piece of white paper (letter or A4 size) over the photos.
3. Close the lid and scan.

Scanning from the HP Director (Windows) or HP Image Zone (Macintosh) will also give you more control over cropping.

NOTE for the HP Scanjet 4070 Photosmart scanner: If you are using the 4x6 photo holder in the HP Photo Door, do not place more than 12 photos in the 4x6 photo holder.

한국어

! 주의

사진 자르기가 제대로 되지 않으면 다음과 같이 하십시오.

1. 스캐너 덮개를 올리고 사진을 유리 모서리에 놓습니다.
2. 흰색 용지(레터 또는 A4 크기)를 사진 위에 올려 놓습니다.
3. 덮개를 닫고 스캔합니다.

HP 관리자(Windows) 또는 HP Image Zone(Macintosh)에서 스캔하면 자르기 기능을 더 많이 이용할 수 있습니다.

주 HP Scanjet 4070 Photosmart 스캐너에서 HP 사진 덮개의 4x6 사진 보관함을 사용하는 경우, 보관함에 사진을 12장 이상 놓지 마십시오.

繁體中文

! 注意

如果相片未正確裁剪，請按照下列步驟進行。

1. 打開掃描器蓋板，然後將相片放在玻璃板的一個或多個角落中。
2. 將一張白紙（letter 或 A4 大小）放在相片上。
3. 合上蓋板，然後進行掃描。

透過 HP 管理員 (Windows) 或 HP Image Zone (Macintosh) 掃描還可讓您加強對裁剪的控制。

註 對於 HP Scanjet 4070 Photosmart 掃描器：如果使用 HP 相片蓋中的 4x6 相片夾，請勿在 4x6 相片夾中放入超過 12 張的相片。

简体中文

! 注意

如果您的照片裁切不正确，请按以下步骤操作。

1. 打开扫描仪盖板，将照片放在玻璃板的一角或几个角落。
2. 将一张白纸（letter 或 A4 尺寸）放在照片上。
3. 合上盖板，然后扫描。

从 HP 控制器 (Windows) 或 HP Image Zone (Macintosh) 扫描也可以更好地控制裁切功能。

注：对于 HP Scanjet 4070 Photosmart 扫描仪，如果您使用 HP 照片盖中的 4x6 照片夹，则放置在 4x6 照片夹中的照片不要超过 12 张。



L1920-90157

