



# IMPORTANT INFORMATION ABOUT YOUR DVD SOFTWARE

## (ONLY APPLIES TO MODELS WITH DVD DRIVES)

### Do not remove the DVD-ROM Drive

Do not remove the DVD-ROM drive from the FutureBay™ until you have powered on the computer for the first time and initialized your operating system. If your operating system is initialized without the DVD-ROM drive, the DVD player software is not automatically installed.

To manually install the software:

1. Insert the DVD-ROM drive into the FutureBay.
2. Click **Start**.
3. Click **Run**.
4. Type:

`c:\cpqs\quicksr\qria.exe 151715-b2d`

then click **OK**.

Quick Restore automatically unzips and installs the DVD software.

## NOTICE

© 2001 Compaq Computer Corporation

Compaq and the Compaq logo registered U.S. Pat. & Tm. Off.

All other product names mentioned herein may be trademarks of their respective companies.

Compaq shall not be liable for technical or editorial errors or omissions contained herein. The information in this document is provided “as is” without warranty of any kind and is subject to change without notice. The warranties for Compaq products are set forth in the express limited warranty statements accompanying such products. Nothing herein should be construed as constituting an additional warranty.

Fourth Edition (March 2001)



201706-004