Upgrading and Servicing Guide Information

Your PC may use a screw to secure each add-in card instead of the retaining latch described in the procedures under "Removing or Installing an Add-in Card" in your Upgrading and Servicing Guide. When you replace or install an add-in card, follow the instructions in the Guide and at step 4 simply remove the screw that secures the card or the card slot cover.

Keep this document with your PC documentation.

Printed in



Filename: m4adfai.docTitle: Addendum [3-column 1 or 2 pages]Template: HP-Print2K.dotAuthor: James LegattLast Saved By: James LegattRevision #: 9Page: 1 of 1Printed: 06/02/04 01:48 PM