## Important Information About Your Sound Card Remote Control

The Creative Sound Blaster Audigy 2 ZS Platinum sound card comes with a remote control. You need to enable and configure this remote control before you can use it.

To enable and configure the remote control:

- 1 Click Start on the taskbar, choose All Programs, Creative, Creative MediaSource, and then click Remote Control & OSD Settings.
- **2** Select the options you want to enable; specifically, for the remote control, be sure there is a check in the check box for *Enable Creative MediaSource Remote Control*.
- 3 Click the **OK** button.

Printed in



Filename: m4adzrmt.docTitle: Addendum [3-column 3 + pages]Template: HP-Print2K.dotAuthor: James LegattLast Saved By: James LegattRevision #: 6Page: 1 of 1Printed: 08/13/04 12:57 PM