



Macintosh

Setup Poster


HP Deskjet 5700 series




1 Remove ALL orange packing material.





2 Plug in power supply.





3 Load white paper. Pull out extension.




4 **1** Verify light is on. **2** If these lights are flashing, go back to step 1.




5 **1** Open cover. **2** Pull pink tab to remove clear tape.



6 Insert print cartridges.



7 Close cover.



8 Connect printer to computer. Purchase USB cable separately.



For virtually grain-free color photos that have exceptional fade resistance, purchase a photo print cartridge.



9

Install printer software

- 1 Insert the CD into the CD drive.
- 2 Double-click the CD icon in the Finder window.
- 3 Double-click the installer icon.
- 4 Accept the licensing agreement. Follow the installation instructions for your operating system.

OS X

- 1 Click **Install**.
- 2 Click **Quit** when the installation is complete.

OS 9.x

- 1 Click **Install**.
- 2 Click **Continue** to close all open programs.
- 3 Click **Restart** to restart your computer.
- 4 After your computer restarts, open **Chooser** to add the printer.