


hp deskjet 9300



1



2




3





4



5



6




7



8



9



<http://www.hp.com/support/dj9300>



C8136-91001