



Install	Installatie	Instalacja
Installation	Asennus	Instalação
Installation	Εγκατάσταση	Установка
Installazione	Telepítés	Installation
Instalación	Instalasi	การติดตั้ง
安装	インストール	安装
Instalace	설치 설명서	Kurulum
Installation	Instalering	التثبيت
		Lea esto primero


© 2006 Hewlett-Packard Development Company, L.P.

www.hp.com




Q5982-90997


1




2




3




4




5




6




9




10




13




14




17




18




7




8




11




12




15




16




19




20



21



22



23

