


Important Information about Your HP TouchSmart PC


If a system recovery is needed, the IR emitter cable must remain connected to your HP TouchSmart PC and your set-top box during the entire system recovery process. Failure to do so may prevent the IR emitter from working properly.



IR Emitter Cable

NOTE: Connecting an IR emitter cable is optional and is only needed if your HP TouchSmart PC is connected to a set-top box.

Refer to the *HP TouchSmart PC User Guide* for instructions about connecting the IR emitter cable and refer to the *Troubleshooting and Maintenance Guide* for instructions about performing a system recovery.



Connecting an IR Emitter Cable to a Set-top Box

Copyright © 2007 Hewlett-Packard Development Company, L. P.

Printed in



5 9 9 1 - 8 7 6 7