





Print on both sides (duplex)

How do I?	Steps to perform
Print on both sides manually	<ol style="list-style-type: none"><li data-bbox="730 347 1325 459">1 Insert enough paper into one of the trays to accommodate the print job. If you are loading special paper such as letterhead, load it with the top forward and the side to be printed on facing up.<li data-bbox="730 719 1325 775">2 Open the printer driver. On the Finishing tab, select Correct order for straight paper path.<li data-bbox="730 794 1325 850">3 Select Print on both sides (manually), and then open the rear output bin door.<li data-bbox="730 869 869 893">4 Click OK.  





How do I?	Steps to perform
<p>Print on both sides manually (continued)</p>	<p>5 After side one has printed, without changing the orientation, remove the paper stack from the output bin. Do not discard blank sheets. Maintaining the same orientation, insert the paper stack into the priority feed tray or the main tray, printed side down.</p> <p>6 Click Continue to print side two. On the HP LaserJet P1500 Series, press Go on the device control panel after clicking Continue.</p> 