

# HP LaserJet P1000 and P1500 Series – Print



## Select page orientation

How do I?	Steps to perform
Select page orientation	<ol style="list-style-type: none"><li>1 Open the printer driver, and click the <b>Finishing</b> tab.</li><li>2 In the <b>Orientation</b> area, click <b>Portrait</b> or <b>Landscape</b>.</li><li>3 To print the page image upside down, click <b>Rotate by 180 degrees</b>.</li><li>4 Click <b>OK</b>.</li></ol>

