



Replace print cartridges

How do I?

Replace the print cartridge

NOTE: See the recycling information inside the print-cartridge box. To prevent damage to the print cartridge, minimize its exposure to direct light by covering it with a sheet of paper.

Steps to perform

- 1 Open the print-cartridge door, and remove the old print cartridge.
- 2 Remove the new print cartridge from the packaging. Pull the tab until all the tape is removed from the cartridge. Put the tab in the print-cartridge box to return for recycling.
- 3 Gently rock the toner cartridge from front to back to distribute the toner evenly inside the cartridge.
- 4 Insert the print cartridge in the device and close the print-cartridge door.

