

# HP Color LaserJet CP6015 Series Select paper and print quality (PCL 6 Driver)



PCL 6 is the default driver and is recommended for printing in all Windows environments. It provides the overall best speed, print quality, and product-feature support for most users, and has been developed to align with the Windows Graphic Device Interface (GDI) for the best speed in Windows environments. However, it might not be fully compatible with third-party and custom software programs that are based on PCL 5. To access the driver, see “Open print driver (PCL 6 Driver)” document.

How do I	Steps to perform
Select a <b>page size</b> .	Click on the <b>Paper/Quality</b> tab (1). Select a size from the <b>Paper size</b> drop-down list (2).
Select a <b>paper source</b> .	Select a tray from the <b>Paper Source</b> drop-down list (3).
Select a <b>paper type</b> .	Select a type from the <b>Paper Type</b> drop-down list (4).
<b>Print covers</b> on different paper. Print the first or last page on different paper.	In the <b>Special pages</b> area (5), click <b>Covers</b> or <b>Print pages on different paper</b> , and then click <b>Settings</b> (6). Select an option to print a blank or preprinted front or back cover, or both. Or, select an option to print the first or last page on different paper. Select options from the <b>Paper source</b> and <b>Paper type</b> drop-down lists, and then click <b>Add</b> . Click <b>OK</b> .
<b>Adjust the resolution</b> of printed images.	In the <b>Print Quality</b> area (7), select an option from the drop-down list. See the printer driver online Help for information about each of the available options.

