

# HP Color LaserJet CP6015 Series Replace image drums



How do I	Steps to perform
Replace image drums.	<p>Replace an image drum when the control panel displays the REPLACE &lt;COLOR&gt; DRUM message.</p> <p>The control panel display will also indicate the color that should be replaced (if a genuine HP cartridge is currently installed).</p> <p>Grasp the grips on the sides of the front door and pull down to open (1).</p> <p>Locate the handle of the image drum above the rectangular color label.</p> <p>With one hand, lift and slowly pull the used image drum out of the product, while supporting the length of the image drum by holding the blue handle. (2).</p> <p>Store the used image drum in the protective bag. Information about recycling used image drums is on the image drum box.</p> <p>Remove the new image drum from its packaging (3).</p> <p><b>Note:</b> Do not touch the green cylinder on the bottom of the drum with your fingers or any surface to avoid damaging the drum.</p> <p>Align the slots of the image drum. (4).</p> <p>Insert the image drum until it clicks into place (5).</p> <p>Close the front door (6).</p>

