

HP Color LaserJet CP6015 Series **Replace print cartridges**



How do I	Steps to perform
Replace print cartridges.	<p>Replace a print cartridge when the control panel displays the REPLACE <COLOR> CARTRIDGE message.</p> <p>The control panel display will also indicate the color that should be replaced (if a genuine HP cartridge is currently installed).</p> <p>Grasp the grips on the sides of the front door and pull down to open (1).</p> <p>Grasp the handle of the used print cartridge above the square color label and pull out to remove (2).</p> <p>Remove the new print cartridge from its packaging (3).</p> <p>Hold both ends of the cartridge and shake up and down 5-6 times (4).</p> <p>Align the slots of the print cartridge (5).</p> <p>Insert the print cartridge until it clicks into place (6).</p> <p>Close the front door (7).</p>

