









Display the IP address on the control panel

How do I?	Steps to perform
<p data-bbox="92 375 705 411">Display the IP address on the control panel</p> <p data-bbox="92 603 684 683">NOTE: You can also view the IP address in the EWS or HP ToolboxFX by selecting the Advanced Network Settings tab.</p>	<ol style="list-style-type: none"><li data-bbox="722 347 1129 375">1 On the control panel, press Setup. <li data-bbox="722 608 1192 659">2 Use the arrow buttons to select Network configuration, and then press OK. <p data-bbox="1478 659 1633 715">Network configuration</p><li data-bbox="722 935 1192 986">3 Use the arrow buttons to select Show IP address, and then press OK. <p data-bbox="1520 967 1619 1023">Show IP address</p>

