




Display the IP address on the control panel

How do I?	Steps to perform	
<p data-bbox="86 375 711 411">Display the IP address on the control panel</p> <p data-bbox="86 563 711 643">NOTE: You can also view the IP address in the EWS or HP ToolboxFX by selecting the Advanced Network Settings tab.</p>	<ol data-bbox="716 343 1354 837" style="list-style-type: none"><li data-bbox="716 343 1354 375">1 On the control panel, press Setup.<li data-bbox="716 563 1354 627">2 Use the arrow buttons to select Network configuration, and then press OK.<li data-bbox="716 786 1354 837">3 Use the arrow buttons to select Show IP address, and then press OK.	 <p data-bbox="1801 635 1961 691">Network configuration</p> <p data-bbox="1801 850 1898 906">Show IP address</p>

