

HP Color LaserJet CP3525 Series Printer



Clear Jams
清除卡紙
Elakadások elhárítása
Устранение замятий

Eliminer les bourrages
Odstranění uvíznutých médií
용지 걸림 해결
Rensa trassel


Staus beseitigen
Afhjælp papirstop
Fjerne fastkjørt papir
清除卡紙

Eliminazione degli inceppamenti
Stringen verhelpen
Usuwanie zacięć
Kağıt sıkışmalarını Giderme


Eliminación de atascos
Tukosten poistaminen
Limpar atolamentos
Eliminació d'embussos

紙詰まりの解消


13.30.00




1




2




3




13.30.00
13.01.00
13.02.00




1




2




3




4




5




6




13.30.00
13.01.00
13.04.00




1




2




3




4




5




6




13.12.00
13.13.00




1




2




3




3




13.05.00
13.06.00
13.10.00




1




2



3



3



3

