HP Color LaserJet CP3525 Series Printer - Animation: Clear Tray 3 Jams

This animation demonstrates the correct procedure for removing a jam from tray 3 of the product.

Click the file below to begin the animation (Adobe Acrobat version 9 required to view animation):

