

HP Color LaserJet CP3525 Series Printer - Animation: Replace Print Cartridges

This animation demonstrates the correct procedure for replacing the print cartridges in the product.

Click the file below to begin the animation (Adobe Acrobat version 9 required to view animation):

