

HP LaserJet P3010 Series Printer - Animation: Clear Tray 1 Jams

This animation demonstrates the correct procedure for removing a jam from tray 1 of the product.

Click the file below to begin the animation (Adobe Acrobat version 9 required to view animation):

