## HP LaserJet P3010 Series Printer - Animation: Load Tray 1

This animation demonstrates how to load media in to tray 1 of the product.

Click the file below to begin the animation (Adobe Acrobat version 9 required to view animation):

