

HP LaserJet P3010 Series Printer - Animation: Load Tray 2

This animation demonstrates how to load media in to tray 2 of the product.

Click the file below to begin the animation (Adobe Acrobat version 9 required to view animation):

