

The c200 combines flexibility and power. It offers you 14 MP high resolution along with 720p HD video recording to capture amazing images in bold colors. The c200 features over 25 different scene modes. With the easy-to-navigate user interface, the c200 makes taking pictures simple and fun, giving you everything you need to capture quality pictures and videos to share with family and friends.



High definition images with outstanding clarity

The c200 offers you 14MP high resolution and 720p HD video recording to capture amazing photos or videos in detail and vivid colors. With 3X optical zoom, the c200 lets you magnify and capture sharp images when taking pictures from a distance. The c200 offers you everything you need to capture life-like images to share with family and friends.

Easy-to-navigate user interface

The user interface features modern 3D icons and greater color contrast for improved visibility when navigating menu selections in bright light. Additionally, when choosing scene modes, two images are shown as examples of what a picture would look like in comparison to using the auto mode.

Smile detection and blink detection

With smile detection, the camera will search for a smile and automatically take the picture when the subject is smiling. This feature is especially helpful when trying to capture pictures of young children. When using the blink detection feature, the camera alerts you if a subject is blinking when the picture is taken. The camera will then prompt you to either keep or delete the picture. When using the high-speed burst mode, the camera will take six 3MP resolution shots in one second. This feature is perfect for capturing fast-moving scenes. Now you can capture clear amazing pictures at sporting events.

Over 25 scene modes

With over 25 scene modes, you can easily ensure the best shot is captured in different shooting situations. Pick the mode that best matches your activity or use the intelligent scene mode to let the camera detect the conditions and select the best mode for you.

The c200 comes with three new scene modes for you to create fun special effects: LOMO, Fisheye, and D-lighting. When using LOMO, the camera will create a halo effect around your picture, and capture the people and objects in an artistic, over-saturated color. Using the Fisheye scene mode, the camera will create a circular fish-eye appearance. Turn on D-Lighting to balance high contrast images. The camera optimizes the image by improving details of the darker areas while maintaining natural contrast for a realistic image.

Package contents

- HP c200 digital camera
- Wrist strap
- 0.8 meter USB cable
- 2 x AA batteries
- Quick start guide
- Software install and electronic user manual CD-ROM
- Warranty document



SPECIFICATIONS

LCD Display	2.7" screen
Sensor Type	14 MP CMOS
Total Pixels	14.6 MP (4416 × 3312)
Effective Pixels	14.0 MP (4320 × 3240)
Zoom	3X optical zoom, 5X digital zoom
Still Image Format	JPEG/EXIF 2.2
ISO Sensitivity	Auto, 50, 100, 200, 400, 800, 1600
Video Format	AVI (Motion JPEG)
Storage Media	SD/SDHC (Up to 32GB)
Minimum System Requirements	Microsoft Windows XP/Vista/7 Pentium III 1GHz processor or equivalent 512 MB RAM or greater 300 MB available hard disk space for software installation
Power	2 x AA batteries
Dimensions	92.0 x 60.5 x 25.0 mm (3.54 x 2.38 x 0.98 in)
Weight	0.11 kg (0.25 lb) (without battery)
Warranty	One year limited hardware warranty from date of purchase

Questions about the HP Digital Camera? Look us up online at http://www.hp.com