



## Web Services

Your new HP printer supports the following web services. To use Web Services, your printer needs a wireless network connection to the Internet.

### ePrint

Use HP's free ePrint service to print email and attachments. If you can email it, you can print it. To register for ePrint, visit [www.eprintcenter.com](http://www.eprintcenter.com).

### eFax

Send and receive faxes with eFax – without a phone line – using a web-based faxing service. This service is free when you send up to 20 pages and receive up to 20 pages per month. To register for eFax, visit [www.eFax.com](http://www.eFax.com).

Note: eFax may not be available in all countries/regions.

### Print Apps

Print web content without using a computer. Select Apps on the printer's Home screen to print pages for the whole family. Print coupons, recipes, maps, news, coloring pages, and more.

## Power On Troubleshooting

If your printer does not turn on, try these steps:

1. Unplug the power cord.
2. Plug the power cord back in, and then press the **Ⓢ** button.  
Take care to press the **Ⓢ** button only once.

## Network Troubleshooting

Run a Wireless Network Test to check that your printer is on the network.

1. On the printer display, touch the **Wireless** icon to open the **Wireless** menu.
2. Touch **Settings**, then select **Wireless Network Test**. A Wireless Network Test report prints when the test completes.

If your printer is not connected to the network:

1. Touch the **Wireless** icon to open the **Wireless** menu.
2. Select **Settings**, then **Wireless Setup Wizard**.
3. Follow the instructions on the screen.

For more information, go to the HP Wireless Printing Center website ([www.hp.com/go/wirelessprinting](http://www.hp.com/go/wirelessprinting)).

## Auto Wireless Connect

Auto Wireless Connect automatically configures the printer with your wireless network settings. Follow the instructions on the printer display to set up the printer, and then insert the printer software CD. The software guides you through the software installation.


## Advanced printer controls on your mobile device

Download an HP mobile app to bring premium print controls to your mobile device—print, scan, copy and more:

- Access advanced printer controls on your mobile device.
- Scan directly to social network sites.
- Scan directly to an email account.

For supported devices and functionality, see [www.hp.com/go/mobile-printing-solutions](http://www.hp.com/go/mobile-printing-solutions).


## Home Screen



Touch a button or icon to activate. Swipe left or right to scroll through the Apps.

Note: eFax may not be available in all countries/regions.

## Get to Know



# ENVY 110 Series





ENVY<sup>110</sup> Series

Quick Reference



Printed in [English]  
© 2011 Hewlett-Packard Development Company, L.P.



CQ809-90043