The c500 combines flexibility and power. It offers 14.2 MP high resolution along with 720p HD video recording to capture amazing images in bold colors. The c500 features over 30 different scene modes. The easy-to-navigate user interface makes taking pictures with the c500 simple and fun. The c500 gives you everything you need to capture quality pictures and videos to share with family and friends.



High definition images with outstanding clarity

The c500 offers 14.2MP high resolution and 720p HD video recording to capture amazingly detailed photos and videos in vivid colors. With a 5X optical zoom, the c500 lets you magnify and capture sharp images when taking pictures from a distance. The c500 offers you everything you need to capture life-like images to share with family and friends.

Easy-to-navigate user interface

The user interface features modern 3D icons and greater color contrast for improved visibility when navigating menu selections in bright light.

Additionally, when choosing scene modes, two example images are shown to illustrate what a picture would look like using the scene mode compared to using the auto mode.

Smile detection and blink detection

With smile detection, the camera will search for a smile and automatically take the picture when the subject is smiling. This feature is especially helpful when trying to capture pictures of young children. When using the blink detection feature, the camera alerts you if a subject is blinking when the picture is taken. The camera will then prompt you to either keep or delete the picture. When using the high-speed burst mode, the camera will take 30 VGA -quality photos in one second. This feature is perfect for capturing fast-moving scenes. Now you can capture clear amazing pictures at sporting events.

Over 30 scene modes

With over 30 scene modes, you can easily ensure the best shot is captured in different shooting situations. Pick the mode that best matches your activity or use the intelligent scene mode to let the camera detect the conditions and select the best mode for you.

The c500 comes with three new scene modes for you to create fun special effects: LOMO, Fisheye, and D-lighting. When using LOMO, the camera will create a halo effect around your picture, and capture the people and objects in an artistic, over-saturated color. Using the Fisheye scene mode, the camera will create a circular fish-eye appearance. Turn on D-Lighting to balance high contrast images. The camera optimizes the image by improving details of the darker areas while maintaining natural contrast for a realistic image.

Package contents

- HP c500 digital camera
- Wrist strap
- 0.8 meter USB cable
- 2 x AA batteries
- Quick start guide
- Software install and electronic user manual CD-ROM
- Warranty document



SPECIFICATIONS

LCD Display 2.7" screen

Sensor Type 14.2 MP CCD

Total Pixels 14.5 MP (4440 x 3274)

Effective Pixels 14.2 MP (4368 x 3256)

Zoom 5X optical zoom, 5X digital zoom

Still Image Format JPEG/EXIF 2.2

ISO Sensitivity Auto, 100, 200, 400, 800, 1600, 3200, 6400

Video Format AVI (Motion JPEG)

Storage Media SD/SDHC (Up to 32GB)

Minimum System Microsoft Windows XP/Vista/7

Requirements Pentium III 1GHz processor or equivalent

512 MB RAM or greater

300 MB available hard disk space for software installation

Power 2 x AA batteries

Dimensions $94.5 \times 61 \times 21.4 \text{ mm} (3.72 \times 2.40 \times 0.84 \text{ in})$

Weight 0.105 kg (0.23 lb) (without battery)

Warranty One year limited hardware warranty from date of purchase