



HP Retail Integrated Webcam Installation Instructions



Copyright © 2012 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice. Printed in



691055-002

Installing Drivers for the Webcam

The drivers for the Webcam are available on the CD included with this product. You can also download the latest drivers from www.hp.com.

Configuring the Webcam


To configure the Webcam, insert the CD included with this product and follow the instructions on the CD.

NOTE: Refer to the *HP L6015tm and L6017tm Retail Touch Monitors User Guide* at www.hp.com for detailed instructions on installing USB modules.


CAUTION: This accessory is for use only with compatible UL Listed host products that have been evaluated for the operating altitude up to 3048m/10,000 feet. Use only with Listed ITE.

HP L6015tm and L6017tm Retail Touch Monitors

1




2




3




4




5




6




7



8



9





HP Retail Integrated Webcam Installation Instructions



Copyright © 2012 Hewlett-Packard Development Company, L.P. The information contained herein is subject to change without notice. Printed in



691055-002


NOTE: Drivers for the Webcam are provided by the Windows operating system that supports the retail product.

NOTE: Refer to the *HP RP7 Retail System Hardware Reference Guide* at www.hp.com for detailed instructions on installing USB modules.


CAUTION: This accessory is for use only with compatible UL Listed host products that have been evaluated for the operating altitude up to 3048m/10,000 feet. Use only with Listed ITE.

HP RP7 Retail System


1




2




3




4



5



6



7



8

