






1





2





3





4



123.hp.com



EN Go to **123.hp.com** to complete printer setup.

DE Rufen Sie **123.hp.com** auf, um die Druckereinrichtung abzuschließen.

FR Allez sur **123.hp.com** pour compléter la configuration de l'imprimante.

IT Vai su **123.hp.com** per completare la configurazione della stampante.

ES Vaya a **123.hp.com** para completar la configuración de la impresora.

PT Acesse **123.hp.com** para concluir a configuração da impressora.

NL Ga naar **123.hp.com** om de installatie van de printer te voltooien.

SV Gå till **123.hp.com** för att slutföra skrivarinställningarna.

NO Gå til **123.hp.com** for å fullføre oppsett av skriver.

DA Gå til **123.hp.com** for at udføre printeropsætning.

FI Viimeistele tulostinmääritykset osoitteessa **123.hp.com**.

ET Printeri seadistamise lõpuleviimiseks minge veebisaidile **123.hp.com**.

LV Lai pabeigtu printera iestatīšanu, dodieties uz **123.hp.com**.

LT Apsilankykite adresu **123.hp.com**, kad užbaigtumėte spausdintuvo sąranką.

? www.hp.com/support/dj3700

