



## Storage Considerations

HP OfficeJet Pro X Series (X451, X551, X476, X576)

HP PageWide Pro Series (352, 377, 452, 477, 552, 577)

HP PageWide Color/Color MFP Series (556, 586)

### Summary

Sometimes products in the HP Officejet Pro X series, the HP PageWide Pro series, and the HP PageWide Color/Color MFP series will go for long periods of time with little to no use (for example, during a holiday break). To maintain the lifespan and print quality of the product, leave it turned on. After the product is initialized, it should not be turned off for longer than three (3) months.

NOTE: The printer must always be properly shut down using the power button and not by unplugging the power cord.

© 2019 HP Inc. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.