Hewlett-Packard Certificate of Volatility				
Model:		Part Number:		Address:
HP LaserJet Pro		G3Q59A = M130fn		Hewlett Packard Company
M130/M132/M134		G3Q63A = M132fn		11311 Chinden Blvd
Multifunction Printer Series		G3Q64A = M132fp		Boise, ID 83714
		G3Q67A = M134fn		,
Volatile Memory				
Does the device contain volatile memory (Memory whose contents are lost when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below				
	Size:	tne type, size, fur User Modifiable:	Function: Used for temporary	Steps to clear memory:
Type (SIVAINI, DIVAINI, etc).	256MB	Oser Modifiable.	storage during the processing	
DDR3-DRAM			of jobs and for applications	OFF, the memory is erased.
			running on the OS.	
		☐ Yes ⊠ No	-	
Type (SRAM, DRAM, etc):	Size:	User Modifiable:	Function:	Steps to clear memory:
		☐ Yes ☐ No		
Type (SRAM, DRAM, etc):	Size:	User Modifiable:	Function:	Steps to clear memory:
		Yes No		
Non-Volatile Memory				
Does the device contain non-volatile memory (Memory whose contents are retained when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below				
Type (Flash, EEPROM, etc):	Size:	User Modifiable:	Function:	Steps to clear memory:
	0.20.	Coor Modification		Ctope to creat memory.
EEPROM	40170		0,000	De Constant NVD ANA Self-eller of the
	16KB	☐ Yes ⊠ No	Store customer setting data for backup/restore	Perform NVRAM initialization according to service manual, it
			backup/restore	returns most system parameter
				in NVRAM to default factory
				setting.
Type (Flash, EEPROM, etc):	Size:	User Modifiable:	Function:	Steps to clear memory:
Nand-Flash	128MB	☐ Yes ⊠ No	Store firmware code, File	Permanent storage requires
			system, customer setting date for backup/restore	a special code to clear or update firmware- Typically not done by
			loi backup/restore	the user
Type (Flash, EEPROM, etc):	Size:	User Modifiable:	Function:	Steps to clear memory:
		Yes No		
Mass Storage				
Does the device contain mass storage memory (Hard Disk Drive, Tape Backup)?				
Yes No If Yes please describe the type, size, function, and steps to clear the memory below				
Type (HDD, Tape, etc):	Size:	User Modifiable:	Function:	Steps to clear memory:
		Yes No		
T. m a /LIDD T	0:	Lloon Maratici - Ial		Chang to slope as a second
Type (HDD, Tape, etc):	Size:	User Modifiable:	Function:	Steps to clear memory:
USB				
Does the item accept USB input and if so, for what purpose (i.e Print Jobs, device firmware updates, scan upload)?				
☐ Yes ☐ No If Yes please describe below The front USB host can accept print jobs, scan uploads, photos and can be used to upload printer firmware.				
Can any data other than scan upload be sent to the USB device)?				
☐ Yes ☐ No If Yes please describe below				
Rear USB host when configured will accept stored jobs, encrypted files stored and deleted by user.				