HP PageWide C500 Press

Customer Self-Repair Document (CSR)





Replacing the Aerosol Cassettes

Service Code:	AER[x]
CSR Level:	CSR B
Part Number:	CX245-06610
Part Name:	AEROSOL CASSETTE
Frequency:	as needed
Document ID:	c05942234
Revision:	Draft 1
Date:	01-May-2018



Required personnel:	1
Required time:	10 minutes
Required tools:	None

Important:


Make sure to comply with all relevant federal, state, and local regulations when disposing of replaced parts.



Procedure

- 1. Open the print engine service doors on the operator side of the press.
- 2. Disconnect the vacuum hose coming from the aerosol vacuum pump.





1 Vacuum hose

3. Disconnect the water tube.




4. Pull out the aerosol cassette.




2/3 Rev. Preliminary



5. Take the new cassette and carefully insert the rail into the bearings on the bridge. Keep inserting until you hear the click.





1	Bearings on bridge
2	Cassette rail

Caution:

The space for inserting the aerosol cassette is very narrow. Insert the cassette carefully to prevent possible damage to the capping assembly.

- **6.** Reconnect the water tube.
- **7.** Reconnect the vacuum tube.
- **8.** Close the print engine service doors.

Rev. Preliminary 3/3