




Optimum Resolution

80 cm/31.5-inch: 2560 × 1440 @ 60 Hz











www.hp.com/support


© Copyright 2019 HP Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein. First Edition: March 2019


RMN: HSD-0023-W Printed in XXX























EN English

WARNING: To reduce the risk of electric shock or damage to the equipment: • Plug the power cord into an AC outlet that is easily accessible at

all times. • Disconnect power from the monitor by unplugging the power cord

from the AC outlet. If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature

Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental

information, refer to the Product Notices provided with your product. In some countries or regions. HP may provide the HP Limited Warranty in the box. For countries or regions where the

warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address

AR Arabic

WARNING: To reduce the risk of electric shock or damage to 4 the equipment:

 Plug the power cord into an AC outlet that is easily accessible at all times.

• Disconnect power from the monitor by unplugging the power cord from the AC outlet.

• If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental

information, refer to the *Product Notices* provided with your product. In some countries or regions, HP may provide the HP Limited

Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

D Bahasa Indonesia

WARNING: To reduce the risk of electric shock or damage to 4 the equipment:

• Plug the power cord into an AC outlet that is easily accessible at all times.

• Disconnect power from the monitor by unplugging the power cord from the AC outlet. • If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental

information, refer to the Product Notices provided with your product. In some countries or regions, HP may provide the HP Limited

Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

вс Български

WARNING: To reduce the risk of electric shock or damage to the equipment:

• Plug the power cord into an AC outlet that is easily accessible at all times.

• Disconnect power from the monitor by unplugging the power cord from the AC outlet.

• If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

Go to **www.hp.com/support** to locate your user guide, drivers, and software. For safety, regulatory, and environmental **L** Ελληνικά

information, refer to the *Product Notices* provided with your product. In some countries or regions. HP may provide the HP Limited Warranty in the box. For countries or regions where the

warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

Česky CS

WARNING: To reduce the risk of electric shock or damage to (L) the equipment: Plug the power cord into an AC outlet that is easily accessible at

all times.

• Disconnect power from the monitor by unplugging the power cord

from the AC outlet. • If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the

warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address

DA Dansk

WARNING: To reduce the risk of electric shock or damage to the equipment: • Plug the power cord into an AC outlet that is easily accessible at

all times. • Disconnect power from the monitor by unplugging the power cord

from the AC outlet. If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power

cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature Go to www.hp.com/support to locate your user guide, drivers,

and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

DE Deutsch

WARNING: To reduce the risk of electric shock or damage to (1) the equipment:

- Plug the power cord into an AC outlet that is easily accessible at
- all times. • Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power
- cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.
- In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the

warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

ES Español

WARNING: To reduce the risk of electric shock or damage to the equipment:

• Plug the power cord into an AC outlet that is easily accessible at

all times. • Disconnect power from the monitor by unplugging the power cord from the AC outlet.

• If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power

cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature. Go to www.hp.com/support to locate your user guide, drivers,

and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

Este producto es una pantalla de ordenador con una fuente de alimentación interna o un adaptador de CA externo. El póster de configuración impreso identifica los componentes de hardware de su pantalla. Dependiendo de su modelo de pantalla, los productos tienen una clasificación de potencia de 100-240 V CA, 200-240 V CA o 100-127/200-240 V CA, 50-60 Hz o 50/60 Hz, 1,5 A, 3 A, 4 A, 5,5 A, 6 A o 8 A. El adaptador de CA tiene una clasificación de 100-240 V CA 50-60 Hz o 50/60 Hz, 0,5 A, 0,6 A, 0,8 A, 1 A, 1,2 A, 1,4 A, 1,5 A, 1,6 A, 1,7 A, 2 A, 2,2 A, 2,25 A, 2,4 A, 2,5 A, 2,7 A, 2,9 A o 4 A.

Para acceder a las guías de usuario o los manuales más nuevos de su producto, consulte http://www.hp.com/support. Seleccione Encuentre su producto y siga las instrucciones que aparecen en pantalla.

WARNING: To reduce the risk of electric shock or damage to the equipment:

- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, information, refer to the Product Notices provided with your product.
- In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To

access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

FR Français

WARNING: To reduce the risk of electric shock or damage to (1) the equipment:

• Plug the power cord into an AC outlet that is easily accessible at

LT Lietuviškai

all times.

HU Magyar

all times.

Nederlands

all times.

NO ^{Norsk}

the equipment:

from the AC outlet.

all times.

Polski

all times.

(L) the equipment:

from the AC outlet.

WARNING: To reduce the risk of electric shock or damage to

• Plug the power cord into an AC outlet that is easily accessible at

• Disconnect power from the monitor by unplugging the power cord

If provided with a 3-pin attachment plug on the power cord, plug the

cord grounding pin, for example, by attaching a 2-pin adapter. The

Go to www.hp.com/support to locate your user guide, drivers,

information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited

Warranty in the box. For countries or regions where the

warranty is not provided in the box, you can find it on the Web. To

access an online copy or order a printed copy of your warranty, go to

http://www.hp.com/go/orderdocuments. For products purchased in

Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road

Post Office, Singapore 912006. Include your product name, and your

WARNING: To reduce the risk of electric shock or damage to

Plug the power cord into an AC outlet that is easily accessible at

• Disconnect power from the monitor by unplugging the power cord

• If provided with a 3-pin attachment plug on the power cord, plug the

cord grounding pin, for example, by attaching a 2-pin adapter. The

Go to www.hp.com/support to locate your user guide, drivers,

and software. For safety, regulatory, and environmental

information, refer to the *Product Notices* provided with your product.

In some countries or regions, HP may provide the HP Limited

Warranty in the box. For countries or regions where the

warranty is not provided in the box, you can find it on the Web. To

access an online copy or order a printed copy of your warranty go to

http://www.hp.com/go/orderdocuments. For products purchased in

Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road

Post Office, Singapore 912006. Include your product name, and your

WARNING: To reduce the risk of electric shock or damage to

• Plug the power cord into an AC outlet that is easily accessible at

• Disconnect power from the monitor by unplugging the power cord

• If provided with a 3-pin attachment plug on the power cord, plug the

cord into a grounded (earthed) 3-pin outlet. Do not disable the powe

Go to www.hp.com/support to locate your user quide, drivers,

cord grounding pin, for example, by attaching a 2-pin adapter. The

and software. For safety, regulatory, and environmental

information, refer to the *Product Notices* provided with your product.

In some countries or regions, HP may provide the HP Limited

warranty is not provided in the box, you can find it on the Web. To

access an online copy or order a printed copy of your warranty, go to

http://www.hp.com/go/orderdocuments. For products purchased in

Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road

Post Office, Singapore 912006. Include your product name, and your

WARNING: To reduce the risk of electric shock or damage to

• Plug the power cord into an AC outlet that is easily accessible at

• Disconnect power from the monitor by unplugging the power cord

If provided with a 3-pin attachment plug on the power cord, plug the

cord into a grounded (earthed) 3-pin outlet. Do not disable the powe

cord grounding pin, for example, by attaching a 2-pin adapter. The

Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental

information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited

warranty is not provided in the box, you can find it on the Web. To

access an online copy or order a printed copy of your warranty, go to

http://www.hp.com/go/orderdocuments. For products purchased in

Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road

Post Office, Singapore 912006, Include your product name, and your

WARNING: To reduce the risk of electric shock or damage to

• Plug the power cord into an AC outlet that is easily accessible at

Disconnect power from the monitor by unplugging the power cord

• If provided with a 3-pin attachment plug on the power cord, plug the

cord into a grounded (earthed) 3-pin outlet. Do not disable the power

cord grounding pin, for example, by attaching a 2-pin adapter. The

Go to **www.hp.com/support** to locate your user guide, drivers, and software. For safety, regulatory, and environmental

information, refer to the *Product Notices* provided with your product.

Warranty in the box. For countries or regions where the

warranty is not provided in the box, you can find it on the Web. To

access an online copy or order a printed copy of your warranty, go to

http://www.hp.com/go/orderdocuments. For products purchased in

Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road

Post Office, Singapore 912006. Include your product name, and your

In some countries or regions, HP may provide the HP Limited

Warranty in the box. For countries or regions where the

Warranty in the box. For countries or regions where the

cord into a grounded (earthed) 3-pin outlet. Do not disable the power

and software. For safety, regulatory, and environmental

grounding pin is an important safety feature

name, phone number, and postal address.

grounding pin is an important safety feature.

name, phone number, and postal address.

grounding pin is an important safety feature.

name, phone number, and postal address.

grounding pin is an important safety feature.

name, phone number, and postal address.

grounding pin is an important safety feature.

name, phone number, and postal address

cord into a grounded (earthed) 3-pin outlet. Do not disable the power

- all times. • Disconnect power from the monitor by unplugging the power cord
- from the AC outlet. If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address

T Italiano

WARNING: To reduce the risk of electric shock or damage (1) to the equipment:

- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the varranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

<mark>кк</mark> Қазақша

WARNING: To reduce the risk of electric shock or damage to the (1) equipment: • Plug the power cord into an AC outlet that is easily accessible at

- all times. • Disconnect power from the monitor by unplugging the power cord
- from the AC outlet. • If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the powe cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

ЕНЕ Өндіруші және өндіру мерзімі НР Іпс. Мекенжайы: 1501 Раде Mill Road, Palo Alto, California 94304, U.S. Өнімнің жасалу мерзімін табу үшін өнімнің қызмет көрсету жапсырмасындағы 10 таңбадан тұратын сериялық нөмірін қараңыз 4-ші, 5-ші және 6-шы сандар өнімнің жасалған жылы мен аптасын көрсетеді. 4-ші сан жылын көрсетеді, мысалы «З» саны «2013» дегенді білдіреді. 5-ші және 6-шы сандар берілген жылдың қай аптасында жасалғанын көрсетеді, мысалы, «12» саны «12-ші» апта дегенді білдіреді.

Жергілікті өкілдіктері: Ресей: 000 «ЭйчПи Инк», Ресей Федерациясы, 125171, Мәскеу, Ленинград шоссесі, 16А блок 3. Телефон/факс: +7 495 797 35 00 / +7 499 92132 50 **Қазақстан:** «ЭйчПи Глобал Трэйдинг Би.Ви.» компаниясының Қазақстандағы филиалы, Қазақстан Республикасы, 050040, Алматы к., Бостандык ауданы, Әл-Фараби даңғылы, 77/7, Телефон/факс: +7 727 355 35 52

Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product In some countries or regions, HP may provide the HP Limited

Warranty in the box. For countries or regions where the varranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address

LV Latviski

- WARNING: To reduce the risk of electric shock or damage to the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power ling pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature. Go to www.hp.com/support to locate your user guide, drivers,

and software. For safety, regulatory, and environmental

information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited

warranty is not provided in the box, you can find it on the Web. To

access an online copy or order a printed copy of your warranty, go to

http://www.hp.com/go/orderdocuments. For products purchased in

Asia Pacific, vou can write to HP at POD, PO Box 161, Kitchener Road

Post Office, Singapore 912006. Include your product name, and your

name, phone number, and postal address.

Warranty in the box. For countries or regions where the

PT Português

WARNING: To reduce the risk of electric shock or damage to the equipment:

- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet. If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The
- grounding pin is an important safety feature Go to www.hp.com/support to locate your user guide, drivers,
- and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product. In some countries or regions, HP may provide the HP Limited

Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific you can write to HP at POD PO Box 161 Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address

BR Português (Brasil)

- WARNING: To reduce the risk of electric shock or damage to the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet. • If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power
- cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature. Go to www.hp.com/support to locate your user guide, drivers,
- and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

RO Română

- WARNING: To reduce the risk of electric shock or damage to (1) the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental
- information, refer to the Product Notices provided with your product. In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the
- warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

RU ^{Русский}

- WARNING: To reduce the risk of electric shock or damage to the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

ЕПС Производитель и дата производства НР Inc.

- Адрес:1501 Page Mill Road, Palo Alto, California 94304. U.S. Дата производства зашифрована в 10-значном серийном номере, расположенном на наклейке со служебной информацией изделия
- 4-я, 5-я и 6-я цифры обозначают год и неделю производства. 4-я цифра обозначает год. например. «З» обозначает, что изделие произведено в «2013» году. 5-я и 6-я цифры обозначают номер недели в году производства, например, «12» обозначает «12-ю» неделю.
- Местные представители: Россия: 000 «ЭйчПи Инк». Российская Федерация, 125171, г. Москва, Ленинградское шоссе, 16А, стр.3, телефон/факс: +7 495 797 35 00 / +7 499 92132 50 ии «ЭйчПи Глобал Трэйдинг Би.Ви.» Республика Казахстан, 050040, г. Алматы, Бостандыкский район,
- проспект Аль-Фараби, 77/7, телефон/факс: +7 727 355 35 52 Go to www.hp.com/support to locate your user guide, drivers. and software. For safety, regulatory, and environmental
- information, refer to the *Product Notices* provided with your product. In some countries or regions, HP may provide the HP Limited
- Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

SK Slovenčina

- **WARNING:** To reduce the risk of electric shock or damage to the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.
- In some countries or regions. HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

SI Slovenščina

- WARNING: To reduce the risk of electric shock or damage to the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the *Product Notices* provided with your product.
- In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

FI Suomi

- **WARNING:** To reduce the risk of electric shock or damage to the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

sv ^{Svenska}

- WARNING: To reduce the risk of electric shock or damage to (1) the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.
- In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the

warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

TR ^{Türkçe}

- WARNING: To reduce the risk of electric shock or damage to (L) the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

Go to **www.hp.com/support** to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address

UK Українська

- WARNING: To reduce the risk of electric shock or damage to the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product.

In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road

Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address. Цей продукт – це дисплей комп'ютера із внутрішнім джерелом живлення чи зовнішнім адаптером змінного струму. У посібнику з налаштування наведено апаратні компоненти дисплея. Залежно від моделі дисплеї живляться від електромережі напругою 100–240 В змінного струму, 200–240 В змінного струму або 100–127/200–240 В змінного струму частотою 50–60 Гц або 50/60 Гц та споживають струм 1,5 А, 3 А, 4 А, 5,5 А, 6 А або 8 А. Адаптер змінного струму видає

напругу 100-240 В змінного струму частотою 50-60 Гц або 50/60 Гц га видає струм 0,5 A, 0,6 A, 0,8 A, 1 A, 1,2 A, 1,4 A, 1,5 A, 1,6 A, 1,7 A, 2 A, 2,2 A, 2,25 A, 2,4 A, 2,5 A, 2,7 A, 2,9 A ado 4 A. Актуальні посібники користувача або посібники до ваших продуктів можна знайти на веб-сайті http://www.hp.com/support. Виберіть Найдите свое устройство (Знайдіть свій пристрій) і

JA日本語 WARNING: To reduce the risk of electric shock or damage to

дотримуйтеся вказівок на екрані.

- the equipment: Plug the power cord into an AC outlet that is easily accessible at
- all times. Disconnect power from the monitor by unpluaging the power cord
- from the AC outlet. If provided with a 3-pin attachment plug on the power cord, plug the
- cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental
- information, refer to the Product Notices provided with your product. In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address

KO 한국어

- WARNING: To reduce the risk of electric shock or damage to the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet. If provided with a 3-pin attachment plug on the power cord, plug the
- cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.
- Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental
- information, refer to the Product Notices provided with your product. In some countries or regions, HP may provide the HP Limited

Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your name, phone number, and postal address.

简体中文

- WARNING: To reduce the risk of electric shock or damage to the equipment:
- Plug the power cord into an AC outlet that is easily accessible at all times.
- Disconnect power from the monitor by unplugging the power cord from the AC outlet.
- If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

and software. For safety, regulatory, and environmental

warranty is not provided in the box, you can find it on the Web. To

access an online copy or order a printed copy of your warranty, go to

http://www.hp.com/go/orderdocuments. For products purchased in

Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road

Post Office, Singapore 912006. Include your product name, and your

WARNING: To reduce the risk of electric shock or damage to

• Plug the power cord into an AC outlet that is easily accessible at

• Disconnect power from the monitor by unplugging the power cord

 If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The

Go to www.hp.com/support to locate your user guide, drivers, and software. For safety, regulatory, and environmental information, refer to the Product Notices provided with your product. In some countries or regions, HP may provide the HP Limited Warranty in the box. For countries or regions where the warranty is not provided in the box, you can find it on the Web. To access an online copy or order a printed copy of your warranty, go to http://www.hp.com/go/orderdocuments. For products purchased in Asia Pacific, you can write to HP at POD, PO Box 161, Kitchener Road Post Office, Singapore 912006. Include your product name, and your

name, phone number, and postal address.

grounding pin is an important safety feature.

name, phone number, and postal address.

繁體中文

all times.

(1) the equipment:

from the AC outlet.

Warrantv in the box. For countries or regions where the

information, refer to the Product Notices provided with your product.

In some countries or regions. HP may provide the HP Limited

Go to www.hp.com/support to locate your user guide, drivers,