

Interactive Part Locator

HP Elite Dragonfly Notebook PC

Welcome to the interactive part locator for the
HP Elite Dragonfly Notebook PC

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

Front

Left

Right

Rear

Internal

Parts List

Front View



Left View




USB 3.1 Charging Port

Power button

Security lock slot

Right View



Rear View




Internal View 1


Battery



Internal View 2




Base Enclosure




Battery



Touchpad Board




Fingerprint Reader Board




Right Speakers




M.2 Solid State Drive




WWAN Module




Audio Board




Power Button Board




Fan




USB Board



Heatsink



Motherboard



Top Cover



Display Panel Assembly

Display Panel Assembly

