

# Interactive Part Locator

## ProDesk 600 G4 Small Form Factor

Welcome to the interactive part locator for the  
ProDesk 600 G4 Small Form Factor

### Here's how to use it...

[System Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

**That's it! On every page there is a link that brings you back to either the System Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.**

# System Views

Front

Left


Right

Rear

Internal

# Parts List

# Front View




# Left View



## Right View




# Rear View






# Internal View 1




Go to Internal View 2



# Internal View 2



# Internal View 3




[Back to Internal View 2](#)




# Front Bezel



# Electro Magnetic Shield




# Drive Cage






Fan




# Fan Duct






# Graphics Card




# Optical Disk Drive







# Optical Drive Bracket




# PCI Card






# Storage Drive







# Wireless Antenna






# Wireless LAN Module






# Card Reader Board




# CPU





# Heatsink






# Solid State Drive





# Option Board






# RTC Battery





Speaker





# System Board

