

Interactive BIOS simulator

EliteDesk 800 G4/G5 TWR Series

Welcome to the interactive BIOS simulator for the
EliteDesk 800/880 G4/G5 TWR

Here's how to use it...

[BIOS Utility Menus](#): (Click the link to navigate to the individual menus)

On this page you will find thumbnail images of each of the product's BIOS utility menus. To view a specific menu in greater detail, simply click that thumbnail. Just as in the live BIOS, on each menu, you can select the tab of each of the other utility menus to navigate directly to that menu.

Menu options:


While the menu options cannot be toggled, many of them offer item specific information about that option. To view this information, use the cursor to rollover the option and the information will present in a pane on the right of the BIOS screen.

That's it!

On every page there is a link that brings you back to either this [Welcome](#) page or the [BIOS Utility Menus](#) page enabling you to navigate to whatever BIOS option you wish to review.

BIOS Utility Menus

Back to Welcome Page



Main



Security



Advanced



UEFI Drivers

Main Menu

Back to BIOS Utility Menus

The screenshot displays the HP BIOS Main Menu. At the top, there is a navigation bar with the following options: **Main** | Security | Advanced | UEFI Drivers. The **Main** option is currently selected. To the right of the navigation bar is the HP logo. Below the navigation bar, the text **HP computer setup** is visible. A large, light blue rectangular area is present on the right side of the screen, labeled **Item Specific Help** at its top edge. At the bottom right of the screen, there is a grey bar containing three buttons: **Save**, **Help**, and **Exit**.

Back to Welcome Page

Security Menu

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

Administrator Tools

Security Configuration


TXT cannot be enabled unless VTx, VTd, and TPM are enabled first.

Utilities

Activation Status: Inactive

Absolute[®] Persistence Module Permanent Disable: No

Item Specific Help



Save

Help

Exit

Back to Welcome Page

Advanced Menu

Back to BIOS Utility Menus

Main | Security | **Advanced** | UEFI Drivers



HP computer setup

Item Specific Help

Remote HP PC Hardware Diagnostics

Save Help Exit

Back to Welcome Page

UEFI Drivers

Back to BIOS Utility Menus

Main | Security | Advanced | UEFI Drivers



HP computer setup

This will restart the system into the 3rd Party Option ROM Management application.
You can get this application by pressing F3 during startup.


Item Specific Help

Save Help Exit

Back to Welcome Page

System Information

Back to BIOS Utility Menus



Main | Security | Advanced | UEFI Drivers

HP computer setup

BASIC SYSTEM INFORMATION

Product Name	EliteDesk 800/880 G4/G5 TWR
Processor 1	Genuine Intel(R) CPU 0000 @ 2.90GHz
Memory Size	8192 MB
System BIOS	Q01 Ver.00.18.00 12/06/2017

SERVICE -----

Born On Date	12/21/2017
Serial Number	TBW2030063
SKU Number	2UZ41AV
Universally Unique Identifier (UUID)	B1852B1B-9B18-3CFD-7F62-2704204ECF6B
Asset Tracking Number	TBW2030063

Press Escape to Return


Item Specific Help

Save Help Exit

Back to Welcome Page

System Diagnostics

Back to BIOS Utility Menus



The screenshot shows the HP PC Hardware Diagnostics UEFI interface. On the left is a blue vertical bar with the HP logo. The main area is white and contains the following text and elements:

- HP PC Hardware Diagnostics UEFI
- Version 6.6.0.0
- For more information, please visit: www.hp.com/go/techcenter/PCDiags
- A vertical stack of six dark grey buttons with rounded corners:
 - System Information
 - System Tests
 - Component Tests
 - Test Logs
 - Language (with a globe icon)
 - An unlabeled button at the bottom.
- A light blue rectangular box on the right with the text "Item Specific Help" at the top.

Back to Welcome Page