

Interactive BIOS simulator

HP Desktop 190-000 PC

Welcome to the interactive BIOS simulator for the
HP Desktop 190-000 PC

Here's how to use it...

[BIOS Utility Menus](#): (Click the link to navigate to the individual menus)

On this page you will find thumbnail images of each of the product's BIOS utility menus. To view a specific menu in greater detail, simply click that thumbnail. Just as in the live BIOS, on each menu, you can select the tab of each of the other utility menus to navigate directly to that menu.

Menu options:

While the menu options cannot be toggled, many of them offer item specific information about that option. To view this information, use the cursor to rollover the option and the information will present in a pane on the right of the BIOS screen.

That's it!

On every page there is a link that brings you back to either this Welcome page or the BIOS Utility Menus page enabling you to navigate to whatever BIOS option you wish to review.

BIOS Utility Menus

[Back to Welcome Page](#)



Main



Security



Configuration




Boot Options



Exit

Main Menu

Back to BIOS Utility Menus



MainSecurityConfigurationBoot OptionsExit

System Time[00:09:34]

System Date[10/20/2018]

Product NameHP Desktop PC

System FamilyHP190

Product Number4NS06AV

System Board ID8526

Born On Date00/00/0000

Processor TypeIntel(R) Core(TM) i3-8100 CPU@ 3.60GHz

Total Memory8 GB

BIOS VendorAMI

BIOS RevisionB.09

▶Device Firmware Revision

Serial NumberHSHW310106

UUID Number6867D2A5-D90A-A135-35BB-8FE3F8DB0F40

System Board CT NumberPHMMCX3CYB6B29

Factory installed OSWin10

▶System Log

Build ID18WW2HIT6a#SABG#DABG


Feature Byte2U3E 3K3N 4C6J 6S6b 7B7K 7P7Q 7T7W aBaJ apaq asau bCbh bpcb dUdp dqfP js .8e

Item Specific Help

Back to Welcome Page

Security Menu

Back to BIOS Utility Menus



MainSecurityConfigurationBoot OptionsExit

Administrator Password[Clear]

Power-On Password[Clear]

Intel Software Guard Extensions (SGX)[Enabled]

TPM Device[Available]

TPM State[Enabled]

Clear TMP[No]


Restore Security settings to Factory defaults

Item Specific Help

Back to Welcome Page

Configuration Menu

Back to BIOS Utility Menus



MainSecurityConfigurationBoot OptionsExit


Language[English]
Virtualization Technology[Disabled]
Num Lock State at Power-On[On]
S4/S5 Wake on LAN[Disabled]
▶ Device Options
▶ Thermal
▶ UEFI HII Configuration

Item Specific Help

Back to Welcome Page

Boot Options Menu

Back to BIOS Utility Menus



Main

Security

Configuration

Boot Options

Exit

POST HotKey Delay

USB Boot

Network Boot

Network Boot Protocol

Legacy Support

Secure Boot

Platform Key

Pending Action

Clear All Secure Boot Keys

Load HP Factory Defaults Keys

Load MSFT Debug Policy Keys

UEFI Boot Order

▶ OS Boot Manager

Internal CD/ROM Drive

USB Flash Drives/USB Hard Disk

USB CD/DVD ROM Drive

! USB Network Adapter

Legacy Boot Order

Notebook Hard Drive

USB Flash Drive/USB Hard Disk

USB CD/DVD ROM Drive

! USB Network Adapter

[0]

[Enabled]

[Disabled]

[IPv4+IPv6 (UEFI)]

[Disabled]

[Enabled]

Enrolled


None

Item Specific Help

Back to Welcome Page

Exit Menu

Back to BIOS Utility Menus



MainSecurityConfigurationBoot OptionsExit


Save Changes and Exit
Ignore Changes and Exit
Load Setup Defaults

Item Specific Help

Back to Welcome Page

Device Firmware Revision

[Back to BIOS Utility Menus](#)



Main

Device Firmware Revision


Intel ME (Management Engine)	12.0.6.1120
GOP (Graphic Output Protocol)	9.0.1079

Item Specific Help

[Back to Welcome Page](#)

System Log

[Back to BIOS Utility Menus](#)



Main

System Log

Result
0502

Time:
010109-000039


- No Data -
- No Data -
- No Data -
- No Data -
- No Data -
- No Data -
- No Data -
- No Data -
- No Data -
- No Data -
- No Data -
- No Data -

Item Specific Help

[Back to Welcome Page](#)

Device Options

[Back to BIOS Utility Menus](#)



Configuration

Device Options


Multi-Processor	[Enabled]
Hyper_Threading	[Enabled]
NIC PXE Option ROM Download	[Enabled]
PCI SERR# Generation	[Enabled]
PCI VGA Palette Snooping	[Disabled]

Item Specific Help

[Back to Welcome Page](#)

Thermal

[Back to BIOS Utility Menus](#)



Configuration

Thermal

CPU Fan Speed : 1002 RPM


CPU Fan Check [Enabled]

Item Specific Help

[Back to Welcome Page](#)

UEFI HII Configuration

[Back to BIOS Utility Menus](#)



Configuration

UEFI HII Configuration

▶MAC: 101E7C62944A5-IPv4 network Configuration

▶MAC: 101E7C62944A5-IPv6 network Configuration

Item Specific Help

[Back to Welcome Page](#)