

Interactive Part Locator

HP ProDesk 400 SFF G5 Desktop PC

Welcome to this interactive part locator

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find a thumbnail viewer with a menu of this product's external views. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

[Back to Welcome page](#)



Front



Rear




Internal

[Go to Parts List](#)

Front View


[Back to External Views](#)



[Go to Parts List](#)

Rear View

[Back to External Views](#)



[Go to Parts List](#)

Internal View

[Back to External Views](#)

Front EMI bracket

System Board

Memory module


Heat sink

Fan duct

Speaker

RTC battery

Power supply



[Go to Parts List](#)

Access Panel

Access Panel

- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

Optical Drive

Access Panel

Optical Drive

Expansion Card Board

Main Bezel (Top)

Main Bezel (Bottom)

Dust Filter Bezel

Drive Cage

Hard Disk Drive

System Memory

Fan Duct

PS2 and Serial Port

Heat Sink

Processor (CPU)

Power Supply

SD Card Reader

Speaker

Wireless LAN Antennas

Front EMI Bracket

RTC Battery

System Board (Top)


System Board (Bottom)

Go to External Views



Expansion Card Board

- Access Panel
- Optical Drive
- Expansion Card Board**
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

Main Bezel (Top)

- Access Panel
 - Optical Drive
 - Expansion Card Board
 - Main Bezel (Top)**
 - Main Bezel (Bottom)
 - Dust Filter Bezel
 - Drive Cage
 - Hard Disk Drive
 - System Memory
 - Fan Duct
 - PS2 and Serial Port
 - Heat Sink
 - Processor (CPU)
 - Power Supply
 - SD Card Reader
 - Speaker
 - Wireless LAN Antennas
 - Front EMI Bracket
 - RTC Battery
 - System Board (Top)
 - System Board (Bottom)
- [Go to External Views](#)



Main Bezel (Bottom)

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)**
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



Dust Filter Bezel


- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel**
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

Drive Cage

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage**
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

Hard Disk Drive

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive**
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

System Memory

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory**
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

Fan Duct


- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct**
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

PS2 and Serial Port

- Access Panel
 - Optical Drive
 - Expansion Card Board
 - Main Bezel (Top)
 - Main Bezel (Bottom)
 - Dust Filter Bezel
 - Drive Cage
 - Hard Disk Drive
 - System Memory
 - Fan Duct
 - PS2 and Serial Port**
 - Heat Sink
 - Processor (CPU)
 - Power Supply
 - SD Card Reader
 - Speaker
 - Wireless LAN Antennas
 - Front EMI Bracket
 - RTC Battery
 - System Board (Top)
 - System Board (Bottom)
- [Go to External Views](#)



Heat Sink

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink**
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)



Processor (CPU)

- Access Panel
 - Optical Drive
 - Expansion Card Board
 - Main Bezel (Top)
 - Main Bezel (Bottom)
 - Dust Filter Bezel
 - Drive Cage
 - Hard Disk Drive
 - System Memory
 - Fan Duct
 - PS2 and Serial Port
 - Heat Sink
 - Processor (CPU)**
 - Power Supply
 - SD Card Reader
 - Speaker
 - Wireless LAN Antennas
 - Front EMI Bracket
 - RTC Battery
 - System Board (Top)
 - System Board (Bottom)
- Go to External Views



Power Supply

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply**
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

SD Card reader

- Access Panel
 - Optical Drive
 - Expansion Card Board
 - Main Bezel (Top)
 - Main Bezel (Bottom)
 - Dust Filter Bezel
 - Drive Cage
 - Hard Disk Drive
 - System Memory
 - Fan Duct
 - PS2 and Serial Port
 - Heat Sink
 - Processor (CPU)
 - Power Supply
 - SD Card Reader**
 - Speaker
 - Wireless LAN Antennas
 - Front EMI Bracket
 - RTC Battery
 - System Board (Top)
 - System Board (Bottom)
- [Go to External Views](#)



Speaker


- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker**
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

Wireless LAN Antennas

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas**
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

Front EMI Bracket

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket**
- RTC Battery
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

RTC Battery

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery**
- System Board (Top)
- System Board (Bottom)



[Go to External Views](#)

System Board (Top)

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)**
- System Board (Bottom)



[Go to External Views](#)

System Board (Bottom)

- Access Panel
- Optical Drive
- Expansion Card Board
- Main Bezel (Top)
- Main Bezel (Bottom)
- Dust Filter Bezel
- Drive Cage
- Hard Disk Drive
- System Memory
- Fan Duct
- PS2 and Serial Port
- Heat Sink
- Processor (CPU)
- Power Supply
- SD Card Reader
- Speaker
- Wireless LAN Antennas
- Front EMI Bracket
- RTC Battery
- System Board (Top)
- System Board (Bottom)**



[Go to External Views](#)