

Interactive Part Locator

HP EliteOne 800 G4 23.8 T & NT AiO PC

Welcome to this interactive part locator

Here's how to use it...

[External Views](#) (Click the link to navigate to the views)

On this page you will find large icons of each of the external views of this product. To view a specific view in greater detail, simply click that view.

[Parts List](#) (Click the link to navigate to the parts)

On this page, you will find a list of all of the replaceable parts for this product. To view a specific part and its location in the product, click the part name in the list.

That's it! On every page there is a link that brings you back to either the External Views or the Parts List, enabling you to navigate to whatever view or part you wish to review.

External Views

[Back to Welcome page](#)



Front




Left



Right



Rear




Display



Top



Bottom




Internal

[Go to Parts List](#)

Front View


[Back to External Views](#)



[Go to Parts List](#)

Left View

[Back to External Views](#)



[Go to Parts List](#)

Right View

[Back to External Views](#)



Fingerprint
reader

[Go to Parts List](#)

Rear View

[Back to External Views](#)




- Rear cover
- Optical drive
- Optical drive LED
- Optical drive eject button
- Force eject hole
- Security lock slot

- Cable cover
- Stand with adjustable height option

[Go to Parts List](#)

Display View


[Back to External Views](#)



[Go to Parts List](#)

Top View


[Back to External Views](#)



[Go to Parts List](#)

Bottom View


[Back to External Views](#)



[Go to Parts List](#)

Internal View

[Back to External Views](#)



[Go to Parts List](#)

Cable Cover

- Cable Cover
- Stand
- Rear Cover
- Webcam Plastic Cover
- Webcam
- System Memory
- Hard Disk Drive
- Hard Disk Drive Cage
- Optical Drive
- Wireless LAN Board
- M.2 Drive
- Battery
- Power Button Board Assembly
- Fingerprint Reader Board
- Side Audio Jack Board
- Stand Bracket and Fan Assembly
- System Fan
- Heat Sink
- Processor
- Power Supply
- Cable Pocket
- Rear I/O Bracket
- Speakers
- Motherboard (top)
- Motherboard (bottom)
- Webcam Assembly
- Base Pan
- Base Pan Assembly
- Wireless LAN Antennas
- LCD Panel
- Middle Frame



Go to External Views

- Cable Cover
- Stand**
- Rear Cover
- Webcam Plastic Cover
- Webcam
- System Memory
- Hard Disk Drive
- Hard Disk Drive Cage
- Optical Drive
- Wireless LAN Board
- M.2 Drive
- Battery
- Power Button Board Assembly
- Fingerprint Reader Board
- Side Audio Jack Board
- Stand Bracket and Fan Assembly
- System Fan
- Heat Sink
- Processor
- Power Supply
- Cable Pocket
- Rear I/O Bracket
- Speakers
- Motherboard (top)
- Motherboard (bottom)
- Webcam Assembly
- Base Pan
- Base Pan Assembly
- Wireless LAN Antennas
- LCD Panel
- Middle Frame

Stand



Go to External Views

Rear Cover


- Cable Cover
- Stand
- Rear Cover
- Webcam Plastic Cover
- Webcam
- System Memory
- Hard Disk Drive
- Hard Disk Drive Cage
- Optical Drive
- Wireless LAN Board
- M.2 Drive
- Battery
- Power Button Board Assembly
- Fingerprint Reader Board
- Side Audio Jack Board
- Stand Bracket and Fan Assembly
- System Fan
- Heat Sink
- Processor
- Power Supply
- Cable Pocket
- Rear I/O Bracket
- Speakers
- Motherboard (top)
- Motherboard (bottom)
- Webcam Assembly
- Base Pan
- Base Pan Assembly
- Wireless LAN Antennas
- LCD Panel
- Middle Frame



Go to External Views

Webcam Plastic Cover


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Webcam


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

System Memory


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Hard Disk Drive


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Hard Disk Drive Cage


- Cable Cover
- Stand
- Rear Cover
- Webcam Plastic Cover
- Webcam
- System Memory
- Hard Disk Drive
- Hard Disk Drive Cage**
- Optical Drive
- Wireless LAN Board
- M.2 Drive
- Battery
- Power Button Board Assembly
- Fingerprint Reader Board
- Side Audio Jack Board
- Stand Bracket and Fan Assembly
- System Fan
- Heat Sink
- Processor
- Power Supply
- Cable Pocket
- Rear I/O Bracket
- Speakers
- Motherboard (top)
- Motherboard (bottom)
- Webcam Assembly
- Base Pan
- Base Pan Assembly
- Wireless LAN Antennas
- LCD Panel
- Middle Frame



[Go to External Views](#)

Optical Drive


- Cable Cover
- Stand
- Rear Cover
- Webcam Plastic Cover
- Webcam
- System Memory
- Hard Disk Drive
- Hard Disk Drive Cage
- Optical Drive**
- Wireless LAN Board
- M.2 Drive
- Battery
- Power Button Board Assembly
- Fingerprint Reader Board
- Side Audio Jack Board
- Stand Bracket and Fan Assembly
- System Fan
- Heat Sink
- Processor
- Power Supply
- Cable Pocket
- Rear I/O Bracket
- Speakers
- Motherboard (top)
- Motherboard (bottom)
- Webcam Assembly
- Base Pan
- Base Pan Assembly
- Wireless LAN Antennas
- LCD Panel
- Middle Frame



[Go to External Views](#)

Wireless LAN Board


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

M.2 Drive


- Cable Cover
- Stand
- Rear Cover
- Webcam Plastic Cover
- Webcam
- System Memory
- Hard Disk Drive
- Hard Disk Drive Cage
- Optical Drive
- Wireless LAN Board
- M.2 Drive**
- Battery
- Power Button Board Assembly
- Fingerprint Reader Board
- Side Audio Jack Board
- Stand Bracket and Fan Assembly
- System Fan
- Heat Sink
- Processor
- Power Supply
- Cable Pocket
- Rear I/O Bracket
- Speakers
- Motherboard (top)
- Motherboard (bottom)
- Webcam Assembly
- Base Pan
- Base Pan Assembly
- Wireless LAN Antennas
- LCD Panel
- Middle Frame



[Go to External Views](#)

Battery


- Cable Cover
- Stand
- Rear Cover
- Webcam Plastic Cover
- Webcam
- System Memory
- Hard Disk Drive
- Hard Disk Drive Cage
- Optical Drive
- Wireless LAN Board
- M.2 Drive
- Battery**
- Power Button Board Assembly
- Fingerprint Reader Board
- Side Audio Jack Board
- Stand Bracket and Fan Assembly
- System Fan
- Heat Sink
- Processor
- Power Supply
- Cable Pocket
- Rear I/O Bracket
- Speakers
- Motherboard (top)
- Motherboard (bottom)
- Webcam Assembly
- Base Pan
- Base Pan Assembly
- Wireless LAN Antennas
- LCD Panel
- Middle Frame



[Go to External Views](#)

Power Button Board Assembly


- Cable Cover
- Stand
- Rear Cover
- Webcam Plastic Cover
- Webcam
- System Memory
- Hard Disk Drive
- Hard Disk Drive Cage
- Optical Drive
- Wireless LAN Board
- M.2 Drive
- Battery
- Power Button Board Assembly**
- Fingerprint Reader Board
- Side Audio Jack Board
- Stand Bracket and Fan Assembly
- System Fan
- Heat Sink
- Processor
- Power Supply
- Cable Pocket
- Rear I/O Bracket
- Speakers
- Motherboard (top)
- Motherboard (bottom)
- Webcam Assembly
- Base Pan
- Base Pan Assembly
- Wireless LAN Antennas
- LCD Panel
- Middle Frame



[Go to External Views](#)

Fingerprint Reader Board



Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Side Audio Jack Board


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Stand Bracket and Fan Assembly


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

System Fan


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Heat Sink

Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Processor


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Power Supply

Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Cable Pocket


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Rear I/O Bracket


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Speakers

Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame




[Go to External Views](#)

Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame

[Go to External Views](#)


Motherboard (top)



Motherboard (bottom)


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame

[Go to External Views](#)



Webcam Assembly


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Base Pan


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Base Pan Assembly


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

Wireless LAN Antennas


Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)

LCD Panel

- Cable Cover
- Stand
- Rear Cover
- Webcam Plastic Cover
- Webcam
- System Memory
- Hard Disk Drive
- Hard Disk Drive Cage
- Optical Drive
- Wireless LAN Board
- M.2 Drive
- Battery
- Power Button Board Assembly
- Fingerprint Reader Board
- Side Audio Jack Board
- Stand Bracket and Fan Assembly
- System Fan
- Heat Sink
- Processor
- Power Supply
- Cable Pocket
- Rear I/O Bracket
- Speakers
- Motherboard (top)
- Motherboard (bottom)
- Webcam Assembly
- Base Pan
- Base Pan Assembly
- Wireless LAN Antennas
- LCD Panel**
- Middle Frame



Go to External Views

Middle Frame

Cable Cover
Stand
Rear Cover
Webcam Plastic Cover
Webcam
System Memory
Hard Disk Drive
Hard Disk Drive Cage
Optical Drive
Wireless LAN Board
M.2 Drive
Battery
Power Button Board Assembly
Fingerprint Reader Board
Side Audio Jack Board
Stand Bracket and Fan Assembly
System Fan
Heat Sink
Processor
Power Supply
Cable Pocket
Rear I/O Bracket
Speakers
Motherboard (top)
Motherboard (bottom)
Webcam Assembly
Base Pan
Base Pan Assembly
Wireless LAN Antennas
LCD Panel
Middle Frame



[Go to External Views](#)